2025 PARTS CATALOG



BFT 200D BFT 225D BFT 250D Models US





Instruction for use of parts catalogue

- This parts catalogue was prepared based on the latest information available as of January 1, 2025.
- · See the Service Bulletin for any revision that is made after January 1, 2025.
- · Always specify the part number when ordering a part.
- · Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
- · Note that the illustrations (part drawings) can differ from the actual parts in shape.
 - Illustrations are given just to help you to refer to the parts.
- · When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times.


Initial version issue date January 1, 2025

CONTENTS

L-1	CYLINDER HEAD COVER · · · · · · · · · · · · · · · · · · ·
E-3	CYLINDER BLOCK · · · · · · · · · · · · · · · · · · ·
E-3-10	CRANK CASE
E-4	EXHAUST MANIFOLD / THERMOSTAT · · · · · · · · · · · · · · · · · ·
E-5	OILPUMP/FLYWHEEL · · · · · · · · · · · · · · · · · ·
E-6	OIL PAN · · · · · · · · · · · · · · · · · · ·
E-6-10	MOUNT CASE · · · · · · · · · · · · · · · · · · ·
E-7	CRANK SHAFT/PISTON · · · · · · · · · · · · · · · · · · ·
E-9	CYLINDER HEAD · · · · · · · · · · · · · · · · · · ·
E-9-10	CAMSHAFT / ROCKERARM · · · · · · · · · · · · · · · · · · ·
E-13	TIMING BELT
E-13-10	TIMINGBELT COVER······ 51
E-14	FUEL PIPE/INJECTOR····· 53
E-14-10	INTAKE MANIFOLD · · · · · · · · · · · · · · · · · · ·
E-15	THROTTLE BODY · · · · · · · · · · · · · · · · · · ·
E-18	VAPOR SEPARATOR ASSY · · · · · · · · · · · · · · · · · ·
	FUEL STRAINER
	PIPING
E-19	A. C. GENERATOR • • • • • • • • • • • • • • • • • • •
E-20	SPARK PLUG
E-20-10	ELECTRONIC CONTROL UNIT
E-21	STARTER MOTOR · · · · · · · · · · · · · · · · · · ·
E0P-1	GASKET KIT · · · · · · · · · · · · · · · · · · ·
F-2	SHIFT SHAFT (MECH) · · · · · · · · · · · · · · · · · · ·
F-2-1	SHIFT SHAFT (DBW) · · · · · · · · · · · · · · · · · · ·
F-3	GEAR CASE · · · · · · · · · · · · · · · · · · ·
F-3-10	
F 2 20	GEAR CASE ASSY 108 EXTENSION CASE
	UNDER COVER
F-3-30	WATER PUMP_VERTICAL SHAFT · · · · · · · · · · · · · · · · · · ·
F-4	PROPELLER SHAFT · · · · · · · · · · · · · · · · · · ·
F-5	
F-5-1	PROPELLER SHAFT (COUNTERROTATION) · · · · · · · · · · · · · · · · · · ·
	FUEL TUBE · · · · · · · · · · · · · · · · · · ·
	WIRE HARNESS • • • • • • • • • • • • • • • • • •
F-7-10	STARTER CABLE
	FUSEBOX/RELAY
F-8	ENGINE COVER····································
F-10	STERN BRACKET/SWIVEL CASE · · · · · · · · · · · · · · · · · · ·
F-11	POWER TRIM-TILT 173
F-12	LABEL • • • • • • • • • • • • • • • • • • •
F-13	TOOL · · · · · · · · · · · · · · · · · ·
F-18	ACTUATOR 189
FOP-2	WATER PUMP IMPELLER SET 191
F0P-3	REMOTE CONTROL (TOP MOUNT SINGLETYPE) (RIGHT) (MECH)
F0P-3-1	REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT) (MECH)
F0P-3-2	REMOTE CONTROL (TOP MOUNT DUALTYPE) (RIGHT) (MECH)
	REMOTE CONTROL (NHK MEC) (MECH)
F0P-3-4	REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (DBW)
F0P-3-5	REMOTE CONTROL (TOP MOUNT DUAL TYPE) (MAIN) (DBW)
	REMOTE CONTROL (TOP MOUNT DUAL TYPE) (MAIN) (DBW)
F0P-3-7	REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (SECOND) (DBW)
F0P-3-8	REMOTE CONTROL (TOP MOUNT DUAL TYPE) (SECOND) (DBW)
F0P-3-9	REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (NHK MEC)
F0P-3-10	REMOTE CONTROL (TOP MOUNT DUAL TYPE) (NHK MEC)
F0P-4	METER · · · · · · · · · · · · · · · · · · ·
F0P-5	SWITCH PANEL KIT(1) (MECH) · · · · · · · · · · · · · · · · · · ·
F0P-5-1	SWITCH PANEL KIT (2) (MECH) · · · · · · · · · · · · · · · · · · ·
F0P-5-2	SWITCH PANEL KIT(3) (MECH) 253 SWITCH PANEL KIT(4) (MECH) 255
F0P-5-3	
F0P-5-4	SWITCH PANEL KIT (5) (MECH) · · · · · · · · · · · · · · · · · · ·
F0P-5-5	SWITCH PANEL KIT (6) (DBW) · · · · · · · · · · · · · · · · · · ·
F0P-6	SWITCH PANEL KIT (POWER TILT) · · · · · · · · · · · · · · · · · · ·
F0P-6-1	SWITCH PANEL KIT (START STOP) · · · · · · · · · · · · · · · · · · ·
F0P-6-2	SWITCH PANEL KIT(FUNCTION) · · · · · · · · · · · · · · · · · · ·
F0P-7	INTERFACE CABLE KIT · · · · · · · · · · · · · · · · · · ·
F0P-10	CABLE KIT 271
	PROPELLER • • • • • • • • • • • • • • • • • • •
F0P-17	GEAR CASE KIT · · · · · · · · · · · · · · · · · · ·
F0P-18	MAINTENANCE KIT (200) • • • • • • • • • • • • • • • • • •
F0P-18-1	MAINTENANCE KIT (400) • • • • • • • • • • • • • • • • • •
INDEX	(Parts Number) • • • • • • • • • • • • • • • • • • •

How to refer to the part information

A. Reference with "Illustrated index"



Ref No.	Part N	s	Description	Q'ty BF250A	Remarks
E=15	1 HZY3-1601	6-003 SCREN	W SET	1	
E=15	2 HZY3-1617	6-000 GASKE	ET, THROTTLE BODY	1	
E=15	3 HZY3-1640	HAD1 THRO	TTLE BODY ASSY.	1	
E=15	4 HZX2=1640	4-000 SPACE	ER, THROTTLE BODY	- 1	
E-15	5 HZY3-1640	5-000 GASKS	ET, EAC VALVE	1	
E-15	7 HPY3+1724	9-000 SPRIN	G, AIR FLOW TUBE	- 1	
E=15	8 HZY9=1731	5-000 BAND.	AIR FLOW	- 1	
E=15	9 HZX2=1737	4-000 GROM	MET, SILENCER	- 1	
E=15	10 HZY3-1791	0-013 CABLE	COMP, THROTTLE	2	
E-15	16 HZW5-3566	5-003 SENSO	OR ASSY, AIR TEMP	- 1	
E-15	17 HZY3-3655	D-003 VALVE	ASSY., EAC	- 1	
E-15	18 HZV5-4010	2-000 GROM	MET, UNDER CASE	4	
E-15	19 HZW1-9001	3-000 BOLT-	WASHER 6X25	2	
E-15	20 HZY9-9001	7-000 BOLT-	WASHER, 5X30	-1	
E=15	21 HZY3-9003	0-000 BOLT.	FLANGE, 6022	2	
E-15	22 HZY3-9003	4-000 BOLT.	FLANGE, 6060	2	
E-15	23 HZY3-9003	7-000 BOLT.	FLANGE, 8065	4	
E-15	24 HZY3-9050	E-000 WASHI	ER PLAIN 6MM	ž	
E-15	25 HP0A-9130	3-A02 0-RSN	G	-1	
E=15	28 HZV5=9155	3-010 COLLA	AR, CULL UNIT CASE	4	
E-15	28 HOO-94301-	-06100 DOWE	L PIN, 6X10	2	
E=15	29 HZX2=1954	D-010 COVE	R ASSY, COOLING FAN	1	-
닉	1			\supset	
-1					


B. Reference with "Parts number index"

1		
	INDEX (Parts Number)
1H2-31534-0	346-64083-0	369-63433-1
	346-640840	
309-06972-0 8-13	346-64124-5	369-84398-0 6-75 369-84398-0
309-06972-0 8-37	346-64211-6	
309-06972-0 9-36		
309-65032-0 9-62		369-84398-0 10-5
332-60005-2 3-36	346-64231-5	394-70260-0 16-13
	346-64302-5	398-06830-0 16-27
	346-64303-5	398-06972-0 8-14
	346-64303-5	
3324000060 24442	346-64327-0	398-12396-1 13-3
332-60103-0	346-64328-0	398-76063-0 16-26
	346-65013-0	
332 62101-1 12-96	346-65013-0	3A0-76079-0 5-28
332-62101-1 13-47	346-65017-2	340-76079-0
332-64221-0	346-66037-0	3A0-76079-0 8-24
332-65022-0	346-66037-0	3A0-76079-0 9-43
332 65022 0 24 5 3	346-66321-0	3A1-60235-0
332-66021-0	346-66322-0	3A3-06830-0
332-66021-0	346-66323-1	3A3-62396-1
332-70201-0	346-66331-0	3A3-72560-0
332062102 1 12-94	346-66334-0	3A3-72591-0
	346-66334-0	3A3-76037-0
	346-66334-0	
	346-67113-0 6-21	
336-06973-0 23-44-12	346-67113-0 16-2	

C. Reference with "Parts name index"


		INDEX
		INDEX
	do	BOLT 9-63
ı	ADJUST SCREW	BOLT
ı	ADJUSTING NUT	BOLT
ı	ADJUSTING SCREW	BOLT
ı	ADJUSTING SCREW	BOLT
ı	48 FLTER	BOLT
ı	MR VENT ASSY 6-67	ROLT
ı	ALTERNATOR ASSY	BOLT
ı	ANCIDE	BOLT
ı	ANODE	BOLT 114-38
ı	ANCIDE	BOLT
ı	ANODE PLUG. 1-12	ROLT 11848
ı	6/9DN 10-28	BOLT
ı	ASSIST CORD (REIO) = 200 23-46-2	ROLT 12-19
ı	ASSET CORD (BLU) L=200	BOLT 12-24
ı	ASSIST CORD (RED) L=200 22-12	BOLT 12-31
ı	ASSET CORD (RED) L=200	BOLT 12-40
ı	di	BOLT 12-46
ı	BACKUP MNG	BOLT
ı	BALL 14-21	BOLT 12-50
ı	BALL 3/8	BOLT 13-58
ı	BALL REARING 6205	BOLT 12-63
ı	BALL JOINT CONNECTOR	ROLT 17-88
ı	BAND	BOLT
ı	RAND 104 8-29	ROLT 13-6
ı	BAND 104 8-10	BOLT 11-19
ı	RAND 158 6-25	ROLT 14-26
ı	BAND 158 8-11	BOLT 14-12

Part catalogue structure



- ① Fig. Number
- ② Fig. Title
- ③ Ref. Number
- 4 Parts Number
- (5) Parts Name
- ⑥ Q.ty
- ⑦ Remarks
- (8) Defferent specification
- Direction Arrow
- n Parts enclosed within a doted line are sub assembly parts.
- ① A solid arrow indicates the block No. the part in question is connected to.

How to check the part block and serial numbers



Models, parts catalogue codes and applicable serial numbers

• Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.

Model	Туре	Parts catalogue	Eng	jine	Applicable engine	Applicable frame
		type	Model	Туре	serial No.	serial No.
	LRA	LRA				BBRJ-6000001~
BFT200D	XCRA	XCRA	BF200D	SE3	BEBRJ-1000001~	BBRJ-7000001~
	XRA	XRA				BBRJ-6000001~
	LRA	LRA		3E3		BBPJ-6000001~
BFT225D	XCRA	XCRA	BF225D		BEBPJ-1000001~	BBPJ-7000001~
	XRA	XRA				BBPJ-6000001~
	LDA	LDA		SE1		BBNJ-6000001~
	LRA	LRA		SE3		BBNJ-0000001~
	UCDA	UCDA		SE1		BBNJ-7000001~
	UCRA	UCRA		SE3		BBNJ-7000001~
BFT250D	UDA	UDA	BF250D	SE1	BEBNJ-1000001~	BBNJ-6000001~
BF1250D	URA	URA	BF230D	SE3	BEBNJ-1000001~	BBNJ-0000001~
	XCDA	XCDA		SE1		BBNJ-7000001~
	XCRA	XCRA		SE3		BBNJ-7000001~
ŀ	XDA	XDA		SE1		BBNJ-6000001~
	XRA	XRA		SE3		DD140-0000001~

Features of each type

• See the following table for the features of each type. (Items in brackets are optional)


	Model	В	BFT200D			BFT225	D	BFT250D			
Specifications	LRA	XCRA	XRA	LRA	XCRA	XRA	LDA	LRA	UCDA	UCRA	
	508mm	•			•			•	•		
Transom height	635mm		•	•		•	•				
	762mm									•	•
Counter rotation	Counter rotation					•				•	•
DBW	DBW							•		•	

	Model	BFT250D											
Specifications	Туре	UDA	URA	XCDA	XCRA	XDA	XRA						
	508mm												
Transom height	635mm			•	•	•	•						
	762mm	•	•										
Counter rotation			•	•									
DBW	•		•		•								

Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets () underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name. (For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)


Bulk part number of fuel hose, general purpose hose and vinyl hose.




CAUTION: It is DANGEROUS to confuse the fuel hose with the general purpose hose or vinyl hose.

Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.


E-1 CYLINDER HEAD COVER




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-1	1	HZVL-12310-405ZA	COVER COMP., CYLINDER HEAD(R.)	1	1	1	*NH8* DARK GRAY
E-1	2	HZY3-12312-000	PACKING, HEAD COVER	2	2	2	
E-1	3	HZVL-12320-405ZA	COVER COMP., CYLINDER HEAD(L.)	1	1	1	*NH8* DARK GRAY
E-1	4	HP08-12342-004	SEAL, SPARK PLUG TUBE (NOK)	6	6	6	
E-1	5	HZY3-15425-010	TUBE, OIL	2	2	2	
E-1	6	HZVL-16916-000	STAY B, FUEL STRAINER	1	1	1	
E-1	7	HMT2-17193-000	T-JOINT	1	1	1	
E-1	8	HZVL-32104-000	BRACKET, FUEL PUMP COUPLER	1	1	1	
E-1	9	HZVL-32114-000	BRACKET, CLIP B	1	1	1	
E-1	10	HZY3-32129-000	BRACKET C, HARNESS CLIP	3	3	3	
E-1	11	HHE0-50310-003	CLIP A, WIRE	1	1	1	
E-1	12	HZZ5-90011-M01	BOLT, FLANGE, 6X14(CT200)	6	6	6	
E-1	13	HZZ5-90019-M01	BOLT, FLANGE, 6X35	16	16	16	
E-1	14	HZY3-90602-020	CLAMP, TUBE (D32. 5)	2	2	2	
E-1	15	HSA0-90683-003	CLIP, WIRE HARNESS, 25MM	1	1	1	
E-1	16	HZY3-91401-A00	TUBE COMP. A, BREATHER	1	1	1	
E-1	17	HZY3-91402-030	TUBE B, BREATHER	1	1	1	
E-1	18	HZY3-91403-000	TUBE C, BREATHER	1	1	1	
E-1	19	HSK7-91566-003	CLIP D, WASHER TUBE	1	1	1	
-							
-							
			<u> </u>	-1			




Ref. No. Part No. Description Page						Q'ty		_
E-3 1 H2VL-11200-000 COVER ASSY. CRANKCASE UPPER 1 1 ~1002916 E-3 1 H2VL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 ~1002917~ E-3 1 H2VL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 1002917~ E-3 1 H2VL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 1002917~ E-3 1 H2VL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 1002917~ E-3 1 H2VL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 1002917~ E-3 2 H2YG-11300-000 CASE ASSY. OIL SEAL 1 1 1 1 1 ~1002917~ E-3 3 H2VL-12000-0002A BLOCK ASSY. CYLINDER **NR8** DARK GRAY 1 1 ~1002573 E-3 3 H2VL-12000-0002A BLOCK ASSY. CYLINDER **NR8** DARK GRAY 1 1 ~1002560 E-3 3 H2VL-12000-0002A BLOCK ASSY. CYLINDER **NR8** DARK GRAY 1 1 1002574~1007206 E-3 3 H2VL-12000-0102A BLOCK ASSY. CYLINDER **NR8** DARK GRAY 1 1 1002574~1007206 E-3 3 H2VL-12000-0102A BLOCK ASSY. CYLINDER **NR8** DARK GRAY 1 1 1002574~1007206 E-3 3 H2VL-12000-0102A BLOCK ASSY. CYLINDER **NR8** DARK GRAY 1 1 1002560-1005609 E-3 3 H2VL-12000-0102A BLOCK ASSY. CYLINDER **NR8** DARK GRAY 1 1 1002730~102694 E-3 3 H2VL-12000-0102A BLOCK ASSY. CYLINDER **NR8** DARK GRAY 1 1 1002730~ E-3 3 H2VL-12000-0102A BLOCK ASSY. CYLINDER **NR8** DARK GRAY 1 1 1007230~1020694 E-3 4 H2VL-12100-0202A BLOCK ASSY. CYLINDER **NR8** DARK GRAY 1 1 1002560~ E-3 4 H2VL-12155-A00 METAL ANODE 6 1 ~1007206 E-3 4 H2V4-12155-A00 METAL ANODE 6 1 1007207~ E-3 5 H2Y3-12155-A00 METAL ANODE 6 1 1007207~ E-3 5 H2Y3-12155-A00 METAL ANODE 2 1 ~1005809 E-3 5 H2Y3-12155-A00 METAL ANODE 2 1 ~1005809 E-3 5 H2Y3-12155-000 METAL ANODE 2 1 ~1005809	Ref. No.	•	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-3 1 HZVL-11200-000 COVER ASSY. CRANKCASE UPPER 1 1 1002627~ E-3 1 HZVL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 1002627~ E-3 1 HZVL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 1002617~ E-3 1 HZVL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 1002617~ E-3 1 HZVL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 1002617~ E-3 2 HZYS-11300-000 CASE ASSY. OIL SEAL 1 1 1 1 1 1 E-3 3 HZVL-12000-000ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 ~1002650 E-3 3 HZVL-12000-000ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 ~1007292 E-3 3 HZVL-12000-000ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 3 HZVL-12000-000ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 3 HZVL-12000-020ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 3 HZVL-12000-020ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 4 HZVL-12100-020ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1 E-3 4 HZVL-12105-A00 METAL. ANDOE 6 E-3 4 HZVL-12155-A00 METAL. ANDOE 6 E-3 4 HZVL-12155-A01 METAL. ANDOE 6 E-3 5 HZY3-12155-A01 METAL. ANDOE 7 E-3 6 HZY3-12155-000 METAL. ANDOE 7 E-3 7 HZY3-12155-000 METAL. ANDOE 7 E-3 8 HZY3-12155-000 METAL. ANDOE 7 E-3 9 HZY3-12155-000 METAL. ANDOE 7 E-3 1 HZY3-12155-010 METAL. ANDOE 7 E-3 5 HZY3-12155-010 METAL.	E-3	1	HZVL-11200-000	COVER ASSY., CRANKCASE UPPER	1			~1002626
E-3 1 HZVL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1002817~ E-3 1 HZVL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 1002817~ E-3 1 HZVL-11200-010 COVER ASSY. CRANKCASE UPPER 1 1 1007540~ E-3 2 HZY3-11300-000 CASE ASSY. CRANKCASE UPPER 1 1 1007540~ E-3 3 HZVL-12000-000ZA BLOCK ASSY. CYLINDER **NHS** DARK GRAY 1 1 ~ 1002573 E-3 3 HZVL-12000-000ZA BLOCK ASSY. CYLINDER **NHS** DARK GRAY 1 1 ~ 1002650 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER **NHS** DARK GRAY 1 1 ~ 1002732 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER **NHS** DARK GRAY 1 1 1002674~1007206 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER **NHS** DARK GRAY 1 1 1002674~1007206 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER **NHS** DARK GRAY 1 1 1002651~1005809 E-3 3 HZVL-12000-010ZA BLOCK ASSY. CYLINDER **NHS** DARK GRAY 1 1 1007293~1020694 E-3 3 HZVL-12000-020ZA BLOCK ASSY. CYLINDER **NHS** DARK GRAY 1 1 1007207~ E-3 3 HZVL-12000-020ZA BLOCK ASSY. CYLINDER **NHS** DARK GRAY 1 1 1007207~ E-3 3 HZVL-12000-020ZA BLOCK ASSY. CYLINDER **NHS** DARK GRAY 1 1 1007207~ E-3 4 HZV4-12155-A00 METAL. ANDDE 6 1 1007207~ E-3 4 HZV4-12155-A00 METAL. ANDDE 6 1 1007207~ E-3 4 HZV4-12155-A00 METAL. ANDDE 6 1 1007207~ E-3 4 HZV4-12155-A01 METAL. ANDDE 6 1 1007207~ E-3 5 HZY3-12155-000 METAL. ANDDE 2 2 ~ 1005809 E-3 5 HZY3-12155-000 METAL. ANDDE 2 2 ~ 1005809 E-3 5 HZY3-12155-000 METAL. ANDDE 2 2 ~ 1005809 E-3 5 HZY3-12155-000 METAL. ANDDE 2 2 ~ 1005809	E-3	1	HZVL-11200-000	COVER ASSY., CRANKCASE UPPER		1		~1002916
E-3 1 HZVL-11200-010 CDVER ASSY. CRANKCASE UPPER	E-3	1	HZVL-11200-000	COVER ASSY., CRANKCASE UPPER			1	~1007539
E-3 1 HZVL-1200-010 COVER ASSY. CRAINCASE UPPER 1 1 1007540~ E-3 2 HZY3-11300-C00 CASE ASSY. OIL SEAL 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-3	1	HZVL-11200-010	COVER ASSY., CRANKCASE UPPER	1			1002627~
E-3 2 HZY3-11300-C00 CASE ASSY. OIL SEAL 1 1 1 1 1 1	E-3	1	HZVL-11200-010	COVER ASSY., CRANKCASE UPPER		1		1002917~
E-3 3 HZVL-12000-000ZA BLOCK ASSY., CYLINDER *NH8* DARK GRAY 1 \ \times	E-3	1	HZVL-11200-010	COVER ASSY., CRANKCASE UPPER			1	1007540~
E-3 3 H2VL-12000-000ZA BLOCK ASSY. CYLINDER **NH8* DARK GRAY 1 1 ~1002650 E-3 3 H2VL-12000-010ZA BLOCK ASSY. CYLINDER **NH8* DARK GRAY 1 1 ~1002574~1007296 E-3 3 H2VL-12000-010ZA BLOCK ASSY. CYLINDER **NH8* DARK GRAY 1 1 1002651~1005809 E-3 3 H2VL-12000-010ZA BLOCK ASSY. CYLINDER **NH8* DARK GRAY 1 1 1002651~1005809 E-3 3 H2VL-12000-010ZA BLOCK ASSY. CYLINDER **NH8* DARK GRAY 1 1 1007293~1020694 E-3 3 H2VL-12000-020ZA BLOCK ASSY. CYLINDER **NH8* DARK GRAY 1 1 1007297~ E-3 3 H2VL-12000-020ZA BLOCK ASSY. CYLINDER **NH8* DARK GRAY 1 1 1007297~ E-3 3 H2VL-12000-020ZA BLOCK ASSY. CYLINDER **NH8* DARK GRAY 1 1 1005810~ E-3 4 H2V4-12155-A00 METAL. ANODE 6 ~1005809 E-3 4 HZV4-12155-A00 METAL. ANODE 6 ~1007206 E-3 4 HZV4-12155-A01 METAL. ANODE 6 ~1007207~ E-3 4 HZV4-12155-A01 METAL. ANODE 6 1007207~ E-3 5 HZY3-12155-000 METAL. ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL. ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL. ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL. ANODE 2 ~1007207~ E-3 5 HZY3-12155-000 METAL. ANODE 2 ~1007207~ E-3 5 HZY3-12155-010 METAL. ANODE 2 ~1007207~	E-3	2	HZY3-11300-C00	CASE ASSY., OIL SEAL	1	1	1	
E-3 3 HZVL-12000-000ZA BLOCK ASSY., CYLINDER *NH8+ DARK GRAY 1 1 ~1007292 E-3 3 HZVL-12000-010ZA BLOCK ASSY., CYLINDER *NH8+ DARK GRAY 1 1 1002574~1007206 E-3 3 HZVL-12000-010ZA BLOCK ASSY., CYLINDER *NH8+ DARK GRAY 1 1 1002651~1005809 E-3 3 HZVL-12000-010ZA BLOCK ASSY., CYLINDER *NH8+ DARK GRAY 1 1 1007293~1020694 E-3 3 HZVL-12000-020ZA BLOCK ASSY., CYLINDER *NH8+ DARK GRAY 1 1 1007207~ E-3 3 HZVL-12000-020ZA BLOCK ASSY., CYLINDER *NH8+ DARK GRAY 1 1 1005810~ E-3 3 HZVL-12000-020ZA BLOCK ASSY., CYLINDER *NH8+ DARK GRAY 1 1 1005810~ E-3 4 HZV4-12155-A00 METAL, ANDDE 6 ~1007206 E-3 4 HZV4-12155-A00 METAL, ANDDE 6 ~1007206 E-3 4 HZV4-12155-A00 METAL, ANDDE 6 1007207~ E-3 4 HZV4-12155-A01 METAL, ANDDE 6 1007207~ E-3 5 HZV3-12155-000 METAL, ANDDE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANDDE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANDDE 2 ~1006809 E-3 5 HZY3-12155-000 METAL, ANDDE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANDDE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANDDE 2 ~1007207~ E-3 5 HZY3-12155-010 METAL, ANDDE 2 ~1007207~ E-3 5 HZY3-12155-010 METAL, ANDDE 2 ~1007207~ E-3 5 HZY3-12155-010 METAL, ANDDE 2 ~1007207~	E-3	3	HZVL-12000-000ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	1			~1002573
E-3 3 HZVL-12000-010ZA BLOCK ASSY CYLINDER *NH8* DARK GRAY 1 1 1002574~1007206 E-3 3 HZVL-12000-010ZA BLOCK ASSY CYLINDER *NH8* DARK GRAY 1 1 1007293~1020694 E-3 3 HZVL-12000-010ZA BLOCK ASSY CYLINDER *NH8* DARK GRAY 1 1 1007293~1020694 E-3 3 HZVL-12000-020ZA BLOCK ASSY CYLINDER *NH8* DARK GRAY 1 1 1007207~ E-3 3 HZVL-12000-020ZA BLOCK ASSY CYLINDER *NH8* DARK GRAY 1 1 1005810~ E-3 3 HZVL-12000-020ZA BLOCK ASSY CYLINDER *NH8* DARK GRAY 1 1 1020695~ E-3 4 HZV4-12155-A00 METAL. ANODE 6 ~ ~1007206 E-3 4 HZV4-12155-A00 METAL. ANODE 6 ~ ~1005809 E-3 4 HZV4-12155-A01 METAL. ANODE 6 1007207~ E-3 4 HZV4-12155-A01 METAL. ANODE 6 1005810~ E-3 4 HZV4-12155-A01 METAL. ANODE 6 1005810~ E-3 5 HZY3-12155-000 METAL. ANODE 2 ~ ~1007206	E-3	3	HZVL-12000-000ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY		1		~1002650
E-3 3 HZVL-12000-010ZA BLOCK ASSY., CYLINDER *NH8* DARK GRAY 1 1 1002651~1005809 E-3 3 HZVL-12000-010ZA BLOCK ASSY., CYLINDER *NH8* DARK GRAY 1 1 1007293~1020694 E-3 3 HZVL-12000-020ZA BLOCK ASSY., CYLINDER *NH8* DARK GRAY 1 1 1007207~ E-3 3 HZVL-12000-020ZA BLOCK ASSY., CYLINDER *NH8* DARK GRAY 1 1 1005810~ E-3 3 HZVL-12000-020ZA BLOCK ASSY., CYLINDER *NH8* DARK GRAY 1 1 1020695~ E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1007206 E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810~ E-3 5 HZY3-12155-A01 METAL, ANODE 2 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANODE 2 1 1007207~ E-3 5 HZY3-12155-000 METAL, ANODE 2 1 1007207~ E-3 5 HZY3-12155-000 METAL, ANODE 2 1 1007207~ E-3 5 HZY3-12155-000 METAL, ANODE 2 2 ~1005809 E-3 5 HZY3-12155-010 METAL, ANODE 2 1 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1 1007207~	E-3	3	HZVL-12000-000ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY			1	~1007292
E-3 3 HZVL-12000-010ZA BLOCK ASSY CYLINDER *NH8* DARK GRAY 1 1007293~1020694 E-3 3 HZVL-12000-020ZA BLOCK ASSY CYLINDER *NH8* DARK GRAY 1 1007207~ E-3 3 HZVL-12000-020ZA BLOCK ASSY CYLINDER *NH8* DARK GRAY 1 1005810~ E-3 3 HZVL-12000-020ZA BLOCK ASSY CYLINDER *NH8* DARK GRAY 1 1005810~ E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1007206 E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1007206 E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810~ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-000 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-000 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~	E-3	3	HZVL-12000-010ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	1			1002574~1007206
E-3 3 HZVL-12000-020ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1007207~ E-3 3 HZVL-12000-020ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1005810~ E-3 3 HZVL-12000-020ZA BLOCK ASSY. CYLINDER *NH8* DARK GRAY 1 1020695~ E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1007206 E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1005809 E-3 4 HZV4-12155-A01 METAL, ANODE 6 ~1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1020695~ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007207~ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~	E-3	3	HZVL-12000-010ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY		1		1002651~1005809
E-3 3 HZVL-12000-020ZA BLOCK ASSY., CYLINDER *NH8* DARK GRAY 1 1 1005810∼ E-3 3 HZVL-12000-020ZA BLOCK ASSY., CYLINDER *NH8* DARK GRAY 1 1 1020695∼ E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1007206 E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1005809 E-3 4 HZV4-12155-A00 METAL, ANODE 6 1007207∼ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1007207∼ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810∼ E-3 5 HZY3-12155-A01 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007207∼ E-3 5 HZY3-12155-010 METAL, ANODE 2 ~1007207∼ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207∼ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207∼	E-3	3	HZVL-12000-010ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY			1	1007293~1020694
E-3 3 HZVL-12000-020ZA BLOCK ASSY., CYLINDER *NH8* DARK GRAY E-3 4 HZV4-12155-A00 METAL, ANODE E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1005809 E-3 4 HZV4-12155-A01 METAL, ANODE 6 ~1002694 E-3 4 HZV4-12155-A01 METAL, ANODE 6 1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 102695~ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007207 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007207~ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE	E-3	3	HZVL-12000-020ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY	1			1007207~
E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1007206 E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1005809 E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1020694 E-3 4 HZV4-12155-A01 METAL, ANODE 6 1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1020695~ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007207~ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~	E-3	3	HZVL-12000-020ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY		1		1005810~
E-3 4 HZV4-12155-A00 METAL, ANODE 6 ~1005809 E-3 4 HZV4-12155-A01 METAL, ANODE 6 ~1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 102695~ E-3 4 HZV4-12155-A01 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~	E-3	3	HZVL-12000-020ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY			1	1020695~
E-3 4 HZV4-12155-A00 METAL, ANODE 6 1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1020695~ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~	E-3	4	HZV4-12155-A00	METAL, ANODE	6			~1007206
E-3 4 HZV4-12155-A01 METAL, ANODE 6 1007207~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810~ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1020695~ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~	E-3	4	HZV4-12155-A00	METAL, ANODE		6		~1005809
E-3 4 HZV4-12155-A01 METAL, ANODE 6 1005810∼ E-3 4 HZV4-12155-A01 METAL, ANODE 6 1020695∼ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1020694 E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207∼ E-3 5 HZY3-12155-010 METAL, ANODE 2 1005810∼	E-3	4	HZV4-12155-A00	METAL, ANODE			6	~1020694
E-3 4 HZV4-12155-A01 METAL, ANODE 6 1020695~ E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1020694 E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1005810~	E-3	4	HZV4-12155-A01	METAL, ANODE	6			1007207~
E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1007206 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1020694 E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1005810~	E-3	4	HZV4-12155-A01	METAL, ANODE		6		1005810~
E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1005809 E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1020694 E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1005810~	E-3	4	HZV4-12155-A01	METAL, ANODE			6	1020695~
E-3 5 HZY3-12155-000 METAL, ANODE 2 ~1020694 E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1005810~	E-3	5	HZY3-12155-000	METAL, ANODE	2			~1007206
E-3 5 HZY3-12155-010 METAL, ANODE 2 1007207~ E-3 5 HZY3-12155-010 METAL, ANODE 2 1005810~	E-3	5	HZY3-12155-000	METAL, ANODE		2		~1005809
E-3 5 HZY3-12155-010 METAL, ANODE 2 1005810~	E-3	5	HZY3-12155-000	METAL, ANODE			2	~1020694
	E-3	5	HZY3-12155-010	METAL, ANODE	2			1007207~
E-3 5 HZY3-12155-010 METAL, ANODE 2 1020695~	E-3	5	HZY3-12155-010	METAL, ANODE		2		1005810~
	E-3	5	HZY3-12155-010	METAL, ANODE			2	1020695~
E-3 6 HZY3-12164-000 BOLT, SEALING, 22MM 6 6 6	E-3	6	HZY3-12164-000	BOLT, SEALING, 22MM	6	6	6	




Ref. No. Part No. Description Sec. Sec.						Q' ty		
E-3 8 NZYS-12214-000 WASHER, SEALING (22M0) 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-3 9 HP8A-15115-A01 PACKING, OIL HOLE 1 1 1 1 1 1	E-3	7	HZY3-12171-305	WASHER, SEALING, 22MM	6	6	6	
E-3 10 NPBA-15140-A00 ORIFICE ASSY. OIL CONTROL 2 2 2 2 E-3 11 HPBA-15142-A00 O-RING. 8.882.4 2 2 2 2 E-3 12 HPBA-15150-A00 JOINT ASSY. OIL PIPE 1 1 1 1 1 E-3 12 HPBA-15150-A00 BODY, OIL JET 3 3 3 3 3 E-3 14 HR70-15280-A00 BODY, OIL JET 3 3 3 3 3 E-3 14 HR70-15280-A00 BODY, OIL JET 3 3 3 3 3 E-3 15 HZVL-15655-000 GAUGE COMP. OIL LEVEL 1 1 1 1 1 E-3 16 HZYL-15656-000 COVER, OIL LEVEL GAUGE 1 1 1 1 1 E-3 17 HZY3-15657-000 PAGKING, OIL LEVEL GAUGE 1 1 1 1 1 E-3 18 HZYL-15610-000ZA VALVE ASSY., SPOOL 1 1 + NHR8+ DARK GRAY E-3 18 HZYL-15810-000ZA VALVE ASSY., SPOOL 1 1 1 1 1 E-3 19 HZY2-15825-000 FILTER ASSY., SPOOL 1 1 1 1 1 E-3 19 HZY2-15825-000 FILTER ASSY., SPOOL 1 1 1 1 1 E-3 20 HSYS-30530-JOI SENSOR, KNOCK 1 1 1 1 1 E-3 21 HZVL-32114-000 BRACKET, CLIP B 1 1 1 1 E-3 22 HZY-35673-003 SENSOR ASSY., MATER 1 1 1 1 1 E-3 24 HZYL-32100-000 SENSOR, OIL PRESSURE 1 1 1 1 1 E-3 25 HZYB-35673-003 SENSOR ASSY., MATER 1 1 1 1 1 E-3 26 HZYL-90001-000 BOLT, FLANGE, 1ZX95 2 1 10022693 E-3 26 HZYL-90001-000 BOLT, FLANGE, 1ZX95 2 1 10022694~ E-3 26 HZYL-90001-010 BOLT, FLANGE, 1ZX95 2 1 10022694~ E-3 26 HZYL-90001-010 BOLT, FLANGE, 1ZX95 2 1 10022573	E-3	8	HZV5-12214-000	WASHER, SEALING(22MM)	1	1	1	
E-3 11	E-3	9	HP8A-15115-A01	PACKING, OIL HOLE	1	1	1	
E-3 12 HP8A-15150-A00 JUINT ASSY., DIL PIPE 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-3	10	HP8A-15140-A00	ORIFICE ASSY., OIL CONTROL	2	2	2	
E-3 13 HR70-15280-A00 B0DY, OIL JET 3 3 3 3 3 E-3 14 HRJA-15290-000 B0LT COMP., OIL JET 3 3 3 3 3 3 E-3 15 HZVL-15655-000 GAUGE COMP., OIL LEVEL 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-3	11	HP8A-15142-A00	O-RING, 8.8X2.4	2	2	2	
E-3 14 HRJA-15290-000 BOLT COMP. OIL JET 3 3 3 3 3 E-3 15 HZVL-15656-000 GAUGE COMP. OIL LEVEL 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-3	12	HP8A-15150-A00	JOINT ASSY., OIL PIPE	1	1	1	
E-3 15 H2VL-15655-000 GAUGE COMP., OIL LEVEL 1 1 1 1 1 E-3 16 H2VL-15656-000 COVER, OIL LEVEL GAUGE 1 1 1 1 1 E-3 17 H2Y3-15657-000 PACKING, OIL LEVEL GAUGE 1 1 1 1 1 E-3 18 H2V2-15810-0002A VALVE ASSY., SPOOL 1 1 **NH8* DARK GRAY E-3 18 H2V2-15810-0032A VALVE ASSY., SPOOL 1 1 **NH8* DARK GRAY E-3 19 H2Y3-15825-000 FILTER ASSY., SPOOL 1 1 1 E-3 19 H2Y3-15825-000 FILTER ASSY., SPOOL VALVE 1 1 E-3 19 H2Y3-15825-000 FILTER ASSY., SPOOL VALVE 1 1 1 E-3 20 H5YS-30530-J01 SENSOR, KNOCK 1 1 1 1 E-3 21 H2VL-32114-000 BRACKET, CLIP B 1 1 1 1 E-3 22 H2VL-32193-000 CORD, SWITCH 1 1 1 1 E-3 23 H2Y3-35673-003 SENSOR ASSY., MATER 1 1 1 1 TEMPERATURE E-3 24 HRNA-37260-A01 SENSOR, OIL PRESSURE 1 1 1 1 E-3 25 HPNB-37500-003 SENSOR ASSY., GRANK 1 1 1 1 E-3 26 H2VL-90001-000 BOLT, FLANGE, 12X95 2 ~*1002493 E-3 26 H2VL-90001-000 BOLT, FLANGE, 12X95 2 ~*1002494~ E-3 26 H2VL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 H2VL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 H2VL-90001-010 BOLT, FLANGE, 12X95 2 1002573	E-3	13	HR70-15280-A00	BODY, OIL JET	3	3	3	
E-3 16 HZVL-15656-000 COVER, OIL LEVEL GAUGE 1 1 1 1 1 E-3 17 HZY3-15657-000 PACKING, OIL LEVEL GAUGE 1 1 1 1 1 E-3 18 HZY2-15810-000ZA VALVE ASSY SPOOL 1 **NHB* DARK GRAY* E-3 18 HZVL-15810-003ZA VALVE ASSY SPOOL 1 1 **NHB* DARK GRAY* E-3 19 HZY2-15825-000 FILTER ASSY SPOOL VALVE 1 1	E-3	14	HRJA-15290-000	BOLT COMP., OIL JET	3	3	3	
E-3 17 HZY3-15657-000 PACKING, OIL LEVEL GAUGE 1 1 1 1 1 E-3 18 HZY2-15810-000ZA VALVE ASSY., SPOOL 1 1 +NH6+ DARK GRAY E-3 18 HZY2-15825-000 FILTER ASSY., SPOOL 1 1 1 1 E-3 19 HZY3-15825-000 FILTER ASSY., SPOOL VALVE 1 1 1 E-3 19 HZY3-15825-003 FILTER ASSY., SPOOL VALVE 1 1 1 1 E-3 20 H5Y8-30530-J01 SENSOR, KNOCK 1 1 1 1 1 E-3 21 HZVL-32114-000 BRACKET, CLIP B 1 1 1 1 1 E-3 22 HZYL-32193-000 CORD, SWITCH 1 1 1 1 1 E-3 23 HZY3-35673-003 SENSOR ASSY., WATER 1 1 1 1 TEMPERATURE E-3 24 HRNA-37260-A01 SENSOR, OIL PRESSURE 1 1 1 1 1 E-3 25 HPNB-37500-003 SENSOR ASSY., CRANK 1 1 1 1 1 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002493 E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1 0002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1 1002573	E-3	15	HZVL-15655-000	GAUGE COMP., OIL LEVEL	1	1	1	
E-3 18 HZY2-15810-000ZA VALVE ASSY., SPOOL 1 1 **NH8* DARK GRAY E-3 18 HZYL-15810-003ZA VALVE ASSY., SPOOL 1 1 1 1 E-3 19 HZY2-15825-000 FILTER ASSY., SPOOL VALVE 1 1 1 1 1 E-3 19 HZY3-15825-003 FILTER ASSY., SPOOL VALVE 1 1 1 1 1 E-3 20 H5YS-30530-J01 SENSOR, KNOCK 1 1 1 1 1 E-3 21 HZVL-32114-000 BRACKET, CLIP B 1 1 1 1 E-3 22 HZVL-32193-000 CORD, SWITCH 1 1 1 1 1 E-3 23 HZY3-35673-003 SENSOR ASSY., WATER 1 1 1 1 TEMPERATURE E-3 24 HRNA-37260-A01 SENSOR, OIL PRESSURE 1 1 1 1 1 E-3 25 HPNB-37500-003 SENSOR ASSY., CRANK 1 1 1 1 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002583 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002583 E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002694~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 10026952~ E-3 27 HZVL-90001-010 BOLT, FLANGE, 12X95 2 10026573	E-3	16	HZVL-15656-000	COVER, OIL LEVEL GAUGE	1	1	1	
E-3 18 HZVL-15810-003ZA VALVE ASSY. SPOOL	E-3	17	HZY3-15657-000	PACKING, OIL LEVEL GAUGE	1	1	1	
E-3 19 HZY2-15825-000 FILTER ASSY., SPOOL VALVE 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-3	18	HZY2-15810-000ZA	VALVE ASSY., SPOOL	1			*NH8* DARK GRAY
E-3 19 HZY3-15825-003 FILTER ASSY., SPOOL VALVE	E-3	18	HZVL-15810-003ZA	VALVE ASSY., SPOOL		1	1	
E-3 20 H5YS-30530-J01 SENSOR, KNOCK 1 1 1 1 1 E-3 21 HZVL-32114-000 BRACKET, CLIP B 1 1 1 1 E-3 22 HZVL-32193-000 CORD, SWITCH 1 1 1 1 E-3 23 HZY3-35673-003 SENSOR ASSY., WATER 1 1 1 1 1 E-3 24 HRNA-37260-A01 SENSOR, OIL PRESSURE 1 1 1 1 1 E-3 25 HPNB-37500-003 SENSOR ASSY., CRANK 1 1 1 1 1 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002493 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002583 E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1006952~ E-3 27 HZVL-90006-003 BOLT-WASHER, 10X109 1	E-3	19	HZY2-15825-000	FILTER ASSY., SPOOL VALVE	1			
E-3 21 HZVL-32114-000 BRACKET, CLIP B 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-3	19	HZY3-15825-003	FILTER ASSY., SPOOL VALVE		1	1	
E-3 22 HZYL-32193-000 CORD, SWITCH 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-3	20	H5YS-30530-J01	SENSOR, KNOCK	1	1	1	
E-3 23 HZY3-35673-003 SENSOR ASSY., WATER 1 1 1 1 TEMPERATURE E-3 24 HRNA-37260-A01 SENSOR, OIL PRESSURE 1 1 1 1 E-3 25 HPNB-37500-003 SENSOR ASSY., CRANK 1 1 1 1 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002493 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002583 E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 ~1006951 E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1006952~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 1 2 1006952~ E-3 27 HZVL-90006-003 BOLT-WASHER, 10X109 1 ~1002573	E-3	21	HZVL-32114-000	BRACKET, CLIP B	1	1	1	
E-3 24 HRNA-37260-A01 SENSOR, OIL PRESSURE 1 1 1 1 1 E-3 25 HPNB-37500-003 SENSOR ASSY., CRANK 1 1 1 1 1 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002493 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002583 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1006951 E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1006952~ E-3 27 HZVL-90001-010 BOLT, FLANGE, 12X95 1	E-3	22	HZVL-32193-000	CORD, SWITCH	1	1	1	
E-3 25 HPNB-37500-003 SENSOR ASSY., CRANK 1 1 1 1 1 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002583 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002583 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1006951 E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002494∼ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584∼ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1006952∼ E-3 27 HZVL-90006-003 BOLT, FLANGE, 10X109 1 ~1002573	E-3	23	HZY3-35673-003	SENSOR ASSY., WATER	1	1	1	TEMPERATURE
E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002583 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002583 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1006951 E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1006952~ E-3 27 HZVL-90006-003 BOLT-WASHER, 10X109 1 ~1002573	E-3	24	HRNA-37260-A01	SENSOR, OIL PRESSURE	1	1	1	
E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1002583 E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1006951 E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1006952~ E-3 27 HZVL-90006-003 BOLT-WASHER, 10X109 1 ~1002573	E-3	25	HPNB-37500-003	SENSOR ASSY., CRANK	1	1	1	
E-3 26 HZVL-90001-000 BOLT, FLANGE, 12X95 2 ~1006951 E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1006952~ E-3 27 HZVL-90006-003 BOLT-WASHER, 10X109 1 ~1002573	E-3	26	HZVL-90001-000	BOLT, FLANGE, 12X95	2			~1002493
E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002494~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1006952~ E-3 27 HZVL-90006-003 BOLT-WASHER, 10X109 1 ~1002573	E-3	26	HZVL-90001-000	BOLT, FLANGE, 12X95		2		~1002583
E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1002584~ E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1006952~ E-3 27 HZVL-90006-003 BOLT-WASHER, 10X109 1 ~1002573	E-3	26	HZVL-90001-000	BOLT, FLANGE, 12X95			2	~1006951
E-3 26 HZVL-90001-010 BOLT, FLANGE, 12X95 2 1006952~ E-3 27 HZVL-90006-003 BOLT-WASHER, 10X109 1 ~1002573	E-3	26	HZVL-90001-010	BOLT, FLANGE, 12X95	2			1002494~
E-3 27 HZVL-90006-003 B0LT-WASHER, 10X109 1 ~1002573	E-3	26	HZVL-90001-010	BOLT, FLANGE, 12X95		2		1002584~
	E-3	26	HZVL-90001-010	BOLT, FLANGE, 12X95			2	1006952~
E-3 27 HZVL-90006-013 B0LT-WASHER, 10X109 1 1002574~	E-3	27	HZVL-90006-003	BOLT-WASHER, 10X109	1			~1002573
	E-3	27	HZVL-90006-013	BOLT-WASHER, 10X109	1			1002574~




Ref. No. Part No. Description Fig. Fig.						Q'ty		_
E-3 27 HZVL-90006-013 B0LT-MASHER, 10X109	Ref. No	•	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-3 27 HZVL-90006-003 B0LT-MASHER, 10X109	E-3	27	HZVL-90006-003	BOLT-WASHER, 10X109		1		~1002650
E-3 27 HZVL-90006-013 B0LT-MASHER, 10X109 E-3 28 HZVL-90008-013 B0LT-MASHER, 10X60 E-3 29 HZVL-90008-013 B0LT-MASHER, 10X60 E-3 29 HZVL-90008-013 B0LT-MASHER, 10X60 E-3 29 HZVL-90009-013 B0LT-MASHER, 10X60 E-3 29 HZVL-90009-013 B0LT-MASHER, 10X80 E-3 30 HZZS-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002570 E-3 30 HZZS-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002571 E-3 30 HZZS-90021-M01 B0LT, FLANGE, 6X14 1 1 1002571 E-3 30 HZZS-90021-M01 B0LT, FLANGE, 6X14 E-3 30 HZZS-90021-M00 B0LT, FLANGE, 6X14 E-3 30 HZZS-90017-M00 B0LT, FLANGE, 6X14 E-3 30 HZZS-90017-M00 B0LT, FLANGE, 6X14 E-3 32 HZZS-90017-M00 B0LT, FLANGE, 6X16 E-3 32 HZZS-90017-M01 B0LT, FLANGE, 6X16 E-3 32 HZZS-90017-M01 B0LT, FLANGE, 6X16 E-3 32 HZZS-90017-M01 B0LT, FLANGE, 6X16	E-3	27	HZVL-90006-013	BOLT-WASHER, 10X109		1		1002651~
E-3 28 HZVL-90008-003 B0LT-WASHER, 10X60 5 1002573 E-3 28 HZVL-90008-013 B0LT-WASHER, 10X60 5 1002574∼ E-3 28 HZVL-90008-013 B0LT-WASHER, 10X60 5 1002650 E-3 28 HZVL-90008-013 B0LT-WASHER, 10X60 5 1002651∼ E-3 28 HZVL-90008-013 B0LT-WASHER, 10X60 5 1007292 E-3 28 HZVL-90008-013 B0LT-WASHER, 10X60 5 1007292 E-3 29 HZVL-90009-013 B0LT-WASHER, 10X60 2 1002573 E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 1002573 E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 1002574∼ E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 1002650 E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 1002651∼ E-3 30 HZZ5-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002570 E-3 30 HZZ5-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002571∼ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 ~1002571∼ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002571∼ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002571∼ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002571∼ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002571∼ E-3 31 HRCA-90014-A01 B0LT, FLANGE, 6X14 1 1 1002571∼ E-3 32 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002571∼ E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 1 ~1002560∼	E-3	27	HZVL-90006-003	BOLT-WASHER, 10X109			1	~1007292
E-3 28 HZVL-90008-013 B0LT-WASHER, 10X60 5 10002574~ E-3 28 HZVL-90008-013 B0LT-WASHER, 10X60 5 10002650 E-3 28 HZVL-90008-013 B0LT-WASHER, 10X60 5 10002651~ E-3 28 HZVL-90008-013 B0LT-WASHER, 10X60 5 1007292 E-3 28 HZVL-90008-013 B0LT-WASHER, 10X60 5 1007293~ E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 10002574~ E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 11002574~ E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 11002574~ E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 11002650 E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 11002650 E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 11002651~ E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 2 1007292 E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 2 1007292 E-3 30 HZZ5-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002570 E-3 30 HZZ5-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002570 E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002916 E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90017-M00 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 31 HRCA-90014-A01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 1 ~1002550~ E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 1 ~1002550~	E-3	27	HZVL-90006-013	BOLT-WASHER, 10X109			1	1007293~
E-3 28 HZVL-90008-003 B0LT-MASHER, 10X60 5 1002651~ E-3 28 HZVL-90008-013 B0LT-MASHER, 10X60 5 1002651~ E-3 28 HZVL-90008-013 B0LT-MASHER, 10X60 5 1007292 E-3 28 HZVL-90008-013 B0LT-MASHER, 10X60 5 1007293~ E-3 29 HZVL-90009-013 B0LT-MASHER, 10X80 2 1002573 E-3 29 HZVL-90009-013 B0LT-MASHER, 10X80 2 1002574~ E-3 29 HZVL-90009-013 B0LT-MASHER, 10X80 2 1002650 E-3 29 HZVL-90009-013 B0LT-MASHER, 10X80 2 1002650 E-3 29 HZVL-90009-013 B0LT-MASHER, 10X80 2 1002651~ E-3 30 HZZ5-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002570 E-3 30 HZZ5-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002570 E-3 30 HZZ5-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002571~ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002916 E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 31 HRGA-90014-A01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 1 ~1002617 E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 1 ~1002550~	E-3	28	HZVL-90008-003	BOLT-WASHER, 10X60	5			~1002573
E-3 28 H2VL-90008-013 B0LT-WASHER, 10X60	E-3	28	HZVL-90008-013	BOLT-WASHER, 10X60	5			1002574~
E-3 28 H2VL-90008-003 B0LT-WASHER, 10X60	E-3	28	HZVL-90008-003	BOLT-WASHER, 10X60		5		~1002650
E-3 28 HZVL-90008-013 BOLT-WASHER, 10X60 2 1 ~1007293~ E-3 29 HZVL-90009-003 BOLT-WASHER, 10X80 2 1 1002573 E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 1 1002574~ E-3 29 HZVL-90009-003 BOLT-WASHER, 10X80 2 1 1002650 E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 1 1002651~ E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 1 1007293~ E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1002570 E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1002916 E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1002916 E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002571~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 31 HRCA-90014-A01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1007290~ E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002617 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002550~	E-3	28	HZVL-90008-013	BOLT-WASHER, 10X60		5		1002651~
E-3 29 HZVL-90009-003 BOLT-WASHER, 10X80 2 1002573 E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 1002574~ E-3 29 HZVL-90009-003 BOLT-WASHER, 10X80 2 1002650 E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 1002651~ E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 1002651~ E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 2 ~1007292 E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 1007293~ E-3 30 HZZ5-90021-W00 BOLT, FLANGE, 6X14 1 ~1002570 E-3 30 HZZ5-90021-W00 BOLT, FLANGE, 6X14 1 ~1002570 E-3 30 HZZ5-90021-W00 BOLT, FLANGE, 6X14 1 1 ~1002916 E-3 30 HZZ5-90021-W01 BOLT, FLANGE, 6X14 1 1 1002571~ E-3 30 HZZ5-90021-W01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-W01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-W01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 32 HZZ5-90017-W00 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 32 HZZ5-90017-W00 BOLT, FLANGE, 6X16 1 1 ~1002549 E-3 32 HZZ5-90017-W00 BOLT, FLANGE, 6X16 1 1 ~1002150~ E-3 32 HZZ5-90017-W00 BOLT, FLANGE, 6X16 1 1 ~1002150~ E-3 32 HZZ5-90017-W00 BOLT, FLANGE, 6X16 1 1 ~1002150~	E-3	28	HZVL-90008-003	BOLT-WASHER, 10X60			5	~1007292
E-3 29 H2VL-90009-013 B0LT-WASHER, 10X80 2 2 1002650 E-3 29 H2VL-90009-003 B0LT-WASHER, 10X80 2 2 ~1002650 E-3 29 H2VL-90009-013 B0LT-WASHER, 10X80 2 2 1002651~ E-3 29 H2VL-90009-003 B0LT-WASHER, 10X80 2 2 ~1007292 E-3 29 H2VL-90009-013 B0LT-WASHER, 10X80 2 2 1007292 E-3 29 H2VL-90009-013 B0LT-WASHER, 10X80 2 1007293~ E-3 30 H2Z5-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002570 E-3 30 H2Z5-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1002570 E-3 30 H2Z5-90021-M00 B0LT, FLANGE, 6X14 1 1 ~1007289 E-3 30 H2Z5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002571~ E-3 30 H2Z5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 30 H2Z5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 30 H2Z5-9001-M01 B0LT, FLANGE, 6X14 1 1 1007290~ E-3 31 HRGA-90014-A01 B0LT, FLANGE, 6X14 1 1 1007290~ E-3 32 H2Z5-90017-M00 B0LT, FLANGE, 6X16 1 1 ~1002617 E-3 32 H2Z5-90017-M00 B0LT, FLANGE, 6X16 1 1 ~1002550~	E-3	28	HZVL-90008-013	BOLT-WASHER, 10X60			5	1007293~
E-3 29 HZVL-9009-003 BOLT-WASHER, 10X80 2 1002650 E-3 29 HZVL-9009-013 BOLT-WASHER, 10X80 2 1002651∼ E-3 29 HZVL-9009-003 BOLT-WASHER, 10X80 2 2 1007292 E-3 29 HZVL-9009-013 BOLT-WASHER, 10X80 2 1007293∼ E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1002570 E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1002916 E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 1002571∼ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002571∼ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002571∼ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917∼ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917∼ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1007290∼ E-3 31 HRCA-90014-A01 BOLT-WASHER, 11X105 8 8 8 8 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002549 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002617 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002550∼	E-3	29	HZVL-90009-003	BOLT-WASHER, 10X80	2			~1002573
E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 1002651~ E-3 29 HZVL-90009-003 BOLT-WASHER, 10X80 2 2 ~1007292 E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 1007293~ E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 ~1002570 E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 ~1002916 E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1007289 E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002571~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002571~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-9001-M01 BOLT, FLANGE, 6X14 1 1 1007290~ E-3 31 HRCA-90014-A01 BOLT, FLANGE, 6X16 1 1 ~1002549 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002617 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002550~	E-3	29	HZVL-90009-013	BOLT-WASHER, 10X80	2			1002574~
E-3 29 HZVL-90009-003 B0LT-WASHER, 10X80 2 ~1007292 E-3 29 HZVL-90009-013 B0LT-WASHER, 10X80 2 1007293~ E-3 30 HZZ5-90021-M00 B0LT, FLANGE, 6X14 1	E-3	29	HZVL-90009-003	BOLT-WASHER, 10X80		2		~1002650
E-3 29 HZVL-90009-013 BOLT-WASHER, 10X80 2 1007293~ E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1002570 E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1002916 E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1002571~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002571~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1007290~ E-3 31 HRGA-90014-A01 BOLT, FLANGE, 6X14 1 1 ~1007290~ E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002549 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~100217 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~100217 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002550~	E-3	29	HZVL-90009-013	BOLT-WASHER, 10X80		2		1002651~
E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1002570 E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 ~1007289 E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 1002571~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1007290~ E-3 31 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1007290~ E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1002549 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1002617 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1007152 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1007152 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002550~	E-3	29	HZVL-90009-003	BOLT-WASHER, 10X80			2	~1007292
E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1	E-3	29	HZVL-90009-013	BOLT-WASHER, 10X80			2	1007293~
E-3 30 HZZ5-90021-M00 BOLT, FLANGE, 6X14 1 1 1002571~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1 1007290~ E-3 31 HRCA-90014-A01 BOLT-WASHER, 11X105 8 8 8 8 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1002549 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1002617 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1007152 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 1 ~1007152 E-3 32 HZZ5-90017-M01 BOLT, FLANGE, 6X16 1 1 1002550~	E-3	30	HZZ5-90021-M00	BOLT, FLANGE, 6X14	1			~1002570
E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1002571~ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1002917~ E-3 31 HRCA-90014-A01 B0LT, FLANGE, 6X14 1 1007290~ E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 ~1002549 E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 ~1002617 E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 ~1007152 E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 1 ~1007152 E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 1 ~1007152	E-3	30	HZZ5-90021-M00	BOLT, FLANGE, 6X14		1		~1002916
E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1002917~ E-3 30 HZZ5-90021-M01 B0LT, FLANGE, 6X14 1 1 1007290~ E-3 31 HRCA-90014-A01 B0LT-WASHER, 11X105 8 8 8 8 E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 ~1002549 E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 ~1002617 E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 ~1007152 E-3 32 HZZ5-90017-M00 B0LT, FLANGE, 6X16 1 1 ~1007152	E-3	30	HZZ5-90021-M00	BOLT, FLANGE, 6X14			1	~1007289
E-3 30 HZZ5-90021-M01 BOLT, FLANGE, 6X14 1 1007290~ E-3 31 HRCA-90014-A01 BOLT-WASHER, 11X105 8 8 8 8 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1002549 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1002617 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1007152 E-3 32 HZZ5-90017-M01 BOLT, FLANGE, 6X16 1 1002550~	E-3	30	HZZ5-90021-M01	BOLT, FLANGE, 6X14	1			1002571~
E-3 31 HRCA-90014-A01 BOLT-WASHER, 11X105 8 8 8 8 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1002549 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1002617 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1007152 E-3 32 HZZ5-90017-M01 BOLT, FLANGE, 6X16 1 1002550~	E-3	30	HZZ5-90021-M01	BOLT, FLANGE, 6X14		1		1002917~
E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1002549 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1002617 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1007152 E-3 32 HZZ5-90017-M01 BOLT, FLANGE, 6X16 1 1002550~	E-3	30	HZZ5-90021-M01	BOLT, FLANGE, 6X14			1	1007290~
E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1002617 E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1007152 E-3 32 HZZ5-90017-M01 BOLT, FLANGE, 6X16 1 1002550~	E-3	31	HRCA-90014-A01	BOLT-WASHER, 11X105	8	8	8	
E-3 32 HZZ5-90017-M00 BOLT, FLANGE, 6X16 1 ~1007152 E-3 32 HZZ5-90017-M01 BOLT, FLANGE, 6X16 1 1002550~	E-3	32	HZZ5-90017-M00	BOLT, FLANGE, 6X16	1			~1002549
E-3 32 HZZ5-90017-M01 BOLT, FLANGE, 6X16 1 1002550~	E-3	32	HZZ5-90017-M00	BOLT, FLANGE, 6X16		1		~1002617
	E-3	32	HZZ5-90017-M00	BOLT, FLANGE, 6X16			1	~1007152
E-3 32 HZZ5-90017-M01 BOLT, FLANGE, 6X16 1 1002618~	E-3	32	HZZ5-90017-M01	BOLT, FLANGE, 6X16	1			1002550~
	E-3	32	HZZ5-90017-M01	BOLT, FLANGE, 6X16		1		1002618~
E-3 32 HZZ5-90017-M01 BOLT, FLANGE, 6X16 1 1007153~	E-3	32	HZZ5-90017-M01	BOLT, FLANGE, 6X16			1	1007153~



Ref. No. Part No. Description Section	-					Q' ty		_
E-3 33 H2Z5-90019-M00 B0LT, FLANGE, 6X35 E-3 33 HZZ5-90019-M01 B0LT, FLANGE, 6X35 F-3 34 HZZ5-90019-M01 B0LT, FLANGE, 6X35 F-3 34 HZZ1-90029-000 B0LT, FLANGE, 8X50 F-3 34 HZZ1-90029-000 B0LT, FLANGE, 8X50 F-3 34 HZZ1-90029-010 B0LT, FLANGE, 8X50 F-3 34 HZZ1-90020-010 B0LT, FLANGE, 8X50 F-3 34 HZZ1-90020-010 B0LT, FLANGE, 8X50 F-3 35 HZZ1-90020-010 B0LT, FLANGE, 6X18 F-3 35 HZZ1-90020-000 B0LT, FLANGE, 6X18 F-3 35 HZZ1-90020-000 B0LT, FLANGE, 6X18 F-3 35 HZZ1-90020-010 B0LT, FLANGE, 6X18 F-3 36 HZZ1-90020-010 B0LT, FLANGE, 6X18 F-3 37 HZZ1-90020-010 B0LT, FLANGE, 6X18 F-3 36 HZZ1-90020-010 B0LT, FLANGE, 6X18 F-3 37 HZZ1-90020-010 B0LT, FLANGE, 6X18 F-3 36 HZZ1-90020-010 B0LT, FLANGE, 6X18 F-3 37 HZZ1-90020-010 B0LT, FLANGE, 6X18 F-3 36 HZZ5-90020-010 B0LT, FLANGE, 6X18 F-3 37 HZZ1-90020-010 B0LT, FLANGE, 6X22 F-3 38 HZZ1-90020-010 B0LT, FLANGE, 6X22 F-3 36 HZZ5-90020-010 B0LT, FLANGE, 6X22 F-3 37 HZZ1-90020-010 B0LT, FLANGE, 6X22 F-3 37 HZZ1-90020-010 B0LT, FLANGE, 6X22 F-3 37 HZZ1-90020-000 B0LT, FLANGE, 6X75 F-3 37 HZZ1-90020-000 B0LT, FLANGE, 6	Ref. No	Ref.No. Part No.		Description	BFT200D	BFT225D	BFT250D	Remarks
E-3 33 HZZ5-90019-M00 BOLT, FLANGE, 6X35 7 1002550~ E-3 33 HZZ5-90019-M01 BOLT, FLANGE, 6X35 7 1002550~ E-3 33 HZZ5-90019-M01 BOLT, FLANGE, 6X35 7 1002618~ E-3 33 HZZ5-90019-M01 BOLT, FLANGE, 6X35 7 1007153~ E-3 34 HZV1-90020-000 BOLT, FLANGE, 8X50 2 1 ~1002549 E-3 34 HZV1-90020-000 BOLT, FLANGE, 8X50 2 1 ~1002617 E-3 34 HZV1-90020-000 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 34 HZV1-90020-010 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 34 HZV1-90020-010 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 34 HZV1-90020-010 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 34 HZV1-90020-010 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 35 HZV1-90028-000 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 35 HZV1-90028-000 BOLT, FLANGE, 8X18 4 ~1002549 E-3 35 HZV1-90028-000 BOLT, FLANGE, 6X18 4 ~1002550~ E-3 35 HZV1-90028-010 BOLT, FLANGE, 6X18 4 1 1002550~ E-3 35 HZV1-90028-010 BOLT, FLANGE, 6X18 4 1 1002550~ E-3 35 HZV1-90028-010 BOLT, FLANGE, 6X18 4 1 1002550~ E-3 35 HZV1-90028-010 BOLT, FLANGE, 6X18 4 1 1002550~ E-3 35 HZV1-90028-010 BOLT, FLANGE, 6X18 4 1 1002550~ E-3 36 HZZ5-90030-M00 BOLT, FLANGE, 6X18 4 1 1002550~ E-3 36 HZZ5-90030-M00 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 36 HZZ5-90030-M00 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X25 1 1 ~1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X75 1 1 ~1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X75 1 1 ~1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X75 1 1 ~1002550~ E-3 37 HZV1-90038-000 BOLT, FLANGE, 6X75 1 1 ~1002550~	E-3	33	HZZ5-90019-M00	BOLT, FLANGE, 6X35	7			~1002549
E-3 33 H2Z5-90019-M01 B0LT, FLANGE, 6X35 7 1002550~ E-3 33 HZZ5-90019-M01 B0LT, FLANGE, 6X35 7 1002618~ E-3 33 HZZ5-90019-M01 B0LT, FLANGE, 6X35 7 1007153~ E-3 34 HZVL-90020-000 B0LT, FLANGE, 8X50 2 1 ~1002617 E-3 34 HZVL-90020-000 B0LT, FLANGE, 8X50 2 ~1002617 E-3 34 HZVL-90020-010 B0LT, FLANGE, 8X50 2 1002550~ E-3 34 HZVL-90020-010 B0LT, FLANGE, 8X50 2 1002550~ E-3 34 HZVL-90020-010 B0LT, FLANGE, 8X50 2 1002618~ E-3 34 HZVL-90020-010 B0LT, FLANGE, 8X50 2 1002618~ E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 ~1002617 E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 ~1002617 E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 ~1002617 E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002617 E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002617 E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002550~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002617 E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002550~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X18 4 1002550~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X18 4 1002550~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X12 8 ~1002550~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 6X22 8 1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 6X22 8 1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 6X75 1 1 ~1002560~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 6X75 1 1 ~1002560~	E-3	33	HZZ5-90019-M00	BOLT, FLANGE, 6X35		7		~1002617
E-3 33 HZZ5-90019-N01 BOLT, FLANGE, 6X35 7 1002618~ E-3 34 HZVL-90020-000 BOLT, FLANGE, 6X35 7 1007153~ E-3 34 HZVL-90020-000 BOLT, FLANGE, 8X50 2 1 ~1002617 E-3 34 HZVL-90020-000 BOLT, FLANGE, 8X50 2 1 ~1002617 E-3 34 HZVL-90020-010 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 34 HZVL-90020-010 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 34 HZVL-90020-010 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 34 HZVL-90020-010 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 34 HZVL-90020-010 BOLT, FLANGE, 8X50 2 1 1002550~ E-3 35 HZVL-90028-000 BOLT, FLANGE, 6X18 4 ~1007152 — E-3 35 HZVL-90028-000 BOLT, FLANGE, 6X18 4 ~1002617 E-3 35 HZVL-90028-000 BOLT, FLANGE, 6X18 4 ~1002550~ E-3 35 HZVL-90028-010 BOLT, FLANGE, 6X18 4 1 1002550~ E-3 35 HZVL-90028-010 BOLT, FLANGE, 6X18 4 1 1002550~ E-3 35 HZVL-90028-010 BOLT, FLANGE, 6X18 4 1 1002618~ E-3 35 HZVL-90028-010 BOLT, FLANGE, 6X18 4 1 1002618~ E-3 35 HZVL-90028-010 BOLT, FLANGE, 6X18 4 1 1002618~ E-3 35 HZVL-90028-010 BOLT, FLANGE, 6X18 4 1 1002618~ E-3 36 HZZ5-90030-N00 BOLT, FLANGE, 6X22 8 1 ~1002550~ E-3 36 HZZ5-90030-N00 BOLT, FLANGE, 6X22 8 1 ~1002550~ E-3 36 HZZ5-90030-N00 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 36 HZZ5-90030-N00 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 37 HZVL-90028-000 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 37 HZVL-90038-000 BOLT, FLANGE, 6X22 8 1 1002550~ E-3 37 HZVL-90038-000 BOLT, FLANGE, 6X22 8 1 1002618~ E-3 37 HZVL-90038-000 BOLT, FLANGE, 6X22 8 1 10026549 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 1 ~1002550~ E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 1 ~1002550~ E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 1 ~1002550~	E-3	33	HZZ5-90019-M00	BOLT, FLANGE, 6X35			7	~1007152
E-3 33 HZZE-90019-801 B0LT, FLANGE, 6X35 E-3 34 HZZU-90020-000 B0LT, FLANGE, 8X50 E-3 34 HZZU-90020-000 B0LT, FLANGE, 8X50 E-3 34 HZZU-90020-000 B0LT, FLANGE, 8X50 E-3 34 HZZU-90020-010 B0LT, FLANGE, 6X18 E-3 35 HZZU-90028-000 B0LT, FLANGE, 6X18 E-3 35 HZZU-90028-000 B0LT, FLANGE, 6X18 E-3 35 HZZU-90028-010 B0LT, FLANGE, 6X18 E-3 35 HZZU-90030-910 B0LT, FLANGE, 6X18 E-3 36 HZZE-90030-910 B0LT, FLANGE, 6X22 B 1 1002549 E-3 36 HZZE-90030-910 B0LT, FLANGE, 6X22 B 1 1002550- E-3 36 HZZE-90030-910 B0LT, FLANGE, 6X22 B 1 1002550- E-3 36 HZZE-90030-910 B0LT, FLANGE, 6X22 B 1 1002550- E-3 36 HZZE-90030-910 B0LT, FLANGE, 6X22 B 1 1002550- E-3 36 HZZE-90030-910 B0LT, FLANGE, 6X22 B 1 1002550- E-3 37 HZZU-90038-000 B0LT, FLANGE, 6X22 B 1 1002550- E-3 37 HZZU-90038-000 B0LT, FLANGE, 6X22 B 1 1002550- E-3 37 HZZU-90038-000 B0LT, FLANGE, 6X22 B 1 1 ~1002549 E-3 37 HZZU-90038-000 B0LT, FLANGE, 8X75 1 1 ~1002550- E-3 37 HZZU-90038-000 B0LT, FLANGE, 8X75 1 1 ~1002550-	E-3	33	HZZ5-90019-M01	BOLT, FLANGE, 6X35	7			1002550~
E-3 34 HZVL-90020-000 B0LT, FLANGE, 8X50 2	E-3	33	HZZ5-90019-M01	BOLT, FLANGE, 6X35		7		1002618~
E-3 34 HZVL-90020-000 B0LT, FLANGE, 8X50	E-3	33	HZZ5-90019-M01	BOLT, FLANGE, 6X35			7	1007153~
E-3 34 H2VL-90020-000 B0LT, FLANGE, 8X50 2 1002550~ E-3 34 H2VL-90020-010 B0LT, FLANGE, 8X50 2 1002618~ E-3 34 H2VL-90020-010 B0LT, FLANGE, 8X50 2 1002618~ E-3 34 H2VL-90020-010 B0LT, FLANGE, 8X50 2 1007153~ E-3 35 H2VL-90028-000 B0LT, FLANGE, 6X18 4 ~1002617 E-3 35 H2VL-90028-000 B0LT, FLANGE, 6X18 4 ~1002617 E-3 35 H2VL-90028-010 B0LT, FLANGE, 6X18 4 ~1002650~ E-3 35 H2VL-90028-010 B0LT, FLANGE, 6X18 4 1002650~ E-3 35 H2VL-90028-010 B0LT, FLANGE, 6X18 4 1002650~ E-3 35 H2VL-90028-010 B0LT, FLANGE, 6X18 4 1002650~ E-3 35 H2VL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 H2VL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 36 H2Z5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002617 E-3 36 H2Z5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002617 E-3 36 H2Z5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 H2Z5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 37 H2VL-90038-000 B0LT, FLANGE, 6X22 8 1002618~ E-3 37 H2VL-90038-000 B0LT, FLANGE, 6X22 8 1002618~ E-3 37 H2VL-90038-000 B0LT, FLANGE, 6X22 8 1002619~ E-3 37 H2VL-90038-000 B0LT, FLANGE, 6X25 1 1 ~1002550~ E-3 37 H2VL-90038-000 B0LT, FLANGE, 6X75 1 1 ~1002550~ E-3 37 H2VL-90038-010 B0LT, FLANGE, 6X75 1 1 ~1002550~	E-3	34	HZVL-90020-000	BOLT, FLANGE, 8X50	2			~1002549
E-3 34 HZVL-90020-010 B0LT, FLANGE, 8X50 2 1002550~ E-3 34 HZVL-90020-010 B0LT, FLANGE, 8X50 2 1002618~ E-3 34 HZVL-90028-000 B0LT, FLANGE, 8X50 2 1007153~ E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 ~1002549 E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 ~1002617 E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 ~1002550~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002550~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002550~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002549 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 6X22 8 1002618~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 6X22 8 1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 6X22 8 1002617 E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 1 ~1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 1 ~1007152 E-3 37 HZVL-90038-010 B0LT, FLANGE, 8X75 1 1 ~1007152	E-3	34	HZVL-90020-000	BOLT, FLANGE, 8X50		2		~1002617
E-3 34 HZVL-90020-010 B0LT, FLANGE, 8X50 2 1002618~ E-3 34 HZVL-90020-010 B0LT, FLANGE, 8X50 2 1007153~ E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 ~1002549 E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 ~1002617 E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 ~1002550~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002550~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1007153~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1007153~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002549 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002550~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 6X25 1 1 ~1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 1 ~1002550~ E-3 37 HZVL-90038-010 B0LT, FLANGE, 8X75 1 1 ~1007152	E-3	34	HZVL-90020-000	BOLT, FLANGE, 8X50			2	~1007152
E-3 34 HZVL-90020-010 BOLT, FLANGE, 8X50 E-3 35 HZVL-90028-000 BOLT, FLANGE, 6X18 E-3 35 HZVL-90028-000 BOLT, FLANGE, 6X18 E-3 35 HZVL-90028-000 BOLT, FLANGE, 6X18 E-3 35 HZVL-90028-010 BOLT, FLANGE, 6X18 E-3 36 HZZ5-90030-MO0 BOLT, FLANGE, 6X22 B	E-3	34	HZVL-90020-010	BOLT, FLANGE, 8X50	2			1002550~
E-3 35 H2VL-90028-000 B0LT, FLANGE, 6X18 4 ~1002549 E-3 35 H2VL-90028-000 B0LT, FLANGE, 6X18 4 ~1002617 E-3 35 H2VL-90028-000 B0LT, FLANGE, 6X18 4 ~1002550~ E-3 35 H2VL-90028-010 B0LT, FLANGE, 6X18 4 1002550~ E-3 35 H2VL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 H2VL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 H2VL-90028-010 B0LT, FLANGE, 6X18 4 1007153~ E-3 36 H2Z5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002549 E-3 36 H2Z5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002617 E-3 36 H2Z5-90030-M00 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 H2Z5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 H2Z5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 H2Z5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 37 H2VL-90038-000 B0LT, FLANGE, 8X75 1 ~1002549 E-3 37 H2VL-90038-000 B0LT, FLANGE, 8X75 1 ~1002550~	E-3	34	HZVL-90020-010	BOLT, FLANGE, 8X50		2		1002618~
E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 ~1002617 E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 ~1002550~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002550~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1007153~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002649 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002617 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002617 E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002650~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 1 ~1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 1 ~1002550~	E-3	34	HZVL-90020-010	BOLT, FLANGE, 8X50			2	1007153~
E-3 35 HZVL-90028-000 B0LT, FLANGE, 6X18 4 1002550~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1007153~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002549 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002617 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002617 E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002549 E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002550~	E-3	35	HZVL-90028-000	BOLT, FLANGE, 6X18	4			~1002549
E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002550~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1007153~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002549 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002617 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002549 E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002550~	E-3	35	HZVL-90028-000	BOLT, FLANGE, 6X18		4		~1002617
E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1002618~ E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1007153~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002549 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002617 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002549 E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 1 ~1002550~ E-3 37 HZVL-90038-010 B0LT, FLANGE, 8X75 1 1 ~1002550~	E-3	35	HZVL-90028-000	BOLT, FLANGE, 6X18			4	~1007152
E-3 35 HZVL-90028-010 B0LT, FLANGE, 6X18 4 1007153~ E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002549 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002617 E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8 ~1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 B0LT, FLANGE, 6X22 8 1002618~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002549 E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 ~1002550~ E-3 37 HZVL-90038-000 B0LT, FLANGE, 8X75 1 1 ~1002550~	E-3	35	HZVL-90028-010	BOLT, FLANGE, 6X18	4			1002550~
E-3 36 HZZ5-90030-M00 B0LT, FLANGE, 6X22 8	E-3	35	HZVL-90028-010	BOLT, FLANGE, 6X18		4		1002618~
E-3 36 HZZ5-90030-M00 BOLT, FLANGE, 6X22 8 ~1002617 E-3 36 HZZ5-90030-M00 BOLT, FLANGE, 6X22 8 ~1002550~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1007153~ E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002549 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~10027152 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002550~	E-3	35	HZVL-90028-010	BOLT, FLANGE, 6X18			4	1007153~
E-3 36 HZZ5-90030-M00 BOLT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1007153~ E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002549 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 1 ~1007152 E-3 37 HZVL-90038-010 BOLT, FLANGE, 8X75 1 1 1002550~	E-3	36	HZZ5-90030-M00	BOLT, FLANGE, 6X22	8			~1002549
E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1002550~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1007153~ E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002549 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1007152 E-3 37 HZVL-90038-010 BOLT, FLANGE, 8X75 1 1 ~1007152	E-3	36	HZZ5-90030-M00	BOLT, FLANGE, 6X22		8		~1002617
E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1002618~ E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1007153~ E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002549 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1007152 E-3 37 HZVL-90038-010 BOLT, FLANGE, 8X75 1 1 ~1002550~	E-3	36	HZZ5-90030-M00	BOLT, FLANGE, 6X22			8	~1007152
E-3 36 HZZ5-90030-M01 BOLT, FLANGE, 6X22 8 1007153~ E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002549 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1007152 E-3 37 HZVL-90038-010 BOLT, FLANGE, 8X75 1 1 1002550~	E-3	36	HZZ5-90030-M01	BOLT, FLANGE, 6X22	8			1002550~
E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002549 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1007152 E-3 37 HZVL-90038-010 BOLT, FLANGE, 8X75 1 1002550~	E-3	36	HZZ5-90030-M01	BOLT, FLANGE, 6X22		8		1002618~
E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1002617 E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1007152 E-3 37 HZVL-90038-010 BOLT, FLANGE, 8X75 1 1002550~	E-3	36	HZZ5-90030-M01	BOLT, FLANGE, 6X22			8	1007153~
E-3 37 HZVL-90038-000 BOLT, FLANGE, 8X75 1 ~1007152 E-3 37 HZVL-90038-010 BOLT, FLANGE, 8X75 1 1002550~	E-3	37	HZVL-90038-000	BOLT, FLANGE, 8X75	1			~1002549
E-3 37 HZVL-90038-010 BOLT, FLANGE, 8X75 1 1002550~	E-3	37	HZVL-90038-000	BOLT, FLANGE, 8X75		1		~1002617
	E-3	37	HZVL-90038-000	BOLT, FLANGE, 8X75			1	~1007152
E-3 37 HZVL-90038-010 BOLT, FLANGE, 8X75 1 1 1002618~	E-3	37	HZVL-90038-010	BOLT, FLANGE, 8X75	1			1002550~
	E-3	37	HZVL-90038-010	BOLT, FLANGE, 8X75		1		1002618~




Ref. No.						
	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-3 3	7 HZVL-90038-010	BOLT, FLANGE, 8X75			1	1007153~
E-3 3	8 HZY9-90054-M00	BOLT, FLANGE, 8X35	1			~1002549
E-3 3	8 HZY9-90054-M00	BOLT, FLANGE, 8X35		1		~1002617
E-3 3	8 HZY9-90054-M00	BOLT, FLANGE, 8X35			1	~1007152
E-3 3	8 HZY9-90054-M01	BOLT, FLANGE, 8X35	1			1002550~
E-3 3	8 HZY9-90054-M01	BOLT, FLANGE, 8X35		1		1002618~
E-3 3	8 HZY9-90054-M01	BOLT, FLANGE, 8X35			1	1007153~
E-3 3	9 HZZ5-90081-M00	BOLT, SEALING, 22MM	1			~1002626
E-3 3	9 HZZ5-90081-M00	BOLT, SEALING, 22MM		1		~1002916
E-3 3	9 HZZ5-90081-M00	BOLT, SEALING, 22MM			1	~1007539
E-3 3	9 HZZ5-90081-M01	BOLT, SEALING, 22MM	1			1002627~
E-3 3	9 HZZ5-90081-M01	BOLT, SEALING, 22MM		1		1002917~
E-3 3	9 HZZ5-90081-M01	BOLT, SEALING, 22MM			1	1007540~
E-3 4	0 HPH7-90715-000	DOWEL PIN, 13X37	8	8	8	
E-3 4	.1 HZY3-91212-003	OIL SEAL, 41X66X8	1	1	1	
E-3 4	2 HPNA-91214-014	OIL SEAL, 80X98X10(ARAI)	1	1	1	
E-3 4	3 HZVL-91303-000	O-RING, 8.8X1.9	2	2	2	
E-3 4	4 HPNA-91307-003	0-RING, 9.5X1.9	1	1	1	
E-3 4	5 HP8A-91308-A01	O-RING, 18.3X3.5	1	1	1	
E-3 4	6 HPK1-91308-003	0-RING, 26. 2X2. 4 (NOK)	1	1	1	
E-3 4	7 HP8A-91309-A01	O-RING, 16.3X3.5	1	1	1	
E-3 4	8 HPR3-91319-003	0-RING, 13X1.5(ARAI)	1	1	1	
E-3 4	9 HP0X-91321-003	0-RING, 25X2. 4 (NOK)	1	1	1	
E-3 5	0 HPNA-91333-003	O-RING, 15X1.9	1	1	1	
E-3 5	1 HCO-93500-05016-4J	SCREW, PAN, 5X16	2	2	2	
E-3 5	2 HCO-93500-05020-4J	SCREW, PAN, 5X20	6	6	6	
E-3 5	3 HC0-94301-06100	DOWEL PIN, 6X10	4	4	4	
E-3 5	4 HZY3-12160-000	BOLT ASSY., SEALING, 22MM	6			~1007206
E-3 5	4 HZY3-12160-000	BOLT ASSY., SEALING, 22MM		6		~1005809




				Q' ty		
Ref. No.	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-3 5	4 HZY3-12160-000	BOLT ASSY., SEALING, 22MM			6	~1020694
E-3 5	4 HZY3-12160-010	BOLT ASSY., SEALING, 22MM	6			1007207~
E-3 5	4 HZY3-12160-010	BOLT ASSY., SEALING, 22MM		6		1005810~
E-3 5	4 HZY3-12160-010	BOLT ASSY., SEALING, 22MM			6	1020695~
E-3 5	5 HZVL-06126-000	BOLT KIT, SEALING(22MM)	6	6	6	

E-3-10 CRANKCASE




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-3-10	1	HZVL-11100-900	CRANKCASE COMP.	1			~1002677
E-3-10	1	HZVL-11100-900	CRANKCASE COMP.		1		~1002916
E-3-10	1	HZVL-11100-900	CRANKCASE COMP.			1	~1007539 LRA, UCRA, URA, XCRA, XRA
E-3-10	1	HZVL-11100-020	CRANKCASE COMP.			1	~1008195 LDA, UCDA, UDA, XCDA, XDA
E-3-10	1	HZVL-11100-901	CRANKCASE COMP.	1			1002678~
E-3-10	1	HZVL-11100-901	CRANKCASE COMP.		1		1002917~
E-3-10	1	HZVL-11100-901	CRANKCASE COMP.			1	1007540~ LRA, UCRA, URA, XCRA, XRA
E-3-10	1	HZVL-11100-030	CRANKCASE COMP.			1	1008196~ LDA, UCDA, UDA, XCDA, XDA
E-3-10	2	HZX2-11911-000	HANGER, ENGINE	1			~1002833
E-3-10	2	HZX2-11911-010	HANGER, ENGINE	1			1002834~
E-3-10	2	HZX2-11911-000	HANGER, ENGINE		1		~1002881
E-3-10	2	HZX2-11911-010	HANGER, ENGINE		1		1002882~
E-3-10	2	HZX2-11911-000	HANGER, ENGINE			1	~1008207
E-3-10	2	HZX2-11911-010	HANGER, ENGINE			1	1008208~
E-3-10	3	HZV5-12214-000	WASHER, SEALING(22MM)	1	1	1	
E-3-10	4	HRTA-15400-003	CARTRIDGE, OIL FILTER	1	1	1	(MAHLE TENNEX)
E-3-10	5	HZY9-15600-M00	CAP ASSY., OIL FILLER	1	1	1	
E-3-10	6	HZY9-15631-000	EXTENSION, OIL FILLER	1	1	1	
E-3-10	7	HZZ5-90014-M01	BOLT, FLANGE, 6X25	2	2	2	
E-3-10	8	HPH1-90015-013	HOLDER, OIL FILTER	1	1	1	
E-3-10	9	HZZ5-90032-M00	BOLT, FLANGE, 6X32	15			~1002549
E-3-10	9	HZZ5-90032-M00	BOLT, FLANGE, 6X32		15		~1002617
E-3-10	9	HZZ5-90032-M00	BOLT, FLANGE, 6X32			15	~1007152
E-3-10	9	HZZ5-90032-M01	BOLT, FLANGE, 6X32	15			1002550~
E-3-10	9	HZZ5-90032-M01	BOLT, FLANGE, 6X32		15		1002618~
E-3-10	9	HZZ5-90032-M01	BOLT, FLANGE, 6X32			15	1007153~
E-3-10	10	HZVL-90041-010	BOLT, FLANGE, 10X55	2	2	2	
E-3-10	11	HZZ5-90047-M00	BOLT, FLANGE, 6X55	2			~1002549
E-3-10	11	HZZ5-90047-M00	BOLT, FLANGE, 6X55		2		~1002617




Part No. Part No. Description Part No. Description Part No. Part						Q' ty		_
E-3-10 11 H2Z5-90047-M01 BOLT, FLANGE, 6X55 2 1002550~ E-3-10 11 H2Z5-90047-M01 BOLT, FLANGE, 6X55 2 1002618~ E-3-10 11 H2Z5-90047-M01 BOLT, FLANGE, 6X55 2 1007153~ E-3-10 12 H2VL-90063-000 BOLT, FLANGE, 6X37 2 1 ~1002549 E-3-10 12 H2VL-90063-000 BOLT, FLANGE, 6X37 2 2 ~1007152 E-3-10 12 H2VL-90063-010 BOLT, FLANGE, 6X37 2 1 002550~ E-3-10 12 H2VL-90063-010 BOLT, FLANGE, 6X37 2 1 1002550~ E-3-10 12 H2VL-90063-010 BOLT, FLANGE, 6X37 2 1 1002550~ E-3-10 12 H2VL-90063-010 BOLT, FLANGE, 6X37 2 1 1002550~ E-3-10 12 H2VL-90063-010 BOLT, FLANGE, 6X37 2 1 1002618~ E-3-10 12 H2VL-90063-010 BOLT, FLANGE, 6X37 2 1 1002618~ E-3-10 13 H2Z5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1002617 E-3-10 13 H2Z5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1002916 E-3-10 13 H2Z5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1002916 E-3-10 13 H2Z5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 H2Z5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 H2Z5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 H2Z5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 H2Z5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 H2Z5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 H2Z5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 H2Z5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 H2Z5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 15 H2Z0-90151-M00 BOLT, FLANGE, 8X25 2 1 ~1002559~ E-3-10 15 H2Z0-90151-M00 BOLT, FLANGE, 8X25 2 2 ~1002617 E-3-10 15 H2Z0-90151-M01 BOLT, FLANGE, 8X25 2 2 ~1002617 E-3-10 15 H2Z0-90151-M01 BOLT, FLANGE, 8X25 2 2 1002618~	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-3-10 11 HZZ5-90047-N01 B0LT, FLANGE, 6X55 2 1002618~ E-3-10 12 HZVL-90063-000 B0LT, FLANGE, 6X37 2 1	E-3-10	11	HZZ5-90047-M00	BOLT, FLANGE, 6X55			2	~1007152
E-3-10 11 HZZ5-90047-M01 BOLT, FLANGE, 6X55 2 1007153~ E-3-10 12 HZVL-90063-000 BOLT, FLANGE, 6X37 2 2 ~1002617 E-3-10 12 HZVL-90063-000 BOLT, FLANGE, 6X37 2 2 ~1002617 E-3-10 12 HZVL-90063-010 BOLT, FLANGE, 6X37 2 1002550~ E-3-10 12 HZVL-90063-010 BOLT, FLANGE, 6X37 2 1002650~ E-3-10 12 HZVL-90063-010 BOLT, FLANGE, 6X37 2 1002677 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 ~1002677 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 ~1002739 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1002739 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 1002739 E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 15 HZZ5-90081-M01 BOLT, FLANGE, 8X25 2 ~1002549 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002617 E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002650~	E-3-10	11	HZZ5-90047-M01	BOLT, FLANGE, 6X55	2			1002550~
E-3-10 12 H2VL-90063-000 B0LT, FLANGE, 6X37 2	E-3-10	11	HZZ5-90047-M01	BOLT, FLANGE, 6X55		2		1002618~
E-3-10 12 HzVL-90063-000 BOLT, FLANGE, 6X37 2 2 ~1002617 E-3-10 12 HzVL-90063-000 BOLT, FLANGE, 6X37 2 2 ~1002550~ E-3-10 12 HzVL-90063-010 BOLT, FLANGE, 6X37 2 10025618~ E-3-10 12 HzVL-90063-010 BOLT, FLANGE, 6X37 2 1002618~ E-3-10 12 HzVL-90063-010 BOLT, FLANGE, 6X37 2 1002618~ E-3-10 12 HzVL-90063-010 BOLT, FLANGE, 6X37 2 1002618~ E-3-10 13 HzZ5-90081-M00 BOLT, SEALING, 22MM 1 ~~1002677 E-3-10 13 HzZ5-90081-M00 BOLT, SEALING, 22MM 1 ~~1002916 E-3-10 13 HzZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~~1002916 E-3-10 13 HzZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~~1007539 E-3-10 13 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 ~~1002916 E-3-10 13 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917~ E-3-10 13 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917~ E-3-10 13 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917~ E-3-10 13 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917~ E-3-10 15 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917~ E-3-10 15 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917~ E-3-10 15 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917~ E-3-10 15 HzZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1008196~ LDA, UGDA, UDA, XCDA, XDA E-3-10 15 HzZ5-90151-M00 BOLT, FLANGE, 8X25 2 ~~1002549 E-3-10 15 HzZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~~1002550~ E-3-10 15 HzZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HzZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002550~	E-3-10	11	HZZ5-90047-M01	BOLT, FLANGE, 6X55			2	1007153~
E-3-10 12 HZVL-90063-000 BOLT, FLANGE, 6X37 2 1002550~ E-3-10 12 HZVL-90063-010 BOLT, FLANGE, 6X37 2 1002550~ E-3-10 12 HZVL-90063-010 BOLT, FLANGE, 6X37 2 1002618~ E-3-10 12 HZVL-90063-010 BOLT, FLANGE, 6X37 2 1007153~ E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1002677 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1002677 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1007539 LRA, UCRA, UC	E-3-10	12	HZVL-90063-000	BOLT, FLANGE, 6X37	2			~1002549
E-3-10 12 H2VL-90063-010 B0LT, FLANGE, 6X37 2 1002550~ E-3-10 12 H2VL-90063-010 B0LT, FLANGE, 6X37 2 1002618~ E-3-10 12 H2VL-90063-010 B0LT, FLANGE, 6X37 2 1007153~ E-3-10 13 HZZ5-90081-M00 B0LT, SEALING, 22MM 1	E-3-10	12	HZVL-90063-000	BOLT, FLANGE, 6X37		2		~1002617
E-3-10 12 H2VL-90063-010 B0LT, FLANGE, 6X37 2 1002618~ E-3-10 12 H2VL-90063-010 B0LT, FLANGE, 6X37 2 1007153~ E-3-10 13 H2Z5-90081-M00 B0LT, SEALING, 22MM 1	E-3-10	12	HZVL-90063-000	BOLT, FLANGE, 6X37			2	~1007152
E-3-10 12 HZVL-90063-010 BOLT, FLANGE, 6X37 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 2ZMM 1 1 ~1002916 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 2ZMM 1 1 ~1002916 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 2ZMM 1 1 ~1007539 LRA, URA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 2ZMM 1 1 ~1008195 LDA, UCDA, UDA, XCDA, XDA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 2ZMM 1 1 1002678∼ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 2ZMM 1 1 1002678∼ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 2ZMM 1 1 1002917∼ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 2ZMM 1 1 1007540∼ LRA, UCRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 2ZMM 1 1 1008196∼ LDA, UCDA, UDA, XCDA, XDA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 2ZMM 1 1 1 1008196∼ LDA, UCDA, UDA, XCDA, XDA E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002549 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002617 E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002550∼ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002650∼ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002618∼	E-3-10	12	HZVL-90063-010	BOLT, FLANGE, 6X37	2			1002550~
E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1002677 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1007539 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1007539 ERA, UCRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1008195 EDA, UCDA, UDA, XCDA, XDA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1007540~ ERA, UCRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1007540~ ERA, UCRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1008196~ ERA, UCRA, URA, XCRA, XDA E-3-10 14 HZY3-90082-003 CAP, BOLT, TOMM 1 1 1 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002549 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002618~	E-3-10	12	HZVL-90063-010	BOLT, FLANGE, 6X37		2		1002618~
E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1002916 E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1007539 LRA, UGRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 ~1008195 LDA, UGDA, UDA, XGDA, XDA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1007540~ LRA, UGRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1007540~ LRA, UGRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1008196~ LDA, UGDA, UDA, XCDA, XDA E-3-10 14 HZY3-90082-003 CAP, BOLT, 10MM 1 1 1 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002549 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002617 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 1 1002550~ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1 1002650~ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1 1002650~	E-3-10	12	HZVL-90063-010	BOLT, FLANGE, 6X37			2	1007153~
E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 CARA, UCRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 CARA, UCRA,	E-3-10	13	HZZ5-90081-M00	BOLT, SEALING, 22MM	1			~1002677
E-3-10 13 HZZ5-90081-M00 BOLT, SEALING, 22MM 1 1 CRA, UCRA, UCDA, UDA, XCDA, XDA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002678∼ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917∼ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1007540∼ LRA, UCRA,	E-3-10	13	HZZ5-90081-M00	BOLT, SEALING, 22MM		1		~1002916
E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1002678~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1002917~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1007540~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1008196~ LRA, UCRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1008196~ LDA, UCDA, UDA, XCDA, XDA E-3-10 14 HZY3-90082-003 CAP, BOLT, 10MM 1 1 1 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002549 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002617 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002618~	E-3-10	13	HZZ5-90081-M00	BOLT, SEALING, 22MM			1	
E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1002917~ E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1007540~ LRA, UCRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1008196~ LDA, UCDA, UDA, XCDA, XDA E-3-10 14 HZY3-90082-003 CAP, BOLT, 10MM 1 1 1 1 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002549 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002617 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002618~	E-3-10	13	HZZ5-90081-M00	BOLT, SEALING, 22MM			1	
E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1007540~ LRA, UCRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1008196~ LDA, UCDA, UDA, XCDA, XDA E-3-10 14 HZY3-90082-003 CAP, BOLT, 10MM 1 1 1 1 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002549 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002617 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002618~	E-3-10	13	HZZ5-90081-M01	BOLT, SEALING, 22MM	1			1002678~
E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 LRA, UCRA, URA, XCRA, XRA E-3-10 13 HZZ5-90081-M01 BOLT, SEALING, 22MM 1 1 1008196~ LDA, UCDA, UDA, XCDA, XDA E-3-10 14 HZY3-90082-003 CAP, BOLT, 10MM 1 1 1 1 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002549 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1002617 E-3-10 15 HZZ0-90151-M00 BOLT, FLANGE, 8X25 2 ~1007152 E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZ0-90151-M01 BOLT, FLANGE, 8X25 2 1002618~	E-3-10	13	HZZ5-90081-M01	BOLT, SEALING, 22MM		1		1002917~
E-3-10	E-3-10	13	HZZ5-90081-M01	BOLT, SEALING, 22MM			1	
E-3-10 15 HZZO-90151-M00 BOLT, FLANGE, 8X25 2 ~1002549 E-3-10 15 HZZO-90151-M00 BOLT, FLANGE, 8X25 2 ~1002617 E-3-10 15 HZZO-90151-M00 BOLT, FLANGE, 8X25 2 ~1007152 E-3-10 15 HZZO-90151-M01 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZO-90151-M01 BOLT, FLANGE, 8X25 2 1002618~	E-3-10	13	HZZ5-90081-M01	BOLT, SEALING, 22MM			1	
E-3-10 15 HZZO-90151-M00 BOLT, FLANGE, 8X25 2 ~1002617 E-3-10 15 HZZO-90151-M00 BOLT, FLANGE, 8X25 2 ~1007152 E-3-10 15 HZZO-90151-M01 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZO-90151-M01 BOLT, FLANGE, 8X25 2 1002618~	E-3-10	14	HZY3-90082-003	CAP, BOLT, 10MM	1	1	1	
E-3-10 15 HZZO-90151-M00 BOLT, FLANGE, 8X25 2 ~1007152 E-3-10 15 HZZO-90151-M01 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZO-90151-M01 BOLT, FLANGE, 8X25 2 1002618~	E-3-10	15	HZZ0-90151-M00	BOLT, FLANGE, 8X25	2			~1002549
E-3-10 15 HZZO-90151-M01 BOLT, FLANGE, 8X25 2 1002550~ E-3-10 15 HZZO-90151-M01 BOLT, FLANGE, 8X25 2 1002618~	E-3-10	15	HZZ0-90151-M00	BOLT, FLANGE, 8X25		2		~1002617
E-3-10 15 HZZO-90151-M01 BOLT, FLANGE, 8X25 2 1002618~	E-3-10	15	HZZ0-90151-M00	BOLT, FLANGE, 8X25			2	~1007152
	E-3-10	15	HZZ0-90151-M01	BOLT, FLANGE, 8X25	2			1002550~
E-3-10 15 HZZO-90151-M01 BOLT, FLANGE, 8X25 2 1007153~	E-3-10	15	HZZ0-90151-M01	BOLT, FLANGE, 8X25		2		1002618~
	E-3-10	15	HZZ0-90151-M01	BOLT, FLANGE, 8X25			2	1007153~
E-3-10 16 HZVL-90204-010 NUT, FLANGE CAP, 10MM 2 2 2 2	E-3-10	16	HZVL-90204-010	NUT, FLANGE CAP, 10MM	2	2	2	
E-3-10 17 HMAL-91302-601 0-RING, 18.1X3.6 1 1 1	E-3-10	17	HMAL-91302-601	0-RING, 18.1X3.6	1	1	1	
E-3-10 18 HPF4-91324-004 0-RING, 28.3X2.4 (NOK) 1 1 1	E-3-10	18	HPF4-91324-004	0-RING, 28. 3X2. 4 (NOK)	1	1	1	
E-3-10 19 HCO-94301-08140 DOWEL PIN, 8X14 2 2 2	E-3-10	19	HCO-94301-08140	DOWEL PIN, 8X14	2	2	2	

E-4 EXHAUST MANIFOLD/THERMOSTAT




Ref. No.	Part No.					
		Description	BFT200D	BFT225D	BFT250D	Remarks
E-4 1	HZV5-12155-000	METAL, ANODE	4			~1007135
E-4 1	HZV5-12155-000	METAL, ANODE		4		~1005671
E-4 1	HZV5-12155-000	METAL, ANODE			4	~1020694
E-4 1	HZV5-12155-010	METAL, ANODE	4			1007136~
E-4 1	HZV5-12155-010	METAL, ANODE		4		1005672~
E-4 1	HZV5-12155-010	METAL, ANODE			4	1020695~
E-4 2	HZVL-18110-000ZA	MANIFOLD COMP., R. EX.	1	1	1	*NH8* DARK GRAY
E-4 3	HZY3-18115-003	GASKET, R. EX. MANIFOLD	1	1	1	
E-4 4	HZVL-18120-000ZA	MANIFOLD COMP., L. EX.	1	1	1	*NH8* DARK GRAY
E-4 5	HZY3-18125-003	GASKET, L. EX. MANIFOLD	1	1	1	
E-4 6	HZVL-19255-010	TUBE, R. WATER RETURN		1		~1003857
E-4 6	HZVL-19255-010	TUBE, R. WATER RETURN			1	~1011828
E-4 6	HZVL-19255-020	TUBE, R. WATER RETURN	1			
E-4 6	HZVL-19255-020	TUBE, R. WATER RETURN		1		1003858~
E-4 6	HZVL-19255-020	TUBE, R. WATER RETURN			1	1011829~
E-4 7	HZY3-19256-010	TUBE, WATER RELIEF	2	2	2	
E-4 8	HZY3-19257-010	TUBE, WATER	2	2	2	
E-4 9	HZY3-19261-000	TUBE, L. WATER RETURN	1	1	1	
E-4 10	HZX2-19300-003	THERMOSTAT ASSY.	2	2	2	
E-4 11	HZX2-19303-003	RUBBER, RING	2	2	2	
E-4 12	P HZVL-19313-010ZA	SPACER, THERMOSTAT COVER	1	1	1	*NH8* DARK GRAY
E-4 13	HZVL-19315-010ZA	COVER, THERMOSTAT	2	2	2	*NH8* DARK GRAY
E-4 14	HZY3-35673-003	SENSOR ASSY., WATER	2	2	2	TEMPERATURE
E-4 15	HZZ5-90019-M01	BOLT, FLANGE, 6X35	1	1	1	
E-4 16	HZY9-90027-M01	BOLT, FLANGE, 8X60	8	8	8	
E-4 17	7 HZVL-90034-010	BOLT, FLANGE, 6X60	5	5	5	
E-4 18	HZZ5-90055-M01	BOLT, FLANGE, 8X40	8	8	8	
E-4 19	HZY3-90601-030	CLAMP, TUBE (D10.5)	2	2	2	
E-4 20	HZY3-90603-020	CLAMP, TUBE (D29)	4	4	4	


E-4 EXHAUST MANIFOLD/THERMOSTAT




					Q'ty		
Ref. No	•	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-4	21	HZY3-90604-020	CLAMP, TUBE (D21)	2	2	2	
E-4	22	HZY3-91301-003	0-RING, 66.4X3.1	2	2	2	
E-4	23	HPNA-91307-003	0-RING, 9.5X1.9	2	2	2	
E-4	24	HSD4-91356-952	0-RING, 31.5X2.4(ARAI)	1	1	1	
E-4	25	HCO-93500-06018-4J	SCREW, PAN, 6X18	4			#~1001006
E-4	25	HZX2-90004-000	BOLT, FLANGE, 6X18	4			#1001007~
E-4	25	HCO-93500-06018-4J	SCREW, PAN, 6X18		4		#~1000931
E-4	25	HZX2-90004-000	BOLT, FLANGE, 6X18		4		#1000932~
E-4	25	HZX2-90004-000	BOLT, FLANGE, 6X18			4	LDA, UCDA, UDA, XCDA, XDA
E-4	25	HCO-93500-06018-4J	SCREW, PAN, 6X18			4	LRA, UCRA, URA, XCRA, XRA #~1002438
E-4	25	HZX2-90004-000	BOLT, FLANGE, 6X18			4	LRA, UCRA, URA, XCRA, XRA #1002439∼
E-4	26	HZY3-90601-030	CLAMP, TUBE (D10.5)	2			~1004416
E-4	26	HZVL-90601-000	CLAMP, TUBE (D12. 5)	2			1004417~
E-4	26	HZY3-90601-030	CLAMP, TUBE (D10.5)		2		~1003857
E-4	26	HZVL-90601-000	CLAMP, TUBE (D12.5)		2		1003858~
E-4	26	HZY3-90601-030	CLAMP, TUBE (D10.5)			2	~1011758
E-4	26	HZVL-90601-000	CLAMP, TUBE (D12.5)			2	1011759~




Ref. No.	5					
	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-5 1	HZVL-15100-000ZA	PUMP ASSY., OIL *NH8*	1			~1002630
E-5 1	HZVL-15100-000ZA	PUMP ASSY., OIL *NH8*		1		~1002916
E-5 1	HZVL-15100-000ZA	PUMP ASSY., OIL *NH8*			1	~1007614
E-5 1	HZVL-15100-010ZA	PUMP ASSY., OIL *NH8*	1			1002631~
E-5 1	HZVL-15100-010ZA	PUMP ASSY., OIL *NH8*		1		1002917~
E-5 1	HZVL-15100-010ZA	PUMP ASSY., OIL *NH8*			1	1007615~
E-5 2	HZY3-15112-013	PACKING, OIL PUMP BODY	1	1	1	
E-5 3	HZY3-15113-000	RUBBER, OIL PUMP	1	1	1	
E-5 4	HZY3-15121-000	COVER, OIL PUMP	1	1	1	
E-5 5	HZY3-15131-405	ROTOR, OIL PUMP INNER	1	1	1	
E-5 6	HZY3-15132-405	ROTOR, OIL PUMP OUTER	1	1	1	
E-5 7	HZY3-15220-020	STRAINER COMP., OIL	1	1	1	
E-5 8	HPE0-15231-000	VALVE, RELIEF	1	1	1	
E-5 9	HPG6-15232-000	SPRING, RELIEF VALVE	1	1	1	
E-5 10) HPC6-15233-000	BOLT, SEALING, 18MM	1	1	1	
E-5 1	1 HZX2-31110-000ZA	FLYWHEEL COMP.	1	1	1	*TBLACK* BLACK
E-5 1:	2 HZY3-31116-000	BOSS, FLYWHEEL	1	1	1	
E-5 1	3 HZX2-90001-000	BOLT, 12MM	8	8	8	
E-5 14	4 HZW5-90002-013	BOLT, SPECIAL, 8MM	8	8	8	
E-5 1	5 HZZ5-90081-M00	BOLT, SEALING, 22MM	2			~1002630
E-5 1	5 HZZ5-90081-M00	BOLT, SEALING, 22MM		2		~1002916
E-5 1	5 HZZ5-90081-M00	BOLT, SEALING, 22MM			2	~1007614
E-5 1	5 HZZ5-90081-M01	BOLT, SEALING, 22MM	2			1002631~1005855
E-5 1	5 HZZ5-90081-M01	BOLT, SEALING, 22MM		2		1002917~1004879
E-5 1	5 HZZ5-90081-M01	BOLT, SEALING, 22MM			2	1007615~1015842
E-5 1	5 HPH7-90081-000	BOLT, SEALING, 22MM	2			1005856~
E-5 1	5 HPH7-90081-000	BOLT, SEALING, 22MM		2		1004880~
E-5 1	5 HPH7-90081-000	BOLT, SEALING, 22MM			2	1015843~
E-5 10	6 HPW5-90701-000	DOWEL PIN, 14X15	1	1	1	




Ref. No. Part No. Description 87 000 <t< th=""><th></th></t<>	
E-5 18 HP01-91212-003 01L SEAL, 31X46X7 (NOK) 1 1 1 1 E-5 19 HPC6-91324-000 0-RING, 20. 6X2. 6 1 1 1 1 E-5 20 HC0-93600-06016-0A SCREW, FLAT, 6X16 8 8 8 E-5 21 HC0-94302-10160 PIN B, DOWEL, 10X16 1 1 1 1	
E-5 19 HPC6-91324-000	
E-5 20 HCO-93600-06016-0A SCREW, FLAT, 6X16 8 8 8 E-5 21 HCO-94302-10160 PIN B, DOWEL, 10X16 1 1 1	
E-5 21 HCO-94302-10160 PIN B, DOWEL, 10X16 1 1 1	
E-5 22 HCO-95701-06014-09 BOLT, FLANGE, 6X14 2 2 2	
E-5 23 HCO-95701-06018-09 BOLT, FLANGE, 6X18 2 2 2	
E-5 24 HCO-95701-08030-09 BOLT, FLANGE, 8X30 4 4 4	
E-5 25 HCO-96220-50080 ROLLER, 5X8 2 2 2	





					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-6	1	HZVL-11310-000ZA	PAN ASSY., OIL	1	1	1	*TGRAY* GRAY
E-6	2	HZVL-11381-003	PACKING, OIL PAN	1	1	1	
E-6	3	HZY3-18330-020	PIPE COMP., R. EX.	1	1	1	
E-6	4	HZVL-18333-003	GASKET, EX. PIPE	2	2	2	
E-6	5	HZY3-18340-020	PIPE COMP., L. EX.	1	1	1	
E-6	6	HZY3-19252-000	GROMMET, WATER TUBE	1	1	1	
E-6	7	HZY3-19254-000	PLATE, WATER TUBE	1	1	1	
E-6	8	HZVL-90070-000	BOLT-WASHER, 8X35 (SUS)	21			~1002742 LRA, UCRA, URA, XCRA, XRA
E-6	8	HZVL-90070-000	BOLT-WASHER, 8X35 (SUS)		21		~1002792
E-6	8	HZVL-90070-000	BOLT-WASHER, 8X35 (SUS)			21	~1007891
E-6	8	HZVL-90070-010	BOLT-WASHER, 8X35 (SUS)	21			1002743~
E-6	8	HZVL-90070-010	BOLT-WASHER, 8X35 (SUS)		21		1002793~
E-6	8	HZVL-90070-010	BOLT-WASHER, 8X35 (SUS)			21	1007892~
E-6	9	HZVL-90071-000	BOLT-WASHER, 8X28 (SUS)	6	6	6	
E-6	10	HZV4-90127-000	BOLT, HEX., 6X16	1	1	1	
E-6	11	HZV5-90131-000	BOLT, DRAIN PLUG	1	1	1	
E-6	12	HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	1	1	1	
				*			







					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-6-10	1	HZY3-12155-000	METAL, ANODE	2			~1007135
E-6-10	1	HZY3-12155-000	METAL, ANODE		2		~1005671
E-6-10	1	HZY3-12155-000	METAL, ANODE			2	~1020694
E-6-10	1	HZY3-12155-010	METAL, ANODE	2			1007136~
E-6-10	1	HZY3-12155-010	METAL, ANODE		2		1005672~
E-6-10	1	HZY3-12155-010	METAL, ANODE			2	1020695~
E-6-10	2	HGHB-16163-610	CLIP, TUBE	1	1	1	
E-6-10	3	HZY3-18141-A00ZA	GUIDE, R. EX.	1	1	1	*TGRAY* GRAY
E-6-10	4	HZY3-18148-003	SEAL, EXHAUST GUIDE	2	2	2	
E-6-10	5	HZY3-18149-A01	SEAL B, EX. GUIDE	2	2	2	
E-6-10	6	HZY3-18151-A00ZA	GUIDE, L. EX.	1	1	1	*TGRAY* GRAY
E-6-10	7	HZVL-19257-000	TUBE, WATER	1	1	1	
E-6-10	8	HZY3-19277-000ZA	COVER, FLUSH VALVE	1	1	1	*TGRAY* DARK GRAY
E-6-10	9	HZY3-19278-000	CASE, FLUSH VALVE	1	1	1	
E-6-10	10	HZW9-19279-010	SPRING, FLUSH VALVE	1	1	1	
E-6-10	11	HZW5-19291-000	VALVE, RELIEF	2	2	2	
E-6-10	12	HZW9-19291-000	VALVE, FLASH	1	1	1	
E-6-10	13	HZW5-19292-000	SPRING, RELIEF VALVE	2	2	2	
E-6-10	14	HZY3-19294-000ZB	SPACER, R. RELIEF VALVE	1	1	1	*TGRAY* GRAY
E-6-10	15	HZY3-19295-000	COVER, R. RELIEF VALVE	1	1	1	
E-6-10	16	HZY3-19296-000	PACKING, RELIEF VALVE COVER	2	2	2	
E-6-10	17	HZW5-19297-000	PACKING, RELIEF VALVE	2	2	2	
E-6-10	18	HZW9-19297-010	PACKING, FLASH VALVE	1	1	1	
E-6-10	19	HZY3-19297-000	COVER, L. RELIEF VALVE	1	1	1	
E-6-10	20	HZY3-19298-000ZB	SPACER, L. RELIEF VALVE	1	1	1	*TGRAY* GRAY
E-6-10	21	HZVL-19361-010	COVER, R. WATER JACKET	1	1	1	
E-6-10	22	HZVL-19362-000	PACKING, WATER JACKET COVER	2	2	2	
E-6-10	23	HZVL-19366-010	COVER, L. WATER JACKET	1	1	1	
E-6-10	24	HZVL-23170-020ZA	CASE COMP., MOUNT	1	1	1	*NH8* GRAY






Ref. No.				Q'ty		
Ret. No.	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-6-10 25	HZVL-23172-003	GASKET, MOUNT CASE	1	1	1	
E-6-10 26	H371-90009-015	BOLT, FLANGE, 10X120 (SATO)	1	1	1	
E-6-10 27	HZY3-90010-000	BOLT, HEX., 12X120	2	2	2	
E-6-10 28	HZY3-90011-000	BOLT, HEX., 12X65	1	1	1	
E-6-10 29	HZY3-90013-000	BOLT, HEX., 10X85	1	1	1	
E-6-10 30	HZY3-90015-000	BOLT, HEX., 10X60	2	2	2	
E-6-10 31	HZZ5-90030-M01	BOLT, FLANGE, 6X22	2	2	2	
E-6-10 32	HZZ5-90032-M00	BOLT, FLANGE, 6X32	4			~1002549
E-6-10 32	HZZ5-90032-M00	BOLT, FLANGE, 6X32		4		~1002617
E-6-10 32	HZZ5-90032-M00	BOLT, FLANGE, 6X32			4	~1007152
E-6-10 32	HZZ5-90032-M01	BOLT, FLANGE, 6X32	4			1002550~
E-6-10 32	HZZ5-90032-M01	BOLT, FLANGE, 6X32		4		1002618~
E-6-10 32	HZZ5-90032-M01	BOLT, FLANGE, 6X32			4	1007153~
E-6-10 33	HZVL-90045-000	BOLT, STUD, 10X45	2			~1002549
E-6-10 33	HZVL-90045-000	BOLT, STUD, 10X45		2		~1002617
E-6-10 33	HZVL-90045-000	BOLT, STUD, 10X45			2	~1007152
E-6-10 33	HZVL-90045-010	BOLT, STUD, 10X45	2			1002550~
E-6-10 33	HZVL-90045-010	BOLT, STUD, 10X45		2		1002618~
E-6-10 33	HZVL-90045-010	BOLT, STUD, 10X45			2	1007153~
E-6-10 34	HZVL-90046-000	BOLT, FLANGE, 8X120	8	8	8	
E-6-10 35	HZVL-90049-000	BOLT, FLANGE, 8X30	4			~1002549
E-6-10 35	HZVL-90049-000	BOLT, FLANGE, 8X30		4		~1002617
E-6-10 35	HZVL-90049-000	BOLT, FLANGE, 8X30			4	~1007152
E-6-10 35	HZVL-90049-010	BOLT, FLANGE, 8X30	4			1002550~
E-6-10 35	HZVL-90049-010	BOLT, FLANGE, 8X30		4		1002618~
E-6-10 35	HZVL-90049-010	BOLT, FLANGE, 8X30			4	1007153~
E-6-10 36	HZY3-90059-000	BOLT-WASHER, 6X29	1	1	1	
E-6-10 37	HHW1-90207-671	BOLT, FLANGE, 6X40	2	2	2	
E-6-10 38	HZV5-90559-000	WASHER, PLAIN, 12MM	3	3	3	






					Q' ty		_
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-6-10	39	HZV5-90563-000	WASHER, PLAIN, 10MM	3	3	3	
E-6-10	40	HZY3-90601-030	CLAMP, TUBE (D10.5)	1	1	1	
E-6-10	41	HZV4-90605-000	CLIP, TUBE (B12. 5)	1	1	1	
E-6-10	42	HPW5-90701-000	DOWEL PIN, 14X15	1	1	1	
E-6-10	43	HZY3-91001-003	BEARING, NEEDLE, 20X28X13	1	1	1	(SOLID)
E-6-10	44	HZW5-91202-003	SEAL, WATER, 22X35X7	2	2	2	
E-6-10	45	H800-91303-000	O-RING, 16MM	1	1	1	
E-6-10	46	HZY3-91304-000	O-RING, 49.4X3.1	2	2	2	
E-6-10	47	HZY3-91305-003	O-RING, 33.5X2	2	2	2	
E-6-10	48	HZY3-91306-003	O-RING, 23.5X2	2	2	2	
E-6-10	49	HZY3-91405-000	TUBE, FLUSH VALVE	1	1	1	
E-6-10	50	HCO-93500-05016-4J	SCREW, PAN, 5X16	2	2	2	
E-6-10	51	HCO-94302-10160	PIN B, DOWEL, 10X16	1	1	1	
E-6-10	52	HCO-95701-10070-09	BOLT, FLANGE, 10X70	2	2	2	
E-6-10	53	HCO-95701-12120-09	BOLT, FLANGE, 12X120	2	2	2	
E-6-10	55	HZV4-90605-000	CLIP, TUBE (B12. 5)	1			~1002815
E-6-10	55	HZV4-90605-000	CLIP, TUBE (B12. 5)		1		~1002916
E-6-10	55	HZV4-90605-000	CLIP, TUBE (B12. 5)			1	~1008195
E-6-10	55	HZY6-90651-000	CLIP B1, TUBE	1			1002816~
E-6-10	55	HZY6-90651-000	CLIP B1, TUBE		1		1002917~
E-6-10	55	HZY6-90651-000	CLIP B1, TUBE			1	1008196~
-							
-							

E-7 CRANKSHAFT/PISTON




Ref. No.						Q' ty		
E-7 1 REX2-1301-000 RING SET. PISTON(0.25) 6 6 6 6 E-7 2 NZX2-1310-000 PISTON 6 6 6 6 E-7 2 NZX2-1310-000 PISTON 6 6 6 6 E-7 3 HPEA-1311-000 PISTON 6 6 6 6 6 E-7 3 HPEA-1311-000 PIN. PISTON 6 6 6 6 6 E-7 4 HP5A-13115-000 GLIP. PISTON 12 12 12 12 E-7 5 HPRA-13210-000 ROCOMP., CONNECTING ROD 12 12 12 12 E-7 6 NRKG-13210-000 ROD COMP., CONNECTING ROD 12 12 12 12 E-7 7 HRYE-13212-001 BERRING A. CONNECTING ROD 12 12 12 12 (GROWN (TAING)) E-7 7 HRYE-13212-010 BERRING B. CONNECTING ROD (BLACK) 12 12 12 (GROWN (TAING)) E-7 7 HRYE-13213-01 BERRING B. CONNECTING ROD (BLACK) 12 12 12 (GROWN (TAING)) E-7 7 HRYE-13213-01 BERRING B. CONNECTING ROD (BROWN) 12 12 12 12 (GROWN (TAING)) E-7 7 HRYE-13213-01 BERRING B. CONNECTING ROD (GREEN) 12 12 12 (GROWN (TAING)) E-7 7 HRYE-13215-01 BERRING B. CONNECTING ROD (PINK) 12 12 12 (CREEN) (TAING) E-7 8 HXZZ-13310-000 GRANSHAFT COMP. 11 1 1 E-7 9 HZXZ-1332-003 BERRING B. MAIN UPPER (BROWN) 1 1 1 1 1 E-7 9 HZXZ-1332-003 BERRING B. MAIN UPPER (BROWN) 4 4 4 4 (TAING) E-7 9 HZXZ-1332-003 BERRING B. MAIN UPPER (BREDN) 4 4 4 4 (TAING) E-7 9 HZZZ-1332-003 BERRING B. MAIN UPPER (BREDN) 4 4 4 4 (TAING) E-7 9 HZZZ-1332-003 BERRING B. MAIN UPPER (BREDN) 4 4 4 4 (TAING) E-7 9 HZZZ-1332-003 BERRING B. MAIN UPPER (BREDN) 4 4 4 4 (TAING) E-7 10 HZY3-1332-003 BERRING B. MAIN UPPER (BREDN) 4 4 4 4 (TAING) E-7 11 HZZZ-13340-003 BERRING F. MAIN UPPER (BREDN) 4 4 4 4 (TAING) E-7 11 HZZZ-13340-003 BERRING B. MAIN UPPER (BREDN) 4 4 4 4 (TAING) E-7 11 HZZZ-13340-003 BERRING B. MAIN UPPER (BREDN) 4 4 4 4 (TAING) E-7 11 HZZZ-13340-003 BERRING B. MAIN LONER (BREDN) 4 4 4 4 (TAING) E-7 11 HZZZ-13340-003 BERRING B. MAIN LONER (BREDN) 4 4 4 4 (TAING) E-7 11 HZZZ-13340-003 BERRING B. MAIN LONER (BREDN) 4 4 4 4 (TAING) E-7 11 HZZZ-13340-003 BERRING B. MAIN LONER (BREDN) 4 4 4 4 (TAING) E-7 11 HZZZ-13340-003 BERRING B. MAIN LONER (BREDN) 4 4 4 4 (TAING)	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-7 2 HZX2-13101-000 PISTON 6 6 6 6 E-7 2 HZX2-13102-000 PISTON 6 6 6 6 E-7 3 HPEA-13111-000 PIN, PISTON 6 6 6 6 E-7 4 HP5A-13115-000 CLIP, PISTON PIN 12 12 12 E-7 5 HP8A-13115-000 CLIP, PISTON PIN 12 12 12 12 E-7 6 HPRA-13210-000 ROD COMP., CONNECTING ROD 12 12 12 12 E-7 7 HRYE-13210-001 BEARING A, CONNECTING ROD 12 12 12 12 E-7 7 HRYE-13212-A01 BEARING B, CONNECTING ROD (BROWN) 12 12 12 12 (BROWN) (TAIND) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (GREEN) 12 12 12 (GREEN) (TAIND) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (GREEN) 12 12 12 (CREEN) (TAIND) E-7 7 HRYE-13215-A01 BEARING C, CONNECTING ROD (GREEN) 12 12 12 (CREEN) (TAIND) E-7 7 HRYE-13215-A01 BEARING C, CONNECTING ROD (FINC) 12 12 12 (CREEN) (TAIND) E-7 8 HZX2-13310-000 GRANKSHAFT COMP. 11 1 1 E-7 9 HZX2-13321-003 BEARING A, MAIN UPPER (BROWN) 4 4 4 4 (TAIND) E-7 9 HZX2-13322-003 BEARING G, MAIN UPPER (GREEN) 4 4 4 (TAIND) E-7 9 HZX2-13323-003 BEARING G, MAIN UPPER (GREEN) 4 4 4 (TAIND) E-7 9 HZX2-13324-003 BEARING G, MAIN UPPER (FINC) 4 4 4 4 (TAIND) E-7 9 HZX2-13324-003 BEARING G, MAIN UPPER (FINC) 4 4 4 4 (TAIND) E-7 10 HZX2-13324-003 BEARING G, MAIN UPPER (FINC) 4 4 4 4 (TAIND) E-7 11 HZX2-13343-003 BEARING G, MAIN UPPER (FINC) 4 4 4 4 (TAIND) E-7 11 HZX2-13343-003 BEARING G, MAIN UPPER (FINC) 4 4 4 4 (TAIND) E-7 11 HZX2-13343-003 BEARING G, MAIN UPPER (FINC) 4 4 4 4 (TAIND) E-7 11 HZX2-13343-003 BEARING G, MAIN UPPER (FINC) 4 4 4 4 (TAIND) E-7 11 HZX2-13343-003 BEARING G, MAIN UPPER (FINC) 4 4 4 4 (TAIND) E-7 11 HZX2-13344-003 BEARING G, MAIN LOWER (FINK) 4 4 4 4 (TAIND) E-7 11 HZX2-13344-003 BEARING G, MAIN LOWER (FINK) 4 4 4 4 (TAIND) E-7 11 HZX2-13345-003 BEARING G, MAIN LOWER (FINK) 4 4 4 4 (TAIND) E-7 11 HZX2-13346-003 BEARING G, MAIN LOWER (FINK) 4 4 4 4 (TAIND) E-7 11 HZX2-13346-003 BEARING G, MAIN LOWER (FINK) 4 4 4 4 (TAIND)	E-7	1	HZX2-13010-000	RING SET, PISTON(STD.)	6	6	6	
E-7 2 HZX2-13102-000 PISTON (0.25) 6 6 6 6 E-7 3 MPEA-13111-000 PIN, PISTON 6 6 6 6 E-7 4 HPSA-13115-000 CLIP, PISTON PIN 12 12 12 12 E-7 5 MPSA-13204-A01 BOLT, CONNECTING ROD 12 12 12 12 E-7 6 HRKG-13210-000 ROD COWP., CONNECTING ROD 12 12 12 12 E-7 7 HRYE-13211-A01 BEARING A, CONNECTING ROD 12 12 12 12 (GLACK) (TAIHO) E-7 7 HRYE-13212-A01 BEARING B, CONNECTING ROD (GREEN) 12 12 12 (GREEN) (TAIHO) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (GREEN) 12 12 12 (GREEN) (TAIHO) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (FINO) 12 12 12 12 (GREEN) (TAIHO) E-7 7 HRYE-13215-A01 BEARING C, CONNECTING ROD (FINO) 12 12 12 12 (GREEN) (TAIHO) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (FINO) 12 12 12 12 (FINO) (TAIHO) E-7 8 HZX2-13310-000 GRAMKSHAFT COMP. 1 1 1 1 E-7 9 HZX2-13321-003 BEARING A, MAIN UPPER (BEOMN) 4 4 4 4 (TAIHO) E-7 9 HZX2-13323-003 BEARING B, MAIN UPPER (BEOMN) 4 4 4 4 (TAIHO) E-7 9 HZX2-13323-003 BEARING B, MAIN UPPER (FINO) 4 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING B, MAIN UPPER (FINO) 4 4 4 4 (TAIHO) E-7 10 HZX2-13326-003 BEARING B, MAIN UPPER (FINO) 4 4 4 4 (TAIHO) E-7 10 HZX2-13326-003 BEARING B, MAIN UPPER (BEOMN) 4 4 4 4 (TAIHO) E-7 10 HZX2-13326-003 BEARING B, MAIN UPPER (BEOMN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING B, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING B, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING B, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING B, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING B, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING B, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING B, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING B, MAIN LOWER (BEEN) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING B, MAIN LOWER (BEEN) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING B, MAIN LOWER (BEEN) 4 4 4 (TAIHO)	E-7	1	HZX2-13011-000	RING SET, PISTON(0.25)	6	6	6	
E-7 3 HPEA-1311-000 PIN, PISTON 6 6 6 6 E-7 4 HPBA-1311-000 CLIP, PISTON PIN 12 12 12 E-7 5 HPBA-13204-A01 BOLT, CONNECTING ROD 12 12 12 12 E-7 6 HPRA-13210-000 ROD COMP., CONNECTING ROD 12 12 12 12 E-7 6 HPRYE-13210-A01 BEARING A, CONNECTING ROD (BLACK) 12 12 12 12 (BLACK) (TAIHO) E-7 7 HRYE-13212-A01 BEARING B, CONNECTING ROD (BROWN) 12 12 12 12 (GREEN) (TAIHO) E-7 7 HRYE-13213-A01 BEARING B, CONNECTING ROD (GREEN) 12 12 12 (CREEN) (TAIHO) E-7 7 HRYE-13214-A01 BEARING B, CONNECTING ROD (GREEN) 12 12 12 (CREEN) (TAIHO) E-7 7 HRYE-13215-A01 BEARING B, CONNECTING ROD (PINK) 12 12 12 12 (CPINK) (TAIHO) E-7 7 HRYE-13215-A01 BEARING B, CONNECTING ROD (PINK) 12 12 12 12 (CPINK) (TAIHO) E-7 8 HZZ2-13321-000 GRAINSHAFT COMP. 1 1 1 1 E-7 9 HZZ2-13321-003 BEARING B, MAIN UPPER (BROWN) 4 4 4 4 (TAIHO) E-7 9 HZZ2-13323-003 BEARING B, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZZ2-13323-003 BEARING B, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZZ2-13325-003 BEARING B, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZZ2-13325-003 BEARING B, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZZ2-13325-003 BEARING B, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 10 HZZ2-13325-003 BEARING F, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 11 HZZ2-13341-003 BEARING F, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 11 HZZ2-13340-003 BEARING B, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZZ2-13340-003 BEARING B, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZZ2-13340-003 BEARING B, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZZ2-13340-003 BEARING B, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZZ2-13340-003 BEARING B, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZZ2-13340-003 BEARING B, MAIN LOWER (FLLOW) 4 4 4 (TAIHO) E-7 11 HZZ2-13340-003 BEARING B, MAIN LOWER (FLLOW) 4 4 4 (TAIHO) E-7 11 HZZ2-13340-003 BEARING B, MAIN LOWER (FLLOW) 4 4 4 (TAIHO) E-7 11 HZZ2-13340-003 BEARING B, MAIN LOWER (FLLOW) 4 4 4 (TAIHO)	E-7	2	HZX2-13101-000	PISTON	6	6	6	
E-7 4 HP5A-13115-000 CLIP, PISTON PIN 12 12 12 E-7 5 HP6A-13204-A01 BOLT, CONNECTING ROD 12 12 12 E-7 6 HRKG-13210-000 ROD COWP., CONNECTING COMPANDED CONNECTING COMPANDED CONNECTING COMPANDED CONNECTING COMPANDED CONNECTING COMPANDED COMPANDED CONNECTING ROD (BLACK) 12 12 12 (BLACK) (TAIHO) E-7 7 HRYE-13212-A01 BEARING B, CONNECTING ROD (BROWN) 12 12 12 12 (GREEN) (TAIHO) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (GREEN) 12 12 12 (GREEN) (TAIHO) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (GREEN) 12 12 12 (CREEN) (TAIHO) E-7 7 HRYE-13215-A01 BEARING E, CONNECTING ROD (YELLOW) 12 12 12 (CREEN) (TAIHO) E-7 8 HZX2-13310-000 CRAINSHAFT COMP. 1 1 1 E-7 9 HZX2-13321-003 BEARING E, MAIN UPPER (BLOCK) 4 4 4 (TAIHO) E-7 9 HZX2-13322-003 BEARING B, MAIN UPPER (GROWN) 4 4 4 (TAIHO) E-7 9 HZX2-13323-003 BEARING C, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZX2-13323-003 BEARING E, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING E, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZX2-13326-003 BEARING E, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 10 HZX2-13326-003 BEARING E, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13310-003 BEARING F, MAIN UPPER (GROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING E, MAIN LOWER (GROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING E, MAIN LOWER (GROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING E, MAIN LOWER (GROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING E, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING E, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING E, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING E, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING E, MAIN LOWER (GREEN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13340-003 BEARING E, MAIN LOWER (GREEN) 4 4 4 4 (TAIHO)	E-7	2	HZX2-13102-000	PISTON (0. 25)	6	6	6	
E-7 5 HP8A-13204-A01 BOLT, CONNECTING ROD E-7 6 HRKG-13210-000 ROD COMP., CONNECTING E-7 7 HRYE-13211-A01 BEARING A, CONNECTING ROD (BLACK) E-7 7 HRYE-13212-A01 BEARING B, CONNECTING ROD (BLACK) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (BROWN) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (GREEN) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (GREEN) E-7 7 HRYE-13215-A01 BEARING D, CONNECTING ROD (YELLOW) E-7 7 HRYE-13215-A01 BEARING E, CONNECTING ROD (YELLOW) E-7 8 HZX2-13310-000 GRAWKSHAFT COMP. E-7 9 HZX2-13321-003 BEARING B, MAIN UPPER (BLACK) E-7 9 HZX2-13322-003 BEARING B, MAIN UPPER (GREEN) E-7 9 HZX2-13322-003 BEARING C, MAIN UPPER (GREEN) E-7 9 HZX2-13322-003 BEARING C, MAIN UPPER (YELLOW) E-7 9 HZX2-13322-003 BEARING C, MAIN UPPER (YELLOW) E-7 9 HZX2-13326-003 BEARING C, MAIN UPPER (YELLOW) E-7 10 HZX2-13326-003 BEARING F, MAIN UPPER (RED) E-7 11 HZX2-13341-003 BEARING F, MAIN UPPER (RED) E-7 11 HZX2-13341-003 BEARING F, MAIN UPPER (GROWN) E-7 11 HZX2-13341-003 BEARING R, MAIN LOWER (GROWN) E-7 11 HZX2-13342-003 BEARING R, MAIN LOWER (GROWN) E-7 11 HZX2-13343-003 BEARING R, MAIN LOWER (GROW	E-7	3	HPEA-13111-000	PIN, PISTON	6	6	6	
E-7 6 HRKG-13210-000 ROD COMP., CONNECTING 6 6 6 6 E-7 7 HRYE-13211-A01 BEARING A, CONNECTING ROD (BLACK) 12 12 12 (BLACK) (TAIHO) E-7 7 HRYE-13212-A01 BEARING BEAR	E-7	4	HP5A-13115-000	CLIP, PISTON PIN	12	12	12	
E-7 7 HRYE-13213-A01 BEARING A. CONNECTING ROD (BLACK) 12 12 12 (BLACK) (TAIHO) E-7 7 HRYE-13213-A01 BEARING B. CONNECTING ROD (BROWN) 12 12 12 12 (BROWN) (TAIHO) E-7 7 HRYE-13213-A01 BEARING C. CONNECTING ROD (GREEN) 12 12 12 (GREEN) (TAIHO) E-7 7 HRYE-13214-A01 BEARING D. CONNECTING ROD (FEEN) 12 12 12 (CYELLOW) (TAIHO) E-7 7 HRYE-13215-A01 BEARING E. CONNECTING ROD (PINK) 12 12 12 (CYELLOW) (TAIHO) E-7 8 HZX2-13316-A01 BEARING E. CONNECTING ROD (PINK) 12 12 12 (CYELLOW) (TAIHO) E-7 9 HZX2-13321-003 BEARING A. MAIN UPPER (BLACK) 4 4 4 (TAIHO) E-7 9 HZX2-13322-003 BEARING B. MAIN UPPER (BROWN) 4 4 4 (TAIHO) E-7 9 HZX2-13323-003 BEARING C. MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING D. MAIN UPPER (FINK) 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING E. MAIN UPPER (PINK) 4 4 4 (TAIHO) E-7 10 HZX2-13326-003 BEARING F. MAIN UPPER (RED) 4 4 4 (TAIHO) E-7 11 HZX2-13341-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13341-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO)	E-7	5	HP8A-13204-A01	BOLT, CONNECTING ROD	12	12	12	
E-7 7 HRYE-13212-A01 BEARING B, CONNECTING ROD (BROWN) E-7 7 HRYE-13213-A01 BEARING C, CONNECTING ROD (GREEN) E-7 7 HRYE-13214-A01 BEARING D, CONNECTING ROD (GREEN) E-7 7 HRYE-13215-A01 BEARING D, CONNECTING ROD (FULLOW) E-7 7 HRYE-13215-A01 BEARING D, CONNECTING ROD (FULLOW) E-7 8 HZX2-13310-000 CRANKSHAFT COMP. E-7 9 HZX2-13321-003 BEARING A, MAIN UPPER (BLACK) E-7 9 HZX2-13322-003 BEARING B, MAIN UPPER (BROWN) E-7 9 HZX2-13322-003 BEARING C, MAIN UPPER (GREEN) E-7 9 HZX2-13324-003 BEARING D, MAIN UPPER (GREEN) E-7 9 HZX2-13325-003 BEARING D, MAIN UPPER (FUNK) E-7 10 HZX3-13331-A06 WASHER, THRUST E-7 11 HZX2-13341-003 BEARING D, MAIN LOWER (BLACK) E-7 11 HZX2-13343-003 BEARING D, MAIN LOWER (BROWN) E-7 11 HZX2-13343-003 BEARING D, MAIN LOWER (BROWN) E-7 11 HZX2-13343-003 BEARING D, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (FUNK) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (FUNK) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (FUNK) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (FUNK) 4 4 4 (TAIHO)	E-7	6	HRKG-13210-000	ROD COMP., CONNECTING	6	6	6	
E-7 7 HRYE-13213-A01 BEARING C. CONNECTING ROD (GREEN) 12 12 12 (GREEN) (TAIHO) E-7 7 HRYE-13214-A01 BEARING D. CONNECTING ROD (YELLOW) 12 12 12 12 (YELLOW) (TAIHO) E-7 7 HRYE-13215-A01 BEARING E. CONNECTING ROD (YELLOW) 12 12 12 12 (YELLOW) (TAIHO) E-7 8 HZX2-13310-000 GRANKSHAFT COMP. 1 1 1 1 E-7 9 HZX2-13321-003 BEARING A. MAIN UPPER (BROWN) 4 4 4 4 (TAIHO) E-7 9 HZX2-13322-003 BEARING B. MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZX2-13324-003 BEARING C. MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING E. MAIN UPPER (PINK) 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING E. MAIN UPPER (PINK) 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING E. MAIN UPPER (PINK) 4 4 4 (TAIHO) E-7 10 HZX3-1331-A06 WASHER. THRUST 2 2 2 2 E-7 11 HZX2-13341-003 BEARING A. MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING B. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING B. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING B. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING B. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (FINKO) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING B. MAIN LOWER (FINKO) 4 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E. MAIN LOWER (FINKO) 4 4 4 4 (TAIHO)	E-7	7	HRYE-13211-A01	BEARING A, CONNECTING ROD (BLACK)	12	12	12	(BLACK) (TAIHO)
E-7 7 HRYE-13214-A01 BEARING D. CONNECTING ROD (YELLOW) 12 12 12 (YELLOW) (TAIHO) E-7 7 HRYE-13215-A01 BEARING E. CONNECTING ROD (PINK) 12 12 12 12 (PINK) (TAIHO) E-7 8 HZX2-13310-000 CRANKSHAFT COMP. 1 1 1 1 E-7 9 HZX2-13321-003 BEARING A. MAIN UPPER (BLACK) 4 4 4 (TAIHO) E-7 9 HZX2-13322-003 BEARING B. MAIN UPPER (BROWN) 4 4 4 (TAIHO) E-7 9 HZX2-13323-003 BEARING C. MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZX2-13324-003 BEARING D. MAIN UPPER (PINK) 4 4 4 (TAIHO) E-7 9 HZX2-13326-003 BEARING E. MAIN UPPER (PINK) 4 4 4 (TAIHO) E-7 9 HZX2-13326-003 BEARING F. MAIN UPPER (RED) 4 4 4 (TAIHO) E-7 10 HZX2-13340-003 BEARING F. MAIN UPPER (RED) 4 4 4 (TAIHO) E-7 11 HZX2-13341-003 BEARING A. MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING B. MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING B. MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING D. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING D. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D. MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D. MAIN LOWER (GREEN) 4 4 4 (TAIHO)	E-7	7	HRYE-13212-A01	BEARING B, CONNECTING ROD (BROWN)	12	12	12	(BROWN) (TAIHO)
E-7 7 HRYE-13215-A01 BEARING E. CONNECTING ROD (PINK) 12 12 12 (PINK) (TAIHO) E-7 8 HZX2-13310-000 CRANKSHAFT COMP. 1 1 1 1 E-7 9 HZX2-13321-003 BEARING A. MAIN UPPER (BLACK) 4 4 4 (TAIHO) E-7 9 HZX2-13322-003 BEARING B. MAIN UPPER (BROWN) 4 4 4 (TAIHO) E-7 9 HZX2-13323-003 BEARING C. MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZX2-13324-003 BEARING D. MAIN UPPER (YELLOW) 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING E. MAIN UPPER (YELLOW) 4 4 4 (TAIHO) E-7 9 HZX2-13326-003 BEARING F. MAIN UPPER (RED) 4 4 4 (TAIHO) E-7 10 HZY3-13331-A06 WASHER. THRUST 2 2 2 E-7 11 HZX2-13341-003 BEARING B. MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING B. MAIN LOWER (BROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C. MAIN LOWER (BROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C. MAIN LOWER (GROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING D. MAIN LOWER (GROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13344-003 BEARING D. MAIN LOWER (FUNK) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D. MAIN LOWER (FUNK) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D. MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E. MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F. MAIN LOWER (PINK) 4 4 4 (TAIHO)	E-7	7	HRYE-13213-A01	BEARING C, CONNECTING ROD(GREEN)	12	12	12	(GREEN) (TAIHO)
E-7 8 HZX2-13310-000 CRANKSHAFT COMP. 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-7	7	HRYE-13214-A01	BEARING D, CONNECTING ROD(YELLOW)	12	12	12	(YELLOW) (TAIHO)
E-7 9 HZX2-13321-003 BEARING A, MAIN UPPER (BLACK) 4 4 4 (TAIHO) E-7 9 HZX2-13322-003 BEARING B, MAIN UPPER (BROWN) 4 4 4 4 (TAIHO) E-7 9 HZX2-13323-003 BEARING C, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZX2-13324-003 BEARING D, MAIN UPPER (YELLOW) 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING E, MAIN UPPER (PINK) 4 4 4 (TAIHO) E-7 9 HZX2-13326-003 BEARING F, MAIN UPPER (RED) 4 4 4 (TAIHO) E-7 10 HZY3-13331-A06 WASHER, THRUST 2 2 2 2 E-7 11 HZX2-13341-003 BEARING A, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING B, MAIN LOWER (BROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (FROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (FROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (FROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING E, MAIN LOWER (FROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING E, MAIN LOWER (FROWN) 4 4 4 (TAIHO)	E-7	7	HRYE-13215-A01	BEARING E, CONNECTING ROD(PINK)	12	12	12	(PINK) (TAIHO)
E-7 9 HZX2-13322-003 BEARING B, MAIN UPPER (BROWN) 4 4 4 4 (TAIHO) E-7 9 HZX2-13323-003 BEARING C, MAIN UPPER (GREEN) 4 4 4 4 (TAIHO) E-7 9 HZX2-13324-003 BEARING D, MAIN UPPER (YELLOW) 4 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING E, MAIN UPPER (YELLOW) 4 4 4 4 (TAIHO) E-7 9 HZX2-13326-003 BEARING F, MAIN UPPER (RED) 4 4 4 4 (TAIHO) E-7 10 HZY3-13331-A06 WASHER. THRUST 2 2 2 2 E-7 11 HZX2-13341-003 BEARING A, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING B, MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13344-003 BEARING D, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (YELLOW) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (PINK) 4 4 4 (TAIHO)	E-7	8	HZX2-13310-000	CRANKSHAFT COMP.	1	1	1	
E-7 9 HZX2-13323-003 BEARING C, MAIN UPPER (GREEN) 4 4 4 (TAIHO) E-7 9 HZX2-13324-003 BEARING D, MAIN UPPER (YELLOW) 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING E, MAIN UPPER (PINK) 4 4 4 (TAIHO) E-7 9 HZX2-13326-003 BEARING F, MAIN UPPER (RED) 4 4 4 (TAIHO) E-7 10 HZY3-13331-A06 WASHER, THRUST 2 2 2 E-7 11 HZX2-13341-003 BEARING A, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING B, MAIN LOWER (BROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING D, MAIN LOWER (YELLOW) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (RED) 4 4 4 (TAIHO)	E-7	9	HZX2-13321-003	BEARING A, MAIN UPPER(BLACK)	4	4	4	(TAIHO)
E-7 9 HZX2-13324-003 BEARING D, MAIN UPPER (YELLOW) 4 4 4 4 (TAIHO) E-7 9 HZX2-13325-003 BEARING E, MAIN UPPER (PINK) 4 4 4 4 (TAIHO) E-7 9 HZX2-13326-003 BEARING F, MAIN UPPER (RED) 4 4 4 4 (TAIHO) E-7 10 HZY3-13331-A06 WASHER, THRUST 2 2 2 2 E-7 11 HZX2-13341-003 BEARING A, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING B, MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING D, MAIN LOWER (FINK) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO)	E-7	9	HZX2-13322-003	BEARING B, MAIN UPPER(BROWN)	4	4	4	(TAIHO)
E-7 9 HZX2-13325-003 BEARING E, MAIN UPPER (PINK) 4 4 4 4 (TAIHO) E-7 9 HZX2-13326-003 BEARING F, MAIN UPPER (RED) 4 4 4 4 (TAIHO) E-7 10 HZY3-13331-A06 WASHER, THRUST 2 2 2 2 E-7 11 HZX2-13341-003 BEARING A, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING B, MAIN LOWER (BROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13344-003 BEARING D, MAIN LOWER (YELLOW) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (RED) 4 4 4 (TAIHO)	E-7	9	HZX2-13323-003	BEARING C, MAIN UPPER(GREEN)	4	4	4	(TAIHO)
E-7 9 HZX2-13326-003 BEARING F, MAIN UPPER (RED) 4 4 4 4 (TAIHO) E-7 10 HZY3-13331-A06 WASHER, THRUST 2 2 2 2 E-7 11 HZX2-13341-003 BEARING A, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING B, MAIN LOWER (BROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13344-003 BEARING D, MAIN LOWER (YELLOW) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (RED) 4 4 4 (TAIHO)	E-7	9	HZX2-13324-003	BEARING D, MAIN UPPER(YELLOW)	4	4	4	(TAIHO)
E-7 10 HZY3-13331-A06 WASHER, THRUST 2 2 2 2 E-7 11 HZX2-13341-003 BEARING A, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING B, MAIN LOWER (BROWN) 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13344-003 BEARING D, MAIN LOWER (YELLOW) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (RED) 4 4 4 (TAIHO)	E-7	9	HZX2-13325-003	BEARING E, MAIN UPPER(PINK)	4	4	4	(TAIHO)
E-7 11 HZX2-13342-003 BEARING A, MAIN LOWER (BLACK) 4 4 4 (TAIHO) E-7 11 HZX2-13342-003 BEARING C, MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13344-003 BEARING D, MAIN LOWER (YELLOW) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (RED) 4 4 4 (TAIHO)	E-7	9	HZX2-13326-003	BEARING F, MAIN UPPER(RED)	4	4	4	(TAIHO)
E-7 11 HZX2-13342-003 BEARING B, MAIN LOWER (BROWN) 4 4 4 4 (TAIHO) E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13344-003 BEARING D, MAIN LOWER (YELLOW) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (RED) 4 4 4 (TAIHO)	E-7	10	HZY3-13331-A06	WASHER, THRUST	2	2	2	
E-7 11 HZX2-13343-003 BEARING C, MAIN LOWER (GREEN) 4 4 4 (TAIHO) E-7 11 HZX2-13344-003 BEARING D, MAIN LOWER (YELLOW) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (RED) 4 4 4 (TAIHO)	E-7	11	HZX2-13341-003	BEARING A, MAIN LOWER(BLACK)	4	4	4	(TAIHO)
E-7 11 HZX2-13344-003 BEARING D, MAIN LOWER (YELLOW) 4 4 4 (TAIHO) E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (RED) 4 4 4 (TAIHO)	E-7	11	HZX2-13342-003	BEARING B, MAIN LOWER(BROWN)	4	4	4	(TAIHO)
E-7 11 HZX2-13345-003 BEARING E, MAIN LOWER (PINK) 4 4 4 (TAIHO) E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (RED) 4 4 4 (TAIHO)	E-7	11	HZX2-13343-003	BEARING C, MAIN LOWER(GREEN)	4	4	4	(TAIHO)
E-7 11 HZX2-13346-003 BEARING F, MAIN LOWER (RED) 4 4 4 (TAIHO)	E-7	11	HZX2-13344-003	BEARING D, MAIN LOWER(YELLOW)	4	4	4	(TAIHO)
	E-7	11	HZX2-13345-003	BEARING E, MAIN LOWER(PINK)	4	4	4	(TAIHO)
E-7 12 HZY3-13391-010 RETAINER, SPRING 1 1 1	E-7	11	HZX2-13346-003	BEARING F, MAIN LOWER(RED)	4	4	4	(TAIHO)
	E-7	12	HZY3-13391-010	RETAINER, SPRING	1	1	1	
E-7 13 HZX2-13392-000 SEAT, SPRING (250) 1 1 1	E-7	13	HZX2-13392-000	SEAT, SPRING(250)	1	1	1	

E-7 CRANKSHAFT/PISTON




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-7	14	HZY3-13398-003	SPRING, SUPPORT	1	1	1	

E-9 CYLINDER HEAD




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-9	1	HZY3-11911-010	HANGER, ENGINE	2	2	2	
E-9	4	HPZ1-12210-004	SEAL A, VALVE STEM(NOK)	12	12	12	
E-9	5	HZVL-12210-000ZA	HEAD COMP., CYLINDER	2			*NH8* DRAK GRAY ~1005722
E-9	5	HZVL-12210-000ZA	HEAD COMP., CYLINDER		2		*NH8* DRAK GRAY ~1004733
E-9	5	HZVL-12210-000ZA	HEAD COMP., CYLINDER			2	*NH8* DRAK GRAY ~1015425
E-9	5	HZVL-12210-010ZA	HEAD COMP., CYLINDER	2			*NH8* DRAK GRAY 1005723~
E-9	5	HZVL-12210-010ZA	HEAD COMP., CYLINDER		2		*NH8* DRAK GRAY 1004734~
E-9	5	HZVL-12210-010ZA	HEAD COMP., CYLINDER			2	*NH8* DRAK GRAY 1015426~
E-9	6	HPZ1-12211-004	SEAL B, VALVE STEM(NOK)	12	12	12	
E-9	7	HZVL-12231-000	COVER, R. CAMSHAFT THRUST	1	1	1	
E-9	8	HZY3-12241-000	COVER, L. CAMSHAFT THRUST	1	1	1	
E-9	9	HZY3-12251-A01	GASKET COMP., CYLINDER HEAD	2	2	2	(NIPPON LEAKLESS)
E-9	10	HP8F-14820-A01	MOTION COMP., LOST		6	6	
E-9	11	HPT0-90005-003	BOLT-WASHER, 12X163	16	16	16	
E-9	12	HZY9-90026-M01	BOLT, FLANGE, 8X20	4	4	4	
E-9	13	HZVL-90035-010	BOLT, FLANGE, 8X28	4	4	4	
E-9	14	HP8A-90701-A00	DOWEL PIN, 6X10	4	4	4	
E-9	15	HPT0-90705-000	DOWEL PIN, 16X22	4	4	4	
E-9	16	HRKG-91213-003	OIL SEAL, 39X53X8 (NOK)	2	2	2	
E-9	17	HP8A-91301-A00	0-RING, 48.5X2.4	2	2	2	
E-9	18	HCO-94302-06100	PIN B, DOWEL, 6X10	4	4	4	

E-9-10 CAMSHAFT/ROCKER ARM




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-9-10	1	HZVJ-14111-000	CAMSHAFT, R.	1			
E-9-10	1	HZX2-14111-000	CAMSHAFT, R.		1	1	
E-9-10	2	HZVJ-14211-000	CAMSHAFT, L.	1			
E-9-10	2	HZX2-14211-000	CAMSHAFT, L.		1	1	
E-9-10	3	HRDV-14610-J00	ARM ASSY., FR. INTAKE ROCKER	6			
E-9-10	4	HP8A-14620-A01	ARM ASSY., INTAKE ROCKER		6	6	
E-9-10	5	HP8A-14626-A00	ARM COMP. A, EX. ROCKER	6			~1005854
E-9-10	5	HP8A-14626-A00	ARM COMP. A, EX. ROCKER		6		~1004879
E-9-10	5	HP8A-14626-A00	ARM COMP. A, EX. ROCKER			6	~1015842
E-9-10	5	HZVL-14626-700	ARM COMP. A, EX. ROCKER	6			1005855~
E-9-10	5	HZVL-14626-700	ARM COMP. A, EX. ROCKER		6		1004880~
E-9-10	5	HZVL-14626-700	ARM COMP. A, EX. ROCKER			6	1015843~
E-9-10	6	HP8A-14627-A00	ARM COMP. B, EX. ROCKER	6			~1005854
E-9-10	6	HP8A-14627-A00	ARM COMP. B, EX. ROCKER		6		~1004879
E-9-10	6	HP8A-14627-A00	ARM COMP. B, EX. ROCKER			6	~1015842
E-9-10	6	HZVL-14627-700	ARM COMP. B, EX. ROCKER	6			1005855~
E-9-10	6	HZVL-14627-700	ARM COMP. B, EX. ROCKER		6		1004880~
E-9-10	6	HZVL-14627-700	ARM COMP. B, EX. ROCKER			6	1015843~
E-9-10	7	HRDV-14631-J00	SHAFT COMP., FR. INTAKE ROCKERARM	2			ARM
E-9-10	7	HP8A-14631-A00	SHAFT COMP., INTAKE ROCKER ARM		2	2	
E-9-10	8	HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM	2			~1005854
E-9-10	8	HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM		2		~1004879
E-9-10	8	HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM			2	~1015842
E-9-10	8	HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM	2			1005855~
E-9-10	8	HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM		2		1004880~
E-9-10	8	HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM			2	1015843~
E-9-10	9	HP8A-14645-A01	SPRING, ROCKER ARM	6			~1005854
E-9-10	9	HP8A-14645-A01	SPRING, ROCKER ARM		6		~1004879
E-9-10	9	HP8A-14645-A01	SPRING, ROCKER ARM			6	~1015842

E-9-10 CAMSHAFT/ROCKER ARM




Ref. No.						Q'ty		
E-9-10 9 HZVL-14645-700 SPRING, ROCKER ARM E-9-10 10 MEDV-14646-300 MASHER, THRUST 12 E-9-10 11 HRJA-14711-000 VALVE, IN. 12 12 12 E-9-10 11 HRJA-14711-000 VALVE, IN. 12 12 12 E-9-10 13 HPW3-14744-000 SOREW, TAPPET ADJUSTING 12 E-9-10 14 NPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 12 (VI)PPON HATSUJO) E-9-10 15 HRW3-1474-000 SPRING, VALVE (PINK) 12 12 12 (VI)PPON HATSUJO) E-9-10 16 NPSE-14762-A01 SPRING, VALVE (PINK) 12 12 12 (VI)PPON HATSUJO) E-9-10 17 HBDV-14765-300 RETAINER, VALVE SPRING 24 24 24 E-9-10 18 HPW3-14776-000 SEAT, VALVE SPRING 24 24 24 24 E-9-10 19 HRBW-14786-300 RETAINER, VALVE SPRING 24 24 24 24 E-9-10 19 HRBW-14786-300 BOLT, FLANGE, SKAO 24 88 8 E-9-10 20 NPSA-90003-A00 BOLT, FLANGE, SKAO 8 8 8 E-9-10 21 HPSA-90003-A00 BOLT, FLANGE, SKAO 8 8 8 E-9-10 22 HPW3-9026-004 NUT, TAPPET ADJUSTING 12 12 12 E-9-10 23 HPT0-9026-004 NUT, TAPPET ADJUSTING 12 12 12 E-9-10 24 HR70-14646-A00 MASHER, THRUST 12 1006885~ E-9-10 25 HZVL-14646-700 MASHER, THRUST 24 1105885~ E-9-10 26 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1015843~ E-9-10 27 HZVL-14646-700 MASHER, THRUST 24 1105885~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1015843~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1015843~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1015843~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1006885~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1006885~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1006885~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1006885~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1006885~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1006885~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1006885~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1006885~ E-9-10 28 HPT0-14744-004 SOREW, TAPPET ADJUSTING 12 12 1006885~	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-9-10 9 HZVL-14645-700 SPRING, BOCKER ARM E-9-10 10 HR0V-14646-300 WASHER, THRUST 12 12 12 12 12 12 12 12 12 12 12 12 12	E-9-10	9	HZVL-14645-700	SPRING, ROCKER ARM	6			1005855~
E-9-10 10 HRDV-14646-JOO NASHER THRUST 12 12 12 12 12 12 12 12 12 12 12 12 12	E-9-10	9	HZVL-14645-700	SPRING, ROCKER ARM		6		1004880~
E-9-10 11 HRJA-14721-600 VALVE, IN. 12 12 12 E-9-10 12 HRJA-14721-600 VALVE, EX. 12 12 12 E-9-10 13 HRWA-14721-600 VALVE, EX. 12 12 12 E-9-10 13 HRWA-14724-000 SCREW, TAPPET ADJUSTING 12 12 E-9-10 14 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 12 E-9-10 15 HRWG-14761-003 SPRING, EX. VALVE (PINK) 12 12 12 (NIPPON HATSUJO) E-9-10 16 HPBG-14762-A01 SPRING, EX. VALVE (YELLOW GREEN) 12 12 12 (VELLOW GREEN) E-9-10 17 HRDV-14765-JOO RETAINER, VALVE SPRING 24 24 24 E-9-10 18 HPWA-14775-000 SEAT, VALVE SPRING 24 24 24 E-9-10 19 HRGM-14781-A01 COTTER, VALVE (FIJJI VALVE) 48 48 48 E-9-10 20 HPBA-90003-A00 BOLT, FLANGE, BX30 12 12 12 E-9-10 21 HPBA-90004-A00 BOLT, FLANGE, BX30 12 12 12 E-9-10 22 HPWA-9026-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 23 HPT0-90206-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855~ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 12 ~ ~ 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~ ~ 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~ ~ 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~ ~ 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~ ~ 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~ ~ 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~ ~ 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~ ~ 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~ ~ 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~ ~ 1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~ 1005855~	E-9-10	9	HZVL-14645-700	SPRING, ROCKER ARM			6	1015843~
E-9-10 12 HRJ3-14721-E00 VALVE, EX 12 12 12 12 12 12 12 12 13 HPM3-14744-000 SCREW, TAPPET ADJUSTING 12 12 12 12 12 12 12 12 12 12 12 12 12	E-9-10	10	HRDV-14646-J00	WASHER, THRUST	12			
E-9-10 13 HPM3-14744-000 SCREW, TAPPET ADJUSTING 12 12 12 12 12 12 12 12 12 12 12 12 12	E-9-10	11	HRJA-14711-000	VALVE, IN.	12	12	12	
E-9-10 14 HPTO-14744-004 SCREW, TAPPET ADJUSTING 12 12 E-9-10 15 HRKG-14761-003 SPRING, VALVE (PINK) 12 12 12 (NIPPON HATSUJO) E-9-10 16 HPBE-14762-A01 SPRING, EX. VALVE (YELLOW GREEN) 12 12 12 (YELLOW GREEN) E-9-10 17 HRDV-14765-JOO RETAINER, VALVE SPRING 24 24 24 E-9-10 18 HPMS-14775-000 SEAT, VALVE SPRING 24 24 24 E-9-10 19 HRGM-14781-A01 COTTER, VALVE SPRING 24 24 24 E-9-10 20 HPBS-90003-A00 BOLT, FLANGE, 8X30 12 12 12 E-9-10 21 HPBS-90003-A00 BOLT, FLANGE, 8X30 12 12 12 E-9-10 22 HPMS-90206-004 NUT, TAPPET ADJUSTING 12 (TOKAI TRW) E-9-10 23 HPTO-90206-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855~ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005856~ E-9-10 26 HPTO-14744-004 SCREW, TAPPET ADJUSTING 12 ~1004879 E-9-10 26 HPTO-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005855~	E-9-10	12	HRJA-14721-E00	VALVE, EX.	12	12	12	
E-9-10 15 HRKG-14761-003 SPRING, VALVE (PINK) 12 12 12 (NIPPON HATSUJO) E-9-10 16 HPBE-14762-A01 SPRING, EX. VALVE (YELLOW GREEN) 12 12 12 (YELLOW GREEN) E-9-10 17 HRDV-14765-JOO RETAINER, VALVE SPRING 24 24 24 E-9-10 18 HPM3-14775-000 SEAT, VALVE SPRING 24 24 24 E-9-10 19 HRGM-14781-A01 COTTER, VALVE (FUJI VALVE) 48 48 48 E-9-10 20 HPBA-90003-A00 BOLT, FLANGE, 8X30 12 12 12 E-9-10 21 HPBA-90004-A00 BOLT, FLANGE, 8X40 8 8 8 E-9-10 22 HPM3-90206-004 NUT, TAPPET ADJUSTING 12 (TOKAI TRW) E-9-10 23 HPT0-90206-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 24 1105843∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1105880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005800∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005800∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005800∼ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1004879 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005855∼ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005855∼ E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 ~1005855∼	E-9-10	13	HPM3-14744-000	SCREW, TAPPET ADJUSTING	12			
E-9-10 16 HP8E-14762-A01 SPRING, EX. VALVE (YELLOW GREEN) 12 12 12 (YELLOW GREEN) E-9-10 17 HR0V-14765-JOO RETAINER, VALVE SPRING 24 24 24 E-9-10 18 HPW3-14775-000 SEAT, VALVE SPRING 24 24 24 E-9-10 19 HRGM-14781-A01 COTTER, VALVE (FUJI VALVE) 48 48 48 E-9-10 20 HP8A-90003-A00 BOLT, FLANGE, 8X30 12 12 12 E-9-10 21 HP8A-90004-A00 BOLT, FLANGE, 8X40 8 8 8 E-9-10 22 HPW3-90206-004 NUT, TAPPET ADJUSTING 12 (TOKAI TRW) E-9-10 23 HP70-90206-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855~ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855~ E-9-10 26 HP70-14744-004 SCREW, TAPPET ADJUSTING 12 ~ 1005854 E-9-10 26 HP70-14744-004 SCREW, TAPPET ADJUSTING 12 ~ 1005855~ E-9-10 26 HP70-14744-004 SCREW, TAPPET ADJUSTING 12 ~ 1005855~ E-9-10 26 HP70-14744-004 SCREW, TAPPET ADJUSTING 12 ~ 1005855~ E-9-10 26 HP70-14744-004 SCREW, TAPPET ADJUSTING 12 ~ 1005855~ E-9-10 26 HP70-14744-004 SCREW, TAPPET ADJUSTING 12 ~ 1005855~ E-9-10 26 HP70-14744-004 SCREW, TAPPET ADJUSTING 12 ~ 1005855~ E-9-10 26 HP70-14744-004 SCREW, TAPPET ADJUSTING 12 ~ 1005855~	E-9-10	14	HPT0-14744-004	SCREW, TAPPET ADJUSTING		12	12	
E-9-10 17 HRDV-14765-J00 RETAINER, VALVE SPRING 24 24 24 24 24 24 25 24 24 24 24 25 25 25 26 25 26 27 28 27 28 27 28 28 28 28 28 28 28 28 28 28 28 28 28	E-9-10	15	HRKG-14761-003	SPRING, VALVE (PINK)	12	12	12	(NIPPON HATSUJO)
E-9-10 18 HPM3-14775-000 SEAT, VALVE SPRING 24 24 24 E-9-10 19 HRGM-14781-A01 COTTER, VALVE (FUJI VALVE) 48 48 48 E-9-10 20 HP8A-90003-A00 BOLT, FLANGE, 8X30 12 12 12 E-9-10 21 HP8A-90004-A00 BOLT, FLANGE, 8X40 8 8 8 E-9-10 22 HPM3-90206-004 NUT, TAPPET ADJUSTING 12 (TOKAI TRW) E-9-10 23 HPT0-90206-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1005856∼ E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 ∼105855∼	E-9-10	16	HP8E-14762-A01	SPRING, EX. VALVE (YELLOW GREEN)	12	12	12	(YELLOW GREEN)
E-9-10 19 HRGM-14781-A01 COTTER, VALVE (FUJI VALVE) 48 48 48 E-9-10 20 HP8A-90003-A00 BOLT, FLANGE, 8X30 12 12 12 E-9-10 21 HP8A-90004-A00 BOLT, FLANGE, 8X40 8 8 8 8 E-9-10 22 HPM3-90206-004 NUT, TAPPET ADJUSTING 12 (TOKAI TRW) E-9-10 23 HPT0-90206-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1015843∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005855∼	E-9-10	17	HRDV-14765-J00	RETAINER, VALVE SPRING	24	24	24	
E-9-10 20 HP8A-90003-A00 BOLT, FLANGE, 8X30 12 12 12 12 E-9-10 21 HP8A-90004-A00 BOLT, FLANGE, 8X40 8 8 8 8 E-9-10 22 HPW3-90206-004 NUT, TAPPET ADJUSTING 12 (TOKAI TRW) E-9-10 23 HPT0-90206-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855~ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1004880~ E-9-10 25 H2VL-14646-700 WASHER, THRUST 24 1005855~ E-9-10 25 H2VL-14646-700 WASHER, THRUST 24 1015843~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1004879 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005855~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005855~	E-9-10	18	HPM3-14775-000	SEAT, VALVE SPRING	24	24	24	
E-9-10 21 HP8A-90004-A00 B0LT, FLANGE, 8X40 8 8 8 E-9-10 22 HPM3-90206-004 NUT, TAPPET ADJUSTING 12 (TOKAI TRW) E-9-10 23 HPT0-90206-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1004880∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1015843∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1004879 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1005855∼ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1005855∼	E-9-10	19	HRGM-14781-A01	COTTER, VALVE (FUJI VALVE)	48	48	48	
E-9-10 22 HPM3-90206-004 NUT, TAPPET ADJUSTING 12 12 (T0KAI TRW) E-9-10 23 HPT0-90206-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1015843∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1015843∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1015843∼ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1004879 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1015842 E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 1005855∼	E-9-10	20	HP8A-90003-A00	BOLT, FLANGE, 8X30	12	12	12	
E-9-10 23 HPT0-90206-004 NUT, TAPPET ADJUSTING 12 12 E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1004880∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1015843∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1015843∼ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1004879 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1015842 E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 1005855∼	E-9-10	21	HP8A-90004-A00	BOLT, FLANGE, 8X40	8	8	8	
E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1005855∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1004880∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1015843∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1015843∼ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1004879 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1015842 E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 1005855∼	E-9-10	22	HPM3-90206-004	NUT, TAPPET ADJUSTING	12			(TOKAI TRW)
E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1004880∼ E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1015843∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1015843∼ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1015843∼ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1004879 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ∼1015842 E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 1005855∼	E-9-10	23	HPT0-90206-004	NUT, TAPPET ADJUSTING		12	12	
E-9-10 24 HR70-14646-A00 WASHER, THRUST 12 1015843~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1015843~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1004879 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1015842 E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 1005855~	E-9-10	24	HR70-14646-A00	WASHER, THRUST	12			1005855~
E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1005855~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1015843~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1004879 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1015842 E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 1005855~	E-9-10	24	HR70-14646-A00	WASHER, THRUST		12		1004880~
E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1004880~ E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1015843~ E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1005854 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1004879 E-9-10 26 HPT0-14744-004 SCREW, TAPPET ADJUSTING 12 ~1015842 E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 1005855~	E-9-10	24	HR70-14646-A00	WASHER, THRUST			12	1015843~
E-9-10 25 HZVL-14646-700 WASHER, THRUST 24 1015843~ E-9-10 26 HPT0-14744-004 SCREW. TAPPET ADJUSTING 12 ~1005854 E-9-10 26 HPT0-14744-004 SCREW. TAPPET ADJUSTING 12 ~1004879 E-9-10 26 HPT0-14744-004 SCREW. TAPPET ADJUSTING 12 ~1015842 E-9-10 26 HZVL-90017-701 SCREW. TAPPET ADJUSTING 12 1005855~	E-9-10	25	HZVL-14646-700	WASHER, THRUST	24			1005855~
E-9-10 26 HPT0-14744-004 SCREW. TAPPET ADJUSTING 12 ~1005854 E-9-10 26 HPT0-14744-004 SCREW. TAPPET ADJUSTING 12 ~1004879 E-9-10 26 HPT0-14744-004 SCREW. TAPPET ADJUSTING 12 ~1015842 E-9-10 26 HZVL-90017-701 SCREW. TAPPET ADJUSTING 12 1005855~	E-9-10	25	HZVL-14646-700	WASHER, THRUST		24		1004880~
E-9-10 26 HPT0-14744-004 SCREW. TAPPET ADJUSTING 12 ~1004879 E-9-10 26 HPT0-14744-004 SCREW. TAPPET ADJUSTING 12 ~1015842 E-9-10 26 HZVL-90017-701 SCREW. TAPPET ADJUSTING 12 1005855~	E-9-10	25	HZVL-14646-700	WASHER, THRUST			24	1015843~
E-9-10 26 HPT0-14744-004 SCREW. TAPPET ADJUSTING 12 ~1015842 E-9-10 26 HZVL-90017-701 SCREW. TAPPET ADJUSTING 12 1005855~	E-9-10	26	HPT0-14744-004	SCREW, TAPPET ADJUSTING	12			~1005854
E-9-10 26 HZVL-90017-701 SCREW. TAPPET ADJUSTING 12 1005855~	E-9-10	26	HPT0-14744-004	SCREW, TAPPET ADJUSTING		12		~1004879
	E-9-10	26	HPT0-14744-004	SCREW, TAPPET ADJUSTING			12	~1015842
E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 1004880~	E-9-10	26	HZVL-90017-701	SCREW, TAPPET ADJUSTING	12			1005855~
	E-9-10	26	HZVL-90017-701	SCREW, TAPPET ADJUSTING		12		1004880~
E-9-10 26 HZVL-90017-701 SCREW, TAPPET ADJUSTING 12 1015843~	E-9-10	26	HZVL-90017-701	SCREW, TAPPET ADJUSTING			12	1015843~


E-9-10 CAMSHAFT/ROCKER ARM



					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-9-10	27	HPT0-90206-004	NUT, TAPPET ADJUSTING	12			~1005854
E-9-10	27	HPT0-90206-004	NUT, TAPPET ADJUSTING		12		~1004879
E-9-10	27	HPT0-90206-004	NUT, TAPPET ADJUSTING			12	~1015842
E-9-10	27	HPM3-90206-004	NUT, TAPPET ADJUSTING	12			1005855~
E-9-10	27	HPM3-90206-004	NUT, TAPPET ADJUSTING		12		1004880~
E-9-10	27	HPM3-90206-004	NUT, TAPPET ADJUSTING			12	1015843~




Ref. No. E-13 1 E-13 2 E-13 3	Part No. HZY3-13621-C01 HZVL-13622-000	Description	BFT200D	BFT225D	BFT2	Remarks
E-13 2		DILLEY TIMING BELT DRIVE		D	Г250D	
	HZVL-13622-000	PULLEY, TIMING BELT DRIVE	1	1	1	
E-13 3		PLATE, CRANK PULSER	1	1	1	
	HZX2-13811-000	PULLEY, CRANKSHAFT	1	1	1	
E-13 4	HZY3-14261-C00	PULLEY COMP., R. TIMING BELT DRIVEN	1	1	1	DRIVEN
E-13 5	HZVL-14270-010	PULLEY COMP., L. TIMING BELT DRIVEN	1	1	1	DRIVEN
E-13 6	HP8A-14400-A01	BELT, TIMING(197YU26 B-323)	1	1	1	
E-13 7	HZY3-14510-013	TENSIONER COMP., TIMING BELT	1	1	1	
E-13 8	HZY3-14515-000	CAP, TIMING BELT TENSIONER	3	3	3	
E-13 9	HZY3-14520-000	SPRING COMP., TIMING BELT ADJUSTING	1	1	1	ADJUSTING
E-13 10	HZVL-14526-415ZA	BASE COMP., TIMING BELT TENSIONER *NH8* DARK GRAY	1	1	1	
E-13 11	HZY3-14529-000	O-RING, TIMING BELT TENSIONER BASE	1	1	1	BASE
E-13 12	HZY3-14550-003	IDLER, TIMING BELT(KOYO SEIKO)	1	1	1	
E-13 13	HP8A-14551-A01	BOLT, IDLER	1	1	1	
E-13 14	HZVL-14553-003	BOLT, TIMING BELT IDLER	1			~1002549
E-13 14	HZVL-14553-003	BOLT, TIMING BELT IDLER		1		~1002617
E-13 14	HZVL-14553-003	BOLT, TIMING BELT IDLER			1	~1007152
E-13 14	HZVL-14553-013	BOLT, TIMING BELT IDLER	1			1002550~1004477
E-13 14	HZVL-14553-013	BOLT, TIMING BELT IDLER		1		1002618~1003647
E-13 14	HZVL-14553-013	BOLT, TIMING BELT IDLER			1	1007153~1011127
E-13 14	HZVL-14553-023	BOLT, TIMING BELT IDLER	1			1004478~
E-13 14	HZVL-14553-023	BOLT, TIMING BELT IDLER		1		1003648~
E-13 14	HZVL-14553-023	BOLT, TIMING BELT IDLER			1	1011128~
E-13 15	HZY3-14555-003	IDLER B, TIMING BELT	1	1	1	
E-13 16	HZX2-19511-000	FAN, COOLING	1	1	1	
E-13 17	HZY3-31638-003	BELT, A. C. GENERATOR	1	1	1	(6PK745 M-180)
E-13 18	HZVL-32111-000	BRACKET, COUPLER D	1	1	1	
E-13 19	HZV0-41122-000	PIN, VERTICAL SHAFT	1	1	1	
E-13 20	HZZ5-90011-M01	BOLT, FLANGE, 6X14 (CT200)	1	1	1	
E-13 21	HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTI	1			~1002549




Part No. Part No. Description Fig. 98 98 98 98 98 98 98 98						Q'ty		
E-13 21 HZZ5-90012-M01 BOLT, TIMING BELT ADJUSTI 1 1 0002550~ E-13 21 HZZ5-90012-W02 BOLT, TIMING BELT ADJUSTI 1 1 1002618~ E-13 21 HZZ5-90012-W02 BOLT, TIMING BELT ADJUSTI 1 1 1002618~ E-13 21 HZZ5-90012-W02 BOLT, TIMING BELT ADJUSTI 1 1 1007153~ E-13 22 HRJA-90017-W03 BOLT, FLANGE, 16X49 1 1 1 1 E-13 22 HRJA-90017-W01 BOLT, FLANGE, 6X16 4 4 4 4 E-13 23 HZZ5-90013-W01 BOLT, FLANGE, 6X16 4 4 4 4 E-13 24 HZZ5-9003-W01 BOLT, FLANGE, 16X49 1 1 1 1 E-13 26 HZVL-90039-W00 BOLT, FLANGE, 10X40 3 1 ~1002549 E-13 26 HZVL-90039-W00 BOLT, FLANGE, 10X40 3 1 ~1002549 E-13 26 HZVL-90039-W00 BOLT, FLANGE, 10X40 3 1 ~1002550~ E-13 26 HZVL-90039-W01 BOLT, FLANGE, 10X40 3 1 1002550~ E-13 26 HZVL-90039-W01 BOLT, FLANGE, 10X40 3 1 1002550~ E-13 26 HZVL-90039-W01 BOLT, FLANGE, 10X40 3 1 1002550~ E-13 26 HZVL-90039-W01 BOLT, FLANGE, 10X40 3 1 1002550~ E-13 26 HZVL-90039-W01 BOLT, FLANGE, 10X40 3 1 1002550~ E-13 27 HZVL-90040-W01 BOLT, FLANGE, 10X40 1 3 1002550~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X40 1 1 1002711~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 ~1002522 E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002711~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002711~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002711~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002711~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002718~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002718~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002718~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002718~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002718~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002718~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002718~ E-13 27 HZVL-90040-W00 BOLT, FLANGE, 10X43 1 1 1002718~ E-13 28 H8GA-90704-W00 KEY, 4.5 KZ4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Ref. No		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-13 21 H2Z5-90012-M02 B0LT. TIMING BELT ADJUST1 1 1 1002550~ E-13 21 HZ25-90012-M02 B0LT. TIMING BELT ADJUST1 1 1 1002618~ E-13 21 HZ25-90012-M02 B0LT. TIMING BELT ADJUST1 1 1 1007153~ E-13 22 HRJA-90017-M03 B0LT-MASHER. 16X49 1 1 1 1 1 1 E-13 23 HZ25-90017-M01 B0LT. FLANGE. 6X16 4 4 4 4 4 E-13 24 HZZ5-90030-M01 B0LT. FLANGE. 6X22 1 1 1 1 1 E-13 25 HP8A-90031-A01 B0LT-MASHER. 12X35 2 2 2 2 E-13 26 HZVL-90039-000 B0LT. FLANGE. 10X40 3 ~ ~1002549 E-13 26 HZVL-90039-000 B0LT. FLANGE. 10X40 3 ~ ~1002617 E-13 26 HZVL-90039-000 B0LT. FLANGE. 10X40 3 1 1002560~ E-13 26 HZVL-90039-010 B0LT. FLANGE. 10X40 3 1002560~ E-13 26 HZVL-90039-010 B0LT. FLANGE. 10X40 3 1002560~ E-13 26 HZVL-90039-010 B0LT. FLANGE. 10X40 3 1002560~ E-13 27 HZVL-90039-010 B0LT. FLANGE. 10X40 1 3 1002618~ E-13 27 HZVL-90039-010 B0LT. FLANGE. 10X40 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-13	21	HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTI		1		~1002617
E-13 21 H2Z5-90012-M02 BOLT. TIMING BELT ADJUST1	E-13	21	HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTI			1	~1007152
E-13 21 HZZ5-90012-W02 B0LT, TIMING BELT ADJUST1	E-13	21	HZZ5-90012-M02	BOLT, TIMING BELT ADJUSTI	1			1002550~
E-13 22 HRJA-90017-003 B0LT-MASHER. 16X49	E-13	21	HZZ5-90012-M02	BOLT, TIMING BELT ADJUSTI		1		1002618~
E-13 23 H2Z5-90017-H01 B0LT, FLANGE, 6X16 4 4 4 4 4 4 E-13 24 H2Z5-90030-M01 B0LT, FLANGE, 6X22 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-13	21	HZZ5-90012-M02	BOLT, TIMING BELT ADJUSTI			1	1007153~
E-13 24 HZZ5-90030-M01 B0LT. FLANGE, 6X22 1 1 1 1 1 1	E-13	22	HRJA-90017-003	BOLT-WASHER, 16X49	1	1	1	
E-13 25 HP8A-90031-A01 BOLT-WASHER 12X35 2 2 2 2 E-13 26 HZVL-90039-000 BOLT, FLANGE, 10X40 3 ~ ~ 1002549 E-13 26 HZVL-90039-000 BOLT, FLANGE, 10X40 3 ~ ~ 1002617 E-13 26 HZVL-90039-000 BOLT, FLANGE, 10X40 3 ~ ~ 10027152 E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002550~ E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002618~ E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002618~ E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002618~ E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 ~ ~ 1002521 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 ~ ~ 1002522~ 1002710 E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 1002522~ 1002710 E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 ~ ~ 1002617 E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 1002618~ 10027912 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 ~ ~ 1002617 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002618~ 1002792 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002618~ 1002792 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002618~ 1002792 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002618~ 1002792 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007090~ 1007871 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007090~ 1007871 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007090~ 1007871 E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 1 1	E-13	23	HZZ5-90017-M01	BOLT, FLANGE, 6X16	4	4	4	
E-13 26 HZVL-90039-000 BOLT, FLANGE, 10X40 3 ~1002549 E-13 26 HZVL-90039-000 BOLT, FLANGE, 10X40 3 ~1002617 E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 ~1002550~ E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002550~ E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002618~ E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002618~ E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 ~1002521 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 002522~1002710 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002517~ E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 1002711~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 002711~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 002618~1002792 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007099~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007099~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007099~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007099~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007099~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007099~ E-13 28 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007099~ E-13 29 HZYL-90040-010 BOLT, FLANGE, 10X43 1 1 1007099~ E-13 29 HZYL-90040-010 BOLT, FLANGE, 10X43 1 1 1007099~ E-13 29 HZYL-90040-000 BOLT, FLANGE, 10X43 1 1 1 1007099~	E-13	24	HZZ5-90030-M01	BOLT, FLANGE, 6X22	1	1	1	
E-13 26 H2VL-90039-000 B0LT, FLANGE, 10X40 3 ~1002617 E-13 26 H2VL-90039-010 B0LT, FLANGE, 10X40 3 1002550∼ E-13 26 H2VL-90039-010 B0LT, FLANGE, 10X40 3 1002618∼ E-13 26 H2VL-90039-010 B0LT, FLANGE, 10X40 3 1002618∼ E-13 26 H2VL-90039-010 B0LT, FLANGE, 10X40 3 1002618∼ E-13 26 H2VL-90039-010 B0LT, FLANGE, 10X40 3 1007153∼ E-13 27 H2VL-90040-000 B0LT, FLANGE, 10X43 1 1 0002521 E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1002711∼ E-13 27 H2VL-90016-000 B0LT, FLANGE, 10X43 1 1 1002711∼ E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1002617 E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1002617 E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1002617 E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1002618∼1002792 E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1002793∼ E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1002793∼ E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1002793∼ E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 10070789 E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 10070789 E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1007089 E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1007089 E-13 27 H2VL-90040-010 B0LT, FLANGE, 10X43 1 1 1007089 E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 1 1 E-13 29 H2Y3-90741-000 KEY, 4.5X24 1 1 1 1 1	E-13	25	HP8A-90031-A01	BOLT-WASHER, 12X35	2	2	2	
E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002550∼ E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002550∼ E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002618∼ E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1007153∼ E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1002521 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1002711∼ E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1002711∼ E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 1002711∼ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002711∼ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002617 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002618∼1002792 E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 1002793∼ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002703° E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 10027089 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007090~1007871 E-13 27 HZVL-90016-000 BOLT, FLANGE, 10X43 1 1 1007090~1007871 E-13 27 HZVL-90016-000 BOLT, FLANGE, 10X43 1 1 1007090~1007871 E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 1 E-13 29 HZY3-90741-000 KEY, SPECIAL 2 2 2 2	E-13	26	HZVL-90039-000	BOLT, FLANGE, 10X40	3			~1002549
E-13 26 HZVL-90039-010 B0LT, FLANGE, 10X40 3 1002550∼ E-13 26 HZVL-90039-010 B0LT, FLANGE, 10X40 3 1002618∼ E-13 26 HZVL-90039-010 B0LT, FLANGE, 10X40 3 1007153∼ E-13 27 HZVL-90040-000 B0LT, FLANGE, 10X43 1	E-13	26	HZVL-90039-000	BOLT, FLANGE, 10X40		3		~1002617
E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1002618~ E-13 26 HZVL-90039-010 BOLT, FLANGE, 10X40 3 1007153~ E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1	E-13	26	HZVL-90039-000	BOLT, FLANGE, 10X40			3	~1007152
E-13 26 HZVL-90039-010 B0LT, FLANGE, 10X40	E-13	26	HZVL-90039-010	BOLT, FLANGE, 10X40	3			1002550~
E-13 27 HZVL-90040-000 B0LT, FLANGE, 10X43 1 1	E-13	26	HZVL-90039-010	BOLT, FLANGE, 10X40		3		1002618~
E-13 27 HZVL-90040-010 B0LT, FLANGE, 10X43 1 1 1002522~1002710 E-13 27 HZVL-90016-000 B0LT, FLANGE, 10X43 1 1 1002711~ E-13 27 HZVL-90040-000 B0LT, FLANGE, 10X43 1 1 ~1002617 E-13 27 HZVL-90040-010 B0LT, FLANGE, 10X43 1 1 1002618~1002792 E-13 27 HZVL-90016-000 B0LT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-010 B0LT, FLANGE, 10X43 1 1 ~1002793~ E-13 27 HZVL-90040-010 B0LT, FLANGE, 10X43 1 1 ~1007089 E-13 27 HZVL-90040-010 B0LT, FLANGE, 10X43 1 1 1007090~1007871 E-13 27 HZVL-90016-000 B0LT, FLANGE, 10X43 1 1 1007090~1007871 E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 1 E-13 29 HZY3-90741-000 KEY, SPECIAL 2 2 2 2	E-13	26	HZVL-90039-010	BOLT, FLANGE, 10X40			3	1007153~
E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 1002711~ E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 ~1002618~1002792 E-13 27 HZVL-90016-000 BOLT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 ~1007089 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007090~1007871 E-13 27 HZVL-90016-000 BOLT, FLANGE, 10X43 1 1 1007090~1007871 E-13 27 HZVL-90016-000 BOLT, FLANGE, 10X43 1 1 1007092~ E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 1 E-13 29 HZY3-90741-000 KEY, SPECIAL 2 2 2 2	E-13	27	HZVL-90040-000	BOLT, FLANGE, 10X43	1			~1002521
E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 002618 ~ 1002792 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002793 ~ 1 1002793 ~ 1 1 1007089 E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 1007090 ~ 1007871 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007090 ~ 1007871 E-13 27 HZVL-90016-000 BOLT, FLANGE, 10X43 1 1 1007090 ~ 1007871 E-13 27 HZVL-90016-000 BOLT, FLANGE, 10X43 1 1 1007872 ~ 1 1 1007872 ~ 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-13	27	HZVL-90040-010	BOLT, FLANGE, 10X43	1			1002522~1002710
E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1002618~1002792 E-13 27 HZVL-90016-000 BOLT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-000 BOLT, FLANGE, 10X43 1 1 ~1007089 E-13 27 HZVL-90040-010 BOLT, FLANGE, 10X43 1 1 1007090~1007871 E-13 27 HZVL-90016-000 BOLT, FLANGE, 10X43 1 1 1007872~ E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 1 E-13 29 HZY3-90741-000 KEY, SPECIAL 2 2 2 2	E-13	27	HZVL-90016-000	BOLT, FLANGE, 10X43	1			1002711~
E-13 27 HZVL-90016-000 B0LT, FLANGE, 10X43 1 1 1002793~ E-13 27 HZVL-90040-000 B0LT, FLANGE, 10X43 1 1 ~1007089 E-13 27 HZVL-90040-010 B0LT, FLANGE, 10X43 1 1007090~1007871 E-13 27 HZVL-90016-000 B0LT, FLANGE, 10X43 1 1007872~ E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 1 E-13 29 HZY3-90741-000 KEY, SPECIAL 2 2 2 2	E-13	27	HZVL-90040-000	BOLT, FLANGE, 10X43		1		~1002617
E-13 27 HZVL-90040-000 B0LT, FLANGE, 10X43 1 1 ~1007089 E-13 27 HZVL-90040-010 B0LT, FLANGE, 10X43 1 1007090~1007871 E-13 27 HZVL-90016-000 B0LT, FLANGE, 10X43 1 1007872~ E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 E-13 29 HZY3-90741-000 KEY, SPECIAL 2 2 2	E-13	27	HZVL-90040-010	BOLT, FLANGE, 10X43		1		1002618~1002792
E-13 27 HZVL-90040-010 B0LT, FLANGE, 10X43 1 1007090~1007871 E-13 27 HZVL-90016-000 B0LT, FLANGE, 10X43 1 1007872~ E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 E-13 29 HZY3-90741-000 KEY, SPECIAL 2 2 2	E-13	27	HZVL-90016-000	BOLT, FLANGE, 10X43		1		1002793~
E-13 27 HZVL-90016-000 B0LT, FLANGE, 10X43 1 1007872~ E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 E-13 29 HZY3-90741-000 KEY, SPECIAL 2 2 2	E-13	27	HZVL-90040-000	BOLT, FLANGE, 10X43			1	~1007089
E-13 28 HRCA-90704-A00 KEY, 4.5X24 1 1 1 1 1 E-13 29 HZY3-90741-000 KEY, SPECIAL 2 2 2	E-13	27	HZVL-90040-010	BOLT, FLANGE, 10X43			1	1007090~1007871
E-13 29 HZY3-90741-000 KEY, SPECIAL 2 2 2	E-13	27	HZVL-90016-000	BOLT, FLANGE, 10X43			1	1007872~
	E-13	28	HRCA-90704-A00	KEY, 4.5X24	1	1	1	
E-13 30 HCO-94302-06100 DOWEL PIN, 6X10 1 1 1 1	E-13	29	HZY3-90741-000	KEY, SPECIAL	2	2	2	
	E-13	30	HC0-94302-06100	DOWEL PIN, 6X10	1	1	1	
	-							

E-13-10 TIMING BELT COVER




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-13-10	1	HP8A-11812-A00	GROMMET, TIMING BELT COVER	2	2	2	
E-13-10	2	HZVL-11820-000	COVER ASSY., R. TIMING BELT	1	1	1	
E-13-10	3	HZVL-11840-000	COVER ASSY., L. TIMING BELT	1	1	1	
E-13-10	4	HZVL-11861-000	PLATE, L. TIMING BELT COVER	1	1	1	
E-13-10	5	HZY3-11871-000	PLATE, R. TIMING BELT COVER	1	1	1	
E-13-10	6	HR70-37840-A01	SENSOR ASSY., TDC	1	1	1	
E-13-10	7	HZVL-90004-000	BOLT-WASHER, 5X16	1			~1002700
E-13-10	7	HZVL-90004-000	BOLT-WASHER, 5X16		1		~1002916
E-13-10	7	HZVL-90004-000	BOLT-WASHER, 5X16			1	~1007868
E-13-10	7	HZVL-90004-010	BOLT-WASHER, 5X16	1			1002701~
E-13-10	7	HZVL-90004-010	BOLT-WASHER, 5X16		1		1002917~
E-13-10	7	HZVL-90004-010	BOLT-WASHER, 5X16			1	1007869~
E-13-10	8	HZVL-90007-010	BOLT, TIMING BELT COVER	4	4	4	
E-13-10	9	HP8A-90017-A01	BOLT, SPECIAL, 8X29	4	4	4	
E-13-10	10	HZVL-91508-000	COLLAR, TIMING BELT COVER	2	2	2	
-							
-							
-							
-							

E-14 FUEL PIPE/INJECTOR




Ref. No.	Part No.	Description	뫄	В		
E-14 1			BFT200D	BFT225D	BFT250D	Remarks
	HZY6-16450-003	INJECTOR ASSY., FUEL	6	6	6	
E-14 2	HZY3-16451-000	CLIP, INJECTOR	6	6	6	
E-14 3	HZY3-16611-A00	PIPE, R. FUEL	1	1	1	
E-14 4	HP5G-16614-003	MESH, FUEL FILTER	1	1	1	
E-14 5	HZY3-16620-A00	PIPE COMP., L. FUEL	1	1	1	
E-14 6	HZY3-16740-A01	REGULATOR ASSY., PRESSURE	1	1	1	
E-14 7	HPG7-16741-005	O-RING, PRESSURE REGULATOR	1	1	1	
E-14 8	HZVL-16748-000	TUBE, PRESSURE REGULATOR	1	1	1	CONTROL
E-14 9	HZY3-16752-A00	JOINT, FUEL PIPE	3	3	3	
E-14 10	HZVL-16755-003	HOSE COMP., FUEL	1	1	1	
E-14 11	HZY3-16757-003	HOSE COMP., FUEL JOINT	1	1	1	
E-14 12	HZVL-16765-003	HOSE COMP. B, FUEL	1	1	1	
E-14 13	HZVL-16910-003	STRAINER COMP., FUEL (HIGH)	1	1	1	
E-14 14	HZVL-16917-000	SUSPENSION, STRAINER	1	1	1	
E-14 15	HVM0-16965-771	CLAMP, HOSE	1	1	1	
E-14 16	HZY3-17051-A00	BASE, R. INJECTOR	1	1	1	
E-14 17	HRCA-17055-A01	GASKET, FR. INJECTOR BASE	1	1	1	
E-14 18	HZY3-17061-A00	BASE, L. INJECTOR	1	1	1	
E-14 19	HRCA-17065-A01	GASKET, RR. INJECTOR BASE	1	1	1	
E-14 20	HP8E-17105-A01	GASKET, INTAKE MANIFOLD	1	1	1	
E-14 21	HZY3-17108-000	SPACER, INTAKE MANIFOLD	1	1	1	
E-14 22	HS0X-17711-931	RETAINER (BLUE GREEN) (TOKAI)	2	2	2	
E-14 23	HZY3-32112-000	BRACKET, HARNESS CLIP A	4	4	4	
E-14 24	HZZ5-90014-M01	BOLT, FLANGE, 6X25	4	4	4	
E-14 25	HZZ5-90019-M00	BOLT, FLANGE, 6X35	4			~1002570
E-14 25	HZZ5-90019-M00	BOLT, FLANGE, 6X35		4		~1002916
E-14 25	HZZ5-90019-M00	BOLT, FLANGE, 6X35			4	~1007289
E-14 25	HZZ5-90019-M01	BOLT, FLANGE, 6X35	4			1002571~
E-14 25	HZZ5-90019-M01	BOLT, FLANGE, 6X35		4		1002917~

E-14 FUEL PIPE/INJECTOR




					Q'ty		_
Ref. No		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-14	25	HZZ5-90019-M01	BOLT, FLANGE, 6X35			4	1007290~
E-14	26	HZZ5-90021-M00	BOLT, FLANGE, 6X14	6			~1002570
E-14	26	HZZ5-90021-M00	BOLT, FLANGE, 6X14		6		~1002916
E-14	26	HZZ5-90021-M00	BOLT, FLANGE, 6X14			6	~1007289
E-14	26	HZZ5-90021-M01	BOLT, FLANGE, 6X14	6			1002571~
E-14	26	HZZ5-90021-M01	BOLT, FLANGE, 6X14		6		1002917~
E-14	26	HZZ5-90021-M01	BOLT, FLANGE, 6X14			6	1007290~
E-14	27	HZY9-90042-M00	BOLT, FLANGE, 6X10	6			~1002570
E-14	27	HZY9-90042-M00	BOLT, FLANGE, 6X10		6		~1002916
E-14	27	HZY9-90042-M00	BOLT, FLANGE, 6X10			6	~1007289
E-14	27	HZY9-90042-M01	BOLT, FLANGE, 6X10	6			1002571~
E-14	27	HZY9-90042-M01	BOLT, FLANGE, 6X10		6		1002917~
E-14	27	HZY9-90042-M01	BOLT, FLANGE, 6X10			6	1007290~
E-14	28	HZVL-90043-000	BOLT, STUD, 8X28	8			~1002549
E-14	28	HZVL-90043-000	BOLT, STUD, 8X28		8		~1002617
E-14	28	HZVL-90043-000	BOLT, STUD, 8X28			8	~1007152
E-14	28	HZVL-90043-010	BOLT, STUD, 8X28	8			1002550~
E-14	28	HZVL-90043-010	BOLT, STUD, 8X28		8		1002618~
E-14	28	HZVL-90043-010	BOLT, STUD, 8X28			8	1007153~
E-14	29	HZY3-90044-000	BOLT, STUD, 8X45	2			~1002570
E-14	29	HZY3-90044-000	BOLT, STUD, 8X45		2		~1002916
E-14	29	HZY3-90044-000	BOLT, STUD, 8X45			2	~1007289
E-14	29	HZVL-90044-010	BOLT, STUD, 8X45	2			1002571~
E-14	29	HZVL-90044-010	BOLT, STUD, 8X45		2		1002917~
E-14	29	HZVL-90044-010	BOLT, STUD, 8X45			2	1007290~
E-14	30	HZY9-90205-M00	NUT, FLANGE, 8MM	8			~1002556
E-14	30	HZY9-90205-M01	NUT, FLANGE, 8MM	8			1002557~
E-14	30	HZY9-90205-M00	NUT, FLANGE, 8MM		8		~1002646
E-14	30	HZY9-90205-M01	NUT, FLANGE, 8MM		8		1002647~
			•				

E-14 FUEL PIPE/INJECTOR




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-14	30	HZY9-90205-M00	NUT, FLANGE, 8MM			8	~1007289
E-14	30	HZY9-90205-M01	NUT, FLANGE, 8MM			8	1007290~
E-14	31	HSB2-90650-003	CLIP, WIRE HARNESS, 10MM	4	4	4	
E-14	32	HMJ0-91301-003	0-RING, 7.8X1.9(ARAI)	6	6	6	
E-14	33	HPLC-91301-000	0-RING, 7.47X3.6	6	6	6	
E-14	34	HPNA-91302-003	0-RING, 7. 45X3. 61 (NOK)	6	6	6	
E-14	35	HCO-94301-10120	DOWEL PIN, 10X12	4	4	4	
E-14	36	HZVL-06160-010	STRAINER ASSY., FUEL (HIGH)	1	1	1	
	•		•		•	•	




Ref. No.	Part No.	Description	-			
		5556. 1921.6.	BFT200D	BFT225D	BFT250D	Remarks
E-14-10 1	HZY3-17105-004	GASKET, INTAKE MANIFOLD	1	1	1	
E-14-10 2	HZY3-17109-004	PACKING, THROTTLE BODY	1	1	1	
E-14-10 3	HZVL-17110-003	MANIFOLD COMP., INLET	1	1	1	
E-14-10 4	HZVL-17131-000ZA	COVER, INTAKE MANIFOLD UPPER	1	1	1	*NH8* DARK GRAY
E-14-10 5	HZY3-17138-004	PACKING, INTAKE MANIFOLD UP	1	1	1	COVER
E-14-10 6	HRNA-37830-A01	SENSOR ASSY., MAP	1	1	1	
E-14-10 7	HZVL-37831-000	STAY, MAP SENSOR	1	1	1	
E-14-10 8	HZVL-37832-000	COLLAR, 5.5X6.8	1			~1002549
E-14-10 8	HZVL-37832-000	COLLAR, 5.5X6.8		1		~1002617
E-14-10 8	HZVL-37832-000	COLLAR, 5.5X6.8			1	~1007152
E-14-10 8	HZVL-37832-010	COLLAR, 5. 5X6. 8	1			1002550~
E-14-10 8	HZVL-37832-010	COLLAR, 5. 5X6. 8		1		1002618~
E-14-10 8	HZVL-37832-010	COLLAR, 5. 5X6. 8			1	1007153~
E-14-10 9	HPGK-37835-A01	O-RING	1	1	1	
E-14-10 10	HMB9-83551-000	GROMMET	1	1	1	
E-14-10 11	HZVL-90013-000	BOLT-WASHER, 5X12	1			~1002628
E-14-10 11	HZVL-90013-000	BOLT-WASHER, 5X12		1		~1002949
E-14-10 11	HZVL-90013-000	BOLT-WASHER, 5X12			1	~1007539
E-14-10 11	HZVL-90013-010	BOLT-WASHER, 5X12	1			1002629~
E-14-10 11	HZVL-90013-010	BOLT-WASHER, 5X12		1		1002950~
E-14-10 11	HZVL-90013-010	BOLT-WASHER, 5X12			1	1007540~
E-14-10 12	HZVL-90014-000	BOLT-WASHER, 5X28	1			~1002630
E-14-10 12	HZVL-90014-000	BOLT-WASHER, 5X28		1		~1002946
E-14-10 12	HZVL-90014-000	BOLT-WASHER, 5X28			1	~1007539
E-14-10 12	HZVL-90014-010	BOLT-WASHER, 5X28	1			1002631~
E-14-10 12	HZVL-90014-010	BOLT-WASHER, 5X28		1		1002947~
E-14-10 12	HZVL-90014-010	BOLT-WASHER, 5X28			1	1007540~
E-14-10 13	HZVL-90023-010	BOLT, FLANGE, 6X22	10	10	10	
E-14-10 14	HZY3-90031-000	BOLT, FLANGE, 6X32	1			~1002549

E-14-10 INTAKE MANIFOLD




Ref. No. Part No. Description 88 / 69 / 69 / 69 / 69 / 69 / 69 / 69 /						Q'ty			
E-14-10 14 HZY3-90031-000 BOLT, FLANGE, 6X32 1 1 1 -1007152 E-14-10 14 HZZ5-90032-W01 BOLT, FLANGE, 6X32 1 1 1 1002550~ E-14-10 14 HZZ5-90032-W01 BOLT, FLANGE, 6X32 1 1 1002550~ E-14-10 14 HZZ5-90032-W01 BOLT, FLANGE, 6X32 1 1 1002550~ E-14-10 15 HZY4-90156-000 BOLT, FLANGE, 6X32 1 1 1007153~ E-14-10 15 HZY4-90156-000 BOLT, FLANGE, 8X50 7 7 -1002617 E-14-10 15 HZY4-90156-000 BOLT, FLANGE, 8X50 7 7 -1002617 E-14-10 15 HZY4-90156-000 BOLT, FLANGE, 8X50 7 7 -1002617 E-14-10 15 HZY4-90156-000 BOLT, FLANGE, 8X50 7 7 -1002550~ E-14-10 15 HZY4-90200-010 BOLT, FLANGE, 8X50 7 7 1 1002550~ E-14-10 15 HZY4-90200-010 BOLT, FLANGE, 8X50 7 7 1 1002550~ E-14-10 15 HZY4-90200-010 BOLT, FLANGE, 8X50 7 7 1 1002550~ E-14-10 15 HZY4-90200-010 BOLT, FLANGE, 8X50 7 7 1002153~ E-14-10 15 HZY3-90200-010 BOLT, FLANGE, 8X50 7 7 10025550~ E-14-10 15 HZY3-90200-010 BOLT, FLANGE, 8X50 7 7 10025556 E-14-10 15 HZY3-90200-010 BOLT, FLANGE, 8XM 2 1 10025557~ E-14-10 15 HZY3-90200-010 BOLT, FLANGE, 8XM 2 1 10025557~ E-14-10 16 HZY3-90200-010 NUT, FLANGE, 8XM 2 1 1002556 E-14-10 16 HZY3-90200-010 NUT, FLANGE, 8XM 2 1 10025647~ E-14-10 16 HZY3-90200-010 NUT, FLANGE, 8XM 2 1 10025647~ E-14-10 17 HZZ5-90301-000 NUT, FLANGE, 8XM 1 1 -1002648 E-14-10 17 HZZ5-90301-000 NUT, FLANGE, 8XM 1 1 -1002649 E-14-10 17 HZZ5-90301-000 NUT, FLANGE, 8XM 1 1 -10026567 E-14-10 17 HZZ5-90301-000 NUT, FLANGE, 8XM 1 1 -1002617 E-14-10 17 HZZ5-90301-000 NUT, FLANGE, 8XM 1 1 -1002618~ E-14-10 18 HZZ5-90301-000 NUT, FLANGE, 8XM 1 1 -1003153~ E-14-10 18 HZZ5-90301-000 NUT, FLANGE, 8XM 1 1 -1003153~ E-14-10 18 HZZ5-90501-000 NUT, FLANGE, 8XM 1 1 -1003040~ E-14-10 18 HZZ5-90501-000 NUSHER, FLAIN, 8XM 1 1 -1003041~	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks	
E-14-10 14 HZZ5-90032-M01 BOLT, FLANGE, 6X32 1 1 1002550~ E-14-10 14 HZZ5-90032-M01 BOLT, FLANGE, 6X32 1 1 1002618~ E-14-10 14 HZZ5-90032-M01 BOLT, FLANGE, 6X32 1 1 1007153~ E-14-10 15 HZM2-90156-000 BOLT, FLANGE, 8X50 7 7 ~ 1002549 E-14-10 15 HZM2-90156-000 BOLT, FLANGE, 8X50 7 7 ~ 1002617 E-14-10 15 HZM2-90156-000 BOLT, FLANGE, 8X50 7 7 ~ 1002550~ E-14-10 15 HZM2-90156-000 BOLT, FLANGE, 8X50 7 7 1002550~ E-14-10 15 HZM2-90020-010 BOLT, FLANGE, 8X50 7 7 1002550~ E-14-10 15 HZM2-90020-010 BOLT, FLANGE, 8X50 7 7 1002550~ E-14-10 15 HZM2-90020-010 BOLT, FLANGE, 8X50 7 7 1002550~ E-14-10 15 HZM2-90020-010 BOLT, FLANGE, 8X50 7 7 1002550~ E-14-10 16 HZM3-90205-000 NUT, FLANGE, 8X50 7 7 1002555~ E-14-10 16 HZM3-90205-000 NUT, FLANGE, 8XM 2 1 1025557~ E-14-10 16 HZM3-90205-000 NUT, FLANGE, 8XM 2 1 1025557~ E-14-10 16 HZM3-90205-000 NUT, FLANGE, 8XM 2 1 1002641~ E-14-10 16 HZM3-90205-000 NUT, FLANGE, 8XM 2 1 1002647~ E-14-10 16 HZM3-90205-000 NUT, FLANGE, 8XM 2 1 1002647~ E-14-10 16 HZM3-90205-000 NUT, FLANGE, 8XM 2 2 1002646 1 1002647~ E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, 8XM 1 1 ~ 1007289 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	E-14-10	14	HZY3-90031-000	BOLT, FLANGE, 6X32		1		~1002617	
E-14-10 14 HZZ5-9003Z-N01 BBUT, FLANGE, 6X3Z 1 1 1002618~ E-14-10 14 HZZ5-9003Z-N01 BBUT, FLANGE, 6X3Z 1 1 1007153~ E-14-10 15 HZN4-90156-000 BBUT, FLANGE, 8X50 7 7 ~ 1002549 E-14-10 15 HZN4-90156-000 BBUT, FLANGE, 8X50 7 7 ~ 1002617 E-14-10 15 HZN4-90156-000 BBUT, FLANGE, 8X50 7 7 ~ 1002617 E-14-10 15 HZN4-90156-000 BBUT, FLANGE, 8X50 7 7 ~ 1002617 E-14-10 15 HZN4-90156-000 BBUT, FLANGE, 8X50 7 7 1002616~ E-14-10 15 HZN4-90106-001 BBUT, FLANGE, 8X50 7 7 1002616~ E-14-10 15 HZN4-90020-010 BBUT, FLANGE, 8X50 7 7 1002616~ E-14-10 15 HZN4-90020-010 BBUT, FLANGE, 8X50 7 7 1002616~ E-14-10 16 HZN3-90205-000 NUT, FLANGE, 8X50 7 7 1002556~ E-14-10 16 HZN3-90205-000 NUT, FLANGE, 8WM 2 1002557~ E-14-10 16 HZN3-90205-000 NUT, FLANGE, 8WM 2 1002557~ E-14-10 16 HZN3-90205-000 NUT, FLANGE, 8WM 2 1002646 E-14-10 16 HZN3-90205-000 NUT, FLANGE, 8WM 2 1002647~ E-14-10 16 HZN3-90205-000 NUT, FLANGE, 8WM 2 1002647~ E-14-10 16 HZN3-90205-000 NUT, FLANGE, 8WM 2 1002647~ E-14-10 17 HZZ5-90301-NU NUT, FLANGE, 8WM 1 2 1002647~ E-14-10 17 HZZ5-90301-NU NUT, FLANGE, 8WM 1 2 1002649 E-14-10 17 HZZ5-90301-NU NUT, FLANGE, 8WM 1 1 ~ 1002617 E-14-10 17 HZZ5-90301-NU NUT, FLANGE, 5WM 1 1 ~ 1002550~ E-14-10 17 HZZ5-90301-NU NUT, FLANGE, 5WM 1 1 1002650~ E-14-10 17 HZZ5-90301-NU NUT, FLANGE, 5WM 1 1 ~ 1002550~ E-14-10 18 HZZ5-90301-NU NUT, FLANGE, 5WM 1 1 ~ 1002618~ E-14-10 18 HZZ5-90301-NU NUT, FLANGE, 5WM 1 1 ~ 1002618~ E-14-10 18 HZZ5-90501-NU NUT, FLANGE, 5WM 1 1 ~ 1002618~ E-14-10 18 HZZ5-90501-NU NUT, FLANGE, 5WM 1 1 ~ 1003040 E-14-10 18 HZZ5-90501-NU NUT, FLANGE, 5WM 1 1 ~ 1003040 E-14-10 18 HZZ5-90501-NU NUT, FLANGE, 5WM 1 1 ~ 1003040 E-14-10 18 HZZ5-90501-NU NUT, FLANGE, 5WM 1 1 ~ 1003041~	E-14-10	14	HZY3-90031-000	BOLT, FLANGE, 6X32			1	~1007152	
E-14-10 14 HZZ5-9003Z-NO1 BOLT, FLANGE, 6X32 1 1 1007153~ E-14-10 15 HZN4-90156-000 BOLT, FLANGE, 6X50 7 1 -1002549 E-14-10 15 HZN4-90156-000 BOLT, FLANGE, 8X50 7 7 -1002617 E-14-10 15 HZN4-90156-000 BOLT, FLANGE, 8X50 7 7 -1002617 E-14-10 15 HZV4-90020-010 BOLT, FLANGE, 8X50 7 7 1002618~ E-14-10 15 HZV4-90020-010 BOLT, FLANGE, 8X50 7 7 1002618~ E-14-10 15 HZV4-90020-010 BOLT, FLANGE, 8X50 7 7 1002556~ E-14-10 15 HZV4-90020-010 BOLT, FLANGE, 8X50 7 7 1007153~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8X50 7 7 1007553~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 1 1002557~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 1 1002557~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 2 1002646~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 2 1002647~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 2 1002647~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 2 1002647~ E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, 8MM 2 2 1007289 E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, 8MM 1 2 1002550~ E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, 8MM 1 1 -1002549 E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, SMM 1 1 -1002560~ E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, SMM 1 1 1 007152 E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, SMM 1 1 1 002618~ E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, SMM 1 1 1 007153~ E-14-10 18 HZZ5-90301-N00 NUT, FLANGE, SMM 1 1 1 007153~ E-14-10 18 HZZ5-90301-N00 NUT, FLANGE, SMM 1 1 -1002640 E-14-10 18 HZZ5-90501-N00 NUT, FLANGE, SMM 1 1 -1003040 E-14-10 18 HZZ5-90501-N00 NUSHER, PLAIN, SMM 1 1 -1003040 E-14-10 18 HZZ5-90501-N00 NUSHER, PLAIN, SMM 1 1 -1003040 E-14-10 18 HZZ5-90501-N00 NUSHER, PLAIN, SMM 1 1 -1003040	E-14-10	14	HZZ5-90032-M01	BOLT, FLANGE, 6X32	1			1002550~	
E-14-10 15 HZW4-90156-000 BOLT, FLANGE, 8X50 7 7 ~1002549 E-14-10 15 HZW4-90156-000 BOLT, FLANGE, 8X50 7 7 ~1002617 E-14-10 15 HZW4-90156-000 BOLT, FLANGE, 8X50 7 7 ~1002550~ E-14-10 15 HZW4-90156-000 BOLT, FLANGE, 8X50 7 7 1002550~ E-14-10 15 HZW4-9020-010 BOLT, FLANGE, 8X50 7 7 1002580~ E-14-10 15 HZW4-9020-010 BOLT, FLANGE, 8X50 7 7 1002618~ E-14-10 15 HZW4-9020-010 BOLT, FLANGE, 8X50 7 7 1002656~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8X50 7 7 1002556~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 1 1002557~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 2 1002646~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 2 1002646~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 2 1002647~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 2 1002647~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 2 1002647~ E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, 8MM 1 2 1002549 E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, 8MM 1 1 ~1002549 E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, SMM 1 1 ~1002549 E-14-10 17 HZZ5-90301-N00 NUT, FLANGE, SMM 1 1 ~1002550~ E-14-10 17 HZZ5-90301-N01 NUT, FLANGE, SMM 1 1 ~1002550~ E-14-10 17 HZZ5-90301-N01 NUT, FLANGE, SMM 1 1 ~1002550~ E-14-10 17 HZZ5-90301-N01 NUT, FLANGE, SMM 1 1 ~1002550~ E-14-10 17 HZZ5-90301-N01 NUT, FLANGE, SMM 1 1 ~1002550~ E-14-10 18 HZZ5-90301-N01 NUT, FLANGE, SMM 1 1 ~1002550~ E-14-10 18 HZZ5-90301-N01 NUT, FLANGE, SMM 1 1 ~1002550~ E-14-10 18 HZZ5-90301-N01 NUT, FLANGE, SMM 1 1 ~1002550~ E-14-10 18 HZZ5-90501-N00 WASHER, PLAIN, SMM 1 1 ~1003040 E-14-10 18 HZZ5-90501-N00 WASHER, PLAIN, SMM 1 1 ~1003040 E-14-10 18 HZZ5-90501-N01 WASHER, PLAIN, SMM 1 1 ~1003040	E-14-10	14	HZZ5-90032-M01	BOLT, FLANGE, 6X32		1		1002618~	
E-14-10 15 HZW4-90156-000 BOLT, FLANGE, 8X50 7 7 ~1002617 E-14-10 15 HZW4-90156-000 BOLT, FLANGE, 8X50 7 7 ~10027152 E-14-10 15 HZWL-90020-010 BOLT, FLANGE, 8X50 7 1 1002650~ E-14-10 15 HZVL-90020-010 BOLT, FLANGE, 8X50 7 1 1002618~ E-14-10 15 HZVL-90020-010 BOLT, FLANGE, 8X50 7 1 1002618~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8X50 7 1 1002656 E-14-10 16 HZY3-90205-M01 NUT, FLANGE, BIMM 2 1 1002557~ E-14-10 16 HZY3-90205-M01 NUT, FLANGE, BIMM 2 1 1002646 E-14-10 16 HZY3-90205-M01 NUT, FLANGE, BIMM 2 2 1002647~ E-14-10 16 HZY3-90205-M01 NUT, FLANGE, BIMM 2 2 1002647~ E-14-10 16 HZY3-90205-M01 NUT, FLANGE, BIMM 2 2 1002647~ E-14-10 16 HZY3-90205-M01 NUT, FLANGE, BIMM 2 2 1007290~ E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, SIMM 1 2 10072590~ E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, SIMM 1 1 ~1002617 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SIMM 1 1 ~1002617 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SIMM 1 1 1002650~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SIMM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SIMM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SIMM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SIMM 1 1 1002618~ E-14-10 18 HZZ5-90501-M01 NUT, FLANGE, SIMM 1 1 1002618~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, SIMM 1 1 ~1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, SIMM 1 1 ~1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, SIMM 1 1 1003127~	E-14-10	14	HZZ5-90032-M01	BOLT, FLANGE, 6X32			1	1007153~	
E-14-10 15 HZW4-90156-000 BOLT, FLANGE, 8X50 7 ~ ~1007152 E-14-10 15 HZVL-90020-010 BOLT, FLANGE, 8X50 7 1002550~ E-14-10 15 HZVL-90020-010 BOLT, FLANGE, 8X50 7 1002618~ E-14-10 15 HZVL-90020-010 BOLT, FLANGE, 8X50 7 1007153~ E-14-10 15 HZVL-90020-010 BOLT, FLANGE, 8X50 7 1007153~ E-14-10 16 HZY3-90205-000 MUT, FLANGE, BMM 2 1002557~ E-14-10 16 HZY9-90205-M01 NUT, FLANGE, BMM 2 1002646 E-14-10 16 HZY9-90205-M01 NUT, FLANGE, BMM 2 1002647~ E-14-10 16 HZY9-90205-M01 NUT, FLANGE, BMM 2 2 1002647~ E-14-10 16 HZY9-90205-M01 NUT, FLANGE, BMM 2 2 1007290~ E-14-10 16 HZY9-90205-M01 NUT, FLANGE, BMM 2 2 1007290~ E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, BMM 1 2 1007290~ E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, SMM 1 1 ~1002549 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 ~1002617 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 ~1007152 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 ~1007152 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 ~1007153~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 ~1007153~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 ~1007153~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, SMM 1 1 ~1003126 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, SMM 1 1 ~1003041~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, SMM 1 1 ~1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, SMM 1 1 ~1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, SMM 1 1 ~1003127~	E-14-10	15	HZW4-90156-000	BOLT, FLANGE, 8X50	7			~1002549	
E-14-10 15 HZVL-90020-010 BOLT, FLANGE, 8X50 7 1002550~ E-14-10 15 HZVL-90020-010 BOLT, FLANGE, 8X50 7 1002618~ E-14-10 15 HZVL-90020-010 BOLT, FLANGE, 8X50 7 1007153~ E-14-10 16 HZY3-90205-000 NJT, FLANGE, 8MM 2 1002556 E-14-10 16 HZY3-90205-M01 NJT, FLANGE, 8MM 2 1002557~ E-14-10 16 HZY3-90205-M01 NJT, FLANGE, 8MM 2 1002646 E-14-10 16 HZY3-90205-M01 NJT, FLANGE, 8MM 2 1002647~ E-14-10 16 HZY3-90205-M01 NJT, FLANGE, 8MM 2 1002647~ E-14-10 16 HZY3-90205-M01 NJT, FLANGE, 8MM 2 1002647~ E-14-10 16 HZY3-90205-M01 NJT, FLANGE, 8MM 2 10002647~ E-14-10 16 HZY3-90205-M01 NJT, FLANGE, 8MM 2 10002647~ E-14-10 17 HZZ5-90301-M00 NJT, FLANGE, 8MM 2 10002649 E-14-10 17 HZZ5-90301-M00 NJT, FLANGE, 5MM 1 1 ~1002549 E-14-10 17 HZZ5-90301-M00 NJT, FLANGE, 5MM 1 1 ~1002550~ E-14-10 17 HZZ5-90301-M01 NJT, FLANGE, 5MM 1 1 1002550~ E-14-10 17 HZZ5-90301-M01 NJT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NJT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NJT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NJT, FLANGE, 5MM 1 1 1002618~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~1003127~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~1003041~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 ~1003041~	E-14-10	15	HZW4-90156-000	BOLT, FLANGE, 8X50		7		~1002617	
E-14-10 15 H2VL-90020-010 B0LT, FLANGE, 8X50 7 1002618~ E-14-10 15 H2VL-90020-010 B0LT, FLANGE, 8X50 7 1007153~ E-14-10 16 H2Y3-90205-000 NUT, FLANGE, 8MM 2 1002556 E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 1002557~ E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 1002557~ E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 1002646 E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 1002647~ E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 1007289 E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 1007289 E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 8MM 1 2 1007290~ E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 5MM 1 1 ~1002549 E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 5MM 1 1 ~1002550~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002550~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002550~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002550~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002550~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002550~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 10025618~ E-14-10 18 HZZ5-90501-M00 NASHER, PLAIN, 5MM 1 1 ~1003040 E-14-10 18 HZZ5-90501-M00 NASHER, PLAIN, 5MM 1 1 ~1003041~ E-14-10 18 HZZ5-90501-M01 NASHER, PLAIN, 5MM 1 1 1003041~	E-14-10	15	HZW4-90156-000	BOLT, FLANGE, 8X50			7	~1007152	
E-14-10 15 H2VL-90020-010 B0LT, FLANGE, 8X50 7 1007153~ E-14-10 16 H2Y3-90205-000 NUT, FLANGE, 8MM 2 1 1002556 E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 1 1002557~ E-14-10 16 H2Y3-90205-000 NUT, FLANGE, 8MM 2 1 1002646 E-14-10 16 H2Y3-90205-000 NUT, FLANGE, 8MM 2 1 1002647~ E-14-10 16 H2Y3-90205-000 NUT, FLANGE, 8MM 2 1 1002647~ E-14-10 16 H2Y3-90205-000 NUT, FLANGE, 8MM 2 2 1007289 E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 2 1007290~ E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 8MM 1 2 1002549 E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 5MM 1 1 ~1002549 E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 5MM 1 1 ~1002550~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002550~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002550~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 18 H2Z5-90501-M00 NASHER, PLAIN, 5MM 1 1 ~1003126 E-14-10 18 H2Z5-90501-M00 NASHER, PLAIN, 5MM 1 1 ~1003041~ E-14-10 18 HZZ5-90501-M01 NASHER, PLAIN, 5MM 1 1 1003041~	E-14-10	15	HZVL-90020-010	BOLT, FLANGE, 8X50	7			1002550~	
E-14-10 16 HZY3-90205-000 NUT, FLANGE, SMM 2 1002556 E-14-10 16 HZY9-90205-M01 NUT, FLANGE, SMM 2 1002646 E-14-10 16 HZY9-90205-M01 NUT, FLANGE, SMM 2 1002647∼ E-14-10 16 HZY9-90205-M01 NUT, FLANGE, SMM 2 2 ~1007289 E-14-10 16 HZY9-90205-M01 NUT, FLANGE, SMM 2 2 ~1007289 E-14-10 16 HZY9-90205-M01 NUT, FLANGE, SMM 2 2 ~1007290∼ E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, SMM 1 ~1002549 E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, SMM 1 ~1002617 E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, SMM 1 1 ~1002617 E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, SMM 1 1 ~1002550∼ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 1002550∼ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 1002618∼ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 1002618∼ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, SMM 1 1 ~1003126 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, SMM 1 1 ~1003127∼ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, SMM 1 1 ~1003127∼ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, SMM 1 1 ~1003127∼ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, SMM 1 1 ~1003127∼	E-14-10	15	HZVL-90020-010	BOLT, FLANGE, 8X50		7		1002618~	
E-14-10 16 HZY9-90205-M01 NUT, FLANGE, 8MM 2 1002557~ E-14-10 16 HZY3-90205-000 NUT, FLANGE, 8MM 2 1002646 E-14-10 16 HZY9-90205-M01 NUT, FLANGE, 8MM 2 1002647~ E-14-10 16 HZY9-90205-M01 NUT, FLANGE, 8MM 2 1002647~ E-14-10 16 HZY9-90205-M01 NUT, FLANGE, 8MM 2 1007289 E-14-10 16 HZY9-90205-M01 NUT, FLANGE, 8MM 2 1007290~ E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, 5MM 1 ~ ~1002549 E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, 5MM 1 ~ ~1002617 E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, 5MM 1 1 ~ ~1007152 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1002650~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~ ~1003126 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~ ~1003040 E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 ~ ~1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003127~	E-14-10	15	HZVL-90020-010	BOLT, FLANGE, 8X50			7	1007153~	
E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 2 ~1002646 E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 2 1002647~ E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 2 ~1007289 E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 2 1007290~ E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 8MM 1 ~1002549 E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 5MM 1 ~1002617 E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 5MM 1 ~1002617 E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 5MM 1 1 ~1002617 E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002650~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 18 H2Z5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~1003126 E-14-10 18 H2Z5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~1003127~ E-14-10 18 H2Z5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003127~ E-14-10 18 H2Z5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003127~	E-14-10	16	HZY3-90205-000	NUT, FLANGE, 8MM	2			~1002556	
E-14-10 16 HZY9-90205-M01 NUT, FLANGE, 8MM 2 1002647~ E-14-10 16 HZY9-90205-M01 NUT, FLANGE, 8MM 2 1007289 E-14-10 16 HZY9-90205-M01 NUT, FLANGE, 8MM 2 1007290~ E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, 5MM 1 ~ ~1002549 E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, 5MM 1 ~ ~1002617 E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, 5MM 1 ~ ~1007152 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 ~ 1002550~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1007153~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~ ~1003126 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~ ~1003040 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~ ~1003027~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003041~	E-14-10	16	HZY9-90205-M01	NUT, FLANGE, 8MM	2			1002557~	
E-14-10 16 H2Y3-90205-000 NUT, FLANGE, 8MM 2 2 ~1007289 E-14-10 16 H2Y3-90205-M01 NUT, FLANGE, 8MM 2 2 1007290~ E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 5MM 1 ~1002617 E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 5MM 1 ~1002617 E-14-10 17 H2Z5-90301-M00 NUT, FLANGE, 5MM 1 ~1007152 E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 ~1002650~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 H2Z5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1007153~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 ~1003126 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~1003040 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~1003047~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003041~	E-14-10	16	HZY3-90205-000	NUT, FLANGE, 8MM		2		~1002646	
E-14-10 16 HZY9-90205-M01 NUT, FLANGE, SMM 2 1007290~ E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, SMM 1 ~1002549 E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, SMM 1 ~1002617 E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, SMM 1 ~1002617 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 ~1007152 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, SMM 1 1 1007153~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, SMM 1 ~1003126 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, SMM 1 ~1003040 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, SMM 1 ~1003834 E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, SMM 1 1 ~1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, SMM 1 1 1003041~	E-14-10	16	HZY9-90205-M01	NUT, FLANGE, 8MM		2		1002647~	
E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, 5MM 1	E-14-10	16	HZY3-90205-000	NUT, FLANGE, 8MM			2	~1007289	
E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, 5MM 1 \(\timess{1} \) \(1	E-14-10	16	HZY9-90205-M01	NUT, FLANGE, 8MM			2	1007290~	
E-14-10 17 HZZ5-90301-M00 NUT, FLANGE, 5MM 1 1 ~1007152 E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1002550~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1007153~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~1003126 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~1003040 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ~1008834 E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003041~	E-14-10	17	HZZ5-90301-M00	NUT, FLANGE, 5MM	1			~1002549	
E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1002550∼ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618∼ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1007153∼ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ∼1003126 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ∼1003040 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 1 ∼1008834 E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003127∼ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003041∼	E-14-10	17	HZZ5-90301-M00	NUT, FLANGE, 5MM		1		~1002617	
E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1002618~ E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1 1007153~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 ~1003126 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 ~1003040 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 ~1003834 E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1 1003041~	E-14-10	17	HZZ5-90301-M00	NUT, FLANGE, 5MM			1	~1007152	
E-14-10 17 HZZ5-90301-M01 NUT, FLANGE, 5MM 1 1007153~ E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 ~1003126 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 ~1003040 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 ~1008834 E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1003041~	E-14-10	17	HZZ5-90301-M01	NUT, FLANGE, 5MM	1			1002550~	
E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1	E-14-10	17	HZZ5-90301-M01	NUT, FLANGE, 5MM		1		1002618~	
E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 ~1003040 E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 ~1008834 E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1003041~	E-14-10	17	HZZ5-90301-M01	NUT, FLANGE, 5MM			1	1007153~	
E-14-10 18 HZZ5-90501-M00 WASHER, PLAIN, 5MM 1 ~1008834 E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1003041~	E-14-10	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM	1			~1003126	
E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1003127~ E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1003041~	E-14-10	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM		1		~1003040	
E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1003041~	E-14-10	18	HZZ5-90501-M00	WASHER, PLAIN, 5MM			1	~1008834	
	E-14-10	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM	1			1003127~	
E-14-10 18 HZZ5-90501-M01 WASHER, PLAIN, 5MM 1 1008835~	E-14-10	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM		1		1003041~	
	E-14-10	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM			1	1008835~	

E-15 THROTTLE BODY




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-15	1	HZY3-16016-003	SCREW SET	1	1	1	LRA, UCRA, URA, XCRA, XRA
E-15	2	HZY3-16176-000	GASKET, THROTTLE BODY	1	1	1	LRA, UCRA, URA, XCRA, XRA
E-15	3	HZVK-16400-003	THROTTLE BODY ASSY.	1			~1004454
E-15	3	HZVK-16400-003	THROTTLE BODY ASSY.		1		~1004482
E-15	3	HZVK-16400-013	THROTTLE BODY ASSY.	1			1004455~1005212
E-15	3	HZVK-16400-023	THROTTLE BODY ASSY.	1			1005213~
E-15	3	HZVK-16400-023	THROTTLE BODY ASSY.		1		1004483~
E-15	3	HZY3-16400-A01	THROTTLE BODY ASSY.			1	~1014098 LRA, UCRA, URA, XCRA, XRA
E-15	3	HZY3-16400-A02	THROTTLE BODY ASSY.			1	1014099~1014025 LRA, UCRA, URA, XCRA, XRA
E-15	3	HZY3-16400-A03	THROTTLE BODY ASSY.			1	1014026~ LRA, UCRA, URA, XCRA, XRA
E-15	4	HZX2-16404-000	SPACER, THROTTLE BODY	1	1	1	LRA, UCRA, URA, XCRA, XRA
E-15	5	HZY3-16405-000	GASKET, EAC VALVE	1	1	1	LRA, UCRA, URA, XCRA, XRA
E-15	6	HPY3-17249-000	SPRING, AIR FLOW TUBE	1	1	1	
E-15	7	HZY9-17315-M01	BAND, AIR FLOW	1	1	1	
E-15	8	HZX2-17374-000	GROMMET, SILENCER	1	1	1	
E-15	9	HZVL-17910-003	CABLE COMP., THROTTLE	2	2	2	LRA, UCRA, URA, XCRA, XRA
E-15	10	HZVL-19540-010	COVER ASSY., COOLING FAN	1	1	1	
E-15	11	HZW5-35665-003	SENSOR ASSY., AIR TEMPERATURE	1	1	1	
E-15	12	HZY3-36550-003	VALVE ASSY., EAC	1	1	1	LRA, UCRA, URA, XCRA, XRA
E-15	13	HZV5-40102-000	GROMMET, UNDER CASE	4	4	4	
E-15	14	HS0X-46392-A01	CLIP, BRAKE PIPE	2	2	2	LRA, UCRA, URA, XCRA, XRA
E-15	15	HZZ5-90013-M00	BOLT-WASHER, 6X25	2			~1002549
E-15	15	HZZ5-90013-M00	BOLT-WASHER, 6X25		2		~1002617
E-15	15	HZZ5-90013-M00	BOLT-WASHER, 6X25			2	~1007152
E-15	15	HZZ5-90013-M01	BOLT-WASHER, 6X25	2			1002550~
E-15	15	HZZ5-90013-M01	BOLT-WASHER, 6X25		2		1002618~
E-15	15	HZZ5-90013-M01	BOLT-WASHER, 6X25			2	1007153~
E-15	16	HZZ5-90030-M01	BOLT, FLANGE, 6X22	2	2	2	LRA, UCRA, URA, XCRA, XRA
E-15	17	HZVL-90037-010	BOLT, FLANGE, 8X65	4	4	4	LRA, UCRA, URA, XCRA, XRA


E-15 THROTTLE BODY




					Q' ty		
Ref. No		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-15	18	HZVL-90072-010	BOLT-WASHER, 6X60	2	2	2	LRA, UCRA, URA, XCRA, XRA
E-15	19	HP0A-91303-A02	0-RING	1	1	1	
E-15	20	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE	4			~1002629
E-15	20	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE		4		~1002620
E-15	20	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE			4	~1007870
E-15	20	HZVL-91551-000	COLLAR, C.D.I. UNIT CASE	4			1002630~
E-15	20	HZVL-91551-000	COLLAR, C.D.I. UNIT CASE		4		1002621~
E-15	20	HZVL-91551-000	COLLAR, C.D.I. UNIT CASE			4	1007871~
E-15	21	HCO-94301-06100	DOWEL PIN, 6X10	2	2	2	LRA, UCRA, URA, XCRA, XRA
E-15	22	HZVL-16176-003	GASKET, THROTTLE BODY			1	LDA, UCDA, UDA, XCDA, XDA
E-15	23	HZVL-16400-003	THROTTLE BODY, ELECTRONIC			1	CONTROL LDA, UCDA, UDA, XCDA, XDA
E-15	24	HZVL-16404-000	SPACER, THROTTLE BODY			1	LDA, UCDA, UDA, XCDA, XDA
E-15	25	HZVL-16406-000	GUARD, THROTTLE BODY			1	LDA, UCDA, UDA, XCDA, XDA
E-15	26	HZVL-90010-000	BOLT, FLANGE, 8X55			4	~1007152 LDA, UCDA, UDA, XCDA, XDA
E-15	26	HZVL-90010-010	BOLT, FLANGE, 8X55			4	1007153~ LDA, UCDA, UDA, XCDA, XDA
E-15	27	HZVL-90012-000	BOLT, SOCKET, 8X25			4	~1007152 LDA, UCDA, UDA, XCDA, XDA
E-15	27	HZVL-90012-010	BOLT, SOCKET, 8X25			4	1007153~ LDA, UCDA, UDA, XCDA, XDA
E-15	28	HZZ5-90021-M00	BOLT, FLANGE, 6X14			1	~1007289 LDA, UCDA, UDA, XCDA, XDA
E-15	28	HZZ5-90021-M01	BOLT, FLANGE, 6X14			1	1007290~ LDA, UCDA, UDA, XCDA, XDA
E-15	29	HZVL-90034-010	BOLT, FLANGE, 6X60			2	LDA, UCDA, UDA, XCDA, XDA
E-15	30	HCO-94301-06100	DOWEL PIN, 6X10			2	LDA, UCDA, UDA, XCDA, XDA
-							
-							




	Q' ty				Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-18	1	HZY3-16011-A01	VALVE SET, FLOAT	1	1	1	
E-18	2	HZY3-16013-000	FLOAT SET	1	1	1	
E-18	3	HZVL-16015-000	BODY	1	1	1	
E-18	4	HZVL-16020-003	COVER COMP.	1	1	1	
E-18	5	HZY3-16024-000	SCREW SET, DRAIN	1	1	1	
E-18	6	HZY3-16026-000	JOINT SET	1	1	1	
E-18	7	HZVL-16030-003	PUMP UNIT SET A, FUEL	1	1	1	
E-18	8	HZY3-16031-010	STAY, PLATE	1			~1004616
E-18	8	HZY3-16031-010	STAY, PLATE		1		~1004092
E-18	8	HZY3-16031-010	STAY, PLATE			1	~1012174
E-18	8	HZY3-16031-020	STAY, PLATE	1			1004617~
E-18	8	HZY3-16031-020	STAY, PLATE		1		1004093~
E-18	8	HZY3-16031-020	STAY, PLATE			1	1012175~
E-18	9	HZY3-16036-003	PUMP UNIT SET B, FUEL	1	1	1	
E-18	10	HZY3-16041-000	PLATE	1	1	1	
E-18	11	HZY3-16042-000	HOLDER	1	1	1	
E-18	12	HZY3-16061-010	COVER, WATER JACKET	1	1	1	
E-18	13	HZY3-16072-000	0-RING	1	1	1	
E-18	14	HZY3-16073-000	O-RING	1	1	1	
E-18	15	HZY3-16074-000	O-RING	1	1	1	
E-18	16	HZY3-16075-000	O-RING	1	1	1	
E-18	17	HZY3-16076-000	O-RING	1	1	1	
E-18	18	HZY3-16077-000	O-RING	2	2	2	
E-18	19	HZY3-16078-000	O-RING	1	1	1	
E-18	20	HZW5-16081-010	SCREW-WASHER	21	21	21	
E-18	21	HZY3-16082-000	SCREW, PAN	2	2	2	
E-18	22	HZY3-16083-000	SCREW, WASHER	1	1	1	
E-18	23	HZW5-16086-000	COLLAR, SET	8	8	8	
E-18	24	HZW5-16087-000	WASHER, PLAIN	8	8	8	



					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-18	25	HZY3-16087-000	WASHER, PLAIN	1	1	1	
E-18	26	HZY3-16088-000	COLLAR	1	1	1	
E-18	27	HZVL-16700-003	PUMP ASSY., FUEL	1	1	1	
E-18	28	HZX2-16701-003	CASE COMP., PUMP	1	1	1	
E-18	29	HZY3-16708-000	COVER, PUMP	1	1	1	
E-18	30	HZVL-16710-000	RUBBER, FUEL PUMP	2	2	2	
E-18	31	HZW5-16715-023	COVER, PUMP (A)	1	1	1	
E-18	32	HZY6-16718-013	INSULATOR COMP.	1	1	1	
E-18	33	HZY3-16721-000	INSULATOR	1	1	1	
E-18	34	HZY6-16723-003	RING	1	1	1	
E-18	35	HZVL-16725-000	STAY COMP. A, FUEL PUMP	1	1	1	
E-18	36	HZVL-16726-000	STAY COMP. B, FUEL PUMP	1	1	1	
E-18	37	HZVL-16730-023	SEPARATOR ASSY., VAPOR	1			~1004478
E-18	37	HZVL-16730-023	SEPARATOR ASSY., VAPOR		1		~1003857
E-18	37	HZVL-16730-023	SEPARATOR ASSY., VAPOR			1	~1011828
E-18	37	HZVL-16730-033	SEPARATOR ASSY., VAPOR	1			1004479~1004616
E-18	37	HZVL-16730-033	SEPARATOR ASSY., VAPOR		1		1003858~1004092
E-18	37	HZVL-16730-033	SEPARATOR ASSY., VAPOR			1	1011829~1012174
E-18	37	HZVL-16730-043	SEPARATOR ASSY., VAPOR	1			1004617~
E-18	37	HZVL-16730-043	SEPARATOR ASSY., VAPOR		1		1004093~
E-18	37	HZVL-16730-043	SEPARATOR ASSY., VAPOR			1	1012175~
E-18	38	HZW5-16733-000	GROMMET, VAPOR SEPARATOR	1	1	1	
E-18	39	HZY3-16733-000	GROMMET, VAPOR SEPARATOR	2	2	2	
E-18	40	HZY3-16734-000	STAY, PLATE	1	1	1	
E-18	41	HZY3-16735-004	PUMP UNIT, FUEL	1	1	1	
E-18	42	HZY3-16752-000	JOINT, FUEL PIPE	1	1	1	
E-18	43	HZX2-32166-003	HARNESS COMP.	1	1	1	
E-18	44	HZW5-32168-003	BAND	1	1	1	
E-18	45	HPP4-90009-E01	BOLT, SEALING, 6MM	1	1	1	




Ref. No.	Part No.					
		Description	BFT200D	BFT225D	BFT250D	Remarks
E-18 46	HZY9-90014-M01	BOLT-WASHER, 8X35	3	3	3	
E-18 47	HZZ5-90014-M00	BOLT, FLANGE, 6X25	2			~1004478
E-18 47	7 HZZ5-90014-M00	BOLT, FLANGE, 6X25		2		~1003857
E-18 47	HZZ5-90014-M00	BOLT, FLANGE, 6X25			2	~1011828
E-18 47	7 HZZ5-90014-M01	BOLT, FLANGE, 6X25	2			1004479~
E-18 47	7 HZZ5-90014-M01	BOLT, FLANGE, 6X25		2		1003858~
E-18 47	7 HZZ5-90014-M01	BOLT, FLANGE, 6X25			2	1011829~
E-18 48	HZZ5-90016-M00	BOLT, FLANGE, 6X28	2			~1004478
E-18 48	HZZ5-90016-M00	BOLT, FLANGE, 6X28		2		~1003857
E-18 48	HZZ5-90016-M00	BOLT, FLANGE, 6X28			2	~1011828
E-18 48	HZZ5-90016-M01	BOLT, FLANGE, 6X28	2			1004479~
E-18 48	HZZ5-90016-M01	BOLT, FLANGE, 6X28		2		1003858~
E-18 48	HZZ5-90016-M01	BOLT, FLANGE, 6X28			2	1011829~
E-18 49	HZZ5-90017-M00	BOLT, FLANGE, 6X16	2			~1004478
E-18 49	HZZ5-90017-M00	BOLT, FLANGE, 6X16		2		~1003857
E-18 49	HZZ5-90017-M00	BOLT, FLANGE, 6X16			2	~1011828
E-18 49	HZZ5-90017-M01	BOLT, FLANGE, 6X16	2			1004479~
E-18 49	HZZ5-90017-M01	BOLT, FLANGE, 6X16		2		1003858~
E-18 49	HZZ5-90017-M01	BOLT, FLANGE, 6X16			2	1011829~
E-18 50	HZZ5-90021-M00	BOLT, FLANGE, 6X14	2			~1002570
E-18 50	HZZ5-90021-M00	BOLT, FLANGE, 6X14		2		~1002916
E-18 50	HZZ5-90021-M00	BOLT, FLANGE, 6X14			2	~1007289
E-18 50	HZZ5-90021-M01	BOLT, FLANGE, 6X14	2			1002571~
E-18 50	HZZ5-90021-M01	BOLT, FLANGE, 6X14		2		1002917~
E-18 50	HZZ5-90021-M01	BOLT, FLANGE, 6X14			2	1007290~
E-18 51	HPD6-90430-003	WASHER, SEALING, 6MM	1	1	1	
E-18 52	HZB7-90691-003	CLIP, HARNESS	2	2	2	
E-18 53	HMJ0-91301-003	0-RING, 7.8X1.9(ARAI)	2	2	2	
E-18 54	HZY9-91504-M00	COLLAR, 8. 5X14. 5	3			~1002628




					Q' ty		
Ref. No.	•	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-18	54	HZY9-91504-M00	COLLAR, 8. 5X14. 5		3		~1002916
E-18	54	HZY9-91504-M00	COLLAR, 8.5X14.5			3	~1007539
E-18	54	HZY9-91504-M01	COLLAR, 8. 5X14. 5	3			1002629~
E-18	54	HZY9-91504-M01	COLLAR, 8. 5X14. 5		3		1002917~
E-18	54	HZY9-91504-M01	COLLAR, 8. 5X14. 5			3	1007540~
	Ш						
	Ш						
	Ш						
	Ш						


E-18-1 FUEL STRAINER




Ref. No. E-18-1 1 E-18-1 2 E-18-1 3 E-18-1 4	Part No. HZY3-16818-003 HZVL-16840-A00 HZVL-16841-000	Description O-RING TUBE COMP. A, FUEL	BFT200D ─	BFT225D -	BFT250D	Remarks
E-18-1 2 E-18-1 3	HZVL-16840-A00		1	1		
E-18-1 3	HZVL-16841-000	TUBE COMP. A, FUEL			1	
			1	1	1	
E-18-1 4	117111 10050 100	STAY, FUEL TUBE	1	1	1	
	HZVL-16850-A00	TUBE COMP. B, FUEL	1	1	1	
E-18-1 5	HZY9-16896-003	CLAMP B, FUEL TUBE	5	5	5	
E-18-1 6	HZVL-16900-003	STRAINER ASSY., FUEL (LOW)	1	1	1	
E-18-1 7	HZY3-16901-003	STRAINER, FUEL	1	1	1	
E-18-1 8	HZY3-16904-003	SCREW, PAN, 5X12	3	3	3	
E-18-1 9	HZVL-16914-000	STAY A, FUEL STRAINER	1	1	1	
E-18-1 10	HZY3-16915-010	SUSPENSION, STRAINER	1	1	1	
E-18-1 11	HZY3-16918-003	O-RING	1	1	1	
E-18-1 12	HZY3-16919-003	PLATE	1	1	1	
E-18-1 13	HZY3-17738-000	PLUG, FUEL TUBE	1	1	1	
E-18-1 14	HZZ5-90021-M00	BOLT, FLANGE, 6X14	1			~1002570
E-18-1 14	HZZ5-90021-M00	BOLT, FLANGE, 6X14		1		~1002916
E-18-1 14	HZZ5-90021-M00	BOLT, FLANGE, 6X14			1	~1007289
E-18-1 14	HZZ5-90021-M01	BOLT, FLANGE, 6X14	1			1002571~
E-18-1 14	HZZ5-90021-M01	BOLT, FLANGE, 6X14		1		1002917~
E-18-1 14	HZZ5-90021-M01	BOLT, FLANGE, 6X14			1	1007290~
E-18-1 15	HZZ0-90103-M00	BOLT, FLANGE, 6X10	2			~1002549
E-18-1 15	HZZ0-90103-M00	BOLT, FLANGE, 6X10		2		~1002617
E-18-1 15	HZZ0-90103-M00	BOLT, FLANGE, 6X10			2	~1007152
E-18-1 15	HZZ0-90103-M01	BOLT, FLANGE, 6X10	2			1002550~
E-18-1 15	HZZ0-90103-M01	BOLT, FLANGE, 6X10		2		1002618~
E-18-1 15	HZZ0-90103-M01	BOLT, FLANGE, 6X10			2	1007153~
E-18-1 16	HZV0-90604-000	CLIP, TUBE (B12)	3	3	3	
E-18-1 17	HSTK-91540-003	CLIP, HARNESS BAND (BLACK)	1	1	1	(155. 3MM)
E-18-1 18	HZVL-16805-003	CUP SET, WATER SEPARATER	1	1	1	




Ref. No. Part No. Description ET 2000 ET 2000 ET 2000 Remark E-18-10 1 HZY3-16193-A00 CLAMP, CHECK VALVE 1<	e
E-18-10 2 HZY3-16196-A00 TUBE, CHECK VALVE 1 1 1 1 1	_
E-18-10 3 HZY3-16197-000 TUBE A, AIR VENT 1 1 1 1	
E-18-10 4 HZY3-16198-A00 TUBE B, AIR VENT 1 1 1 1	
E-18-10 5 HZY3-16199-A00 TUBE COMP., AIR VENT 1 1 1 1 E-18-10 6 HRMA-16723-E00 JOINT, FUEL FEED HOSE 1 1 1 1	
E-18-10 6 HRMA-16723-E00 JOINT, FUEL FEED HOSE 1 1 1	
E-18-10 7 HZVL-16760-003 VALVE COMP., RELIEF 1 1 1 1	
E-18-10 8 HZVL-16770-A00 TUBE, RELIEF 1 1 1	
E-18-10 9 HZVL-16860-A00 TUBE COMP. C, FUEL 1 1 1	
E-18-10 10 HZVL-16870-A00 TUBE D, FUEL 1 1 1	
E-18-10 11 HZVL-16875-000 JOINT. THREE WAY 1 1 1	
E-18-10 12 HZVL-16880-A00 TUBE E, FUEL 1 1 1	
E-18-10 13 HZVL-16890-A00 TUBE F, FUEL 1 1 1	
E-18-10 14 H759-16911-003 STRAINER, FUEL PUMP 1 1 1	
E-18-10 15 HZW5-16915-000 SUSPENSION, STRAINER 1 1 1	
E-18-10 16 HVMO-16965-771 CLAMP, HOSE 7 7 7	
E-18-10 17 HZY3-17721-000 JOINT, FUEL RETURN 1 1 1	
E-18-10 18 HZY3-17723-A01 HOSE A, PRESSURE REGULATOR 1 1 1 RETURN	
E-18-10 19 HZY3-17724-010 HOSE B, PRESSURE REGULATOR 1 1 1 RETURN	
E-18-10 20 HZY3-19258-010 TUBE, WATER IN. 1 1 1	
E-18-10 21 HZY3-19259-000 TUBE, WATER OUTLET 1 1 1	
E-18-10 22 HZY6-19269-000 T-J01NT 1 1 1	
E-18-10 23 HZY6-36135-003 VALVE, CHECK 1 1 1 1	
E-18-10 24 HSE0-53740-953 CLIP, SENSOR HOSE 1 1 1 1	
E-18-10 25 HZW5-90601-030 CLAMP, TUBE (D10. 7) 4 4 4	
E-18-10 26 HZY3-90601-030 CLAMP, TUBE (D10. 5) 4 4 4	
E-18-10 27 HZW5-90602-030 CLAMP, TUBE (D12) 2 2 2	
E-18-10 28 HZV0-90604-000 CLIP, TUBE (B12) 8 8 8	
E-18-10 29 HZW5-90652-003 CLAMP, 6MM-12MM 1 1 1	




-					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-18-10	30	HCO-95001-35055-40	TUBE, FUEL, 3.5X55	1	1	1	(HCO-95001-35001-60M)
E-18-10	31	HCO-95003-05060-31	TUBE, VINYL, 3.5X6.5X600	1	1	1	(HCO-95003-05001-60M)
				-			
-							
-							
				+			
					<u> </u>	<u> </u>	



			Q'ty			
Ref. No.	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-19	1 HPR7-31105-A	HOLDER ASSY., BRUSH	1	1	1	
E-19	2 HPT0-31111-0	BEARING, RR. GENERATOR	1	1	1	
E-19	3 HPT0-31114-0	BEARING, FR. GENERATOR	1	1	1	
E-19	4 HPT0-31118-0	BUSH, INSULATION	4	4	4	
E-19	5 HPD1-31138-0	COVER, BEARING	1	1	1	
E-19	6 HP13-31141-0	PULLEY	1	1	1	
E-19	7 HPD1-31142-0	NUT, PULLEY LOCK	1	1	1	
E-19	8 HPD1-31145-0	BOLT, STUD, 6X68	4	4	4	
E-19	9 HPT0-31146-0	SCREW	4	4	4	
E-19	10 HP13-31147-0	SCREW	1	1	1	
E-19	11 HPT0-31147-0	SCREW-WASHER	3	3	3	
E-19	12 HP13-31148-0	SCREW, WAVE WASHER	4	4	4	
E-19	13 HPT0-31148-0	SCREW, WAVE WASHER	2	2	2	
E-19	14 HZY3-31630-0	GENERATOR ASSY., A.C.	1	1	1	
E-19	15 HZY3-31631-0	ROTOR ASSY.	1	1	1	
E-19	16 HZVL-31637-0	STAY, A.C. GENERATOR	1	1	1	
E-19	17 HZY3-31639-0	END COVER, RR.	1	1	1	
E-19	18 HZY3-31694-0	BUSH, INSULATION	1	1	1	
E-19	19 HZY3-31710-0	RECTIFIER ASSY.	1	1	1	
E-19 2	20 HZY3-31750-0	REGULATOR ASSY.	1	1	1	
E-19 2	21 HZX2-90002-0	BOLT, FLANGE, 10X90	1			~1002549
E-19 2	21 HZX2-90002-0	BOLT, FLANGE, 10X90		1		~1002617
E-19 2	21 HZX2-90002-0	BOLT, FLANGE, 10X90			1	~1007152
E-19	21 HZVL-90002-0	BOLT, FLANGE, 10X90	1			1002550~
E-19 2	21 HZVL-90002-0	BOLT, FLANGE, 10X90		1		1002618~
E-19	21 HZVL-90002-0	BOLT, FLANGE, 10X90			1	1007153~
E-19 2	22 HZVL-90011-0	BOLT, SPECIAL ADJUSTER	1	1	1	
E-19	23 HZZ5-90017-M	BOLT, FLANGE, 6X16	1	1	1	
E-19	24 HZY3-90055-0	BOLT, TENSIONER	1			~1002549





					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-19	24	HZY3-90055-000	BOLT, TENSIONER		1		~1002617
E-19	24	HZY3-90055-000	BOLT, TENSIONER			1	~1007152
E-19	24	HZVL-90055-010	BOLT, TENSIONER	1			1002550~
E-19	24	HZVL-90055-010	BOLT, TENSIONER		1		1002618~
E-19	24	HZVL-90055-010	BOLT, TENSIONER			1	1007153~
E-19	25	HZW5-90203-010	NUT, FLANGE, 8MM	1			~1002549
E-19	25	HZW5-90203-010	NUT, FLANGE, 8MM		1		~1002617
E-19	25	HZW5-90203-010	NUT, FLANGE, 8MM			1	~1007152
E-19	25	HZVL-90203-010	NUT, FLANGE, 8MM	1			1002550~
E-19	25	HZVL-90203-010	NUT, FLANGE, 8MM		1		1002618~
E-19	25	HZVL-90203-010	NUT, FLANGE, 8MM			1	1007153~
E-19	26	HPD1-90231-014	NUT-WASHER, 5MM	7	7	7	
E-19	27	HCO-94001-06080-0S	NUT, HEX., 6MM	1	1	1	



					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-20	1	HZVL-30520-003	COIL ASSY., PLUG TOP	6	6	6	
E-20	2	HZVL-30525-000	STAY COMP., PLUG TOP COIL	6	6	6	
E-20	3	HZX2-31916-003	PLUG, SPARK (ZFR6K-11E) (NGK)	6	6	6	
E-20	3	HCO-9807B-5617C	PLUG, SPARK (IZFR6K-11E) (NGK)	6	6	6	
E-20	4	HZY9-38553-003	GROMMET, RELAY BRACKET	6	6	6	
E-20	5	HZVL-90015-010	BOLT-WASHER, 6X27	6	6	6	
E-20	6	HZZ5-90018-M01	BOLT, FLANGE, 6X20	6	6	6	
E-20	7	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE	6			~1002629
E-20	7	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE		6		~1002620
E-20	7	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE			6	~1007870
E-20	7	HZVL-91551-000	COLLAR, C.D.I. UNIT CASE	6			1002630~1002815
E-20	7	HZVL-91551-000	COLLAR, C.D.I. UNIT CASE		6		1002621~1002916
E-20	7	HZVL-91551-000	COLLAR, C.D.I. UNIT CASE			6	1007871~1008195
E-20	7	HZVL-91551-010	COLLAR, C.D.I. UNIT CASE	6			1002816~
E-20	7	HZVL-91551-010	COLLAR, C.D.I. UNIT CASE		6		1002917~
E-20	7	HZVL-91551-010	COLLAR, C.D.I. UNIT CASE			6	1008196~
E-20	8	HZVL-30531-000	GUARD, R. PLUG TOP COIL SIDE	1	1	1	
E-20	9	HZVL-30536-000	GUARD, L. PLUG TOP COIL SIDE	1	1	1	


E-20-10 ELECTRONIC CONTROL UNIT






					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-20-10	1	HZVL-30416-000	CASE, ELECTRONIC PARTS	1			~1000781
E-20-10	1	HZVL-30416-000	CASE, ELECTRONIC PARTS		1		~1000697
E-20-10	1	HZVL-30416-000	CASE, ELECTRONIC PARTS			1	LRA, UCRA, URA, XCRA, XRA ~1001981
E-20-10	1	HZVL-30416-010	CASE, ELECTRONIC PARTS	1			1000782~1002549
E-20-10	1	HZVL-30416-010	CASE, ELECTRONIC PARTS		1		1000698~1002617
E-20-10	1	HZVL-30416-010	CASE, ELECTRONIC PARTS			1	1001982~1007152 LRA, UCRA, URA, XCRA, XRA
E-20-10	1	HZVL-30416-010	CASE, ELECTRONIC PARTS			1	~1007152 LDA, UCDA, UDA, XCDA, XDA
E-20-10	1	HZVL-30416-020	CASE, ELECTRONIC PARTS	1			1002550~
E-20-10	1	HZVL-30416-020	CASE, ELECTRONIC PARTS		1		1002618~
E-20-10	1	HZVL-30416-020	CASE, ELECTRONIC PARTS			1	1007153~
E-20-10	2	HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	8	8	8	
E-20-10	3	HZVL-32101-000	BRACKET, A.C. GENERATOR FUSE	4	4	4	
E-20-10	4	HZVL-32102-000	BRACKET, COUPLER A	1	1	1	
E-20-10	5	HZW9-32117-000	BRACKET, COUPLER D		1	1	
E-20-10	6	HZVJ-34750-901	CONTROL UNIT, ELECTRONIC	1			~1000808
E-20-10	6	HZVK-34750-901	CONTROL UNIT, ELECTRONIC	1			~1000808
E-20-10	6	HZVJ-34750-902	CONTROL UNIT, ELECTRONIC	1			1000809~1004021
E-20-10	6	HZVK-34750-903	CONTROL UNIT, ELECTRONIC	1			1004022~1005586
E-20-10	6	HZVK-34750-904	CONTROL UNIT, ELECTRONIC	1			1005587~
E-20-10	6	HZVK-34750-901	CONTROL UNIT, ELECTRONIC		1		~1000737
E-20-10	6	HZVL-34750-902	CONTROL UNIT, ELECTRONIC		1		1000738~1003549
E-20-10	6	HZVL-34750-903	CONTROL UNIT, ELECTRONIC		1		1003550~1004665
E-20-10	6	HZVL-34750-904	CONTROL UNIT, ELECTRONIC		1		1004666~
E-20-10	6	HZVL-34750-063	CONTROL UNIT, ELECTRONIC			1	LDA, UCDA, UDA, XCDA, XDA
E-20-10	6	HZVL-34750-901	CONTROL UNIT, ELECTRONIC			1	~1002101 LRA, UCRA, URA, XCRA, XRA
E-20-10	6	HZVL-34750-902	CONTROL UNIT, ELECTRONIC			1	1002102~1010800 LRA, UCRA, URA, XCRA, XRA
E-20-10	6	HZVL-34750-903	CONTROL UNIT, ELECTRONIC			1	1010801~1014920 LRA, UCRA, URA, XCRA, XRA
E-20-10	6	HZVL-34750-904	CONTROL UNIT, ELECTRONIC			1	1014921~ LRA, UCRA, URA, XCRA, XRA
E-20-10	7	HZVL-34754-000	CASE, ELECTRONIC CONTROL UNIT	1	1	1	


E-20-10 ELECTRONIC CONTROL UNIT






					Q' ty		_
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-20-10	8	HZVL-90015-010	BOLT-WASHER, 6X27	8	8	8	
E-20-10	9	HZZ0-90102-M00	BOLT, TORX (M6X20)	2			~1002700
E-20-10	9	HZZ0-90102-M00	BOLT, TORX (M6X20)		2		~1002916
E-20-10	9	HZZ0-90102-M00	BOLT, TORX (M6X20)			2	~1007868
E-20-10	9	HZZ0-90102-M01	BOLT, TORX (M6X20)	2			1002701~
E-20-10	9	HZZ0-90102-M01	BOLT, TORX (M6X20)		2		1002917~
E-20-10	9	HZZ0-90102-M01	BOLT, TORX (M6X20)			2	1007869~
E-20-10	10	HZZ0-90103-M00	BOLT, FLANGE, 6X10	5			~1002549
E-20-10	10	HZZ0-90103-M00	BOLT, FLANGE, 6X10		6		~1002617
E-20-10	10	HZZ0-90103-M00	BOLT, FLANGE, 6X10			6	~1007152
E-20-10	10	HZZ0-90103-M01	BOLT, FLANGE, 6X10	5			1002550~
E-20-10	10	HZZ0-90103-M01	BOLT, FLANGE, 6X10		6		1002618~
E-20-10	10	HZZ0-90103-M01	BOLT, FLANGE, 6X10			6	1007153~
E-20-10	11	HSA0-90683-003	CLIP, WIRE HARNESS, 25MM	1	1	1	
E-20-10	12	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE	8			~1002629
E-20-10	12	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE		8		~1002620
E-20-10	12	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE			8	~1007870
E-20-10	12	HZVL-91551-000	COLLAR, C.D.I. UNIT CASE	8			1002630~1002815
E-20-10	12	HZVL-91551-000	COLLAR, C.D.I. UNIT CASE		8		1002621~1002916
E-20-10	12	HZVL-91551-000	COLLAR, C.D.I. UNIT CASE			8	1007871~1008195
E-20-10	12	HZVL-91551-010	COLLAR, C.D.I. UNIT CASE	8			1002816~
E-20-10	12	HZVL-91551-010	COLLAR, C.D.I. UNIT CASE		8		1002917~
E-20-10	12	HZVL-91551-010	COLLAR, C.D.I. UNIT CASE			8	1008196~
-							
				•			

E-21 STARTER MOTOR




Ref. No.						
	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-21 1	HZY3-31200-003	MOTOR ASSY., STARTER	1	1	1	
E-21 2	HP5A-31201-005	ROTOR COMP.	1	1	1	
E-21 3	HZY9-31207-H01	CLUTCH COMP., OVERRUNNING	1	1	1	
E-21 4	HPY3-31215-004	GEAR ASSY., PLANETARY	3	3	3	
E-21 5	HZY3-31216-003	YOKE COMP.	1	1	1	
E-21 6	HPY3-31218-004	BALL, STEEL	1	1	1	
E-21 7	HZY3-31226-003	BRUSH SET	1	1	1	
E-21 8	HZY9-31226-H01	SCREW, PAN, 6X22	2	2	2	
E-21 9	HZY9-31229-H01	STOPPER SET, SLEEVE	1	1	1	
E-21 10	HZY3-31232-003	HOLDER COMP., BRUSH	1	1	1	
E-21 11	1 HZY3-31235-003	BRACKET, FR.	1	1	1	
E-21 12	2 HZY3-31236-003	BRACKET, RR.	1	1	1	
E-21 13	3 HZY3-31241-003	SWITCH ASSY., MAGNET	1	1	1	
E-21 14	4 HP5A-31243-005	BOLT A, THROUGH	2	2	2	
E-21 15	5 HZY3-31243-003	SHAFT ASSY., CLUTCH	1	1	1	
E-21 16	6 HZY9-31246-H01	SHAFT ASSY., GEAR	1	1	1	
E-21 17	7 HZY3-31250-003	LEVER SET	1	1	1	
E-21 18	B HZY3-31251-003	GEAR ASSY., INTERNAL	1	1	1	
E-21 19	9 HZVL-90003-000	BOLT, FLANGE, 10X110	1			~1002549
E-21 19	9 HZVL-90003-000	BOLT, FLANGE, 10X110		1		~1002617
E-21 19	9 HZVL-90003-000	BOLT, FLANGE, 10X110			1	~1007152
E-21 19	9 HZVL-90003-010	BOLT, FLANGE, 10X110	1			1002550~
E-21 19	9 HZVL-90003-010	BOLT, FLANGE, 10X110		1		1002618~
E-21 19	9 HZVL-90003-010	BOLT, FLANGE, 10X110			1	1007153~
E-21 20	HZVL-90005-000	BOLT, FLANGE, 10X90	1			~1002549
E-21 20	HZVL-90005-000	BOLT, FLANGE, 10X90		1		~1002617
E-21 20	HZVL-90005-000	BOLT, FLANGE, 10X90			1	~1007152
E-21 20	HZVL-90005-010	BOLT, FLANGE, 10X90	1			1002550~
E-21 20	HZVL-90005-010	BOLT, FLANGE, 10X90		1		1002618~

E-21 STARTER MOTOR




					Q'ty	,	
Ref. No		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
E-21	20	HZVL-90005-010	BOLT, FLANGE, 10X90			1	1007153~
E-21	21	HZW1-90107-004	SCREW, PAN, 5X8	2	2	2	
E-21	22	HZY3-91303-000	O-RING, 59.4X3.1	1	1	1	
	1		<u> </u>		<u> </u>	1	<u> </u>

EOP-1 GASKET KIT




					Q' ty		
Ref. No.		Part No. Description	BFT200D	BFT225D	BFT250D	Remarks	
E0P-1	1	HZVL-06115-010	GASKET KIT (BF175/200/225/250)	1	1	1	
E0P-1	2	HZVL-11381-003	PACKING, OIL PAN	1	1	1	
E0P-1	3	HZY3-12251-A01	GASKET COMP., CYLINDER HEAD (NIPPON LEAKLESS)	2	2	2	
E0P-1	4	HZY3-12312-000	PACKING, HEAD COVER	2	2	2	
E0P-1	5	HZY3-14529-000	O-RING, TIMING BELT TENSIONER BASE	1	1	1	
E0P-1	6	HZY3-15112-013	PACKING, OIL PUMP BODY	1	1	1	
E0P-1	7	HRCA-17055-A01	GASKET, FR. INJECTOR BASE	1	1	1	
E0P-1	8	HRCA-17065-A01	GASKET, RR. INJECTOR BASE	1	1	1	
E0P-1	9	HP8E-17105-A01	GASKET, INTAKE MANIFOLD	1	1	1	
E0P-1	10	HZY3-18115-003	GASKET, R. EX. MANIFOLD	1	1	1	
E0P-1	11	HZY3-18125-003	GASKET, L. EX. MANIFOLD	1	1	1	
E0P-1	12	HZVL-18333-003	GASKET, EX. PIPE	2	2	2	
E0P-1	13	HZVL-23172-003	GASKET, MOUNT CASE	1	1	1	
E0P-1	14	HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	1	1	1	
E0P-1	15	HMJ0-91301-003	0-RING, 7.8X1.9(ARAI)	2	2	2	
E0P-1	16	HZY3-91301-003	0-RING, 66.4X3.1	2	2	2	
E0P-1	17	HPF0-91302-003	0-RING, 26. 9X2. 4 (NOK)	1	1	1	
E0P-1	18	HZY3-91303-000	0-RING, 59.4X3.1	1	1	1	
E0P-1	19	HPNA-91307-003	0-RING, 9.5X1.9	1	1	1	
E0P-1	20	HPR3-91319-003	0-RING, 13X1.5(ARAI)	1	1	1	
E0P-1	21	HPC6-91324-000	0-RING, 20.6X2.6	1	1	1	
E0P-1	22	HZVL-91356-003	0-RING, 31.5X2.4	1	1	1	

F-2 SHIFT SHAFT (MECH)




	0' t		Q'ty				
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-2	1	HKN5-17224-670	WASHER, AIR CLEANER COVER	2	2	2	SETTING LRA, UCRA, URA, XCRA, XRA
F-2	2	HZVL-17877-900	PLATE, REMOTE CONTROL CABLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	3	HZVL-17878-900	COVER, REMOTE CONTROL CABLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	4	HZY3-17931-000	ARM, THROTTLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	5	HZVL-17932-900	SHAFT, THROTTLE ARM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	6	H921-17936-000	WASHER, PIVOT	3	3	3	LRA, UCRA, URA, XCRA, XRA
F-2	7	HZW1-24210-010	SPRING COMP., CLICK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	8	HZY3-24221-000	SPRING, CLICK ASSIST	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	9	HZW1-24327-000	RING, STOPPER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	10	HZY3-24610-A00	SHAFT COMP., SHIFT(A)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	13	HZY3-24617-000	COLLAR, SHIFT SLIDER	2	2	2	LRA, UCRA, URA, XCRA, XRA
F-2	14	HZY3-24618-000	PIVOT, SHIFT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	15	HZY3-24619-000	PLATE, LOCK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	16	HZY3-24620-000	SHAFT COMP., SHIFT(B)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	17	HZVL-24621-000	PIVOT, THROTTLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	18	HZVL-24622-000	PLATE, LOCK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	20	HZVL-24627-900	GUIDE, SHIFT LINK (MECH)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	21	HZVL-24628-900	BRACKET, SHIFT LINK (MECH)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	22	HZW1-24629-000	HOLDER, SEAL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	23	HZX2-35470-013	SWITCH ASSY., NEUTRAL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	24	HZY3-35476-010	BRACKET, NEUTRAL SWITCH	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	25	HZVL-35477-000	COVER, NEUTRAL SWITCH	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	26	HZZ5-90017-M00	BOLT, FLANGE, 6X16	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14	4			~6010052 LRA, XRA
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14	4			∼7010006 XCRA
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14		4		~6010057 LRA, XRA
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14		4		~7010010 XCRA
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14			4	∼6010095 LRA, URA, XRA
F-2	27	HZZ5-90021-M00	BOLT, FLANGE, 6X14			4	~7010024 UCRA, XCRA

F-2 SHIFT SHAFT (MECH)




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14	4			6010053~ LRA, XRA
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14	4			7010007~ XCRA
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14		4		6010058~ LRA, XRA
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14		4		7010011~ XCRA
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14			4	6010096~ LRA, URA, XRA
F-2	27	HZZ5-90021-M01	BOLT, FLANGE, 6X14			4	7010025~ UCRA, XCRA
F-2	28	HZX2-90101-C00	BOLT-WASHER, 6X16	3	3	3	LRA, UCRA, URA, XCRA, XRA
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11	2			~6010052 LRA, XRA
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11	2			~7010006 XCRA
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11		2		~6010057 LRA, XRA
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11		2		~7010010 XCRA
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11			2	~6010095 LRA, URA, XRA
F-2	29	HZZ0-90101-M00	BOLT, FLANGE, 6X11			2	~7010024 UCRA, XCRA
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11	2			6010053~ LRA, XRA
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11	2			7010007~ XCRA
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11		2		6010058~ LRA, XRA
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11		2		7010011~ XCRA
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11			2	6010096~ LRA, URA, XRA
F-2	29	HZZ0-90101-M01	BOLT, FLANGE, 6X11			2	7010025~ UCRA, XCRA
F-2	30	H881-90114-000	BOLT, HEX., 6X40	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM	2			~6010042 LRA, XRA
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM	2			~7010006 XCRA
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM		2		~6010040 LRA, XRA
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM		2		~7010010 XCRA
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM			2	~6010087 LRA, URA, XRA
F-2	31	HZZ5-90201-M00	NUT, FLANGE, 6MM			2	~7010028 UCRA, XCRA
F-2	31	HZY1-90205-000	NUT, SELF-LOCK, 6MM	2			6010043~ LRA, XRA
F-2	31	HZY1-90205-000	NUT, SELF-LOCK, 6MM	2			7010007~ XCRA
F-2	31	HZY1-90205-000	NUT, SELF-LOCK, 6MM		2		6010041~ LRA, XRA

F-2 SHIFT SHAFT (MECH)



				Q'ty		
Ref. No.	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-2	HZY1-90205-000	NUT, SELF-LOCK, 6MM		2		7010011~ XCRA
F-2	HZY1-90205-000	NUT, SELF-LOCK, 6MM			2	6010088~ LRA, URA, XRA
F-2	HZY1-90205-000	NUT, SELF-LOCK, 6MM			2	7010029~ UCRA, XCRA
F-2	HZV5-90302-003	NUT, HEX., 20MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	33 HHA0-90402-000	WASHER, THRUST, 14MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	H958-90428-000	WASHER B, THRUST, 14MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	HZV7-90508-000	WASHER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	36 HZZ5-90508-M01	WASHER, PLAIN, 6MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	HZV4-90512-000	WASHER, PLAIN, 6MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	HZY3-90751-000	PIN, LINK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	HZY3-91152-003	RING, INNER(15X20X23)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	HZW5-91251-003	OIL SEAL, 14X26X6	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	HZY3-91255-003	SEAL, WATER (14X26X8)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	HPF0-91302-003	0-RING, 26. 9X2. 4 (NOK)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-2	HSOA-91541-003	CLIP, HARNESS BAND (BLACK)	1	1	1	(145MM) LRA, UCRA, URA, XCRA, XRA
F-2	HCO-94540-04029	E-RING, 4MM	3	3	3	LRA, UCRA, URA, XCRA, XRA
F-2	HCO-94540-12029	E-RING, 12MM	2	2	2	LRA, UCRA, URA, XCRA, XRA
F-2	HZVL-24640-900	LINK ASSY., SHIFT	1	1	1	LRA, UCRA, URA, XCRA, XRA


F-2-1 SHIFT SHAFT (DBW)



ZVJTF0201D


					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-2-1	1	H921-17936-000	WASHER, PIVOT			3	LDA, UCDA, UDA, XCDA, XDA
F-2-1	2	HZVL-24210-000	SPRING COMP., CLICK			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	3	HZY3-24221-000	SPRING, CLICK ASSIST			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	4	HZW1-24327-000	RING, STOPPER			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	5	HZY3-24610-A00	SHAFT COMP., SHIFT(A)			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	8	HZVL-24614-000	PLATE, SHIFT PIVOT			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	9	HZVL-24617-000	ROD COMP., ACTUATOR LINK			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	10	HZVL-24618-000	PIVOT, SHIFT SLIDE			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	11	HZY3-24620-000	SHAFT COMP., SHIFT(B)			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	12	HZVL-24627-010	GUIDE, SHIFT LINK			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	13	HZW1-24629-000	HOLDER, SEAL			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	14	HZVL-24639-000	SPRING, GEARSHIFT ARM			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	15	HZX2-35470-013	SWITCH ASSY., NEUTRAL			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	16	HZY3-35476-010	BRACKET, NEUTRAL SWITCH			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	17	HZVL-35477-000	COVER, NEUTRAL SWITCH			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	18	HZZ5-90017-M01	BOLT, FLANGE, 6X16			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1	19	HZZ5-90021-M00	BOLT, FLANGE, 6X14			2	~6010095 LDA, UDA, XDA
F-2-1	19	HZZ5-90021-M00	BOLT, FLANGE, 6X14			2	~7010024 UCDA, XCDA
F-2-1	19	HZZ5-90021-M01	BOLT, FLANGE, 6X14			2	6010096~ LDA, UDA, XDA
F-2-1	19	HZZ5-90021-M01	BOLT, FLANGE, 6X14			2	7010025~ UCDA, XCDA
F-2-1	20	HZY3-90026-000	BOLT, FLANGE, 8X20			2	~6010095 LDA, UDA, XDA
F-2-1	20	HZY3-90026-000	BOLT, FLANGE, 8X20			2	~7010024 UCDA, XCDA
F-2-1	20	HZY9-90026-M01	BOLT, FLANGE, 8X20			2	6010096~ LDA, UDA, XDA
F-2-1	20	HZY9-90026-M01	BOLT, FLANGE, 8X20			2	7010025~ UCDA, XCDA
F-2-1	21	HZZ0-90101-M00	BOLT, FLANGE, 6X11			2	∼6010095 LDA, UDA, XDA
F-2-1	21	HZZ0-90101-M00	BOLT, FLANGE, 6X11			2	~7010024 UCDA, XCDA
F-2-1	21	HZZ0-90101-M01	BOLT, FLANGE, 6X11			2	6010096 ~ LDA, UDA, XDA
F-2-1	21	HZZ0-90101-M01	BOLT, FLANGE, 6X11			2	7010025~ UCDA, XCDA
F-2-1	22	HZY1-90205-000	NUT, SELF-LOCK, 6MM			2	LDA, UCDA, UDA, XCDA, XDA

F-2-1 SHIFT SHAFT (DBW)




ZVJTF0201D

Ref. No Part No. Description Table of the content						Q' ty		
F-2-1 24 HHAO-90402-000 WASHER, THRUST, 14MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 25 H958-90428-000 WASHER B, THRUST, 14MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 26 HZV7-90508-000 WASHER 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 27 HZZ5-90508-M01 WASHER, PLAIN, 6MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 29 HSD2-90705-931 PIN, SNAP, 6MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 30 HZY3-91152-003 RING, INNER (15X20X23) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 31 HZW5-91251-003 OIL SEAL, 14X26X6 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 32 HZY3-91255-003 SEAL, WATER (14X26X8) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 33 HPF0-91302-003 0-RING, 26, 9X2, 4 (NOK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 34 HS0A-91541-003 CLIP, HARNESS BAND (BLACK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HC0-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	Ref. No		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-2-1 25 H958-90428-000 WASHER B, THRUST, 14MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 26 HZV7-90508-000 WASHER 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 27 HZZ5-90508-M01 WASHER, PLAIN, 6MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 29 HSD2-90705-931 PIN, SNAP, 6MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 30 HZY3-91152-003 RING, INNER (15X20X23) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 31 HZW5-91251-003 OIL SEAL, 14X26X6 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 32 HZY3-91255-003 SEAL, WATER (14X26X8) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 33 HPF0-91302-003 O-RING, 26.9X2.4 (NOK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 34 HS0A-91541-003 CLIP, HARNESS BAND (BLACK) 1 (145MM) LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HCO-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	F-2-1	23	HZV5-90302-003	NUT, HEX., 20MM			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1 26 HZV7-90508-000 WASHER 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 27 HZZ5-90508-M01 WASHER, PLAIN, 6MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 29 HSD2-90705-931 PIN, SNAP, 6MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 30 HZY3-91152-003 RING, INNER (15X20X23) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 31 HZW5-91251-003 OIL SEAL, 14X26X6 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 32 HZY3-91255-003 SEAL, WATER (14X26X8) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 33 HPF0-91302-003 O-RING, 26. 9X2. 4 (NOK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 34 HS0A-91541-003 CLIP, HARNESS BAND (BLACK) 1 (145MM) LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HC0-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	F-2-1	24	HHA0-90402-000	WASHER, THRUST, 14MM			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1 27 HZZ5-90508-M01 WASHER, PLAIN, 6MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 29 HSD2-90705-931 PIN, SNAP, 6MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 30 HZY3-91152-003 RING, INNER (15X20X23) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 31 HZW5-91251-003 OIL SEAL, 14X26X6 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 32 HZY3-91255-003 SEAL, WATER (14X26X8) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 33 HPF0-91302-003 O-RING, 26. 9X2. 4 (NOK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 34 HSOA-91541-003 CLIP, HARNESS BAND (BLACK) 1 (145MM) LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HCO-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	F-2-1	25	H958-90428-000	WASHER B, THRUST, 14MM			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1 29 HSD2-90705-931 PIN, SNAP, 6MM 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 30 HZY3-91152-003 RING, INNER (15X20X23) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 31 HZW5-91251-003 OIL SEAL, 14X26X6 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 32 HZY3-91255-003 SEAL, WATER (14X26X8) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 33 HPF0-91302-003 O-RING, 26. 9X2. 4 (NOK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 34 HSOA-91541-003 CLIP, HARNESS BAND (BLACK) 1 (145MM) LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HCO-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	F-2-1	26	HZV7-90508-000	WASHER			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1 30 HZY3-91152-003 RING, INNER (15X20X23) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 31 HZW5-91251-003 OIL SEAL, 14X26X6 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 32 HZY3-91255-003 SEAL, WATER (14X26X8) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 33 HPF0-91302-003 0-RING, 26.9X2.4 (NOK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 34 HSOA-91541-003 CLIP, HARNESS BAND (BLACK) 1 (145MM) LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HCO-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	F-2-1	27	HZZ5-90508-M01	WASHER, PLAIN, 6MM			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1 31 HZW5-91251-003 OIL SEAL, 14X26X6 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 32 HZY3-91255-003 SEAL, WATER (14X26X8) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 33 HPF0-91302-003 0-RING, 26. 9X2. 4 (NOK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 34 HS0A-91541-003 CLIP, HARNESS BAND (BLACK) 1 (145MM) LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HC0-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	F-2-1	29	HSD2-90705-931	PIN, SNAP, 6MM			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1 32 HZY3-91255-003 SEAL, WATER (14X26X8) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 33 HPF0-91302-003 0-RING, 26. 9X2. 4 (NOK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 34 HS0A-91541-003 CLIP, HARNESS BAND (BLACK) 1 (145MM) LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HC0-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	F-2-1	30	HZY3-91152-003	RING, INNER(15X20X23)			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1 33 HPF0-91302-003 0-RING, 26.9X2.4 (NOK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 34 HS0A-91541-003 CLIP, HARNESS BAND (BLACK) 1 (145MM) LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HC0-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	F-2-1	31	HZW5-91251-003	OIL SEAL, 14X26X6			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1 34 HS0A-91541-003 CLIP, HARNESS BAND (BLACK) 1 (145MM) LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HC0-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	F-2-1	32	HZY3-91255-003	SEAL, WATER (14X26X8)			1	LDA, UCDA, UDA, XCDA, XDA
F-2-1 34 HSUA-91541-UU3 CLIP, HARNESS BAND (BLACK) 1 LDA, UCDA, UDA, XCDA, XDA F-2-1 35 HCO-94540-12029 E-RING, 12MM 2 LDA, UCDA, UDA, XCDA, XDA	F-2-1	33	HPF0-91302-003	0-RING, 26. 9X2. 4 (NOK)			1	LDA, UCDA, UDA, XCDA, XDA
	F-2-1	34	HS0A-91541-003	CLIP, HARNESS BAND (BLACK)			1	
F-2-1 37 HZVL-24640-000 LINK ASSY SHIFT 1 LDA, UCDA, UDA, XODA, XDA Image: Control of the control of	F-2-1	35	HCO-94540-12029	E-RING, 12MM			2	LDA, UCDA, UDA, XCDA, XDA
	F-2-1	37	HZVL-24640-000	LINK ASSY., SHIFT			1	LDA, UCDA, UDA, XCDA, XDA




F-3 1 F-3 2	Part No. HZW1-19286-B00	Description	BFT200D	BFT225D	BF:	Remarks
	HZW1-19286-B00		Ð	225D	BFT250D	Roller Ro
F-3 2		PLATE, RUBBER SETTING	1	1	1	
	HZY3-40202-621ZC	SEPARATOR, EXTENSION			1	*T107* BAY BLUE UCDA, UCRA, UDA, URA
F-3 3	HZX2-41101-C01ZC	CASE, GEAR	1	1	1	*T107* BAY BLUE
F-3 4	HZW1-41102-B00	GROMMET, GEAR CASE	1	1	1	
F-3 5	HZX2-41102-E00ZC	COVER, GEAR CASE	1	1	1	*T107* BAY BLUE UCDA, UCRA, XCDA, XCRA
F-3 6	HZY3-41104-C01	SCREEN, R. WATER	1	1	1	
F-3 7	HZY3-41105-C01	SCREEN, L. WATER	1	1	1	
F-3 8	HZX2-41107-C00ZC	TAB, TRIM	1	1	1	*T107* BAY BLUE LDA, LRA, UDA, URA, XDA, XRA
F-3 9	HZW1-41109-B00	METAL COMP., ANODE	2	2	2	
F-3 10	HZX2-41110-305ZB	CASE COMP., GEAR	1	1	1	*T107* BAY BLUE
F-3 11	HZW9-90101-003	BOLT, OIL CHECK	1	1	1	
F-3 12	HZZ0-90101-000	SCREW, FLAT, 5X55	1	1	1	
F-3 13	HZY6-90103-000	BOLT-WASHER, 10X32	1	1	1	
F-3 14	HZX2-90107-C00	BOLT-WASHER, 10X47	6	6	6	LDA, LRA, XCDA, XCRA, XDA, XRA
F-3 15	HZY3-90120-000	BOLT, DRAIN PLUG	1	1	1	
F-3 16	HZY3-90124-000	BOLT, STUD, 12X40	1	1	1	LDA, LRA, XCDA, XCRA, XDA, XRA
F-3 17	HZY3-90130-620	BOLT, STUD, 12X170			1	UCDA, UCRA, UDA, URA
F-3 18	HZY3-90131-620	BOLT, STUD, 10X170			6	UCDA, UCRA, UDA, URA
F-3 19	HZY1-90205-000	NUT, SELF-LOCK, 6MM	1	1	1	
F-3 20	HZV4-90302-000	NUT, SELF-LOCK, 5MM	1	1	1	
F-3 21	HZV5-90306-003	NUT, SELF-LOCK, 10MM			6	UCDA, UCRA, UDA, URA
F-3 22	HZW1-90308-003	NUT, SELF-LOCK, 12MM	1	1	1	
F-3 23	HZV5-90559-000	WASHER, PLAIN, 12MM	1	1	1	
F-3 24	HZV5-90563-000	WASHER, PLAIN, 10MM			6	UCDA, UCRA, UDA, URA
F-3 25	HZV5-90756-000	DOWEL PIN, 6X10	2	2	2	LDA, LRA, XCDA, XCRA, XDA, XRA
F-3 25	HZV5-90756-000	DOWEL PIN, 6X10			4	UCDA, UCRA, UDA, URA
F-3 26	HZW4-91301-003	0-RING, 6. 9X1. 45	2	2	2	
F-3 27	HCO-92101-06055-4J	BOLT, HEX., 6X55	1	1	1	






Perf. No.						Q' ty		
F-3-10 1 R2VL-41100-000ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -6011040 F-3-10 1 R2VL-41100-000ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -6011040 F-3-10 1 R2VL-41100-010ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -6011040 F-3-10 1 R2VL-41100-010ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -6011040 F-3-10 1 R2VL-41100-010ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -6011041 F-3-10 1 R2VL-41100-010ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -6011041 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -6011077 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -6011077 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -6011077 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -601107-6011089 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -601107-6011089 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -601107-6011089 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -601107-6011089 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -601107-6011089 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -601107-6011089 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -601107-6011089 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -601107-6011109 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -601107-6011109 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107+ BAY BLUE 1 CONTROL -601109-6011115 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107- BAY BLUE 1 CONTROL -601109-6011115 F-3-10 1 R2VL-41100-020ZA CASE ASSY. GEAR CUL +1107- BAY BLUE 1	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-3-10 1 RZVL-41100-000ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 1 SON JOAN JOAN JOAN JOAN JOAN JOAN JOAN JO	F-3-10	1	HZVL-41100-000ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE	1			
F-3-10 1 NZVL-41100-010ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 S011021~6011040 XBA	F-3-10	1	HZVL-41100-000ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE		1		
F-3-10 1 1 1274-41100-0102A CASE ASSY. GEAR OLD **1107* BAY BLUE 1 1 S011024-6011041	F-3-10	1	HZVL-41100-000ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE			1	
F-3-10 1 H2VL-41100-0102A CASE ASSY. GEAR OLL *T107* BAY BLUE 1 S01104-6011106 MAX RA GO11041-6011077 MAX RA GO11041-6011079 MAX RA GO11078-MAX RA GO11078-M	F-3-10	1	HZVL-41100-010ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE	1			
F-3-10 1 NZVL-41100-020ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XXA FROM \$1107* \$1017	F-3-10	1	HZVL-41100-010ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE		1		
F-3-10 1 HZVL-41100-020ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011077 F-3-10 1 HZVL-41100-030ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011078~ F-3-10 1 HZVL-41100-030ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011078~ F-3-10 1 HZVL-41100-030ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011080~ F-3-10 1 HZVL-41100-030ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011080~ F-3-10 1 HZVL-41100-030ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011080~ F-3-10 1 HZVL-41100-602ZC CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011080~ F-3-10 1 HZVL-41100-602ZC CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011108~ F-3-10 1 HZVL-41100-602ZC CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011110~ F-3-10 1 HZVL-41100-602ZC CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011110~ F-3-10 1 HZVL-41100-602ZC CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011110~ F-3-10 1 HZVL-41100-700ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011110~ F-3-10 1 HZVL-41100-700ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011200~ F-3-10 1 HZVL-41100-700ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA 6011200~ F-3-10 1 HZVL-41100-700ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 XDA XRA ABY BAY BAY BAY BAY BAY BAY BAY BAY BA	F-3-10	1	HZVL-41100-010ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE			1	
F-3-10 1 H2VL-41100-020ZA CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 S011042 ~6011059 F-3-10 1 H2VL-41100-030ZA CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 S011037~ 6011188 F-3-10 1 HZVL-41100-030ZA CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 AXDA, XRA 6011080~ F-3-10 1 HZVL-41100-030ZA CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 XDA, XRA 6011189~ F-3-10 1 HZVL-41100-60ZC CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 XDA, XRA 6011189~ F-3-10 1 HZVL-41100-60ZC CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 S011048 UDA, URA 6011115 UDA, URA 6011115 UDA, URA 6011115 UDA, URA 6011116 ~6011209 UDA, URA 6011210~ F-3-10 1 HZVL-41100-60ZC CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 UDA, URA 6011210~ F-3-10 1 HZVL-41100-60ZC CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 UDA, URA 6011210~ F-3-10 1 HZVL-41100-700ZA CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 UDA, URA 6011210~ F-3-10 1 HZVL-41100-700ZA CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 UDA, URA 6011210~ F-3-10 1 HZVL-41100-700ZA CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 UDA, URA 6011210~ F-3-10 1 HZVL-41100-700ZA CASE ASSY., GEAR (XL) *1107* BAY BLUE 1 XCRA CASE ASSY., GE	F-3-10	1	HZVL-41100-020ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE	1			
F-3-10 1 H2VL-41100-030ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 S011107~6011188 F-3-10 1 H2VL-41100-030ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 S011060~ F-3-10 1 H2VL-41100-030ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 S011060~ F-3-10 1 H2VL-41100-600ZC CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 S011048~ GUILL S011049~G011115 UBA, URA F-3-10 1 H2VL-41100-600ZC CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 S011049~6011115 UBA, URA F-3-10 1 H2VL-41100-602ZC CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 S011049~6011115 UBA, URA F-3-10 1 H2VL-41100-602ZC CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 S011049~6011116—6011209 F-3-10 1 H2VL-41100-602ZC CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 S011040~ F-3-10 1 H2VL-41100-700ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 UBA, URA F-3-10 1 H2VL-41100-700ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 S011000 WINTER ROTATION BAY BLUE 1 SAY BLUE 1 WARRA (COUNTER ROTATION) BAY BLUE 1 SAY B	F-3-10	1	HZVL-41100-020ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE		1		
F-3-10 1 H2VL-41100-030ZA CASE ASSY. GEAR (XL) *T107* BAY BLUE 1 SON XRA GO11060~ F-3-10 1 HZVL-41100-030ZA CASE ASSY. GEAR (XL) *T107* BAY BLUE 1 SON XRA GO11189~ F-3-10 1 HZVL-41100-600ZC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 SON XRA GO11189~ F-3-10 1 HZVL-41100-601ZC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 GO11048 UDA, URA GO11115 UDA, URA GO11115 UDA, URA GO11116~ F-3-10 1 HZVL-41100-602ZC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 GO11049~GO11115 UDA, URA GO11210~ F-3-10 1 HZVL-41100-602ZC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 GO11049~GO11115 UDA, URA GO11210~ F-3-10 1 HZVL-41100-602ZC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 GO11049~GO11116~GO11209 UDA, URA GO11210~ F-3-10 1 HZVL-41100-700ZA CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 UDA, URA GO11210~ F-3-10 1 HZVL-41100-700ZA CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 CASE ASSY. GEAR (UL) *T107* CASE ASSY.	F-3-10	1	HZVL-41100-020ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE			1	
F-3-10 1 HZVL-41100-030ZA CASE ASSY., GEAR (XL) *T107* BAY BLUE 1 XDA, XRA 6011188∼ F-3-10 1 HZVL-41100-601ZC CASE ASSY., GEAR (UL) *T107* BAY BLUE 1 COUNTER POTATION BAY BLUE 1 LXDA, URA 6011188∼ F-3-10 1 HZVL-41100-601ZC CASE ASSY., GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011115 UDA, URA 6011167 CASE ASSY., GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 LXDA, URA 6011116 CASE ASSY. GEAR (UL) *T107* CASE ASSY. GEAR (UL)	F-3-10	1	HZVL-41100-030ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE	1			
F-3-10 1 HZVL-41100-600ZC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 COUNTER PART BLUE 1 DA. URA UPA UPA UPA UPA UPA UPA UPA UPA UPA UP	F-3-10	1	HZVL-41100-030ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE		1		
F-3-10 1 HZVL-41100-602CC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 1 G011049-6011115 UDA, URA 101116-6011209 F-3-10 1 HZVL-41100-602CC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 1 UDA, URA 6011116-6011209 F-3-10 1 HZVL-41100-603CC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 1 UDA, URA 6011210-~~ F-3-10 1 HZVL-41100-700ZA CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 1 COBA BAY BLUE 1 1 COBA BAY BLUE 1 1 COBA BAY BLUE	F-3-10	1	HZVL-41100-030ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE			1	
F-3-10 1 HZVL-41100-602ZC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 UDA, URA 6011210~ F-3-10 1 HZVL-41100-603ZC CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 UDA, URA 6011210~ F-3-10 1 HZVL-41100-700ZA CASE ASSY. GEAR (UL) *T107* BAY BLUE 1 UDA, URA 6011210~ F-3-10 1 HZVL-41100-700ZA CASE ASSY. GEAR (XL) *T107* COUNTER ROTATION) BAY BLUE 1 ~7011001 XCRA 77011001 XCRA 77011002 XCRA 77011001 XCRA 77011002 XCRA 77011003 XCRA 77011002 XCRA 77011003 XCDA XCRA 77011003 XCRA 77011003 XCRA 77011003 XCDA XCDA XCDA XCDA XCDA XCDA XCDA XCDA	F-3-10	1	HZVL-41100-600ZC	CASE ASSY., GEAR(UL) *T107* BAY BLUE			1	
F-3-10 1 HZVL-41100-603ZC CASE ASSY., GEAR (UL) *T107* BAY BLUE 1 1 G011116 ~ 6011209 F-3-10 1 HZVL-41100-603ZC CASE ASSY., GEAR (UL) *T107* BAY BLUE 1 1 UDA, URA 6011210 ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	F-3-10	1	HZVL-41100-601ZC	CASE ASSY., GEAR(UL) *T107* BAY BLUE			1	
F-3-10 1 HZVL-41100-700ZA CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 COUNTER ROTATION) BAY BLUE 1 CASE ASSY. GEAR (XL) *1107* BAY BLUE 1 COUNTER ROTATION) BAY BLUE 1 CASE ASSY. GEAR (XL) *1107* COUNTER ROTATION) BAY BLUE 1 CA	F-3-10	1	HZVL-41100-602ZC	CASE ASSY., GEAR(UL) *T107* BAY BLUE			1	
F-3-10	F-3-10	1	HZVL-41100-603ZC	CASE ASSY., GEAR(UL) *T107* BAY BLUE			1	
F-3-10 1 HZVL-41100-700ZA (COUNTER ROTATION) BAY BLUE 1 XCRA F-3-10 1 HZVL-41100-700ZA (CASE ASSY. GEAR (XL) *T107*	F-3-10	1	HZVL-41100-700ZA		1			
F-3-10	F-3-10	1	HZVL-41100-700ZA			1		
F-3-10 1 HZVL-41100-701ZA (COUNTER ROTATION) BAY BLUE 1 XCRA F-3-10 1 HZVL-41100-701ZA (COUNTER ROTATION) BAY BLUE 1 7011003~7011014 XCRA F-3-10 1 HZVL-41100-702ZA (CASE ASSY., GEAR (XL) *T107* (COUNTER ROTATION) BAY BLUE 1 XCRA 7011009~7011015 F-3-10 1 HZVL-41100-702ZA (CASE ASSY., GEAR (XL) *T107* (COUNTER ROTATION) BAY BLUE 1 XCRA 7011015~7011015 F-3-10 1 HZVL-41100-702ZA (COUNTER ROTATION) BAY BLUE 1 XCRA 7011042~7011063 F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 XCRA 7011016~ F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 XCRA 7011016~ F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 XCRA 7011064~ F-3-10 1 HZVL-41100-800ZC (CASE ASSY., GEAR (XL) *T107* (COUNTER ROTATION) BAY BLUE 1 XCDA, XCRA 7011064~ F-3-10 1 HZVL-41100-800ZC (CASE ASSY., GEAR (UL) *T107* (COUNTER ROTATION) BAY BLUE 1 7011016~ F-3-10 1 HZVL-41100-801ZC (COUNTER ROTATION) BAY BLUE 1 7011016~ F-3-10 1 HZVL-41100-801ZC (COUNTER ROTATION) BAY BLUE 1 7011018~ (COUNTER RO	F-3-10	1	HZVL-41100-700ZA				1	
F-3-10 1 HZVL-41100-702ZA CASE ASSY., GEAR (XL) *T107* F-3-10 1 HZVL-41100-702ZA CASE ASSY., GEAR (XL) *T107* (COUNTER ROTATION) BAY BLUE 1 XCRA 7011009~7011015 F-3-10 1 HZVL-41100-702ZA CASE ASSY., GEAR (XL) *T107* (COUNTER ROTATION) BAY BLUE 1 XCRA 7011015~7011015 F-3-10 1 HZVL-41100-702ZA CASE ASSY., GEAR (XL) *T107* (COUNTER ROTATION) BAY BLUE 1 XCDA, XCRA 7011042~7011063 F-3-10 1 HZVL-41100-703ZA CASE ASSY., GEAR (XL) *T107* (COUNTER ROTATION) BAY BLUE 1 XCRA 7011016~ F-3-10 1 HZVL-41100-703ZA CASE ASSY., GEAR (XL) *T107* (COUNTER ROTATION) BAY BLUE 1 XCDA, XCRA 7011016~ F-3-10 1 HZVL-41100-800ZC CASE ASSY., GEAR (UL) *T107* (COUNTER ROTATION) BAY BLUE 1 ~7011016 F-3-10 1 HZVL-41100-800ZC CASE ASSY., GEAR (UL) *T107* (COUNTER ROTATION) BAY BLUE 1 7011018~ (COUNTER ROTATION)	F-3-10	1	HZVL-41100-701ZA		1			
F-3-10 1 HZVL-41100-702ZA (COUNTER ROTATION) BAY BLUE 1 7011099~7011015 F-3-10 1 HZVL-41100-702ZA (COUNTER ROTATION) BAY BLUE 1 XCRA 7011015~7011015 F-3-10 1 HZVL-41100-702ZA (COUNTER ROTATION) BAY BLUE 1 XCDA, XCRA 7011042~7011063 F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 XCRA 7011042~7011063 F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 XCRA 7011016~ F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 XCDA, XCRA 7011016~ F-3-10 1 HZVL-41100-800ZC (COUNTER ROTATION) BAY BLUE 1 XCDA, XCRA 7011064~ F-3-10 1 HZVL-41100-800ZC (CASE ASSY., GEAR (UL) *T107* (COUNTER ROTATION) BAY BLUE 1 XCDA, XCRA 7011016 XCOUNTER ROTATION) BAY BLUE 1 XCDA, XCRA 7011064~ F-3-10 1 HZVL-41100-801ZC (COUNTER ROTATION) BAY BLUE 1 XCDA, XCRA YCTIOTA YCTI	F-3-10	1	HZVL-41100-701ZA			1		
F-3-10 1 HZVL-41100-702ZA (COUNTER ROTATION) BAY BLUE 1 7011015~7011015 F-3-10 1 HZVL-41100-702ZA (COUNTER ROTATION) BAY BLUE 1 XCDA, XCRA 7011042~7011063 F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 1 XCRA 7011016~ F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 1 XCDA, XCRA 7011016~ F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 1 XCDA, XCRA 7011016~ F-3-10 1 HZVL-41100-800ZC (COUNTER ROTATION) BAY BLUE 1 1 XCDA, XCRA 7011064~ F-3-10 1 HZVL-41100-800ZC (COUNTER ROTATION) BAY BLUE 1 1 COUNTER ROTATION) BAY BLUE 1 1 TO11018~ F-3-10 1 HZVL-41100-801ZC (COUNTER ROTATION) BAY BLUE 1 7011018~ F-3-10 1 HZVL-41100-801ZC (COUNTER ROTATION) BAY BLUE 1 7011018~ F-3-10 1 HZVL-41100-9007A (CASE ASSY, GEAR (LL) *T107* RAY BLUE 1 COOLUMER ROTATION) BAY BLUE 1 COOLUMER ROTATION BAY BLUE 1 COOLUMER ROTATION) BAY BLUE 1 COOLUMER ROTATION BAY BLUE 1 COOLUMER RO	F-3-10	1	HZVL-41100-702ZA		1			
F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 7011042~7011063 F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 1 XCRA 7011016~ F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 1 XCDA, XCRA 7011016~ F-3-10 1 HZVL-41100-800ZC (COUNTER ROTATION) BAY BLUE 1 7011064~ F-3-10 1 HZVL-41100-800ZC (COUNTER ROTATION) BAY BLUE 1 ~7011017 UCDA, UCRA F-3-10 1 HZVL-41100-801ZC (COUNTER ROTATION) BAY BLUE 1 7011018~ UCDA, UCRA F-3-10 1 HZVL-41100-900ZA (CASE ASSY., GEAR (UL) *T107*, RAY BLUE 1 ~7011018~ UCDA, UCRA	F-3-10	1	HZVL-41100-702ZA			1		
F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 7011016~ F-3-10 1 HZVL-41100-703ZA (COUNTER ROTATION) BAY BLUE 1 7011016~ F-3-10 1 HZVL-41100-800ZC CASE ASSY., GEAR (UL) *T107* (COUNTER ROTATION) BAY BLUE 1 ~7011017 UCDA, UCRA F-3-10 1 HZVL-41100-801ZC CASE ASSY., GEAR (UL) *T107* (COUNTER ROTATION) BAY BLUE 1 7011018~ UCDA, UCRA F-3-10 1 HZVL-41100-900ZA (CASE ASSY., GEAR (UL) *T107* RAY BLUE 1 ~6011036	F-3-10	1	HZVL-41100-702ZA				1	
F-3-10 1 HZVL-41100-800ZC CASE ASSY., GEAR (UL) *T107*	F-3-10	1	HZVL-41100-703ZA		1	1		
F-3-10 1 HZVL-41100-801ZC (COUNTER ROTATION) BAY BLUE 1 UCDA, UCRA F-3-10 1 HZVL-41100-801ZC CASE ASSY., GEAR (UL) *T107* (COUNTER ROTATION) BAY BLUE 1 7011018~ UCDA, UCRA F-3-10 1 HZVL-41100-9007A CASE ASSY. GEAR (L) *T107* RAY BLUE 1 ~6011036	F-3-10	1	HZVL-41100-703ZA				1	
F-3-10 1	F-3-10	1	HZVL-41100-800ZC				1	
F=3-10	F-3-10	1	HZVL-41100-801ZC				1	
	F-3-10	1	HZVL-41100-900ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE	1			~6011036 LRA

F-3-10 GEAR CASE ASSY.







				1	Q't	,	
Ref. No.		Part No.	Description	BF 1200D	BFT225D	BFT250D	Remarks
F-3-10	1	HZVL-41100-900ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE		1		~6011026 LRA
F-3-10	1	HZVL-41100-901ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE	1			6011037~6011044 LRA
F-3-10	1	HZVL-41100-901ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE		1		6011027~6011048 LRA
F-3-10	1	HZVL-41100-901ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE			1	6011053~6011112 LDA, LRA
F-3-10	1	HZVL-41100-902ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE	1			LRA 6011045~6011085
F-3-10	1	HZVL-41100-902ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE		1		LRA 6011049~6011061
F-3-10	1	HZVL-41100-902ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE			1	LDA, LRA 6011113~6011258
F-3-10	1	HZVL-41100-903ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE	1			LRA 6011086~
F-3-10	1	HZVL-41100-903ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE		1		LRA 6011062~
F-3-10	1	HZVL-41100-903ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE			1	LDA, LRA 6011259~




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-3-20	1	HZY3-19270-000	NUT, WATER MOUTH	1	1	1	
F-3-20	2	HZY3-19271-000	JOINT, WATER HOSE	1	1	1	
F-3-20	3	HZY3-19272-000	SEAT, WATER MOUTH	1	1	1	
F-3-20	4	HZVL-19274-000	SEAT, WATER JOINT	1	1	1	
F-3-20	5	HZY3-19289-000	CAP, WATER JOINT	1	1	1	
F-3-20	6	HZY3-23173-010	RUBBER, MOUNT CASE SEAL	3	3	3	
F-3-20	7	HZY3-35640-013	SWITCH ASSY., POWER TILT	1	1	1	
F-3-20	8	HZY9-35645-000	STAY, POWER TILT SWITCH	1	1	1	
F-3-20	9	HZVL-40100-000	CASE ASSY., ENGINE UNDER	1			~6010044 LRA, XRA
F-3-20	9	HZVL-40100-000	CASE ASSY., ENGINE UNDER	1			~7010006 XCRA
F-3-20	9	HZVL-40100-000	CASE ASSY., ENGINE UNDER		1		~6010049 LRA, XRA
F-3-20	9	HZVL-40100-000	CASE ASSY., ENGINE UNDER		1		~7010010 XCRA
F-3-20	9	HZVL-40100-000	CASE ASSY., ENGINE UNDER			1	~6010089 LDA, LRA, UDA, URA, XDA, XRA
F-3-20	9	HZVL-40100-000	CASE ASSY., ENGINE UNDER			1	~7010030 UCDA, UCRA, XCDA, XCRA
F-3-20	9	HZVL-40100-010	CASE ASSY., ENGINE UNDER	1			6010045~ LRA, XRA
F-3-20	9	HZVL-40100-010	CASE ASSY., ENGINE UNDER	1			7010007~ XCRA
F-3-20	9	HZVL-40100-010	CASE ASSY., ENGINE UNDER		1		6010050~ LRA, XRA
F-3-20	9	HZVL-40100-010	CASE ASSY., ENGINE UNDER		1		7010011~ XCRA
F-3-20	9	HZVL-40100-010	CASE ASSY., ENGINE UNDER			1	6010090~ LDA, LRA, UDA, URA, XDA, XRA
F-3-20	9	HZVL-40100-010	CASE ASSY., ENGINE UNDER			1	7010031~ UCDA, UCRA, XCDA, XCRA
F-3-20	10	HZVL-40102-000	SEAL A, UNDER CASE	1	1	1	
F-3-20	11	HZVL-40103-000	SEAL B, UNDER CASE	1	1	1	
F-3-20	12	HZVL-40105-900	GROMMET, UNDER CASE (MECH)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-3-20	12	HZVL-40105-000	GROMMET, UNDER CASE			1	LDA, UCDA, UDA, XCDA, XDA
F-3-20	13	HZVL-40110-000	STAY COMP., HARNESS	1			∼6010057 LRA, XRA
F-3-20	13	HZVL-40110-000	STAY COMP., HARNESS	1			~7010008 XCRA
F-3-20	13	HZVL-40110-000	STAY COMP., HARNESS		1		~6010061 LRA, XRA
F-3-20	13	HZVL-40110-000	STAY COMP., HARNESS		1		~7010010 XCRA
F-3-20	13	HZVL-40110-000	STAY COMP., HARNESS			1	∼6010099 LDA, LRA, UDA, URA, XDA, XRA




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-3-20	13	HZVL-40110-000	STAY COMP., HARNESS			1	~7010030 UCDA, UCRA, XCDA, XCRA
F-3-20	13	HZVL-40110-010	STAY COMP., HARNESS	1			6010058~ LRA, XRA
F-3-20	13	HZVL-40110-010	STAY COMP., HARNESS	1			7010009~ XCRA
F-3-20	13	HZVL-40110-010	STAY COMP., HARNESS		1		6010062~ LRA, XRA
F-3-20	13	HZVL-40110-010	STAY COMP., HARNESS		1		7010011~ XCRA
F-3-20	13	HZVL-40110-010	STAY COMP., HARNESS			1	6010100~ LDA, LRA, UDA, URA, XDA, XRA
F-3-20	13	HZVL-40110-010	STAY COMP., HARNESS			1	7010031~ UCDA, UCRA, XCDA, XCRA
F-3-20	14	HZVL-40116-000	PORT, IDLE EXHAUST	1	1	1	
F-3-20	15	HZVL-40151-000	COVER, SEPARATE	1	1	1	
F-3-20	16	HZVL-40154-000	BRACKET, UNDER CASE FR.	1	1	1	
F-3-20	17	HZVL-40201-000	CASE, EXTENSION (XL)	1	1	1	UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-3-20	18	HZVL-40201-900	CASE, EXTENSION(L)	1	1	1	LDA, LRA
F-3-20	19	HZVL-40209-000	RUBBER, DRAIN PLUG	1	1	1	
F-3-20	20	HZY3-40210-610	BUSH COMP., VERTICAL SHAFT	1	1	1	UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-3-20	21	HZY3-50111-020	HOUSING, LOWER MOUNTING	2	2	2	
F-3-20	22	HZY3-50155-000	MOUNT COMP., LOWER RUBBER	2	2	2	
F-3-20	23	HZY3-50157-010	STOPPER, LOWER MOUNT	2	2	2	
F-3-20	24	H121-51640-730	RUBBER, FR. CARRIER CUSHION	6	6	6	
F-3-20	25	HZVL-63119-000	SPRING, LEVER RETURN	3	3	3	
F-3-20	26	HZVL-63210-000	LEVER, COVER LOCK FR.	1	1	1	
F-3-20	27	HZVL-63212-000	HOOK COMP., COVER LOCK R.	2	2	2	
F-3-20	28	HZVL-63213-000	COLLAR A, COVER LOCK	3	3	3	
F-3-20	29	HZVL-63214-000	COLLAR B, COVER LOCK	3	3	3	
F-3-20	30	HZVL-63220-000	LEVER, COVER LOCK R.	1	1	1	
F-3-20	31	HZVL-63222-000	HOOK COMP., COVER LOCK L.	1	1	1	
F-3-20	32	HZVL-63230-000	LEVER, COVER LOCK L.	1	1	1	
F-3-20	33	HZCO-63515-700	CAP, L. SIDE COVER	1	1	1	
F-3-20	34	HZVL-82873-000	GROMMET, WATER CHECK	1	1	1	
F-3-20	35	HZZ5-90051-M00	BOLT, FLANGE, 8X18	2			~6010052 LRA, XRA




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-3-20	35	HZZ5-90051-M00	BOLT, FLANGE, 8X18	2			~7010006 XCRA
F-3-20	35	HZZ5-90051-M00	BOLT, FLANGE, 8X18		2		~6010057 LRA, XRA
F-3-20	35	HZZ5-90051-M00	BOLT, FLANGE, 8X18		2		~7010010 XCRA
F-3-20	35	HZZ5-90051-M00	BOLT, FLANGE, 8X18			2	~6010095 LDA, LRA, UDA, URA, XDA, XRA
F-3-20	35	HZZ5-90051-M00	BOLT, FLANGE, 8X18			2	~7010024 UCDA, UCRA, XCDA, XCRA
F-3-20	35	HZZ5-90051-M01	BOLT, FLANGE, 8X18	2			6010053~ LRA, XRA
F-3-20	35	HZZ5-90051-M01	BOLT, FLANGE, 8X18	2			7010007~ XCRA
F-3-20	35	HZZ5-90051-M01	BOLT, FLANGE, 8X18		2		6010058~ LRA, XRA
F-3-20	35	HZZ5-90051-M01	BOLT, FLANGE, 8X18		2		7010011~ XCRA
F-3-20	35	HZZ5-90051-M01	BOLT, FLANGE, 8X18			2	6010096~ LDA, LRA, UDA, URA, XDA, XRA
F-3-20	35	HZZ5-90051-M01	BOLT, FLANGE, 8X18			2	7010025~ UCDA, UCRA, XCDA, XCRA
F-3-20	36	HZVL-90102-000	BOLT-WASHER, 10X35	6	6	6	
F-3-20	37	HZW9-90102-000	BOLT, FLANGE, 6X12	1			~6010057 LRA, XRA
F-3-20	37	HZW9-90102-000	BOLT, FLANGE, 6X12	1			~7010008 XCRA
F-3-20	37	HZW9-90102-000	BOLT, FLANGE, 6X12		1		~6010061 LRA, XRA
F-3-20	37	HZW9-90102-000	BOLT, FLANGE, 6X12		1		~7010010 XCRA
F-3-20	37	HZW9-90102-000	BOLT, FLANGE, 6X12			1	∼6010099 LDA, LRA, UDA, URA, XDA, XRA
F-3-20	37	HZW9-90102-000	BOLT, FLANGE, 6X12			1	~7010030 UCDA, UCRA, XCDA, XCRA
F-3-20	37	HZVL-90109-000	BOLT, FLANGE, 6X25	1			6010058~ LRA, XRA
F-3-20	37	HZVL-90109-000	BOLT, FLANGE, 6X25	1			7010009~ XCRA
F-3-20	37	HZVL-90109-000	BOLT, FLANGE, 6X25		1		6010062~ LRA, XRA
F-3-20	37	HZVL-90109-000	BOLT, FLANGE, 6X25		1		7010011~ XCRA
F-3-20	37	HZVL-90109-000	BOLT, FLANGE, 6X25			1	6010100~ LDA, LRA, UDA, URA, XDA, XRA
F-3-20	37	HZVL-90109-000	BOLT, FLANGE, 6X25			1	7010031~ UCDA, UCRA, XCDA, XCRA
F-3-20	38	HZVL-90103-000	BOLT-WASHER, 12X50	11	11	11	
F-3-20	39	HZY3-90105-010	BOLT, HEX., 14X180	2	2	2	
F-3-20	40	HZVL-90107-000	BOLT-WASHER, 8X35	6	6	6	
F-3-20	41	HZVL-90109-000	BOLT, FLANGE, 6X25	2	2	2	
F-3-20	42	H921-90302-000	NUT, HEX., 16MM	1	1	1	




Ref. No.	Part No.					
		Description	BFT200D	BFT225D	BFT250D	Remarks
F-3-20 43	HZY3-90302-000	NUT, SELF-LOCK, 14MM	2	2	2	
F-3-20 44	HZY3-90503-610	WASHER, 30MM	1	1	1	UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-3-20 45	HZY3-90511-000	WASHER, PLAIN, 14MM	2	2	2	
F-3-20 46	HZV4-90605-000	CLIP, TUBE (B12. 5)	1			~6010066 LRA, XRA
F-3-20 46	HZV4-90605-000	CLIP, TUBE (B12. 5)	1			~7010008 XCRA
F-3-20 46	HZV4-90605-000	CLIP, TUBE (B12. 5)		1		~6010061 LRA, XRA
F-3-20 46	HZV4-90605-000	CLIP, TUBE (B12. 5)		1		~7010010 XCRA
F-3-20 46	HZV4-90605-000	CLIP, TUBE (B12. 5)			1	∼6010109 LDA, LRA, UDA, URA, XDA, XRA
F-3-20 46	HZV4-90605-000	CLIP, TUBE (B12. 5)			1	~7010035 UCDA, UCRA, XCDA, XCRA
F-3-20 46	HZY6-90651-000	CLIP B1, TUBE	1			6010067~ LRA, XRA
F-3-20 46	HZY6-90651-000	CLIP B1, TUBE	1			7010009~ XCRA
F-3-20 46	HZY6-90651-000	CLIP B1, TUBE		1		6010062~ LRA, XRA
F-3-20 46	HZY6-90651-000	CLIP B1, TUBE		1		7010011~ XCRA
F-3-20 46	HZY6-90651-000	CLIP B1, TUBE			1	6010110~ LDA, LRA, UDA, URA, XDA, XRA
F-3-20 46	HZY6-90651-000	CLIP B1, TUBE			1	7010036~ UCDA, UCRA, XCDA, XCRA
F-3-20 47	HZY3-90652-000	CIRCLIP, INTERNAL, 43	1	1	1	UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-3-20 48	HZVL-90751-000	PIN, SPRING, 6X22	3	3	3	
F-3-20 49	HZVL-90752-000	PIN, LOCK SPRING	3	3	3	
F-3-20 50	HZV5-90756-000	DOWEL PIN, 6X10	2	2	2	
F-3-20 51	HZVL-91451-000	TUBE, WATER JOINT	1			~6010066 LRA, XRA
F-3-20 51	HZVL-91451-000	TUBE, WATER JOINT	1			~7010008 XCRA
F-3-20 51	HZVL-91451-000	TUBE, WATER JOINT		1		~6010061 LRA, XRA
F-3-20 51	HZVL-91451-000	TUBE, WATER JOINT		1		~7010010 XCRA
F-3-20 51	HZVL-91451-000	TUBE, WATER JOINT			1	∼6010109 LDA, LRA, UDA, URA, XDA, XRA
F-3-20 51	HZVL-91451-000	TUBE, WATER JOINT			1	∼7010035 UCDA, UCRA, XCDA, XCRA
F-3-20 51	HZVL-91451-010	TUBE, WATER JOINT	1			6010067~ LRA, XRA
F-3-20 51	HZVL-91451-010	TUBE, WATER JOINT	1			7010009~ XCRA
F-3-20 51	HZVL-91451-010	TUBE, WATER JOINT		1		6010062~ LRA, XRA
F-3-20 51	HZVL-91451-010	TUBE, WATER JOINT		1		7010011~ XCRA




					Q'ty		
Ref. No.	•	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-3-20	51	HZVL-91451-010	TUBE, WATER JOINT			1	6010110~ LDA, LRA, UDA, URA, XDA, XRA
F-3-20	51	HZVL-91451-010	TUBE, WATER JOINT			1	7010036~ UCDA, UCRA, XCDA, XCRA
F-3-20	52	HZY9-91504-M00	COLLAR, 8. 5X14. 5	6	6	6	
F-3-20	53	HZZ0-91601-M00	GROMMET, 1WAY	2	2	2	
F-3-20	54	HCO-95011-63000	RUBBER C, STAND STOPPER	2	2	2	
F-3-20	55	HGHB-16075-830	0-RING, 1.9X10	1	1	1	
			ı			•	




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-3-30	1	HZV5-40102-000	GROMMET, UNDER CASE	5	5	5	
F-3-30	2	H196-47117-000	RUBBER, STOPPER	2	2	2	
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	1			*T107*BAY BLUE ~6011057 XRA
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)	1			*T107*BAY BLUE ~7011009 XCRA
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)		1		*T107*BAY BLUE ~7011015 XCRA
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)		1		*T107*BAY BLUE ~6011050 XRA
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)			1	*T107*BAY BLUE ~6011155 UDA, URA, XDA, XRA
F-3-30	3	HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL)			1	*T107*BAY BLUE ~7011052 UCDA, UCRA, XCDA, XCRA
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)	1			*T107*BAY BLUE 6011058~ XRA
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)	1			*T107*BAY BLUE 7011010~ XCRA
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)		1		*T107*BAY BLUE 6011051~ XRA
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)		1		*T107*BAY BLUE 7011016~ XCRA
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)			1	*T107*BAY BLUE 6011156~ UDA, URA, XDA, XRA
F-3-30	3	HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)			1	*T107*BAY BLUE 7011053~ UCDA, UCRA, XCDA, XCRA
F-3-30	4	HZVL-63710-900ZA	COVER COMP., ENGINE UNDER R.	1			*T107*BAY BLUE ~6011060 LRA
F-3-30	4	HZVL-63710-900ZA	COVER COMP., ENGINE UNDER R.		1		*T107*BAY BLUE ~6011055 LRA
F-3-30	4	HZVL-63710-900ZA	COVER COMP., ENGINE UNDER R.			1	*T107*BAY BLUE ~6011167 LDA, LRA
F-3-30	4	HZVL-63710-901ZA	COVER COMP., ENGINE UNDER R.	1			*T107*BAY BLUE 6011061~ LRA
F-3-30	4	HZVL-63710-901ZA	COVER COMP., ENGINE UNDER R.		1		*T107*BAY BLUE 6011056~ LRA
F-3-30	4	HZVL-63710-901ZA	COVER COMP., ENGINE UNDER R.			1	*T107*BAY BLUE 6011168~ LDA, LRA
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L.	1	1		*T107*BAY BLUE ~6011057 XRA
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L.	1			*T107*BAY BLUE ~7011009 XCRA
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L.		1		*T107*BAY BLUE ~7011015 XCRA
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L.			1	*T107*BAY BLUE ~6011155 UDA, URA, XDA, XRA
F-3-30	5	HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L.			1	*T107*BAY BLUE ~7011052 UCDA, UCRA, XCDA, XCRA
F-3-30	5	HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L.	1	1		*T107*BAY BLUE 6011058~ XRA
F-3-30	5	HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L.	1			*T107*BAY BLUE 7011010~ XCRA
F-3-30	5	HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L.		1		*T107*BAY BLUE 7011016~ XCRA
F-3-30	5	HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L.			1	*T107*BAY BLUE 6011156~ UDA, URA, XDA, XRA



					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-3-30	5	HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L.			1	*T107*BAY BLUE 7011053~ UCDA, UCRA, XCDA, XCRA
F-3-30	6	HZVL-63715-900ZA	COVER COMP., ENGINE UNDER L.	1			(L) *T107* BAY BLUE LDA, LRA
F-3-30	6	HZVL-63715-900ZA	COVER COMP., ENGINE UNDER L.		1		(L) *T107* BAY BLUE LDA, LRA
F-3-30	6	HZVL-63715-900ZA	COVER COMP., ENGINE UNDER L.			1	(L) *T107* BAY BLUE LDA, LRA
F-3-30	6	HZVL-63715-901ZA	COVER COMP., ENGINE UNDER L.	1			(L) *T107* BAY BLUE LDA, LRA
F-3-30	6	HZVL-63715-901ZA	COVER COMP., ENGINE UNDER L.		1		(L) *T107* BAY BLUE LDA, LRA
F-3-30	6	HZVL-63715-901ZA	COVER COMP., ENGINE UNDER L.			1	(L) *T107* BAY BLUE LDA, LRA
F-3-30	7	HZVL-63730-000	COVER, RR.	1	1	1	
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25	5			~6010066 LRA, XRA
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25	5			~7010008 XCRA
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25		5		XCRA
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25		5		~6010061 LRA, XRA
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25			5	~6010109 LDA, LRA, UDA, URA, XDA, XRA
F-3-30	8	HZVL-90109-000	BOLT, FLANGE, 6X25			5	~7010035 UCDA, UCRA, XCDA, XCRA
F-3-30	9	HZY3-90111-000	BOLT, SPECIAL, 6X17	12	12		LRA
F-3-30	9	HZY3-90111-000	BOLT, SPECIAL, 6X17	14	14		XCRA, XRA
F-3-30	9	HZY3-90111-000	BOLT, SPECIAL, 6X17			12	LDA, LRA
F-3-30	9	HZY3-90111-000	BOLT, SPECIAL, 6X17			14	UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM	5			~6010066 LRA, XRA
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM	5			~7010008 XCRA
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM		5		XCRA
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM		5		~6010061 LRA, XRA
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM			5	~6010109 LDA, LRA, UDA, URA, XDA, XRA
F-3-30	10	HZVL-90512-000	WASHER, PLAIN, 6MM			5	∼7010035 UCDA, UCRA, XCDA, XCRA
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5	3			∼6010066 XRA
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5	3			∼6010089 LRA
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5	3			~7010008 XCRA
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5		3		~6010061 LRA, XRA
F-3-30	11	HZVL-91551-000	COLLAR, 12X6. 5		3		~7010010 XCRA




Ref. No.						Q' ty		
F-3-30 11 HZVL-91551-000 COLLAR, 12X6.5 3 COLLAR, 12X6.5	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-3-30 11 HZVL-91551-010 COLLAR. 12X6.5 3 CO10087~ F-3-30 11 HZVL-91551-010 COLLAR. 12X6.5 3 CO10082~ F-3-30 11 HZVL-91551-010 COLLAR. 12X6.5 3 CO10107~ F-3-30 11 HZVL-91551-010 COLLAR. 12X6.5 3 CO10117~ F-3-30 11 HZVL-91551-010 COLLAR. 12X6.5 3 CO10117~ F-3-30 11 HZVL-91551-010 COLLAR. 12X6.5 3 CO10112~ F-3-30 11 HZVL-91551-010 COLLAR. 12X6.5 3 CO10112~ F-3-30 11 HZVL-91551-010 COLLAR. 12X6.5 3 CO10112~ F-3-30 12 HZVL-91551-000 COLLAR. 12X6.5 3 COLLAR. 12X6.5 5 COLLAR. 12X6.5 5 COLLAR. 12X6.5 5 COLLAR. 12X6.5	F-3-30	11	HZVL-91551-000	COLLAR, 12X6.5			3	
F-3-30 11 H2VL-91551-010 COLLAR, 12X6.5 3 UCDA, UCRA, XCDA, XCRA F-3-30 11 H2VL-91551-010 COLLAR, 12X6.5 3	F-3-30	11	HZVL-91551-000	COLLAR, 12X6.5			3	
F-3-30 11 H2VL-91551-010 COLLAR, 12X6.5 3	F-3-30	11	HZVL-91551-000	COLLAR, 12X6.5			3	
F-3-30 11 HZVL-91551-010 COLLAR, 12X6.5 3 3 COLLAR, 12X6.5 5 COLLAR, 12X6.5 COLLAR, 12X6.5 5 COLLAR, 12X	F-3-30	11	HZVL-91551-010	COLLAR, 12X6. 5	3			
F-3-30 11 HZVL-91551-010 COLLAR, 12X6.5 3 3 KGRA F-3-30 11 HZVL-91551-010 COLLAR, 12X6.5 3 3 COLLAR, 12X6.5 3 2 COLLAR, 12X6.5	F-3-30	11	HZVL-91551-010	COLLAR, 12X6.5	3			
F-3-30 11 HZVL-91551-010 COLLAR, 12X6.5 3 COLLAR, 12X6.5	F-3-30	11	HZVL-91551-010	COLLAR, 12X6.5	3			
F-3-30 11 HZVL-91551-010 COLLAR, 12X6.5 3 XCRA F-3-30 11 HZVL-91551-010 COLLAR, 12X6.5 3 GO10112~ LDA, LRA F-3-30 11 HZVL-91551-010 COLLAR, 12X6.5 3 GO10112~ LDA, LRA F-3-30 11 HZVL-91551-010 COLLAR, 12X6.5 3 UCDA, UCRA, XDA, XRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 6010066 XRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 COLLAR, 12X6.5 3 COLLAR, 12X6.	F-3-30	11	HZVL-91551-010	COLLAR, 12X6.5		3		
F-3-30 11 HZVL-91551-010 COLLAR, 12X6.5 3 UDA, URA, XDA, XRA F-3-30 11 HZVL-91551-010 COLLAR, 12X6.5 3 3 GOIO112 ~ F-3-30 11 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 6010066 F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 6010089 IRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 7010008 XCRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 7010008 XCRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 7010008 XCRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 7010010 XCRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 7010010 XCRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 7010010 XCRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 6010111 LDA, LRA, XDA, XRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 ~ 7010035 UDA, URA, XDA, XRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010035 UDA, URA, XDA, XRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010035 UDA, URA, XDA, XRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010009 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010009 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010009 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010009 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010009 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010009 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010009 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010009 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010009 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010001 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010001 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010011 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010011 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010011 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010011 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010011 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010011 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010011 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 7010011 ~ RRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 ~ 701001	F-3-30	11	HZVL-91551-010	COLLAR, 12X6.5		3		
F-3-30 11 H2VL-91551-010 COLLAR, 12X6.5 3 UCDA, UCDA, XCDA, XCDA XCDA XCDA XCDA XCDA XCDA XCDA XCDA	F-3-30	11	HZVL-91551-010	COLLAR, 12X6.5			3	
F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 COLLAR, 12X6.5	F-3-30	11	HZVL-91551-010	COLLAR, 12X6.5			3	
F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 XRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 CO	F-3-30	11	HZVL-91551-010	COLLAR, 12X6.5			3	
F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 COLLAR, 12X6.5	F-3-30	12	HZVL-91551-000	COLLAR, 12X6.5	2			
F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 C6010061 LRA, XRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 C7010010 XGRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 C6010109 UDA, URA, XDA, XRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 C6010111 LDA, LRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 C7010035 UCDA, UCRA, XCDA, XCRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 C7010035 UCDA, UCRA, XCDA, XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 C6010067∼ XRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 C7010090∼ LRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 C7010090∼ LRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 C7010090∼ XGRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 C7010009∼ XGRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 C7010009∼ XGRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 C70100000000000000000000000000000000000	F-3-30	12	HZVL-91551-000	COLLAR, 12X6.5	2			
F-3-30 12 HZVL-91551-000 COLLAR, 12X6. 5 F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5	F-3-30	12	HZVL-91551-000	COLLAR, 12X6.5	2			
F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 XCRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 C6010109 UDA, URA, XDA, XRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 C6010111 LDA, LRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 COLLAR, XCDA, XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 COLLAR, XCDA, XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 COLLAR, 12X6.5 2 COLLAR, XCDA, XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 COLLAR, XCDA, XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 COLLAR, XCDA, XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 COLLAR, XCDA, XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 COLLAR, XCDA, XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 COLLAR, XCDA, XCRA	F-3-30	12	HZVL-91551-000	COLLAR, 12X6.5		2		
F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 UDA, URA, XDA, XRA F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 2 ~7010035 UDA, UCRA, XCDA, XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 2 6010067~ XRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 6010090~ LRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 7010009~ XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 7010009~ XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 7010017~ XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 7010011~ XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 7010011~ XCRA	F-3-30	12	HZVL-91551-000	COLLAR, 12X6.5		2		
F-3-30 12 HZVL-91551-000 COLLAR, 12X6.5 2 LDA, LRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 COLLAR, 12X6.5	F-3-30	12	HZVL-91551-000	COLLAR, 12X6.5			2	
F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5 2 UGDA, UGRA, XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5 2 G010090~ LRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5 2 T0100090~ LRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5 2 T0100090~ KGRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5 2 T010011~ F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5 2 T010011~ KGRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5 T0100101~ KGRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5 T0100101~ KGRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5 T0100101~ KGRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6. 5 T01001	F-3-30	12	HZVL-91551-000	COLLAR, 12X6.5			2	
F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 XRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 CO	F-3-30	12	HZVL-91551-000	COLLAR, 12X6.5			2	
F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 LRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 TO10009~ XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 6010062~ LRA, XRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 7010011~ XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 6010110~	F-3-30	12	HZVL-91551-010	COLLAR, 12X6.5	2			
F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 Z XCRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 Z 6010062~ LRA, XRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 Z 7010011~ XCRA E-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 Z 6010110~	F-3-30	12	HZVL-91551-010	COLLAR, 12X6.5	2			
F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 LRA, XRA F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 TO10011~ XCRA E-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 6010110~	F-3-30	12	HZVL-91551-010	COLLAR, 12X6.5	2			
F-3-30 12 H7VI_01551_010 COLLAR 12X6.5 2 XCRA E_3-30 12 H7VI_01551_010 COLLAR 12X6.5 2 6010110~	F-3-30	12	HZVL-91551-010	COLLAR, 12X6.5		2		
	F-3-30	12	HZVL-91551-010	COLLAR, 12X6.5		2		
	F-3-30	12	HZVL-91551-010	COLLAR, 12X6.5			2	
F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 6010112~ LDA, LRA	F-3-30	12	HZVL-91551-010	COLLAR, 12X6.5			2	
F-3-30 12 HZVL-91551-010 COLLAR, 12X6.5 2 7010036~ UCDA, UCRA, XCDA, XCRA	F-3-30	12	HZVL-91551-010	COLLAR, 12X6.5			2	
F-3-30 13 HZVL-90110-000 BOLT, WASHER, 6X25 5 6010067~ LRA, XRA	F-3-30	13	HZVL-90110-000	BOLT, WASHER, 6X25	5			6010067~ LRA, XRA
F-3-30 13 HZVL-90110-000 BOLT, WASHER, 6X25 5 7010009~ XCRA	F-3-30	13	HZVL-90110-000	BOLT, WASHER, 6X25	5			7010009~ XCRA




					Q'ty	,	
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-3-30	13	HZVL-90110-000	BOLT, WASHER, 6X25		5		6010062~ LRA, XRA
F-3-30	13	HZVL-90110-000	BOLT, WASHER, 6X25			5	6010110~ LDA, LRA, UDA, URA, XDA, XRA
F-3-30	13	HZVL-90110-000	BOLT, WASHER, 6X25			5	7010036~ UCDA, UCRA, XCDA, XCRA
-							
-							
	ш		l	l	<u> </u>		

F-4 WATER PUMP/VERTICAL SHAFT




				Q' ty			
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-4	1	HZY3-19210-003	IMPELLER, PUMP	1	1	1	
F-4	2	HZY3-19221-010	HOUSING, IMPELLER	1	1	1	
F-4	3	HZY3-19223-000	LINER, PUMP	1	1	1	
F-4	4	HZY3-19231-000	COVER, IMPELLER	1	1	1	
F-4	5	HZX2-19234-C00	GASKET B, IMPELLER	1	1	1	
F-4	6	HZVL-19241-000	HOUSING, WATER PUMP	1			~6011044 LRA
F-4	6	HZVL-19241-000	HOUSING, WATER PUMP	1			~7011008 XCRA
F-4	6	HZVL-19241-000	HOUSING, WATER PUMP		1		~6011048 LRA
F-4	6	HZVL-19241-000	HOUSING, WATER PUMP		1		~7011014 XCRA
F-4	6	HZVL-19241-000	HOUSING, WATER PUMP			1	~6011112 LDA, LRA
F-4	6	HZVL-19241-010	HOUSING, WATER PUMP	1			6011045~ LRA
F-4	6	HZVL-19241-010	HOUSING, WATER PUMP	1			7011009~ XCRA
F-4	6	HZVL-19241-010	HOUSING, WATER PUMP		1		6011049~ LRA
F-4	6	HZVL-19241-010	HOUSING, WATER PUMP		1		7011015~ XCRA
F-4	6	HZVL-19241-010	HOUSING, WATER PUMP			1	6011113~ LDA, LRA
F-4	7	HZY3-19251-000	TUBE, WATER(L)	1	1	1	LDA, LRA
F-4	7	HZY3-19251-611	TUBE, WATER (XL)	1	1	1	XCDA, XCRA, XDA, XRA
F-4	7	HZY3-19251-621	TUBE, WATER (XXL)			1	UCDA, UCRA, UDA, URA
F-4	8	HZY3-19253-000	RING, WATER TUBE SEAL	1	1	1	
F-4	9	HZY3-24310-C00	ROD COMP., SHIFT	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-4	9	HZY3-24310-E00	ROD COMP., SHIFT	1	1	1	(COUNTER ROTATION) UCDA, UCRA, XCDA, XCRA
F-4	10	HZY3-24318-000	SPRING, SHIFT ROD	1	1	1	
F-4	11	HZY6-24320-000	ROD COMP. A, SHIFT(L)	1	1	1	LDA, LRA
F-4	11	HZY6-24320-610	ROD COMP. A, SHIFT(XL)	1	1	1	XCDA, XCRA, XDA, XRA
F-4	11	HZY3-24320-A20	ROD COMP. A, SHIFT(XXL)			1	UCDA, UCRA, UDA, URA
F-4	12	HZW1-24343-B02	HOLDER, SHIFT ROD	1	1	1	
F-4	13	HZY3-40204-000	GROMMET, EXTENSION CASE	1	1	1	
F-4	14	HZX2-41112-C00	SHAFT, VERTICAL(L)	1	1	1	LDA, LRA
F-4	14	HZX2-41112-C10	SHAFT, VERTICAL (XL)	1	1	1	XCDA, XCRA, XDA, XRA

F-4 WATER PUMP/VERTICAL SHAFT




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-4	14	HZX2-41112-C20	SHAFT, VERTICAL (XXL)			1	UCDA, UCRA, UDA, URA
F-4	15	HZY3-41116-000	SLINGER, OIL	1	1	1	
F-4	17	HZX2-90105-C00	BOLT-WASHER, 8X60	4	4	4	
F-4	18	HHW1-90215-671	BOLT, FLANGE, 6X16	1	1	1	
F-4	19	HZX2-90301-C00	NUT, LOCK, 68MM	1	1	1	
F-4	20	HZX2-90303-C00	NUT, HEX., 18MM	1	1	1	
F-4	21	H723-90472-000	WASHER, PLAIN, 12MM	1	1	1	
F-4	22	HZX2-90518-C00	SHIM A, GEAR (0.10)	1	1	1	
F-4	22	HZX2-90519-C00	SHIM B, GEAR (0.15)	1	1	1	
F-4	22	HZX2-90520-C00	SHIM C, GEAR (0.30)	1	1	1	
F-4	22	HZX2-90521-C00	SHIM D, GEAR (0.50)	1	1	1	
F-4	23	HZY3-90752-003	KEY, WOODRUFF	1	1	1	
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10	2	2		~7011015 XCRA
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10	2			~6011077 XRA
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10	2			~6011085 LRA
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10		2		~6011059 XRA
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10		2		~6011061 LRA
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10			2	UCDA, UCRA
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10			2	~6011188 XDA, XRA
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10			2	~6011209 UDA, URA
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10			2	~6011258 LDA, LRA
F-4	24	HZV5-90756-000	DOWEL PIN, 6X10			2	~7011063 XCDA, XCRA
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10	2	2		7011016~ XCRA
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10	2			6011078~ XRA
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10	2			6011086~ LRA
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10		2		6011060~ XRA
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10		2		6011062~ LRA
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10			2	6011189~ XDA, XRA
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10			2	6011210~ UDA, URA


F-4 WATER PUMP/VERTICAL SHAFT




					Q' ty		
Ref. No		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10			2	6011259~ LDA, LRA
F-4	24	HZVL-90756-000	DOWEL PIN, 6X10			2	7011064~ XCDA, XCRA
F-4	25	HZX2-91053-C01	BEARING, NEEDLE, 30.5X47X37	1	1	1	
F-4	26	HZX2-91056-C01	BEARING, TAPER ROLLER,	1	1	1	32X66X49
F-4	27	HZY3-91251-C01	SEAL, WATER, 26X42X7	2	2	2	
F-4	28	HZY3-91254-003	SEAL, WATER, 12X21X6	2	2	2	
F-4	29	HMJ0-91308-003	O-RING	1	1	1	
F-4	30	HZY3-91356-003	O-RING, WATER PUMP	1	1	1	
F-4	31	HZX2-91358-C00	O-RING, WATER PUMP HOUSING	1	1	1	
F-4	32	HZX2-91359-C00	0-RING, 65.4X2.4	1	1	1	
F-4	33	HZY3-91551-000	COLLAR, DISTANCE	4	4	4	
F-4	34	HCO-94520-47000	CIRCLIP, INTERNAL, 47MM	1	1	1	
F-4	35	HCO-94540-10019	E-RING, 10MM	1	1	1	
		<u> </u>	<u> </u>				




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-5	1	HZX2-24101-C00	SHIFTER, CLUTCH	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	2	HZY3-24102-000	PIN, SHIFTER, 8X50	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	3	HZY3-24103-000	RING, CROSS PIN	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	4	HZY3-24113-A01	SLIDER COMP., SHIFT	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	5	HZY3-24122-A01	SLIDER, SHIFT	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	6	HZY3-24123-000	SPRING, SHIFT	2	2	2	LDA, LRA, UDA, URA, XDA, XRA
F-5	7	HZY3-24124-310	PLATE, SHIFT	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	9	HZX2-41151-C00	GEAR, BEVEL (REVERSE) (24T)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	10	HZX2-41161-C00	SHAFT, PROPELLER	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107*	1			~6011036 LRA
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107*		1		~6011026 LRA
F-5	11	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107*	1			6011037~ LRA
F-5	11	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107*		1		6011027~ LRA
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107*	1			~6011009 XRA
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107*		1		~6011020 XRA
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107*			1	~6011033 XDA, XRA
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107*			1	~6011048 UDA, URA
F-5	11	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107*			1	~6011052 LDA, LRA
F-5	11	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107*	1			6011010~ XRA
F-5	11	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107*		1		6011021~ XRA
F-5	11	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107*			1	6011034~ XDA, XRA
F-5	11	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107*			1	6011049~ UDA, URA
F-5	11	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107*			1	6011053~ LDA, LRA
F-5	12	HZX2-41202-C00	HOLDER, BEARING	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	13	HZY3-90123-000	BOLT, HEX., 12X45	2	2	2	LDA, LRA, UDA, URA, XDA, XRA
F-5	14	HZW1-90301-B00	NUT, CASTLE, 18MM	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	15	HZX2-90506-C00	WASHER, PROPELLER THRUST	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	16	HZW5-90509-711	WASHER, THRUST BEARING	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5	17	HZX2-90512-C00	WASHER, PROPELLER	1	1	1	LDA, LRA, UDA, URA, XDA, XRA




Part No. Part No. Description Sep						Q' ty		
F-5 18 NZX2-90329-000 SHIN B. BEVEL (0.15) 2 2 2 LDA. LRA. UDA. URA. XIDA. XIBA. XIBA. F-5 18 NZX2-90330-000 SHIN C. BEVEL (0.50) 2 2 2 LDA. LRA. UDA. URA. XIDA. XIBA. XIBA. XIBA. F-5 19 NZX3-90549-000 SHIN D. THRUST (2.75) 1 1 1 1 LDA. LRA. UDA. URA. XIDA. XIBA. XIBA. XIBA. F-5 19 NZX3-90549-000 SHIN D. THRUST (2.80) 1 1 1 1 LDA. LRA. UDA. URA. XIDA. XIBA. XIBA. XIBA. F-5 19 NZX3-90559-000 SHIN D. THRUST (2.90) 1 1 1 1 LDA. LRA. UDA. URA. XIDA. XIBA. XIBA. XIBA. F-5 19 NZX3-90559-000 SHIN D. THRUST (2.90) 1 1 1 1 LDA. LRA. UDA. URA. XIDA. XIBA. XIBA. XIBA. F-5 19 NZX3-90559-000 SHIN D. THRUST (2.90) 1 1 1 1 LDA. LRA. UDA. URA. XIDA. XIBA. XIBA. XIBA. F-5 19 NZX3-90559-000 SHIN D. THRUST (2.90) 1 1 1 1 LDA. LRA. UDA. URA. XIDA. XIBA. XIBA. XIBA. F-5 19 NZX3-90559-000 SHIN D. THRUST (2.90) 1 1 1 1 LDA. LRA. UDA. URA. XIDA. XIBA. XIBA. XIBA. F-5 19 NZX3-90559-000 SHIN D. THRUST (2.90) 1 1 1 1 LDA. LRA. UDA. URA. XIDA. XIBA. XIBA. XIBA. XIBA. F-5 19 NZX3-90559-000 SHIN D. THRUST (2.90) 1 1 1 1 LDA. LRA. UDA. URA. XIDA. XIBA.	Ref. No		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-5 18 HZX2-90590-C00 SHIM C. BEVEL (0.30) 2 2 2 2 LDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 18 HZX2-90531-C00 SHIM D. BEVEL (0.50) 2 2 2 2 LDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90549-C00 SHIM B. THRUST (2.75) 1 1 1 1 LDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90549-C00 SHIM B. THRUST (2.80) 1 1 1 1 LDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM C. THRUST (2.85) 1 1 1 LDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM C. THRUST (2.95) 1 1 1 LDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM C. THRUST (2.95) 1 1 1 LDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM C. THRUST (2.95) 1 1 LDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM F. THRUST (3.05) 1 1 LDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (3.05) 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (3.05) 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (2.70) 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (2.55) 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (2.55) 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (2.55) 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (2.55) 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (2.55) 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (2.55) 1 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (2.55) 1 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (2.55) 1 1 1 LDA, LRA, LIDA, LRA, LIDA, LRA, LIDA, LRA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM M. THRUST (2.55) 1 1 1 LDA, LRA, LIDA, LRA, LIDA	F-5	18	HZX2-90528-C00	SHIM A, BEVEL (0.10)	2	2	2	LDA, LRA, UDA, URA, XDA, XRA
F-5 18 HZX2-90531-C00 SHIM D. BEVEL (0.50) 2 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90549-C00 SHIM B. THRUST (2.75) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90569-C00 SHIM B. THRUST (2.85) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (2.85) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (2.90) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (2.90) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (3.00) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (3.05) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (3.05) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (3.05) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (3.05) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (2.70) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-C00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZY3-90559-C00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 21 HZY3-90559-C00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90759-B00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90759-B00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90759-B00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90759-B00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90759-B00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90759-B00 SHIM E. THRUST (2.55) 1 1 1 LDA, LRA, UDA, U	F-5	18	HZX2-90529-C00	SHIM B, BEVEL (0.15)	2	2	2	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90569-000 SHIM A, THRUST (2.75) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-6 19 HZY3-90560-000 SHIM C, THRUST (2.80) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90561-000 SHIM D, THRUST (2.90) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90561-000 SHIM E, TIRRUST (2.95) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90562-000 SHIM E, TIRRUST (2.95) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90563-000 SHIM E, TIRRUST (3.00) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90565-000 SHIM E, TIRRUST (3.00) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90565-000 SHIM E, TIRRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90565-000 SHIM E, TIRRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90565-000 SHIM E, TIRRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90566-000 SHIM E, TIRRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90566-000 SHIM E, TIRRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90569-000 SHIM E, TIRRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90569-000 SHIM E, TIRRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90569-000 SHIM E, TIRRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90569-000 SHIM E, TIRRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90569-000 SHIM E, TIRRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90758-B00 PIN, SPLIT, 4 0 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZZ2-9105-001 BEARING, THRUST (F) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 25 HZZ2-9105-001 BEARING, TAPER ROLLER. 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZZ3-9155-000 SEALE, SZ4ZZ300 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 HZZ3-9155-000 CRENG, TAPER ROLLER. 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HZY2-9105-001 BEARING, TAPER ROLLER. 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 HZZ3-9155-000 CRENG, TAPER ROLLER. 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HZY2-9105-001 BEARING, TAPER ROLLER. 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HZY2-9105-000 CRENG, TAPER ROLLER. 2	F-5	18	HZX2-90530-C00	SHIM C, BEVEL(0.30)	2	2	2	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90550-000 SHIM D. THRUST (2.95) 1 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90551-000 SHIM D. THRUST (2.95) 1 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90551-000 SHIM E. THRUST (2.95) 1 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90552-000 SHIM E. THRUST (3.00) 1 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90554-000 SHIM F. THRUST (3.00) 1 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90554-000 SHIM F. THRUST (3.05) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90554-000 SHIM F. THRUST (3.10) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90550-000 SHIM I. THRUST (2.70) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90550-000 SHIM I. THRUST (2.65) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90550-000 SHIM I. THRUST (2.65) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90550-000 SHIM I. THRUST (2.60) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90550-000 SHIM I. THRUST (2.50) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 19 HZY3-90550-000 SHIM I. THRUST (2.50) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 20 HZY3-90550-000 SHIM I. THRUST (2.50) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 21 HZW1-90750-9000 SHIM I. THRUST (2.50) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 22 HZW1-90750-9001 BEARING. THRUST (7.50) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 23 HZY3-91050-001 BEARING. THRUST (7.50) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 24 HZX2-91051-001 BEARING. THRUST (7.50) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 24 HZX2-91051-001 BEARING. THRUST (7.50) 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 24 HZX2-91050-001 BEARING. RADIAL_BALL. 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 24 HZX2-91050-001 BEARING. RADIAL_BALL. 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 25 HZX2-91050-001 BEARING. RADIAL_BALL. 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 26 HZX2-91351-000 GRULER. 3X13.8 1 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 27 HZY3-91151-000 GRULER. 3X13.8 1 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 30 HZZ2-91351-000 GRULER. 3X13.8 1 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 31 HCO-94510-15000 CIRCLIP, EXTERNAL_ISMM 1 1 1 1 LDA_LRA_UDA_URA_XDA_XRA F-5 31 HCO-96211-07000 BALL. STEEL. #7(7/32) 2 2 2 LDA_LRA_UDA_URA_XDA_XRA	F-5	18	HZX2-90531-C00	SHIM D, BEVEL (0.50)	2	2	2	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90550-000 SHIM C. THRUST (2.85) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90551-000 SHIM D. THRUST (2.90) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90552-000 SHIM E. THRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90553-000 SHIM F. THRUST (3.00) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90554-000 SHIM G. THRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90555-000 SHIM H. THRUST (3.10) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90556-000 SHIM I. THRUST (2.70) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM I. THRUST (2.70) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM II. THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM II. THRUST (2.60) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM II. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM M. THRUST (2.50) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM M. THRUST (2.50) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZY3-90559-000 MRASHER, PLAIN, 12MM 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 21 HZY3-90559-000 BEARING, THRUST (7) 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZXI-90758-B00 PIN, SPLIT, 4, 0 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91055-001 BEARING, TAPER ROLLER 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91055-001 BEARING, TAPER ROLLER 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 25 HZX2-91055-003 SEARING, RADIAL BALL, 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZX3-9157-003 BEARING, RADIAL BALL, 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HOO-94510-15000 CIRCLEP, SX13.8 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HOO-94510-15000 CIRCLEP, EXTERNAL ISMM 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HOO-96211-07000 BALL, STEEL, #7(7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	19	HZY3-90548-000	SHIM A, THRUST (2.75)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90551-000 SHIM D. THRUST (2.90) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90552-000 SHIM F. THRUST (3.95) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90553-000 SHIM F. THRUST (3.00) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90554-000 SHIM G. THRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90556-000 SHIM H. THRUST (3.10) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90556-000 SHIM I. THRUST (2.70) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90556-000 SHIM J. THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM K. THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM K. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM K. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM K. THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZV5-90559-000 WASHER, PLAIN, 12MM 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90758-B00 PIN, SPLIT, 4, 0 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 23 HPT2-91005-NO1 BEARING, THRUST (F) 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91051-C01 BEARING, TAPER ROLLER, 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZY3-91057-003 BEARING, NEEDLE, 32X42X30 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 28 HZY3-91151-000 ROLLER, 3X13, 8 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 30 HZY3-91051-000 GIRCLER, 3X13, 8 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HCO-94510-15000 GIRCLER, 2X133, 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HCO-94510-15000 GIRCLER, EXTERNAL, ISMM 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HCO-96211-07000 BALL, STEEL, #7(7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	19	HZY3-90549-000	SHIM B, THRUST (2.80)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 H2Y3-90552-000 SHIM E, THRUST (2.95) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90553-000 SHIM F, THRUST (3.00) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90554-000 SHIM H, THRUST (3.05) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90555-000 SHIM H, THRUST (3.10) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90556-000 SHIM I, THRUST (2.70) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90557-000 SHIM I, THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90558-000 SHIM I, THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90559-000 SHIM I, THRUST (2.50) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90559-000 SHIM I, THRUST (2.50) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90560-000 SHIM I, THRUST (2.50) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 H2Y3-90559-000 WASHER, PLAIN, 12MM 2 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 22 H2W1-90758-B00 PIN, SPL1T, 4.0 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 H2X2-91051-C01 BEARING, TAPER ROLLER, 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 25 H2X2-91055-O01 BEARING, TAPER ROLLER, 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 27 H2Y3-91057-O03 BEARING, REDLE, 32X42X30 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 H2Y3-9151-C000 ROLLER, 3X13.8 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 30 H2X3-91252-003 SEAL, WATER, 30X45X7 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 31 H00-94510-15000 CIRCLIP, EXTERNAL, 15MM 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 H00-94510-15000 CIRCLIP, EXTERNAL, 15MM 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 32 H00-96211-07000 BALL, STEEL, #7 (7/32) 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	19	HZY3-90550-000	SHIM C, THRUST (2.85)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90553-000 SHIM F. THRUST (3.00) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90554-000 SHIM G. THRUST (3.05) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90555-000 SHIM H. THRUST (3.10) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90556-000 SHIM I. THRUST (2.70) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90557-000 SHIM J. THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90558-000 SHIM K. THRUST (2.60) 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM K. THRUST (2.55) 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90569-000 SHIM M. THRUST (2.50) 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZY3-90559-000 WASHER, PLAIN, 12MM 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZWI-90758-B00 PIN, SPLIT, 4.0 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 23 HPT2-91005-N01 BEARING, THRUST (F) 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91051-C01 BEARING, TAPER ROLLER, 1 1 GOX100X30 LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZY3-91057-003 BEARING, NEEDLE, 3ZX42X30 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 HZZ3-91510-000 ROLLER, 3X13.8 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 HZX2-91515-000 PROLLER, 3X13.8 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 30 HZX2-9151000 O -RING, 121X3.1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HOO-96211-07000 BALL, STEEL, #7 (7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	19	HZY3-90551-000	SHIM D, THRUST (2.90)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90554-000 SHIM G, THRUST (3.05) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90555-000 SHIM H, THRUST (2.70) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90556-000 SHIM I, THRUST (2.70) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90557-000 SHIM J, THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90558-000 SHIM K, THRUST (2.60) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM K, THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90560-000 SHIM M, THRUST (2.50) 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZV5-90559-000 WASHER, PLAIN, 12MM 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZWI1-90758-B00 PIN, SPLIT, 4.0 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 23 HPT2-91005-N01 BEARING, THRUST (F) 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91051-C01 BEARING, THRUST (F) 1 LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZY3-91057-003 BEARING, RADIAL BALL, 1 1 S5X100X21 LDA, LRA, UDA, URA, XDA, XRA F-5 28 HZY3-91151-000 ROLLER, 3X13.8 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 HZZ3-91252-003 SEAL, WATER, 30X45X7 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 30 HZX2-91351-C00 CIRCLIP, EXTERNAL, 15MM 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HCO-94510-15000 CIRCLIP, EXTERNAL, 15MM 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 32 LDA, LRA, UDA, URA, XDA, XRA	F-5	19	HZY3-90552-000	SHIM E, THRUST (2.95)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90555-000 SHIM H, THRUST (3.10) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90556-000 SHIM I, THRUST (2.70) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90557-000 SHIM K, THRUST (2.60) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM K, THRUST (2.55) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90560-000 SHIM M, THRUST (2.50) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90560-000 SHIM M, THRUST (2.50) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZY3-90560-000 WASHER, PLAIN, 12MM 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZV5-90559-000 WASHER, PLAIN, 12MM 2 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5	F-5	19	HZY3-90553-000	SHIM F, THRUST (3.00)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 H2Y3-90556-000 SHIM I, THRUST (2.70) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90557-000 SHIM K, THRUST (2.65) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90558-000 SHIM K, THRUST (2.60) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90559-000 SHIM K, THRUST (2.55) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 H2Y3-90560-000 SHIM M, THRUST (2.50) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 H2V5-90559-000 WASHER, PLAIN, 12MM 2 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 22 H2W1-90758-B00 PIN, SPLIT, 4.0 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 23 HPT2-91005-N01 BEARING, THRUST (F) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 H2X2-91051-C01 BEARING, TAPER ROLLER, 1 1 1 1 GOVIOX30 LDA, LRA, UDA, URA, XDA, XRA F-5 27 H2X3-91057-003 BEARING, REDLE, 32X42X30 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 28 H2Y3-91151-000 ROLLER, 3X13.8 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 H2Z3-91252-003 SEAL, WATER, 30X45X7 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HCO-94510-15000 CIRCLP, EXTERNAL, 15MM 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 32 HCO-96211-07000 BALL, STEEL, #7(7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	19	HZY3-90554-000	SHIM G, THRUST (3.05)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90557-000 SH1M J, THRUST (2.65) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90558-000 SH1M K, THRUST (2.60) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SH1M L, THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90560-000 SH1M M, THRUST (2.50) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZV5-90559-000 WASHER, PLAIN, 12MM 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90758-B00 PIN, SPLIT, 4.0 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 23 HPT2-91005-N01 BEARING, THRUST (F) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91051-C01 BEARING, TAPER ROLLER, 1 1 1 1 1 1 55X100X21 F-5 25 HZX2-91057-C01 BEARING, RADIAL BALL, 1	F-5	19	HZY3-90555-000	SHIM H, THRUST (3.10)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90558-000 SHIM K, THRUST (2.60) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90559-000 SHIM L, THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90560-000 SHIM M, THRUST (2.50) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZV5-90559-000 WASHER, PLAIN, 12MM 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90758-B00 PIN, SPLIT, 4.0 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 23 HPT2-91005-N01 BEARING, THRUST (F) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91051-C01 BEARING, RADIAL BALL, 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZY3-91057-003 BEARING, NEEDLE, 32X42X30 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 28 HZY3-91151-000 ROLLER, 3X13.8 1 1	F-5	19	HZY3-90556-000	SHIM I, THRUST (2.70)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90559-000 SHIM L, THRUST (2.55) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 19 HZY3-90560-000 SHIM M, THRUST (2.50) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZV5-90559-000 WASHER, PLAIN, 12MM 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90758-B00 PIN, SPLIT, 4.0 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 23 HPT2-91005-N01 BEARING, THRUST (F) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91051-C01 BEARING, TAPER ROLLER, 1 1 1 1 60X100X30 LDA, LRA, UDA, URA, XDA, XRA F-5 25 HZX2-91055-C01 BEARING, RADIAL BALL, 1 1 1 1 55X100X21 LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZY3-91057-003 BEARING, NEEDLE, 32X42X30 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 28 HZY3-91151-000 ROLLER, 3X13.8	F-5	19	HZY3-90557-000	SHIM J, THRUST(2.65)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 19 HZY3-90560-000 SHIM M, THRUST (2.50) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 20 HZV5-90559-000 WASHER, PLAIN, 12MM 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90758-B00 PIN, SPLIT, 4.0 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 23 HPT2-91005-N01 BEARING, THRUST (F) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91051-C01 BEARING, TAPER ROLLER, 1	F-5	19	HZY3-90558-000	SHIM K, THRUST (2.60)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 20 HZV5-90559-000 WASHER, PLAIN, 12MM 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 22 HZW1-90758-B00 PIN, SPLIT, 4.0 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 23 HPT2-91005-N01 BEARING, THRUST (F) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91051-C01 BEARING, TAPER ROLLER, 1 1 1 1 60X100X30 LDA, LRA, UDA, URA, XDA, XRA F-5 25 HZX2-91055-C01 BEARING, RADIAL BALL, 1 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZY3-91057-003 BEARING, NEEDLE, 32X42X30 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 28 HZY3-91151-000 ROLLER, 3X13.8 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 HZZ3-91252-003 SEAL, WATER, 30X45X7 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 30 HZX2-91351-C00 O-RING, 121X3.1	F-5	19	HZY3-90559-000	SHIM L, THRUST (2.55)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 22 HZW1-90758-B00 PIN, SPLIT, 4.0 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 23 HPT2-91005-N01 BEARING, THRUST (F) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91051-C01 BEARING, TAPER ROLLER, 1 1 1 1 60X100X30 LDA, LRA, UDA, URA, XDA, XRA F-5 25 HZX2-91055-C01 BEARING, RADIAL BALL, 1 1 1 1 1 55X100X21 LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZY3-91057-003 BEARING, NEEDLE, 32X42X30 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 28 HZY3-91151-000 ROLLER, 3X13.8 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 HZZ3-91252-003 SEAL, WATER, 30X45X7 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 30 HZX2-91351-C00 O-RING, 121X3.1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HCO-94510-15000 <t< td=""><td>F-5</td><td>19</td><td>HZY3-90560-000</td><td>SHIM M, THRUST (2.50)</td><td>1</td><td>1</td><td>1</td><td>LDA, LRA, UDA, URA, XDA, XRA</td></t<>	F-5	19	HZY3-90560-000	SHIM M, THRUST (2.50)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 23 HPT2-91005-N01 BEARING, THRUST (F) 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 24 HZX2-91051-C01 BEARING, TAPER ROLLER, 1	F-5	20	HZV5-90559-000	WASHER, PLAIN, 12MM	2	2	2	LDA, LRA, UDA, URA, XDA, XRA
F-5 24 HZX2-91051-C01 BEARING, TAPER ROLLER, 1 1 1 1 1 60X100X30 LDA, LRA, UDA, URA, XDA, XRA F-5 25 HZX2-91055-C01 BEARING, RADIAL BALL, 1	F-5	22	HZW1-90758-B00	PIN, SPLIT, 4.0	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 25 HZX2-91055-C01 BEARING, RADIAL BALL, 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZY3-91057-003 BEARING, NEEDLE, 32X42X30 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 28 HZY3-91151-000 ROLLER, 3X13.8 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 HZZ3-91252-003 SEAL, WATER, 30X45X7 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 30 HZX2-91351-C00 O-RING, 121X3.1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HCO-94510-15000 CIRCLIP, EXTERNAL, 15MM 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 32 HCO-96211-07000 BALL, STEEL, #7(7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	23	HPT2-91005-N01	BEARING, THRUST(F)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 25 HZX2-91055-G01 BEARING, RADIAL BALL, I I I LDA, LRA, UDA, URA, XDA, XRA F-5 27 HZY3-91057-003 BEARING, NEEDLE, 32X42X30 I 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 28 HZY3-91151-000 ROLLER, 3X13.8 I 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 HZZ3-91252-003 SEAL, WATER, 30X45X7 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 30 HZX2-91351-C00 O-RING, 121X3.1 I 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HC0-94510-15000 CIRCLIP, EXTERNAL, 15MM I 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 32 HC0-96211-07000 BALL, STEEL, #7 (7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	24	HZX2-91051-C01	BEARING, TAPER ROLLER,	1	1	1	
F-5 28 HZY3-91151-000 ROLLER, 3X13.8 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 29 HZZ3-91252-003 SEAL, WATER, 30X45X7 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 30 HZX2-91351-C00 O-RING, 121X3.1 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HCO-94510-15000 CIRCLIP, EXTERNAL, 15MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 32 HCO-96211-07000 BALL, STEEL, #7 (7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	25	HZX2-91055-C01	BEARING, RADIAL BALL,	1	1	1	
F-5 29 HZZ3-91252-003 SEAL, WATER, 30X45X7 2 2 2 LDA, LRA, UDA, URA, XDA, XRA F-5 30 HZX2-91351-C00 0-RING, 121X3.1 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HC0-94510-15000 CIRCLIP, EXTERNAL, 15MM 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 32 HC0-96211-07000 BALL, STEEL, #7 (7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	27	HZY3-91057-003	BEARING, NEEDLE, 32X42X30	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 30 HZX2-91351-C00 0-RING, 121X3.1 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 31 HC0-94510-15000 CIRCLIP, EXTERNAL, 15MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 32 HC0-96211-07000 BALL, STEEL, #7 (7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	28	HZY3-91151-000	ROLLER, 3X13.8	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-5 31 HCO-94510-15000 CIRCLIP, EXTERNAL, 15MM 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-5 32 HCO-96211-07000 BALL, STEEL, #7 (7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	29	HZZ3-91252-003	SEAL, WATER, 30X45X7	2	2	2	LDA, LRA, UDA, URA, XDA, XRA
F-5 32 HCO-96211-07000 BALL, STEEL, #7(7/32) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	30	HZX2-91351-C00	0-RING, 121X3.1	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
	F-5	31	HC0-94510-15000	CIRCLIP, EXTERNAL, 15MM	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
- - - - - - - - -	F-5	32	HC0-96211-07000	BALL, STEEL, #7 (7/32)	2	2	2	LDA, LRA, UDA, URA, XDA, XRA
F-5 33 HCO-96211-12000 BALL, STEEL, #12(3/8) 2 2 2 LDA, LRA, UDA, URA, XDA, XRA	F-5	33	HCO-96211-12000	BALL, STEEL, #12(3/8)	2	2	2	LDA, LRA, UDA, URA, XDA, XRA




					Q' ty	Ĵ' ty	
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-5	34	HZX2-06400-C00	GEAR KIT	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
-							
-							
-							



					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-5-1	1	HZX2-24101-C00	SHIFTER, CLUTCH	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	2	HZY3-24102-000	PIN, SHIFTER, 8X50	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	3	HZY3-24103-000	RING, CROSS PIN	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	4	HZY3-24113-A01	SLIDER COMP., SHIFT	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	5	HZY3-24122-A01	SLIDER, SHIFT	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	6	HZY3-24123-000	SPRING, SHIFT	2	2	2	UCDA, UCRA, XCDA, XCRA
F-5-1	7	HZY3-24124-310	PLATE, SHIFT	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	9	HZX2-41150-E00	GEAR COMP., BEVEL (REVERSE)	1	1	1	(24T) (COUNTER ROTATION) UCDA, UCRA, XCDA, XCRA
F-5-1	10	HZX2-41161-E00	SHAFT, PROPELLER	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	11	HZX2-41200-E00	HOLDER ASSY., BEARING	1	1	1	(COUNTER ROTATION) UCDA, UCRA, XCDA, XCRA
F-5-1	12	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	1			~7011001 XCRA
F-5-1	12	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE		1		~7011002 XCRA
F-5-1	12	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE			1	~7011012 XCDA, XCRA
F-5-1	12	HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE			1	~7011017 UCDA, UCRA
F-5-1	12	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE	1			7011002~ XCRA
F-5-1	12	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE		1		7011003~ XCRA
F-5-1	12	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE			1	7011013~ XCDA, XCRA
F-5-1	12	HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE			1	7011018~ UCDA, UCRA
F-5-1	13	HZY3-90123-000	BOLT, HEX., 12X45	2	2	2	UCDA, UCRA, XCDA, XCRA
F-5-1	14	HZW1-90301-B00	NUT, CASTLE, 18MM	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	15	HZX2-90506-C00	WASHER, PROPELLER THRUST	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	16	HZW5-90509-711	WASHER, THRUST BEARING	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	17	HZX2-90512-C00	WASHER, PROPELLER	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	18	HZX2-90528-C00	SHIM A, BEVEL (0.10)	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	18	HZX2-90529-C00	SHIM B, BEVEL (0.15)	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	18	HZX2-90530-C00	SHIM C, BEVEL (0.30)	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	18	HZX2-90531-C00	SHIM D, BEVEL (0.50)	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	19	HZX2-90528-E00	SHIM A, BEVEL (0.10)	1	1	1	(COUNTER ROTATION) UCDA, UCRA, XCDA, XCRA
F-5-1	19	HZX2-90529-E00	SHIM B, BEVEL (0.15)	1	1	1	(COUNTER ROTATION) UCDA, UCRA, XCDA, XCRA




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-5-1	19	HZX2-90530-E00	SHIM C, BEVEL (0.30)	1	1	1	(COUNTER ROTATION) UCDA, UCRA, XCDA, XCRA
F-5-1	19	HZX2-90531-E00	SHIM D, BEVEL (0.50)	1	1	1	(COUNTER ROTATION) UCDA, UCRA, XCDA, XCRA
F-5-1	20	HZX2-90541-E01	WASHER, THRUST, 85X110X2	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	21	HZX2-90542-E01	WASHER, THRUST, 48X74X3	1	1	1	(COUNTER ROTATION) UCDA, UCRA, XCDA, XCRA
F-5-1	22	HZV5-90559-000	WASHER, PLAIN, 12MM	2	2	2	UCDA, UCRA, XCDA, XCRA
F-5-1	23	HZW1-90758-B00	PIN, SPLIT, 4.0	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	24	HPT2-91005-N01	BEARING, THRUST(F)	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	25	HPG4-91033-013	BEARING, NEEDLE, 50X72X4.5	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	26	HZX2-91054-E01	BEARING, THRUST NEEDLE,	1	1	1	85X110X4 UCDA, UCRA, XCDA, XCRA
F-5-1	27	HZX2-91055-C01	BEARING, RADIAL BALL,	1	1	1	55X100X21 UCDA, UCRA, XCDA, XCRA
F-5-1	28	HZY3-91056-711	BEARING, NEEDLE, 28X39X30	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	29	HZY3-91057-003	BEARING, NEEDLE, 32X42X30	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	30	HZY3-91151-000	ROLLER, 3X13.8	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	31	HZZ3-91252-003	SEAL, WATER, 30X45X7	2	2	2	UCDA, UCRA, XCDA, XCRA
F-5-1	32	HZX2-91351-C00	0-RING, 121X3.1	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	33	HCO-94510-15000	CIRCLIP, EXTERNAL, 15MM	1	1	1	UCDA, UCRA, XCDA, XCRA
F-5-1	34	HCO-96211-07000	BALL, STEEL, #7(7/32)	2	2	2	UCDA, UCRA, XCDA, XCRA
F-5-1	35	HCO-96211-12000	BALL, STEEL, #12(3/8)	2	2	2	UCDA, UCRA, XCDA, XCRA
F-5-1	36	HZX2-06400-E01	GEAR KIT	1	1	1	UCDA, UCRA, XCDA, XCRA
-							
-							
-							




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-6	1	3FF-70200-4	PRIMER BULB ASSY	1	1	1	Low Permeation Parts for USA Model
F-6	2	307-70220-1	* JOINT ASSY (INLET)	1	1	1	
F-6	3	307-70224-1	* JOINT ASSY (OUTLET)	1	1	1	
F-6	4	3GF-70211-1	* PRIMER BULB	1	1	1	Low Permeation Parts for USA Model
F-6	5	307-70217-0	* CLAMP	2	2	2	
F-6	6	3GF-70241-1	* LOW PERMEATION HOSE L=700	1	1	1	Low Permeation Parts USA EPA-KRI-15G
F-6	7	3GF-70240-1	* LOW PERMEATION HOSE L=1600	1	1	1	Low Permeation Parts USA EPA-KRI-15G
F-6	8	332-70201-0	* CLAMP	2	2	2	

F-7 WIRE HARNESS







		0' ty					
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-7	1	HZVJ-32100-010	HARNESS ASSY., MAIN WIRE			1	∼6010095 LDA, UDA, XDA
F-7	1	HZVJ-32100-010	HARNESS ASSY., MAIN WIRE			1	~7010024 UCDA, XCDA
F-7	1	HZVJ-32100-030	HARNESS ASSY., MAIN WIRE			1	6010096~ LDA, UDA, XDA
F-7	1	HZVJ-32100-030	HARNESS ASSY., MAIN WIRE			1	7010025~ UCDA, XCDA
F-7	1	HZVJ-32100-040	HARNESS ASSY., MAIN WIRE			1	6010162~ LDA, UDA, XDA
F-7	1	HZVJ-32100-040	HARNESS ASSY., MAIN WIRE			1	7010045~ UCDA, XCDA
F-7	2	HZVL-32106-000	BRACKET, JUNCTION CONNECTOR	1	1	1	
F-7	3	HZVL-32108-003	DUMMY, WATER PROOF CONNECTOR	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-7	3	HZVL-32107-003	TERMINATOR ASSY.			1	LDA, UCDA, UDA, XCDA, XDA
F-7	4	HZZ3-32127-000	SUSPENSION, COUPLER	1	1	1	
F-7	5	HK44-32606-V01	CAP, DUMMY(WPC 4P 090 M) (RED)	1	1	1	
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14	1			~6010052 LRA, XRA
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14	1			~7010006 XCRA
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14		1		~6010057 LRA, XRA
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14		1		~7010010 XCRA
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14			1	~6010095 LDA, LRA, UDA, URA, XDA, XRA
F-7	6	HZZ5-90021-M00	BOLT, FLANGE, 6X14			1	~7010024 UCDA, UCRA, XCDA, XCRA
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14	1			6010053~ LRA, XRA
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14	1			7010007~ XCRA
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14		1		6010058~ LRA, XRA
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14		1		7010011~ XCRA
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14			1	6010096~ LDA, LRA, UDA, URA, XDA, XRA
F-7	6	HZZ5-90021-M01	BOLT, FLANGE, 6X14			1	7010025~ UCDA, UCRA, XCDA, XCRA
F-7	7	HZZ5-90105-M00	BOLT, FLANGE, 6X12	2	2	2	
F-7	8	HZY3-90653-003	CLIP, WIRE HARNESS	3	3	3	
F-7	9	HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	12			(145MM)
F-7	9	HS0A-91541-003	CLIP, HARNESS BAND(BLACK)		13	13	(145MM)




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-7-10	1	HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE	3	3	3	
F-7-10	2	HZVL-32103-000	BRACKET, COUPLER C	2	2	2	
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER	1			XCRA
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER	1			LRA, XRA #~6010028
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER	1			LRA, XRA #6010029~
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER		1		LRA, XRA #~6010018
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER		1		XCRA #~7010008
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER		1		LRA, XRA #6010019~
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER		1		XCRA #7010009∼
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER			1	LDA, UCDA, UDA, XCDA, XDA
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER			1	LRA, URA, XRA #~6010056
F-7-10	3	HZVL-32410-000	CABLE ASSY., STARTER			1	UCRA, XCRA #~7010005
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER			1	LRA, URA, XRA #6010057~
F-7-10	3	HZVL-32410-010	CABLE ASSY., STARTER			1	UCRA, XCRA #7010006∼
F-7-10	4	HZY3-32411-003	COVER, STARTER TERMINAL	1	1	1	
F-7-10	5	HZX2-32414-300	COVER B, TERMINAL (L)	2	2	2	
F-7-10	6	HZY6-32414-640	COVER B, TERMINAL	1	1	1	
F-7-10	7	HZX2-32415-000	CABLE ASSY., POWER TILT RELAY	1	1	1	
F-7-10	8	HZVL-32421-000	PLATE, STARTER CABLE	1	1	1	
F-7-10	9	HZX2-32435-000	CORD, A. C. GENERATOR	1	1	1	
F-7-10	10	HZVL-38550-003	RELAY ASSY., POWER TILT	1	1	1	
F-7-10	11	HZW1-38551-000	GROMMET, RELAY	2	2	2	
F-7-10	12	HZX2-38552-000	CASE, POWER TILT RELAY	1	1	1	
F-7-10	13	HZZ5-90013-M01	BOLT-WASHER, 6X25	2	2	2	
F-7-10	14	HZVL-90015-010	BOLT-WASHER, 6X27	3	3	3	
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10	2			∼6010052 LRA, XRA
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10	2			~7010006 XCRA
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10		2		∼6010057 LRA, XRA
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10		2		~7010010 XCRA



					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10			2	∼6010095 LDA, LRA, UDA, URA, XDA, XRA
F-7-10	15	HZZ0-90103-M00	BOLT, FLANGE, 6X10			2	~7010024 UCDA, UCRA, XCDA, XCRA
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10	2			6010053~ LRA, XRA
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10	2			7010007~ XCRA
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10		2		6010058~ LRA, XRA
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10		2		7010011~ XCRA
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10			2	6010096~ LDA, LRA, UDA, URA, XDA, XRA
F-7-10	15	HZZ0-90103-M01	BOLT, FLANGE, 6X10			2	7010025~ UCDA, UCRA, XCDA, XCRA
F-7-10	16	HZZ5-90105-M00	BOLT, FLANGE, 6X12	4	4	4	
F-7-10	17	HZY3-90107-000	BOLT, FLANGE, 8X18	1	1	1	
F-7-10	18	HZW1-90203-000	NUT-WASHER, 8MM	2	2	2	
F-7-10	19	HZY3-90304-000	NUT-WASHER, 6MM	1	1	1	
F-7-10	20	HZY3-90405-000	WASHER, PLAIN, 8MM	1	1	1	
F-7-10	21	HKV6-90651-003	BAND, WIRE, 165MM(BLACK)	1	1	1	
F-7-10	22	H763-90681-A01	CLIP, WIRE HARNESS	1	1	1	
F-7-10	23	HZX2-90683-003	CLIP, WIRE HARNESS	2	2	2	
F-7-10	24	HZZ5-91501-010	COLLAR, MOUNTING (6MM)	2	2	2	
F-7-10	25	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	3			~6010052 LRA, XRA
F-7-10	25	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE	3			~7010006 XCRA
F-7-10	25	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE		3		~6010057 LRA, XRA
F-7-10	25	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE		3		~7010010 XCRA
F-7-10	25	HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE			3	~6010095 LDA, LRA, UDA, URA, XDA, XRA
F-7-10	25	HZY9-91503-M00	COLLAR, C.D. I. UNIT CASE			3	∼7010024 UCDA, UCRA, XCDA, XCRA
F-7-10	25	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE	3			6010053~6010066 LRA, XRA
F-7-10	25	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE	3			7010007~7010011 XCRA
F-7-10	25	HZY9-91503-M01	COLLAR, C.D. I. UNIT CASE		3		6010058~6010061 LRA, XRA
F-7-10	25	HZY9-91503-M01	COLLAR, C.D. I. UNIT CASE			3	6010096~6010109 LDA, LRA, UDA, URA, XDA, XRA
F-7-10	25	HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE			3	7010025~7010035 UCDA, UCRA, XCDA, XCRA
F-7-10	25	HZVL-91551-010	COLLAR, 12X6.5		3		7010011~ XCRA




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-7-10	25	HZVL-91551-010	COLLAR, 12X6.5	3			6010067~ LRA, XRA
F-7-10	25	HZVL-91551-010	COLLAR, 12X6.5	3			7010012~ XCRA
F-7-10	25	HZVL-91551-010	COLLAR, 12X6.5		3		6010062~ LRA, XRA
F-7-10	25	HZVL-91551-010	COLLAR, 12X6.5			3	6010110~ LDA, LRA, UDA, URA, XDA, XRA
F-7-10	25	HZVL-91551-010	COLLAR, 12X6.5			3	7010036~ UCDA, UCRA, XCDA, XCRA
F-7-10	26	HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	3	3	3	(145MM)
F-7-10	27	HZVL-31575-010	HARNESS ASSY., POWER	1			XCRA
F-7-10	27	HZVL-31575-010	HARNESS ASSY., POWER	1			6010029~ LRA, XRA
F-7-10	27	HZVL-31575-010	HARNESS ASSY., POWER		1		6010019~ LRA, XRA
F-7-10	27	HZVL-31575-010	HARNESS ASSY., POWER		1		7010009~ XCRA
F-7-10	27	HZVL-31575-010	HARNESS ASSY., POWER			1	LDA, UCDA, UDA, XCDA, XDA
F-7-10	27	HZVL-31575-010	HARNESS ASSY., POWER			1	6010057~ LRA, URA, XRA
F-7-10	27	HZVL-31575-010	HARNESS ASSY., POWER			1	7010006~ UCRA, XCRA
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)	2			XCRA
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)	2			6010029~ LRA, XRA
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)		2		6010019~ LRA, XRA
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)		2		7010009~ XCRA
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)			2	LDA, UCDA, UDA, XCDA, XDA
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)			2	6010057~ LRA, URA, XRA
F-7-10	28	HKSV-32501-J00	FUSE, BLADE (40A)			2	7010006~ UCRA, XCRA
F-7-10	29	HZZ3-38216-003	COVER ASSY., FUSE (40A)	1			XCRA
F-7-10	29	HZZ3-38216-003	COVER ASSY., FUSE (40A)	1			6010029~ LRA, XRA
F-7-10	29	HZZ3-38216-003	COVER ASSY., FUSE (40A)		1		6010019~ LRA, XRA
F-7-10	29	HZZ3-38216-003	COVER ASSY., FUSE (40A)		1		7010009~ XCRA
F-7-10	29	HZZ3-38216-003	COVER ASSY., FUSE (40A)			1	LDA, UCDA, UDA, XCDA, XDA
F-7-10	29	HZZ3-38216-003	COVER ASSY., FUSE (40A)			1	6010057~ LRA, URA, XRA
F-7-10	29	HZZ3-38216-003	COVER ASSY., FUSE (40A)			1	7010006~ UCRA, XCRA
F-7-10	30	HZW9-90102-000	BOLT, FLANGE, 6X12	1	1	1	
F-7-10	31	HZVL-32531-000	HARNESS ASSY., LOAD SIGNAL			1	LDA, UCDA, UDA, XCDA, XDA




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-7-10	32	HZ2E-38216-003	COVER ASSY., FUSE			1	LDA, UCDA, UDA, XCDA, XDA
F-7-10	33	HGJE-38221-J01	FUSE, BLADE (MINI) (1A)			1	LDA, UCDA, UDA, XCDA, XDA
F-7-10	34	HZVL-87116-000	LABEL, FUSE (1A)			1	LDA, UCDA, UDA, XCDA, XDA
F-7-10	35	HSR3-91531-003	HOLDER, COUPLER (NATURAL) (128.6MM)			1	LDA, UCDA, UDA, XCDA, XDA

F-7-20 FUSE BOX/RELAY




Ref. No. Fart No. Description Told Remarks R						Q'ty		
F-7-20 1 HZVL-32370-013 BOX ASSY., JUNCTION 1 1 LDA, UCDA, UDA, XCDA, XDA F-7-20 2 HZYL-32371-H01 COVER COMP., FUSE 1 1 1 1 1 LRA, UCRA, URA, XCRA, XRA F-7-20 2 HZVL-32371-003 COVER COMP., FUSE 1 1 LDA, UCDA, UDA, XCDA, XDA F-7-20 3 HZXL-38228-003 FUSE, BLOCK (150A) 2 2 2 2 F-7-20 4 HZYG-38235-004 PULLER, MINI FUSE 1 1 1 1 F-7-20 5 HSDA-39794-004 RELAY ASSY., FUEL PUMP (DENSO) 1 1 1 1 F-7-20 6 HZYG-39794-003 RELAY ASSY., POWER (12V-20A) 2 2 2 2 (MICRO ISO 4P) LRA, UCRA, URA, XCRA, XRA F-7-20 7 HZZ5-90018-M00 BOLT, FLANGE, 6X20 4 4 4 4 F-7-20 8 HZYG-90135-004 SCREW-WASHER, 5X15 2 2 2 F-7-20 9 HCO-98200-41000 FUSE, MINI (10A) 4 4 F-7-20 9 HCO-98200-41000 FUSE, MINI (10A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 10 HCO-98200-41000 FUSE, MINI (10A) 4 4 4 F-7-20 11 HCO-98200-43000 FUSE, MINI (15A) 4 4 4 4 F-7-20 11 HCO-98200-43000 FUSE, MINI (15A) 2 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HCO-98200-43000 FUSE, MINI (10A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 11 HCO-98200-43000 FUSE, MINI (15A) 2 2 LDA, UCDA, UDA, XCDA, XDA F-7-20 11 HCO-98200-43000 FUSE, MINI (30A) 2 2 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HCO-98200-40750 FUSE, MINI (7. 5A) 2 LDA, UCDA, UDA, XCDA, XDA	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-7-20 2 H2Y3-32371-H01 COVER COMP., FUSE 1 1 1 1 LRA, UCRA, URA, XCRA, XRA F-7-20 2 H2VL-32371-003 COVER COMP., FUSE 1 1 LDA, UCDA, UDA, XCDA, XDA F-7-20 3 H2X2-38228-003 FUSE, BLOCK (150A) 2 2 2 2 F-7-20 4 H2Y6-38235-004 PULLER, MINI FUSE 1 1 1 1 F-7-20 5 HSDA-39794-004 RELAY ASSY., FUEL PUMP (DENSO) 1 1 1 1 F-7-20 6 H2Y6-39794-003 RELAY ASSY., POWER (12V-20A) 2 2 2 CMICRO ISO 4P) LRA, UCRA, URA, XCRA, XRA F-7-20 7 H2Z5-90018-M00 BOLT, FLANGE, 6X20 4 4 4 4 F-7-20 8 H2Y6-90135-004 SCREW-WASHER, 5X15 2 2 2 F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 4 F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 4 LRA, UCRA, URA, XCRA, XRA F-7-20 10 HC0-98200-41000 FUSE, MINI (10A) 4 4 4 4 F-7-20 11 HC0-98200-41000 FUSE, MINI (10A) 2 2 2 1 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 2 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 12 HC0-98200-40750 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HC0-98200-40750 FUSE, MINI (30A) 2 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	1	HZY3-32370-H01	BOX ASSY., JUNCTION	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-7-20 2 HZVL-32371-003 COVER COMP. FUSE 1 LDA, UCDA, UDA, XCDA, XDA F-7-20 3 HZX2-38228-003 FUSE, BLOCK (150A) 2 2 2 2 F-7-20 4 HZY6-38235-004 PULLER, MINI FUSE 1 1 1 1 F-7-20 5 HSDA-39794-004 RELAY ASSY. FUEL PUMP (DENSO) 1 1 1 1 F-7-20 6 HZY6-39794-003 RELAY ASSY. POWER (12V-20A) 2 2 2 2 (MICRO ISO 4P) LRA, UCRA, URA, XCRA, XRA F-7-20 6 HZY6-39794-003 RELAY ASSY. POWER (12V-20A) 4 4 LDA, UCDA, UDA, XCDA, XDA F-7-20 7 HZZ5-90018-M00 BOLT, FLANGE, 6X20 4 4 4 F-7-20 8 HZY6-90135-004 SCREW-MSHER, 5X15 2 2 2 2 F-7-20 9 HCO-98200-41000 FUSE, MINI (10A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 10 HCO-98200-41500 FUSE, MINI (30A) 2	F-7-20	1	HZVL-32370-013	BOX ASSY., JUNCTION			1	LDA, UCDA, UDA, XCDA, XDA
F-7-20 3 HZX2-38228-003 FUSE, BLOCK (150A) 2 2 2 2 F-7-20 4 HZY6-38235-004 PULLER, MINI FUSE 1 1 1 1 F-7-20 5 HSDA-39794-004 RELAY ASSY., FUEL PUMP (DENSO) 1 1 1 1 F-7-20 6 HZY6-39794-003 RELAY ASSY., POWER (12V-20A) 2 2 2 2 (MICRO ISO 4P) LRA, UCRA, UCRA, URA, XCRA, XRA F-7-20 6 HZY6-39794-003 RELAY ASSY., POWER (12V-20A) 4 LDA, UCDA, UDA, XCDA, XDA F-7-20 7 HZZ5-90018-M00 BOLT, FLANGE, 6X20 4 4 4 F-7-20 8 HZY6-90135-004 SCREW-WASHER, 5X15 2 2 2 F-7-20 9 HCO-98200-41000 FUSE, MINI (10A) 4 4 F-7-20 9 HCO-98200-41000 FUSE, MINI (10A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 9 HCO-98200-41000 FUSE, MINI (10A) 4 4 4 F-7-20 10 HCO-98200-41500 FUSE, MINI (15A) 4 4 4 F-7-20 11 HCO-98200-43000 FUSE, MINI (30A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HCO-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HCO-98200-43000 FUSE, MINI (30A) 2 2 2 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HCO-98200-40750 FUSE, MINI (7. 5A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	2	HZY3-32371-H01	COVER COMP., FUSE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F-7-20 4 H2Y6-38235-004 PULLER, MINI FUSE 1 2	F-7-20	2	HZVL-32371-003	COVER COMP., FUSE			1	LDA, UCDA, UDA, XCDA, XDA
F-7-20 5 HSDA-39794-004 RELAY ASSY., FUEL PUMP (DENSO) 1 2 2 2 1	F-7-20	3	HZX2-38228-003	FUSE, BLOCK (150A)	2	2	2	
F-7-20 6 HZY6-39794-003 RELAY ASSY., POWER (12V-20A) 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 MICRA, UCRA, URA, XCRA, XRA F-7-20 6 HZY6-39794-003 RELAY ASSY., POWER (12V-20A) 4 4 4 LDA, UCDA, UDA, XCDA, XDA F-7-20 7 HZZ5-90018-M00 BOLT, FLANGE, 6X20 4 4 4 4 F-7-20 8 HZY6-90135-004 SCREW-WASHER, 5X15 2 2 2 2 2 F-7-20 9 HCO-98200-41000 FUSE, MINI (10A) 4 4 4 F-7-20 9 HCO-98200-41000 FUSE, MINI (15A) 4 4 4 F-7-20 10 HCO-98200-41500 FUSE, MINI (30A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HCO-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12	F-7-20	4	HZY6-38235-004	PULLER, MINI FUSE	1	1	1	
F-7-20 6 H2T6-39794-003 RELAT ASST FOWER (12V-20A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 6 H2Y6-39794-003 RELAY ASSY. , POWER (12V-20A) 4 LDA, UCDA, UDA, XCDA, XDA F-7-20 7 HZZ5-90018-M00 BOLT. FLANGE, 6X20 4 4 4 4 F-7-20 8 H2Y6-90135-004 SCREW-WASHER, 5X15 2 2 2 2 F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 4 4 F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 LRA, UCRA, URA, XCRA, XRA F-7-20 10 HC0-98200-41500 FUSE, MINI (15A) 4 4 4 F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HC0-98200-40750 FUSE, MINI (30A) 2 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	5	HSDA-39794-004	RELAY ASSY., FUEL PUMP(DENSO)	1	1	1	
F-7-20 7 HZZ5-90018-M00 BOLT, FLANGE, 6X20 4 4 4 4 F-7-20 8 HZY6-90135-004 SCREW-WASHER, 5X15 2 2 2 2 2 F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 4 4 F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 LRA, UCRA, URA, XCRA, XRA F-7-20 10 HC0-98200-41500 FUSE, MINI (15A) 4 4 4 F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HC0-98200-40750 FUSE, MINI (7.5A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	6	HZY6-39794-003	RELAY ASSY., POWER (12V-20A)	2	2	2	
F-7-20 8 HZY6-90135-004 SCREW-WASHER, 5X15 2 2 2 2 F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 4 4 F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 LRA, UCRA, URA, XCRA, XRA F-7-20 10 HC0-98200-41500 FUSE, MINI (15A) 4 4 4 F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HC0-98200-40750 FUSE, MINI (7.5A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	6	HZY6-39794-003	RELAY ASSY., POWER (12V-20A)			4	LDA, UCDA, UDA, XCDA, XDA
F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 4 F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 LRA, UCRA, URA, XCRA, XRA F-7-20 10 HC0-98200-41500 FUSE, MINI (15A) 4 4 4 F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HC0-98200-40750 FUSE, MINI (7.5A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	7	HZZ5-90018-M00	BOLT, FLANGE, 6X20	4	4	4	
F-7-20 9 HCO-98200-41000 FUSE, MINI (10A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 9 HCO-98200-41000 FUSE, MINI (10A) 4 LRA, UCRA, URA, XCRA, XRA F-7-20 10 HCO-98200-41500 FUSE, MINI (15A) 4 4 4 F-7-20 11 HCO-98200-43000 FUSE, MINI (30A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HCO-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HCO-98200-40750 FUSE, MINI (7. 5A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	8	HZY6-90135-004	SCREW-WASHER, 5X15	2	2	2	
F-7-20 9 HC0-98200-41000 FUSE, MINI (10A) 4 LRA, UCRA, URA, XCRA, XRA F-7-20 10 HC0-98200-41500 FUSE, MINI (15A) 4 4 4 F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HC0-98200-40750 FUSE, MINI (7. 5A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	9	HCO-98200-41000	FUSE, MINI (10A)	4	4		
F-7-20 10 HC0-98200-41500 FUSE, MINI (15A) 4 4 4 4 F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HC0-98200-40750 FUSE, MINI (7. 5A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	9	HCO-98200-41000	FUSE, MINI (10A)			3	LDA, UCDA, UDA, XCDA, XDA
F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 2 2 2 LRA, UCRA, URA, XCRA, XRA F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HC0-98200-40750 FUSE, MINI (7. 5A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	9	HCO-98200-41000	FUSE, MINI (10A)			4	LRA, UCRA, URA, XCRA, XRA
F-7-20 11 HC0-98200-43000 FUSE, MINI (30A) 3 LDA, UCDA, UDA, XCDA, XDA F-7-20 12 HC0-98200-40750 FUSE, MINI (7. 5A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	10	HCO-98200-41500	FUSE, MINI (15A)	4	4	4	
F-7-20 12 HCO-98200-40750 FUSE, MINI (7. 5A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	11	HCO-98200-43000	FUSE, MINI (30A)	2	2	2	LRA, UCRA, URA, XCRA, XRA
	F-7-20	11	HCO-98200-43000	FUSE, MINI (30A)			3	LDA, UCDA, UDA, XCDA, XDA
F-7-20 13 HCO-98200-42000 FUSE, MINI (20A) 2 LDA, UCDA, UDA, XCDA, XDA	F-7-20	12	HCO-98200-40750	FUSE, MINI (7.5A)			2	LDA, UCDA, UDA, XCDA, XDA
	F-7-20	13	HCO-98200-42000	FUSE, MINI (20A)			2	LDA, UCDA, UDA, XCDA, XDA


F-8 ENGINE COVER




Ref. No. Part No. Description						Q'ty		
F-8 2 HZVL-63107-000 BRACKET, HOOK FR. 1 1 1 1 F-8 3 HZVL-63108-000 GROMMET, LOCK HOOK 3 3 3 F-8 4 HZVL-63109-000 ROLLER, HOOK 3 3 3 F-8 5 HZVL-63112-000 BRACKET, HOOK R. 1 1 1 1 F-8 6 HZVL-63117-000 BRACKET, HOOK L. 1 1 1 1 F-8 7 HZVL-90101-000 BOLT, SOCKET, 6X25 3 3 3 F-8 8 HZX1-90101-ROO BOLT, SOCKET, 6X20 6 6 6 F-8 9 HZY1-90205-000 NUT, SELF-LOCK, 6MM 3 3 3 F-8 10 HZV4-90506-000 WASHER, PLAIN, 6MM 3 3 3	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-8 3 HZVL-63108-000 GROMMET, LOCK HOOK 3 3 3 3 F-8 4 HZVL-63109-000 ROLLER, HOOK 3 3 3 3 F-8 5 HZVL-63112-000 BRACKET, HOOK R. 1 1 1 1 1 F-8 6 HZVL-63117-000 BRACKET, HOOK L. 1 2 2 1 2 <td>F-8</td> <td>1</td> <td>HZVL-63100-P01ZA</td> <td>COVER ASSY., ENGINE</td> <td>1</td> <td>1</td> <td>1</td> <td>*T107* BAY BLUE</td>	F-8	1	HZVL-63100-P01ZA	COVER ASSY., ENGINE	1	1	1	*T107* BAY BLUE
F-8 4 HZVL-63109-000 ROLLER, HOOK 3 3 3 3 F-8 5 HZVL-63112-000 BRACKET, HOOK R. 1 1 1 1 1 F-8 6 HZVL-63117-000 BRACKET, HOOK L. 1 2 2 1 2 <td>F-8</td> <td>2</td> <td>HZVL-63107-000</td> <td>BRACKET, HOOK FR.</td> <td>1</td> <td>1</td> <td>1</td> <td></td>	F-8	2	HZVL-63107-000	BRACKET, HOOK FR.	1	1	1	
F-8 5 HZVL-63112-000 BRACKET, HOOK R. 1 1 1 1 F-8 6 HZVL-63117-000 BRACKET, HOOK L. 1 1 1 1 1 F-8 7 HZVL-90101-000 BOLT, SOCKET, 6X25 3 3 3 F-8 8 HZX1-90101-R00 BOLT, SOCKET, 6X20 6 6 6 F-8 9 HZY1-90205-000 NUT, SELF-LOCK, 6MM 3 3 3 F-8 10 HZV4-90506-000 WASHER, PLAIN, 6MM 3 3 3	F-8	3	HZVL-63108-000	GROMMET, LOCK HOOK	3	3	3	
F-8 6 HZVL-63117-000 BRACKET, H00K L. 1 1 1 1 F-8 7 HZVL-90101-000 BOLT, SOCKET, 6X25 3 3 3 F-8 8 HZX1-90101-R00 BOLT, SOCKET, 6X20 6 6 6 F-8 9 HZY1-90205-000 NUT, SELF-LOCK, 6MM 3 3 3 F-8 10 HZV4-90506-000 WASHER, PLAIN, 6MM 3 3 3	F-8	4	HZVL-63109-000	ROLLER, HOOK	3	3	3	
F-8 7 HZVL-90101-000 B0LT, S0CKET, 6X25 3 3 3 3 F-8 8 HZX1-90101-R00 B0LT, S0CKET, 6X20 6 6 6 6 F-8 9 HZY1-90205-000 NUT, SELF-LOCK, 6MM 3 3 3 3 F-8 10 HZV4-90506-000 WASHER, PLAIN, 6MM 3 3 3 3	F-8	5	HZVL-63112-000	BRACKET, HOOK R.	1	1	1	
F-8 8 HZX1-90101-R00 B0LT, S0CKET, 6X20 6 6 6 6 F-8 9 HZY1-90205-000 NUT, SELF-LOCK, 6MM 3 3 3 F-8 10 HZV4-90506-000 WASHER, PLAIN, 6MM 3 3 3	F-8	6	HZVL-63117-000	BRACKET, HOOK L.	1	1	1	
F-8 9 HZY1-90205-000 NUT, SELF-LOCK, 6MM 3 3 3 3 F-8 10 HZV4-90506-000 WASHER, PLAIN, 6MM 3 3 3 3	F-8	7	HZVL-90101-000	BOLT, SOCKET, 6X25	3	3	3	
F-8 10 HZV4-90506-000 WASHER, PLAIN, 6MM 3 3 3	F-8	8	HZX1-90101-R00	BOLT, SOCKET, 6X20	6	6	6	
	F-8	9	HZY1-90205-000	NUT, SELF-LOCK, 6MM	3	3	3	
F-8 11 HZY3-91556-000 COLLAR, DISTANCE, 6.5X9X3 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	F-8	10	HZV4-90506-000	WASHER, PLAIN, 6MM	3	3	3	
	F-8	11	HZY3-91556-000	COLLAR, DISTANCE, 6.5X9X3	8	8	8	




Ref. No.	Part No.					
		Description	BFT200D	BFT225D	BFT250D	Remarks
F-10 1	HZW1-06411-020	METAL KIT, ANODE	1	1	1	LDA, LRA
F-10 2	HZY3-06532-U00	ROD KIT, STEERING	1	1	1	
F-10 3	H747-16731-003	CLIP, TUBE	1	1	1	
F-10 4	HZV1-24210-010	SPRING COMP., CLICK	1	1	1	
F-10 5	HZV4-24221-010	SPRING, CLICK ASSIST	1	1	1	
F-10 6	HKM3-32161-003	BAND, WIRE	2	2	2	LDA, LRA, XCDA, XCRA, XDA, XRA
F-10 6	HKM3-32161-003	BAND, WIRE			4	UCDA, UCRA, UDA, URA
F-10 7	HZY3-35660-003	SENSOR ASSY., TRIM ANGLE	1	1	1	
F-10 8	HZZ3-35745-743	SWITCH ASSY., TILT LIMIT	1	1	1	
F-10 9	HZY3-40219-023	WIRE, LEAD (1.5X116MM)	1	1	1	
F-10 10	0 HZV5-41171-000	END, NIPPLE	1	1	1	
F-10 1	1 HZV5-41172-000	NIPPLE, SENSOR	1	1	1	
F-10 1	2 HZV5-41172-000	NIPPLE, SENSOR	1	1	1	
F-10 1	3 HZVL-50100-000	FRAME COMP., MOUNTING(XL)	1			XCRA
F-10 1	3 HZVL-50100-000	FRAME COMP., MOUNTING(XL)	1			~6010102 XRA
F-10 1	3 HZVL-50100-000	FRAME COMP., MOUNTING(XL)		1		~6010073XRA
F-10 1	3 HZVL-50100-000	FRAME COMP., MOUNTING(XL)		1		~7010010XCRA
F-10 1	3 HZVL-50100-000	FRAME COMP., MOUNTING(XL)			1	~6010157UDA, URA, XDA, XRA
F-10 1	3 HZVL-50100-000	FRAME COMP., MOUNTING(XL)			1	~7010039 UCDA, UCRA, XCDA, XCRA
F-10 1	3 HZVL-50100-900	FRAME COMP., MOUNTING(L)	1			~6010116 LRA
F-10 1	3 HZVL-50100-900	FRAME COMP., MOUNTING(L)		1		~6010071 LRA
F-10 1	3 HZVL-50100-900	FRAME COMP., MOUNTING(L)			1	~6010170 LDA, LRA
F-10 1	3 HZVL-50100-010	FRAME COMP., MOUNTING(XL)	1			6010103~ XRA
F-10 1	3 HZVL-50100-010	FRAME COMP., MOUNTING(XL)		1		6010074~ XRA
F-10 1	3 HZVL-50100-010	FRAME COMP., MOUNTING(XL)		1		7010011~ XCRA
F-10 1	3 HZVL-50100-010	FRAME COMP., MOUNTING(XL)			1	6010158~ UDA, URA, XDA, XRA
F-10 1	3 HZVL-50100-010	FRAME COMP., MOUNTING(XL)			1	7010040~ UCDA, UCRA, XCDA, XCRA
F-10 1	3 HZVL-50100-901	FRAME COMP., MOUNTING(L)	1			6010117~ LRA
F-10 1	3 HZVL-50100-901	FRAME COMP., MOUNTING(L)		1		6010072~ LRA




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-10	13	HZVL-50100-901	FRAME COMP., MOUNTING(L)			1	6010171~ LDA, LRA
F-10	14	HZVL-50109-000	HOUSING, UPPER MOUNTING	1	1	1	
F-10	15	HZY3-50151-000	MOUNT COMP., UPPER RUBBER	2	2	2	
F-10	16	HZY3-50153-000	RUBBER, UPPER MOUNT STOPPER	2	2	2	
F-10	17	HZY3-50161-000ZD	HOUSING, LOWER CENTER MOUNTING	1	1	1	*T107* BAY BLUE LDA, LRA
F-10	17	HZY3-50161-610	HOUSING, LOWER CENTER MOUNTING	1	1	1	(XL) UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT	1			~6011067 LRA, XRA
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT	1			~7011011 XCRA
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT		1		~6011057 LRA, XRA
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT		1		~7011015 XCRA
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT			1	~6011160 LDA, LRA, UDA, URA, XDA, XRA
F-10	18	HZVL-50166-000	COVER, UPPER MOUNT			1	~7011052 UCDA, UCRA, XCDA, XCRA
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT	1			6011068~ LRA, XRA
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT	1			7011012~ XCRA
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT		1		6011058~ LRA, XRA
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT		1		7011016~ XCRA
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT			1	6011161~ LDA, LRA, UDA, URA, XDA, XRA
F-10	18	HZVL-50166-010	COVER, UPPER MOUNT			1	7011053~ UCDA, UCRA, XCDA, XCRA
F-10	19	HZVL-50201-900ZA	CASE, SWIVEL(L)	1	1	1	*T107* BAY BLUE LDA, LRA
F-10	19	HZVL-50201-000ZA	CASE, SWIVEL (XL)	1	1	1	*T107* BAY BLUE UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-10	20	HZY3-50211-000	LINER, SWIVEL CASE	2	2	2	
F-10	21	HZY3-50214-000	BUSH, SWIVEL CASE	2	2	2	
F-10	22	HZVL-50222-000	BRACKET, TILT LIMIT SWITCH	1	1	1	
F-10	23	HZZ3-50223-000	CAM A, TILT LIMIT ANGLE	1	1	1	
F-10	24	HZZ3-50224-000	CAM B, TILT LIMIT ANGLE	1	1	1	
F-10	25	HZY3-50301-030ZC	BRACKET, R. STERN	1	1	1	*T107* BAY BLUE
F-10	26	HZVL-50311-000ZA	BRACKET, L. STERN	1	1	1	*T107* BAY BLUE
F-10	27	HZVL-50381-000	SHAFT, TILTING	1		1	
F-10	27	HZVL-50381-000	SHAFT, TILTING	1			~6010066 LRA, XRA




F-10 27 HZVL F-10 27 HZVL F-10 27 HZVL F-10 27 HZVL	Part No. -50381-000 -50381-000 -50381-000 -50381-010	Description SHAFT, TILTING SHAFT, TILTING SHAFT, TILTING	BFT200D ←	BFT225D	BFT250D	Remarks ∼7010008
F-10 27 HZVL F-10 27 HZVL F-10 27 HZVL	50381-000 50381-000	SHAFT, TILTING	1			~7010008
F-10 27 HZVL	50381-000 50381-000					XCRA
F-10 27 HZVL	50381-000	SHAFT, TILTING		1		~6010061 LRA, XRA
					1	∼6010109 LDA, LRA, UDA, URA, XDA, XRA
F-10 27 HZVL	-50381-010	SHAFT, TILTING			1	~7010035 UCDA, UCRA, XCDA, XCRA
	00001 010	SHAFT, TILTING		1		~7010010 XCRA
F-10 27 HZVL	-50381-010	SHAFT, TILTING		1		7010011~ XCRA
F-10 27 HZVL	-50381-010	SHAFT, TILTING	1			6010067~ LRA, XRA
F-10 27 HZVL	-50381-010	SHAFT, TILTING	1			7010009~ XCRA
F-10 27 HZVL	-50381-010	SHAFT, TILTING		1		6010062~ LRA, XRA
F-10 27 HZVL	-50381-010	SHAFT, TILTING			1	6010110~ LDA, LRA, UDA, URA, XDA, XRA
F-10 27 HZVL	-50381-010	SHAFT, TILTING			1	7010036~ UCDA, UCRA, XCDA, XCRA
F-10 28 HZY3	3-50522-000	BUSH, TILT ARM	2	2	2	
F-10 29 HZY3	3-50527-000	BRACKET, TILTING	1	1	1	
F-10 30 HZVL	50529-000	STOPPER, TILT	2	2	2	
F-10 31 HZY3	3-56516-A00	RECEIVER, THRUST	2	2	2	
F-10 32 HZY3	3-56518-A00	BUSH A, THRUST RECEIVE	2	2	2	
F-10 33 HZY3	3-56519- A 00	BUSH B, THRUST RECEIVE	2	2	2	
F-10 34 HZVL	56539-000	SHAFT, LOWER CYLINDER	1	1	1	
F-10 35 HZWS	9-90005-030	BOLT, FLANGE, 6X20	7	7	7	
F-10 36 HZWS	9-90009-000	BOLT, FLANGE, 6X23	2	2	2	LDA, LRA
F-10 37 HZW1	-90102-000	BOLT, 1/4-28UNF	2	2	2	
F-10 38 HZW9	9-90102-000	BOLT, FLANGE, 6X12	1	1	1	
F-10 39 HZWS	9-90103-010	BOLT, FLANGE, 6X12	1	1	1	
F-10 40 HZY6	6-90103-000	BOLT-WASHER, 10X32	3	3	3	
F-10 41 HZY3	3-90104-010	BOLT, HEX., 12X200	2	2	2	
F-10 42 HZVL	90105-000	BOLT, STUD, 10X28	1	1	1	
F-10 43 HZWS	9-90105-000	BOLT, FLANGE, 6X20	2	2	2	
F-10 44 HZY3	3-90106-A00	BOLT, FLANGE, 8X22	1	1	1	
F-10 45 H881	-90110-000	BOLT, HEX., 6X14	1	1	1	




Ref. No. Part No. Description Sq. 95 S	
F-10 47 H2V5-90119-000 SCREW, PAN, 6X8 1 1 1 1 1 F-10 48 H2X2-90129-000 B0LT, HEX., 12X130 6 6 6 6 6 F-10 49 H2Y1-90205-000 NUT, SELF-LOCK, 6MM 2 2 2 2 F-10 50 H2W5-90302-003 NUT, FLANGE, 12MM 2 2 2 2 F-10 51 H2V5-90304-013 NUT, FLANGE, 12MM 1 1 1 1 F-10 52 H2W4-90306-003 NUT, FLANGE, 10MM 1 1 1 1 F-10 53 H2V5-90307-003 NUT, SELF-LOCK(7/8-14UNF) 2 2 2 2 F-10 54 H2W4-90401-000 WASHER, FLAIN, 4MM 1 1 1 1 F-10 55 H2V5-90501-000 WASHER, WAVE, 40MM 1 1 1 1 1 F-10 56 H2Y3-90501-000 WASHER, WAVE, 40MM 1 1 1 1 1 F-10 57 H2V5-90502-000 WASHER, WAVE, 26MM 2 2 2 2 F-10 58 H2V5-90504-000 WASHER, WAVE, 26MM 2 2 2 2 F-10 59 H2X2-90504-000 WASHER, UPPER MOUNTING STOPPER 2 2 2 F-10 60 H2Y3-90504-000 WASHER, THRUST, 34MM 1 1 1 1 F-10 60 H2Y3-90504-000 WASHER, UPPER MOUNTING STOPPER 2 2 2 F-10 61 H921-90511-000 WASHER, PLAIN, 6MM 2 2 2 2 F-10 63 H2V4-90512-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 64 H2V5-90504-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 65 H2V4-90512-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 66 H2V4-90514-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 67 H7V3-905050-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 66 H2V5-90552-000 WASHER, PLAIN, 12MM 6 6 6 6 F-10 65 H2V5-90551-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 1 F-10 66 H2V5-90551-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 1 1	
F-10 48 HZX2-90129-000 BOLT. HEX., 12X130 6 6 6 F-10 49 HZY1-90205-000 NUT. SELF-LOCK, 6MM 2 2 2 F-10 50 HZW5-90302-003 NUT. FLANGE, 12MM 2 2 2 F-10 51 HZV5-90304-013 NUT. SELF-LOCK (7/8-14UNF) 1 1 1 F-10 52 HZW4-90306-003 NUT. FLANGE, 10MM 1 1 1 1 F-10 53 HZV5-90307-003 NUT. SELF-LOCK (3/8-24UNF) 2 2 2 F-10 54 HZW4-90306-003 NUT. SELF-LOCK (3/8-24UNF) 2 2 2 F-10 54 HZW4-90306-000 WASHER, VAVE, 40MM 1 1 1 F-10 55 HZV5-90501-000 WASHER, WAVE, 12MM 2 2 2 F-10 57 HZV5-90502-000 WASHER, WAVE, 26MM 2 2 2 2 2 F-10 58 HZV5-90504-000 WASHER, T	
F-10 49 HZY1-90205-000 NUT, SELF-LOCK, 6MM 2 2 2 2 F-10 50 HZW5-90302-003 NUT, FLANGE, 12MM 2 2 2 2 F-10 51 HZV5-90304-013 NUT, SELF-LOCK (7/8-14UNF) 1 1 1 1 F-10 52 HZW4-90306-003 NUT, FLANGE, 10MM 1 1 1 1 F-10 53 HZV5-90307-003 NUT, SELF-LOCK (3/8-24UNF) 2 2 2 2 F-10 54 HZW4-90401-000 WASHER, PLAIN, 4MM 1 1 1 1 F-10 55 HZV5-90501-000 WASHER, WAVE, 40MM 1 1 1 1 F-10 56 HZY3-90501-000 WASHER, WAVE, 26MM 2 2 2 2 F-10 57 HZV5-90502-000 WASHER, WAVE, 26MM 2 2 2 2 F-10 58 HZV5-90504-000 WASHER, THRUST, 34MM 1 1 1 1 F-10 59 HZX2-90504-000 WASHER, THRUST, 34MM 1 1 1 1 F-10 60 HZY3-90509-000 WASHER, THRUST, 34MM 1 1 1 1 F-10 61 H921-90511-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 63 HZY3-90509-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 64 HZY3-90509-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 65 HZY4-90514-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 66 HZY4-90514-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 67 HZV5-90552-000 WASHER, PLAIN, 12MM 1 1 1 1 F-10 67 HZY5-90559-000 WASHER, PLAIN, 12MM 1 1 1 1 1 F-10 67 HZY5-90559-000 WASHER, PLAIN, 12MM 1 1 1 1 1 F-10 66 HZY5-90551-000 WASHER, PLAIN, 12MM 1 1 1 1 1 F-10 67 HZY5-90551-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 1 1	
F-10 50 HZW5-90302-003 NUT, FLANGE, 12MM 2 2 2 2 F-10 51 HZV5-90304-013 NUT, SELF-LOCK (7/8-14UNF) 1 1 1 1 F-10 52 HZW4-90306-003 NUT, FLANGE, 10MM 1 1 1 1 F-10 53 HZV5-90307-003 NUT, SELF-LOCK (3/8-24UNF) 2 2 2 2 F-10 54 HZW4-90401-000 WASHER, PLAIN, 4MM 1 1 1 1 F-10 55 HZV5-90501-000 WASHER, WAVE, 40MM 1 1 1 1 1 F-10 55 HZV5-90501-000 WASHER, WAVE, 40MM 2 2 2 2 F-10 57 HZV5-90502-000 WASHER, WAVE, 12MM 2 2 2 2 F-10 58 HZV5-90504-000 WASHER, WAVE, 26MM 2 2 2 2 F-10 58 HZV5-90504-000 WASHER, WAVE, 26MM 2 2 2 2 F-10 60 HZY3-90504-000 WASHER, THRUST, 34MM 1 1 1 1 F-10 61 HZY3-90509-000 WASHER, THRUST, 34MM 1 1 1 1 F-10 60 HZY3-90509-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 61 H921-90511-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 62 HZV4-90512-000 WASHER, PLAIN, 10MM 2 2 2 2 F-10 63 HZV4-90514-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 64 HZV5-90552-000 WASHER, PLAIN, 12MM 6 6 6 6 F-10 65 HZV5-90559-000 WASHER, PLAIN, 12MM 14 14 14 F-10 66 HZV5-90561-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 1	
F-10 51 H2V5-90304-013 NUT. SELF-LOCK (7/8-14UNF) 1 1 1 1 F-10 52 H2W4-90306-003 NUT. FLANGE, 10MM 1 1 1 1 F-10 53 H2V5-90307-003 NUT. SELF-LOCK (3/8-24UNF) 2 2 2 F-10 54 H2W4-90401-000 WASHER. PLAIN. 4MM 1 1 1 1 F-10 55 H2V5-90501-000 WASHER. WAVE. 40MM 1 1 1 1 F-10 56 H2V3-90501-A00 WASHER. WAVE. 40MM 2 2 2 2 F-10 57 H2V5-90502-000 WASHER. WAVE. 26MM 2 2 2 2 F-10 58 H2V5-90504-000 WASHER. WAVE. 26MM 1 1 1 1 F-10 59 H2X2-90504-000 WASHER. THRUST. 34MM 1 1 1 1 F-10 60 H2Y3-90509-000 WASHER. UPPER MOUNTING STOPPER 2 2 2 2 F-10 61 H921-90511-000 WASHER. 7/8" 1 1 1 1 F-10 62 H2V4-90512-000 WASHER. PLAIN. 10MM 1 1 1 1 F-10 63 H2V4-90514-000 WASHER. PLAIN. 6MM 2 2 2 2 F-10 64 H2V5-90559-000 WASHER. 10MM 3 3 3 3 F-10 66 H2V5-90559-000 WASHER. PLAIN. 12MM 6 6 6 6 F-10 66 H2V5-90559-000 WASHER. PLAIN. 12MM 1 1 1 1 F-10 66 H2V5-90559-000 WASHER. PLAIN. 12MM 1 1 1 1 F-10 67 H763-90681-A01 CLIP. WIRE HARNESS 1 1 1 1 1	
F-10 52 HZW4-90306-003 NUT. FLANGE, 10MM 1	
F-10 53 HZV5-90307-003 NUT. SELF-LOCK (3/8-24UNF) 2 2 2 F-10 54 HZW4-90401-000 WASHER. PLAIN. 4MM 1 1 1 1 1 F-10 55 HZV5-90501-000 WASHER. WAVE. 40MM 1	
F-10 54 HZW4-90401-000 WASHER, PLAIN, 4MM 1	
F-10 55 HZV5-90501-000 WASHER, WAVE, 40MM 1	
F-10 56 HZY3-90501-A00 WASHER, WAVE, 12MM 2 2 2 F-10 57 HZV5-90502-000 WASHER, WAVE, 26MM 2 2 2 2 F-10 58 HZV5-90504-000 WASHER, THRUST, 34MM 1 1 1 1 1 F-10 59 HZX2-90504-C00 WASHER, UPPER MOUNTING STOPPER 2 2 2 2 2 F-10 60 HZY3-90509-000 WASHER, T/8" 1 1 1 1 1 F-10 61 H921-90511-000 WASHER, PLAIN, 10MM 1 <td></td>	
F-10 57 HZV5-90502-000 WASHER, WAVE, 26MM 2 2 2 F-10 58 HZV5-90504-000 WASHER, THRUST, 34MM 1 1 1 1 F-10 59 HZX2-90504-C00 WASHER, UPPER MOUNTING STOPPER 2 2 2 2 F-10 60 HZY3-90509-000 WASHER, 7/8" 1 1 1 1 1 F-10 61 H921-90511-000 WASHER, PLAIN, 10MM 1 1 1 1 1 1 F-10 62 HZV4-90512-000 WASHER, PLAIN, 6MM 2 2 2 2 2 F-10 63 HZV4-90514-000 WASHER, 10MM 3 3 3 3 F-10 64 HZV5-90552-000 WASHER, PLAIN, 12MM 6 6 6 F-10 65 HZV5-90559-000 WASHER, PLAIN, 12MM 14 14 14 F-10 66 HZV5-90651-000 CIRCLIP, EXTERNAL, 39MM 1 1 <t< td=""><td></td></t<>	
F-10 58 HZV5-90504-000 WASHER, THRUST, 34MM 1	
F-10 59 HZX2-90504-C00 WASHER, UPPER MOUNTING STOPPER 2 2 2 F-10 60 HZY3-90509-000 WASHER, 7/8" 1 1 1 1 F-10 61 H921-90511-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 62 HZV4-90512-000 WASHER, PLAIN, 6MM 2 2 2 F-10 63 HZV4-90514-000 WASHER, 10MM 3 3 3 F-10 64 HZV5-90552-000 WASHER, PLAIN, 12MM 6 6 6 F-10 65 HZV5-90559-000 WASHER, PLAIN, 12MM 14 14 14 F-10 66 HZV5-90651-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 1 F-10 67 H763-90681-A01 CLIP, WIRE HARNESS 1 1 1 1	
F-10 60 HZY3-90509-000 WASHER, 7/8" 1	
F-10 61 H921-90511-000 WASHER, PLAIN, 10MM 1 1 1 1 F-10 62 HZV4-90512-000 WASHER, PLAIN, 6MM 2 2 2 2 F-10 63 HZV4-90514-000 WASHER, 10MM 3 3 3 F-10 64 HZV5-90552-000 WASHER, PLAIN, 12MM 6 6 6 F-10 65 HZV5-90559-000 WASHER, PLAIN, 12MM 14 14 14 F-10 66 HZV5-90651-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 F-10 67 H763-90681-A01 CLIP, WIRE HARNESS 1 1 1	
F-10 62 HZV4-90512-000 WASHER, PLAIN, 6MM 2 2 2 F-10 63 HZV4-90514-000 WASHER, 10MM 3 3 3 F-10 64 HZV5-90552-000 WASHER, PLAIN, 12MM 6 6 6 F-10 65 HZV5-90559-000 WASHER, PLAIN, 12MM 14 14 14 F-10 66 HZV5-90651-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 F-10 67 H763-90681-A01 CLIP, WIRE HARNESS 1 1 1	
F-10 63 HZV4-90514-000 WASHER, 10MM 3 3 3 F-10 64 HZV5-90552-000 WASHER, PLAIN, 12MM 6 6 6 F-10 65 HZV5-90559-000 WASHER, PLAIN, 12MM 14 14 14 F-10 66 HZV5-90651-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 F-10 67 H763-90681-A01 CLIP, WIRE HARNESS 1 1 1	
F-10 64 HZV5-90552-000 WASHER, PLAIN, 12MM 6 6 6 F-10 65 HZV5-90559-000 WASHER, PLAIN, 12MM 14 14 14 F-10 66 HZV5-90651-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 F-10 67 H763-90681-A01 CLIP, WIRE HARNESS 1 1 1	
F-10 65 HZV5-90559-000 WASHER, PLAIN, 12MM 14 14 14 F-10 66 HZV5-90651-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 1 F-10 67 H763-90681-A01 CLIP, WIRE HARNESS 1 1 1 1	
F-10 66 HZV5-90651-000 CIRCLIP, EXTERNAL, 39MM 1 1 1 1 F-10 67 H763-90681-A01 CLIP, WIRE HARNESS 1 1 1 1	
F-10 67 H763-90681-A01 CLIP, WIRE HARNESS 1 1 1 1	
F-10 68 HZV7-90951-010 NIPPLE, GREASE 6 6 6	
F-10 69 HZV5-91256-003 OIL SEAL, 39. 5X52X6 (ARAI) 1 1 1	
F-10 70 HZY3-91560-000 COLLAR, STEERING ROD 1 1 1 1	
F-10 71 HCO-93500-04014-4J SCREW, PAN, 4X14 1 1 1	
F-10 72 HCO-93500-05020-4J SCREW, PAN, 5X20 2 2 2	
F-10 73 HCO-94001-05490-0S NUT, HEX., 5MM 2 2 2 2	
F-10 74 HC0-94001-12490-0S NUT, HEX., 12MM 12 12 12	




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-10	75	HCO-94002-04490-0S	NUT, HEX., 4MM	1	1	1	
F-10	76	HCO-94305-30203	PIN, SPRING, 3X20	2	2	2	
F-10	77	HCO-95005-50045-30	TUBE, 5X45 (95005-50001-30M)	1	1	1	
F-10	78	HCO-95005-50250-30	TUBE, 5X250 (95005-50001-30M)	1	1	1	LDA, LRA
F-10	79	HCO-95005-50340-30	TUBE, 5X340 (95005-50001-30M)	1	1	1	UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-10	80	HMG9-35701-950	BAND (BLACK 3. 5X140)	1	1	1	
F-10	81	HZVP-06411-000	METAL KIT, ANODE	1	1	1	UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-10	82	HZVP-50116-000	METAL, ANODE	1	1	1	UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-10	83	HZVP-50117-000	PLATE, ANODE METAL	2	2	2	UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA
F-10	84	HHW1-90214-671	BOLT, FLANGE, 6X25 (SUS-D)	2	2	2	UCDA, UCRA, UDA, URA, XCDA, XCRA, XDA, XRA




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-11	1	HZX2-30280-003	BREAKER ASSY.	1			~6011044 LRA, XRA
F-11	1	HZX2-30280-003	BREAKER ASSY.	1			~7011008 XCRA
F-11	1	HZX2-30280-003	BREAKER ASSY.		1		~6011043 LRA, XRA
F-11	1	HZX2-30280-003	BREAKER ASSY.		1		~7011014 XCRA
F-11	1	HZX2-30280-003	BREAKER ASSY.			1	~6011114 LDA, LRA, UDA, URA, XDA, XRA
F-11	1	HZX2-30280-003	BREAKER ASSY.			1	~7011043 UCDA, UCRA, XCDA, XCRA
F-11	1	HZX2-30280-013	BREAKER ASSY.	1			6011045~ LRA, XRA
F-11	1	HZX2-30280-013	BREAKER ASSY.	1			7011009~ XCRA
F-11	1	HZX2-30280-013	BREAKER ASSY.		1		6011044~ LRA, XRA
F-11	1	HZX2-30280-013	BREAKER ASSY.		1		7011015~ XCRA
F-11	1	HZX2-30280-013	BREAKER ASSY.			1	6011115~ LDA, LRA, UDA, URA, XDA, XRA
F-11	1	HZX2-30280-013	BREAKER ASSY.			1	7011044~ UCDA, UCRA, XCDA, XCRA
F-11	2	HZX2-31106-003	BRUSH ASSY.	1			~6011044 LRA, XRA
F-11	2	HZX2-31106-003	BRUSH ASSY.	1			~7011008 XCRA
F-11	2	HZX2-31106-003	BRUSH ASSY.		1		~6011043 LRA, XRA
F-11	2	HZX2-31106-003	BRUSH ASSY.		1		~7011014 XCRA
F-11	2	HZX2-31106-003	BRUSH ASSY.			1	~6011114 LDA, LRA, UDA, URA, XDA, XRA
F-11	2	HZX2-31106-003	BRUSH ASSY.			1	~7011043 UCDA, UCRA, XCDA, XCRA
F-11	2	HZX2-31106-013	BRUSH ASSY.	1			6011045~ LRA, XRA
F-11	2	HZX2-31106-013	BRUSH ASSY.	1			7011009~ XCRA
F-11	2	HZX2-31106-013	BRUSH ASSY.		1		6011044~ LRA, XRA
F-11	2	HZX2-31106-013	BRUSH ASSY.		1		7011015~ XCRA
F-11	2	HZX2-31106-013	BRUSH ASSY.			1	6011115~ LDA, LRA, UDA, URA, XDA, XRA
F-11	2	HZX2-31106-013	BRUSH ASSY.			1	7011044~ UCDA, UCRA, XCDA, XCRA
F-11	3	HMG9-35701-950	BAND (BLACK 3. 5X140)	1	1	1	
F-11	4	HZVL-36104-000	TUBE, SPIRAL (12X14.6)	1	1	1	
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT	1			~6011044 LRA, XRA
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT	1			~7011008 XCRA
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT		1		∼6011043 LRA, XRA



					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT		1		~7011014 XCRA
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT			1	~6011114 LDA, LRA, UDA, URA, XDA, XRA
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT			1	~7011043 UCDA, UCRA, XCDA, XCRA
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT	1			6011045~ LRA, XRA
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT	1			7011009~ XCRA
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT		1		6011044~ LRA, XRA
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT		1		7011015~ XCRA
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT			1	6011115~ LDA, LRA, UDA, URA, XDA, XRA
F-11	5	HZX2-36120-013	MOTOR ASSY., POWER TILT			1	7011044~ UCDA, UCRA, XCDA, XCRA
F-11	6	HZX2-36122-003	BRACKET ASSY.	1			~6010052 LRA, XRA
F-11	6	HZX2-36122-003	BRACKET ASSY.	1			~7010006 XCRA
F-11	6	HZX2-36122-003	BRACKET ASSY.		1		~6010057 LRA, XRA
F-11	6	HZX2-36122-003	BRACKET ASSY.		1		~7010010 XCRA
F-11	6	HZX2-36122-003	BRACKET ASSY.			1	∼6010095 LDA, LRA, UDA, URA, XDA, XRA
F-11	6	HZX2-36122-003	BRACKET ASSY.			1	~7010024 UCDA, UCRA, XCDA, XCRA
F-11	6	HZX2-36122-013	BRACKET ASSY.	1			6010053~6011044 LRA, XRA
F-11	6	HZX2-36122-013	BRACKET ASSY.	1			7010007~7011008 XCRA
F-11	6	HZX2-36122-013	BRACKET ASSY.		1		6010058~6011043 LRA, XRA
F-11	6	HZX2-36122-013	BRACKET ASSY.		1		7010011~7011014 XCRA
F-11	6	HZX2-36122-013	BRACKET ASSY.			1	6010096~6011114 LDA, LRA, UDA, URA, XDA, XRA
F-11	6	HZX2-36122-013	BRACKET ASSY.			1	7010025~7011043 UCDA, UCRA, XCDA, XCRA
F-11	6	HZX2-36122-023	BRACKET ASSY.	1			7010025~ UCDA, UCRA, XCDA, XCRA
F-11	6	HZX2-36122-023	BRACKET ASSY.	1			7010025~ UCDA, UCRA, XCDA, XCRA
F-11	6	HZX2-36122-023	BRACKET ASSY.		1		7010025~ UCDA, UCRA, XCDA, XCRA
F-11	6	HZX2-36122-023	BRACKET ASSY.		1		7010025~ UCDA, UCRA, XCDA, XCRA
F-11	6	HZX2-36122-023	BRACKET ASSY.			1	7010025~ UCDA, UCRA, XCDA, XCRA
F-11	6	HZX2-36122-023	BRACKET ASSY.			1	7010025~ UCDA, UCRA, XCDA, XCRA
F-11	7	HZY3-36123-013	ARMATURE COMP.	1	1	1	
F-11	8	HZX2-36129-003	YOKE ASSY.	1	1	1	




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-11	9	HZV5-36136-821	SPRING, MOTOR	2	2	2	
F-11	10	HZW1-40107-700	GROMMET, UNDER CASE(C)	1	1	1	
F-11	11	HZY3-40219-023	WIRE, LEAD(1.5X116MM)	1	1	1	
F-11	12	HZV5-50214-003	BUSH, SWIVEL CASE	2	2	2	
F-11	13	HZX2-56000-043	TRIM-TILT ASSY., POWER	1			~6010052 LRA, XRA
F-11	13	HZX2-56000-043	TRIM-TILT ASSY., POWER	1			~7010006 XCRA
F-11	13	HZX2-56000-043	TRIM-TILT ASSY., POWER		1		~6010057 LRA, XRA
F-11	13	HZX2-56000-043	TRIM-TILT ASSY., POWER		1		~7010010 XCRA
F-11	13	HZX2-56000-043	TRIM-TILT ASSY., POWER			1	∼6010095 LDA, LRA, UDA, URA, XDA, XRA
F-11	13	HZX2-56000-043	TRIM-TILT ASSY., POWER			1	~7010024 UCDA, UCRA, XCDA, XCRA
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER	1			6010053~6010057 LRA, XRA
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER	1			7010007~7010008 XCRA
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER		1		6010058~6010061 LRA, XRA
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER		1		7010011~ XCRA
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER			1	6010096~6010099 LDA, LRA, UDA, URA, XDA, XRA
F-11	13	HZX2-56000-053	TRIM-TILT ASSY., POWER			1	7010025~7010030 UCDA, UCRA, XCDA, XCRA
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER	1			6010058~6011044 LRA, XRA
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER	1			7010009~7011008 XCRA
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER		1		6010062~6011043 LRA, XRA
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER		1		7010011~7011014 XCRA
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER			1	6010100~6011114 LDA, LRA, UDA, URA, XDA, XRA
F-11	13	HZX2-56000-063	TRIM-TILT ASSY., POWER			1	7010031~7011043 UCDA, UCRA, XCDA, XCRA
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER	1			6011045~ LRA, XRA
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER	1			7011009~ XCRA
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER		1		6011044~ LRA, XRA
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER		1		7011015~ XCRA
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER			1	6011115~ LDA, LRA, UDA, URA, XDA, XRA
F-11	13	HZX2-56000-073	TRIM-TILT ASSY., POWER			1	7011044~ UCDA, UCRA, XCDA, XCRA
F-11	14	HZY3-56100-013	PUMP ASSY.	1			∼6010052 LRA, XRA




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-11	14	HZY3-56100-013	PUMP ASSY.	1			~7010006 XCRA
F-11	14	HZY3-56100-013	PUMP ASSY.		1		~6010057 LRA, XRA
F-11	14	HZY3-56100-013	PUMP ASSY.		1		~7010010 XCRA
F-11	14	HZY3-56100-013	PUMP ASSY.			1	~6010095 LDA, LRA, UDA, URA, XDA, XRA
F-11	14	HZY3-56100-013	PUMP ASSY.			1	~7010024 UCDA, UCRA, XCDA, XCRA
F-11	14	HZY3-56100-023	PUMP ASSY.	1			6010053~ LRA, XRA
F-11	14	HZY3-56100-023	PUMP ASSY.	1			7010007~ XCRA
F-11	14	HZY3-56100-023	PUMP ASSY.		1		6010058~ LRA, XRA
F-11	14	HZY3-56100-023	PUMP ASSY.		1		7010011~ XCRA
F-11	14	HZY3-56100-023	PUMP ASSY.			1	6010096~ LDA, LRA, UDA, URA, XDA, XRA
F-11	14	HZY3-56100-023	PUMP ASSY.			1	7010025~ UCDA, UCRA, XCDA, XCRA
F-11	15	HZW1-56110-701	ROD COMP., PISTON(B)	2	2	2	
F-11	16	HZW1-56113-701	JOINT, DRIVE	1	1	1	
F-11	17	HZY9-56115-023	GUIDE COMP., ROD	2	2	2	
F-11	18	HZW1-56116-701	FILTER B	1	1	1	
F-11	19	HZV5-56117-821	RING, BACK UP	1	1	1	
F-11	20	HZV5-56118-820	BUSH, MOTOR CODE	1	1	1	
F-11	21	HZY3-56120-023	ROD COMP., PISTON	1	1	1	
F-11	22	HZW1-56130-702	PISTON COMP., FREE	1	1	1	
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL	1			~6010052 LRA, XRA
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL	1			~7010006 XCRA
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL		1		~6010057 LRA, XRA
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL		1		~7010010 XCRA
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL			1	∼6010095 LDA, LRA, UDA, URA, XDA, XRA
F-11	23	HZY3-56170-013	VALVE COMP., MANUAL			1	~7010024 UCDA, UCRA, XCDA, XCRA
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL	1			6010053~ LRA, XRA
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL	1			7010007~ XCRA
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL		1		6010058~ LRA, XRA
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL		1		7010011~ XCRA

F-11 POWER TRIM-TILT




	0' ty		Q' ty				
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL			1	6010096~ LDA, LRA, UDA, URA, XDA, XRA
F-11	23	HZY3-56170-023	VALVE COMP., MANUAL			1	7010025~ UCDA, UCRA, XCDA, XCRA
F-11	24	HZW1-56180-701	VALVE COMP., RESERVOIR	1	1	1	
F-11	25	HZV5-56513-000	BUSH, LOWER CYLINDER	2	2	2	
F-11	26	HZX2-56532-C00	PIN, UPPER CYLINDER	1	1	1	
F-11	27	HZW1-56851-703	TANK, OIL	1	1	1	
F-11	28	HZW1-56860-701	CAP COMP., OIL TANK	1	1	1	
F-11	29	HZW1-90113-702	BOLT, RECESSED	3	3	3	
F-11	30	HZW1-90114-702	BOLT, SOCKET (A)	1	1	1	
F-11	31	HZW1-90115-702	BOLT, SOCKET (B)	2	2	2	
F-11	32	HZW1-90116-702	BOLT, HEX.	4	4	4	
F-11	33	HZV5-90119-000	SCREW, PAN, 6X8	1	1	1	
F-11	34	HZW1-90652-702	CIRCLIP, INTERNAL	1	1	1	
F-11	35	HZV5-91203-821	OIL SEAL	1	1	1	
F-11	36	HZW1-91207-013	0-RING, 2.0X70.5	1	1	1	
F-11	37	HZV5-91302-821	O-RING, 1.8X69.6	1	1	1	
F-11	38	HZV5-91316-821	0-RING, 3.5X38.7	2	2	2	
F-11	39	HZX2-91352-003	0-RING, 1.68X7.25	6	6	6	
F-11	40	HZW1-91353-703	O-RING, 1.9X11	1	1	1	
F-11	41	HZW1-91354-701	O-RING, 3.5X35.7	2	2	2	
F-11	42	HZW1-91355-701	0-RING, 3.5X41.7	1	1	1	
F-11	43	HZW1-91357-701	O-RING SET, 3.5X31.7	2	2	2	
F-11	44	HZX2-91358-003	SEAL, WATER	2	2	2	
F-11	45	HZW1-91361-701	PACKING	2	2	2	
F-11	46	HZW1-91557-701	COLLAR, ORIFICE	1			~6010057 LRA, XRA
F-11	46	HZW1-91557-701	COLLAR, ORIFICE	1			~7010008 XCRA
F-11	46	HZW1-91557-701	COLLAR, ORIFICE		1		~6010061 LRA, XRA
F-11	46	HZW1-91557-701	COLLAR, ORIFICE		1		~7010010 XCRA
F-11	46	HZW1-91557-701	COLLAR, ORIFICE			1	∼6010099 LDA, LRA, UDA, URA, XDA, XRA


F-11 POWER TRIM-TILT




					Q' ty		_
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-11	46	HZW1-91557-701	COLLAR, ORIFICE			1	~7010030 UCDA, UCRA, XCDA, XCRA
F-11	46	HZX2-91557-003	COLLAR, ORIFICE	1			6010058~ LRA, XRA
F-11	46	HZX2-91557-003	COLLAR, ORIFICE	1			7010009~ XCRA
F-11	46	HZX2-91557-003	COLLAR, ORIFICE		1		6010062~ LRA, XRA
F-11	46	HZX2-91557-003	COLLAR, ORIFICE		1		7010011~ XCRA
F-11	46	HZX2-91557-003	COLLAR, ORIFICE			1	6010100~ LDA, LRA, UDA, URA, XDA, XRA
F-11	46	HZX2-91557-003	COLLAR, ORIFICE			1	7010031~ UCDA, UCRA, XCDA, XCRA
F-11	47	HCO-94540-15029	E-RING, 15MM	2	2	2	
F-11	48	HZY3-90136-003	SCREW, 4X16	2		2	
F-11	48	HZY3-90136-003	SCREW, 4X16		2		LRA, XRA



					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-12	1	HZVL-87117-S00	LABEL, FUSE & OIL CAUTION(E)	1	1	1	(M) LRA, UCRA, URA, XCRA, XRA
F-12	1	HZVL-87117-A01	LABEL, FUSE & OIL CAUTION			1	LDA, UCDA, UDA, XCDA, XDA
F-12	2	HZVJ-87121-P00	MARK, RR. (BFT200)	1			
F-12	3	HZVK-87121-P00	MARK, RR. (BFT225)		1		
F-12	4	HZVL-87121-P00	MARK, RR. (BFT250)			1	
F-12	5	HZVL-87132-P00	MARK, SIDE STRIPE	2	2	2	
F-12	6	HZVJ-87301-P00	MARK, FR. (BFT200)	1			
F-12	7	HZVK-87301-P00	MARK, FR. (BFT225)		1		
F-12	8	HZVL-87301-P00	MARK, FR. (BFT250)			1	
F-12	9	HZVL-87302-P01	MARK, FR. EMBLEM	1	1	1	
F-12	10	HZV1-87538-C23	LABEL, WARNING OPERATOR	1	1	1	
-							
-							
-							
-							
	П						
	П						
			1	-1			





Ref. No Part No Description 89 80 80 80 80 80 80 80 80 80 80 80 80 80						Q' ty		
F-13 2 H355-89217-000 WRENCH, BOX (10MM) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 3 H371-89221-000 WRENCH, HEX., 6MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 4 HC0-99003-10000 DRIVER 1, PLUS SCREW (NO. 2) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 5 HC0-99003-50000 GRIP, SCREW DRIVER 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 6 HC0-99006-19000 WRENCH, EYE, 19MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 7 HC0-99008-02000 BAG, TOOL, 200MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 8 HMR5-16966-000 JOINT, FUEL TUBE 1 1 1 F-13 9 HZV4-17704-010 BAND, TUBE CLIP, 12.5MM 1 1 1	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-13 3 H371-89221-000 WRENCH, HEX., 6MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 4 HC0-99003-10000 DRIVER 1, PLUS SCREW (NO. 2) 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 5 HC0-99003-50000 GRIP, SCREW DRIVER 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 6 HC0-99006-19000 WRENCH, EYE, 19MM 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 7 HC0-99008-02000 BAG, TOOL, 200MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 8 HMR5-16966-000 JOINT, FUEL TUBE 1 1 1 F-13 9 HZV4-17704-010 BAND, TUBE CLIP, 12.5MM 1 1 1	F-13	1	HSF4-89216-000	WRENCH, PLUG	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-13	F-13	2	H355-89217-000	WRENCH, BOX (10MM)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-13 5 HCO-99003-50000 GRIP, SCREW DRIVER 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 6 HCO-99006-19000 WRENCH, EYE, 19MM 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 7 HCO-99008-02000 BAG, TOOL, 200MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 8 HMR5-16966-000 JOINT, FUEL TUBE 1 1 1 F-13 9 HZV4-17704-010 BAND, TUBE CLIP, 12.5MM 1 1 1	F-13	3	H371-89221-000	WRENCH, HEX., 6MM	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-13 6 HCO-99006-19000 WRENCH, EYE, 19MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 7 HCO-99008-02000 BAG, TOOL, 200MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 8 HMR5-16966-000 JOINT, FUEL TUBE 1 1 1 F-13 9 HZV4-17704-010 BAND, TUBE CLIP, 12.5MM 1 1 1	F-13	4	HCO-99003-10000	DRIVER 1, PLUS SCREW(NO.2)	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-13 7 HCO-99008-02000 BAG, TOOL, 200MM 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA F-13 8 HMR5-16966-000 JOINT, FUEL TUBE 1 1 1 F-13 9 HZV4-17704-010 BAND, TUBE CLIP, 12.5MM 1 1	F-13	5	HCO-99003-50000	GRIP, SCREW DRIVER	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-13 8 HMR5-16966-000 JOINT, FUEL TUBE 1 1 1 1 F-13 9 HZV4-17704-010 BAND, TUBE CLIP, 12.5MM 1 1 1	F-13	6	HCO-99006-19000	WRENCH, EYE, 19MM	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
F-13 9 HZV4-17704-010 BAND, TUBE CLIP, 12.5MM 1 1	F-13	7	HCO-99008-02000	BAG, TOOL, 200MM	1	1	1	LDA, LRA, UDA, URA, XDA, XRA
	F-13	8	HMR5-16966-000	JOINT, FUEL TUBE	1	1	1	
F-13 9 HZV4-17704-010 BAMD. TUBE CLIP. 12 5WM 1	F-13	9	HZV4-17704-010	BAND, TUBE CLIP, 12.5MM	1	1		
	F-13	9	HZV4-17704-010	BAND, TUBE CLIP, 12.5MM			2	



				1	Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F-18	1	HZVL-36520-003	ACTUATOR ASSY., SHIFT			1	LDA, UCDA, UDA, XCDA, XDA
F-18	2	HZVL-36521-000	BRACKET, SHIFT ACTUATOR			1	LDA, UCDA, UDA, XCDA, XDA
F-18	3	HZVL-36522-000	RUBBER, CUSHION			6	LDA, UCDA, UDA, XCDA, XDA
F-18	4	HZVL-90106-000	BOLT, SOCKET, 6X30			4	6010109LDA, UDA, XDA LDA, UDA, XDA
F-18	4	HZVL-90106-000	BOLT, SOCKET, 6X30			4	7010037UCDA, XCDA UCDA, XCDA
F-18	4	HZVL-90106-010	BOLT, SOCKET, 6X30			4	∼LDA, UDA, XDA LDA, UDA, XDA
F-18	4	HZVL-90106-010	BOLT, SOCKET, 6X30			4	∼UCDA, XCDA UCDA, XCDA
F-18	5	HZVL-90107-000	BOLT-WASHER, 8X35			3	LDA, UCDA, UDA, XCDA, XDA
F-18	6	HZY9-91504-M00	COLLAR, 8. 5X14. 5			3	~6010109 LDA, UDA, XDA
F-18	6	HZY9-91504-M00	COLLAR, 8. 5X14. 5			3	~7010037 UCDA, XCDA
F-18	6	HZY9-91504-M01	COLLAR, 8. 5X14. 5			3	6010110~ LDA, UDA, XDA
F-18	6	HZY9-91504-M01	COLLAR, 8. 5X14. 5			3	7010038~ UCDA, XCDA


FOP-2 WATER PUMP IMPELLER SET









					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
FOP-2	1	HZX2-06192-C02	PUMP KIT, IMPELLER	1	1	1	
FOP-2	2	HZX2-06193-C02	PUMP KIT, IMPELLER	1	1	1	
FOP-2	3	HZY3-19210-003	IMPELLER, PUMP	1	1	1	
FOP-2	4	HZY3-19221-010	HOUSING, IMPELLER	1	1	1	
FOP-2	5	HZY3-19223-000	LINER, PUMP	1	1	1	
FOP-2	6	HZY3-19231-000	COVER, IMPELLER	1	1	1	
FOP-2	7	HZX2-19234-C00	GASKET B, IMPELLER	1	1	1	
FOP-2	8	HZY3-19253-000	RING, WATER TUBE SEAL	1	1	1	
FOP-2	9	HZX2-90105-C00	BOLT-WASHER, 8X60	4	4	4	
FOP-2	10	HZY3-90752-003	KEY, WOODRUFF	1	1	1	
FOP-2	11	HZY3-91356-003	O-RING, WATER PUMP	1	1	1	
FOP-2	12	HZX2-91358-C00	O-RING, WATER PUMP HOUSING	1	1	1	
FOP-2	13	HZX2-91359-C00	0-RING, 65. 4X2. 4	1	1	1	
FOP-2	14	HZY3-91551-000	COLLAR, DISTANCE	4	4	4	
FOP-2	15	HZVL-90756-000	DOWEL PIN, 6X10	2	2	2	




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3	1	HZZ3-06240-R31	BOX KIT, REMOTE CONTROL	1	1	1	(TOP MOUNT SINGLE) (R.) LRA, UCRA, URA, XCRA, XRA
F0P-3	2	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	1	1	(TOP MOUNT) LRA, UCRA, URA, XCRA, XRA
F0P-3	3	HZW5-24811-U01	HANDLE, REMOTE CONTROL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	4	HZW5-24812-U01	COVER, L. GRIP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	5	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	6	HZW5-24814-U01	CAP, GRIP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	7	HZW5-24815-U01	CAP, SWITCH	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	8	HZW5-24816-U01	BUTTON, THROTTLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	9	HZW5-24817-U01	PLATE, HANDLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	10	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	11	HZW5-24819-U01	BRACKET, REMOTE CONTROL	2	2	2	HOUSING LRA, UCRA, URA, XCRA, XRA
F0P-3	12	HZZ3-24820-R12	HOUSING COMP., REMOTE CONTROL	1	1	1	BOX LRA, UCRA, URA, XCRA, XRA
F0P-3	13	HZW5-24825-U01	HOUSING, LEAD	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	14	HZW5-24826-U01	PLATE, DWELL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	15	HZW5-24831-U01	TERMINAL, CABLE	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3	16	HZW5-24832-U01	SPACER, CABLE CLAMP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	17	HZW5-24834-U01	PACKING, SINGLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	18	HZW7-32530-U00	SUB HARNESS ASSY., POWER	1	1	1	TRIM-TILT(A) LRA, UCRA, URA, XCRA, XRA
F0P-3	19	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	1	1	(A) Lra, Ucra, Ura, XCra, Xra
F0P-3	20	HZZ3-87703-R82	MARK, REMOTE CONTROL(SINGLE)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	21	HZW5-90101-U00	SCREW, PAN, 5X16	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3	22	HZW5-90102-U00	SCREW, PAN, 5X10	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3	23	HZW5-90103-U01	SCREW, PAN, 5X20	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3	24	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3	25	HZW5-90105-U01	SCREW, PAN, 4X10	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3	26	HZW5-90106-U00	SCREW, PAN, 6X18	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3	27	HZW5-90107-U00	SCREW, PAN, 5X40	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3	28	HZW5-90301-U00	NUT, HEX., 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3	29	HZW5-90501-U00	WASHER, LOCK, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA




					Q' ty		
Ref. No		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
FOP-3	30	HZW5-90502-U00	WASHER, LOCK, 6MM	2	2	2	LRA, UCRA, URA, XCRA, XRA
FOP-3	31	HZW5-90503-U00	WASHER, PLAIN, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3	32	HCO-94540-06029	E-RING, 6MM	2	2	2	LRA, UCRA, URA, XCRA, XRA
				+			
				+			
_				+			
				-			
				+			
				+			
				-			
				+			
				+			
	1	<u> </u>	l		<u> </u>	I	




Ref. No. Part No. Description Ref. No. Ref. No. Part No. Description Ref. No. Ref. No. Ref. No. Part No. Description Ref. No. Ref. No. <th></th> <th></th>		
FOP-3-1 2 HZW7-24810-U01 HOUSING ASSY., R. INNER 1 1 FOP-3-1 3 HZW7-24811-U01 HANDLE, REMOTE CONTROL 1 1 FOP-3-1 4 HZW7-24812-U01 COVER, GRIP 1 1 FOP-3-1 5 HZW7-24813-U01 ARM, NEUTRAL LOCK 1 1 FOP-3-1 6 HZW7-24814-U01 COVER, LOCK ARM 1 1 FOP-3-1 7 HZW7-24815-U01 SPRING, NEUTRAL LOCK ARM 1 1 FOP-3-1 8 HZW5-24816-U01 BUTTON, THROTTLE 1 1 FOP-3-1 9 HZW7-24817-U01 SHAFT, THROTTLE BUTTON 1 1 FOP-3-1 10 HZW5-24826-U01 PLATE, DWELL 1 1 FOP-3-1 11 HZZ3-24830-R42 COVER ASSY. 1 1 FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 FOP-3-1 13 HZW5-24832-U01 SPACER, CABLE CLAMP 1 1	BFT250D	Remarks
FOP-3-1 3 HZW7-24811-U01 HANDLE, REMOTE CONTROL 1 1 1 FOP-3-1 4 HZW7-24812-U01 COVER, GRIP 1 1 1 FOP-3-1 5 HZW7-24813-U01 ARM, NEUTRAL LOCK 1 1 1 FOP-3-1 6 HZW7-24814-U01 COVER, LOCK ARM 1 1 1 FOP-3-1 7 HZW7-24815-U01 SPRING, NEUTRAL LOCK ARM 1 1 1 FOP-3-1 8 HZW5-24816-U01 BUTTON, THROTTLE 1 1 1 FOP-3-1 9 HZW7-24817-U01 SHAFT, THROTTLE BUTTON 1 1 1 FOP-3-1 10 HZW5-24826-U01 PLATE, DWELL 1 1 1 FOP-3-1 11 HZZ3-24830-R42 COVER ASSY. 1 1 1 FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 2 FOP-3-1 13 HZW5-24832-U01 SPAGER, CABLE CLAMP 1 1 1 </td <td>1</td> <td>(FLUSH MOUNT) (R.) LRA, UCRA, URA, XCRA, XRA</td>	1	(FLUSH MOUNT) (R.) LRA, UCRA, URA, XCRA, XRA
FOP-3-1 4 HZW7-24812-U01 COVER, GRIP 1 1 FOP-3-1 5 HZW7-24813-U01 ARM, NEUTRAL LOCK 1 1 FOP-3-1 6 HZW7-24814-U01 COVER, LOCK ARM 1 1 FOP-3-1 7 HZW7-24815-U01 SPRING, NEUTRAL LOCK ARM 1 1 FOP-3-1 8 HZW5-24816-U01 BUTTON, THROTTLE 1 1 FOP-3-1 9 HZW7-24817-U01 SHAFT, THROTTLE BUTTON 1 1 FOP-3-1 10 HZW5-24826-U01 PLATE, DWELL 1 1 FOP-3-1 11 HZZ3-24830-R42 COVER ASSY. 1 1 FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 FOP-3-1 13 HZW5-24832-U01 SPAGER, CABLE CLAMP 1 1	1	(FLUSH MOUNT) LRA, UCRA, URA, XCRA, XRA
FOP-3-1 5 HZW7-24813-U01 ARM, NEUTRAL LOCK 1 1 FOP-3-1 6 HZW7-24814-U01 COVER, LOCK ARM 1 1 FOP-3-1 7 HZW7-24815-U01 SPRING, NEUTRAL LOCK ARM 1 1 FOP-3-1 8 HZW5-24816-U01 BUTTON, THROTTLE 1 1 FOP-3-1 9 HZW7-24817-U01 SHAFT, THROTTLE BUTTON 1 1 FOP-3-1 10 HZW5-24826-U01 PLATE, DWELL 1 1 FOP-3-1 11 HZZ3-24830-R42 COVER ASSY. 1 1 FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 FOP-3-1 13 HZW5-24832-U01 SPAGER, CABLE CLAMP 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 6 HZW7-24814-U01 COVER, LOCK ARM 1 1 FOP-3-1 7 HZW7-24815-U01 SPRING, NEUTRAL LOCK ARM 1 1 FOP-3-1 8 HZW5-24816-U01 BUTTON, THROTTLE 1 1 FOP-3-1 9 HZW7-24817-U01 SHAFT, THROTTLE BUTTON 1 1 FOP-3-1 10 HZW5-24826-U01 PLATE, DWELL 1 1 FOP-3-1 11 HZZ3-24830-R42 COVER ASSY. 1 1 FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 FOP-3-1 13 HZW5-24832-U01 SPAGER, CABLE CLAMP 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 7 HZW7-24815-U01 SPRING, NEUTRAL LOCK ARM 1 1 FOP-3-1 8 HZW5-24816-U01 BUTTON, THROTTLE 1 1 FOP-3-1 9 HZW7-24817-U01 SHAFT, THROTTLE BUTTON 1 1 FOP-3-1 10 HZW5-24826-U01 PLATE, DWELL 1 1 FOP-3-1 11 HZZ3-24830-R42 COVER ASSY. 1 1 FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 FOP-3-1 13 HZW5-24832-U01 SPACER, CABLE CLAMP 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 8 HZW5-24816-U01 BUTTON, THROTTLE 1 1 1 FOP-3-1 9 HZW7-24817-U01 SHAFT, THROTTLE BUTTON 1 1 1 FOP-3-1 10 HZW5-24826-U01 PLATE, DWELL 1 1 1 FOP-3-1 11 HZZ3-24830-R42 COVER ASSY. 1 1 1 FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 FOP-3-1 13 HZW5-24832-U01 SPACER, CABLE CLAMP 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 9 HZW7-24817-U01 SHAFT, THROTTLE BUTTON 1 1 FOP-3-1 10 HZW5-24826-U01 PLATE, DWELL 1 1 FOP-3-1 11 HZZ3-24830-R42 COVER ASSY. 1 1 FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 FOP-3-1 13 HZW5-24832-U01 SPACER, CABLE CLAMP 1 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 10 HZW5-24826-U01 PLATE, DWELL 1 1 FOP-3-1 11 HZZ3-24830-R42 COVER ASSY. 1 1 FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 FOP-3-1 13 HZW5-24832-U01 SPACER, CABLE CLAMP 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 11 HZZ3-24830-R42 COVER ASSY. 1 1 1 FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 FOP-3-1 13 HZW5-24832-U01 SPACER, CABLE CLAMP 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 12 HZW5-24831-U01 TERMINAL, CABLE 2 2 FOP-3-1 13 HZW5-24832-U01 SPACER, CABLE CLAMP 1 1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-1 13 HZW5-24832-U01 SPACER, CABLE CLAMP 1 1	1	LRA, UCRA, URA, XCRA, XRA
	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-1 14 HZW7-24832-U01 HOLDER, NEUTRAL LOCK 1 1 1	1	LRA, UCRA, URA, XCRA, XRA
	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 15 HZW7-24833-U01 BASE 1 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 16 HZW7-32530-U20 SUB HARNESS ASSY., POWER 1 1	1	TRIM-TILT(C) LRA, UCRA, URA, XCRA, XRA
FOP-3-1 17 HZW7-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1	1	(C) LRA, UCRA, URA, XCRA, XRA
FOP-3-1 18 HZZ3-87701-R41 MARK, HANDLE FLUSH MOUNT 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 19 HZW7-87703-U00 MARK, FLUSH MOUNT 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 20 HZW5-90101-U00 SCREW, PAN, 5X16 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 21 HZW7-90101-U01 SCREW, TRUSS, 4X12 1 1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 22 HZW7-90102-U01 SCREW, PAN, 5X30 4 4	4	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 23 HZW7-90103-U01 SCREW, PAN, 6X35 3 3	3	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 24 HZW7-90104-U01 SCREW, TAPPING, 6X30 3 3	3	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 25 HZW7-90301-U01 NUT, HEX., 6MM 3 3	3	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 26 HZW5-90501-U00 WASHER, LOCK, 5MM 4 4	4	LRA, UCRA, URA, XCRA, XRA
FOP-3-1 27 HZW7-90502-U00 WASHER, PLAIN, 6MM 3 3	3	LRA, UCRA, URA, XCRA, XRA
F0P-3-1 28 HC0-94540-06029 E-RING, 6MM 2 2 2	2	LRA, UCRA, URA, XCRA, XRA




Ref. No.						Q' ty		
FOR-3-2 2 NZMS-2481G-U01 HOUSING ASSY. L. INNER 1 1 1 1 1 LRA LUCRA LURA XCRA KRA FOR-3-2 3 NZMS-2481G-U11 HOUSING ASSY. R. INNER 1 1 1 1 1 LRA LUCRA LURA XCRA KRA FOR-3-2 4 HZMS-2481G-U11 HOUSING ASSY. R. INNER 1 1 1 1 1 LRA LUCRA LURA LUCRA LURA XCRA KRA FOR-3-2 5 HZMS-2481G-U01 COVER, L. GRIP 1 1 1 1 LRA LUCRA LURA LUCRA LURA XCRA KRA FOR-3-2 6 HZMS-2481G-U01 GRIP, REMOTE CONTROL HAMDLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 7 HZMS-2481G-U01 COVER, DUAL GRIP 1 1 1 LRA LUCRA LURA XCRA KRA FOR-3-2 8 HZMS-2481G-U01 CAP, GRIP 2 2 FOR-3-2 8 HZMS-2481G-U01 CAP, GRIP 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 9 HZMS-2481G-U01 GAP, GRIP 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 10 HZMS-2481G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 11 HZMS-2481G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 11 HZMS-2481G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 11 HZMS-2481G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 11 HZMS-2481G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 11 HZMS-2481G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 11 HZMS-2481G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 11 HZMS-2481G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 11 HZMS-2481G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 11 HZMS-2481G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 1 HUZMS-2482G-U01 PLATE CABLE CLAMP 1 1 1 LRA LUCRA LURA XCRA KRA FOR-3-2 1 HZMS-2482G-U01 BUTTON, THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 1 HZMS-2483G-U01 BUTTON THROTTLE 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 1 HZMS-2483G-U01 SPRACER CABLE CLAMP 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 2 1 HZMS-2483G-U01 SPRACER CABLE CLAMP 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 2 1 HZMS-2483G-U01 SPRACER CABLE CLAMP 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 2 1 HZMS-2483G-U01 SPRACER CABLE CLAMP 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 2 1 HZMS-2483G-U01 SPRACER CABLE CLAMP 2 2 2 LRA LUCRA LURA XCRA KRA FOR-3-2 2 1 HZMS-35370-U02 SINTOH ASSY. POWER TRIN-TILT	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
FOP-3-2 2 RAMS-24810-U11 HOUSING ASSY. R. INMER 1 1 1 1 1 LA LUGA, URA, XERA, KRA FOP-3-2 4 HZW5-24810-U11 HOUSING ASSY. R. INMER 1 1 1 1 1 LRA LUGA, URA, XERA, KRA FOP-3-2 5 NZW5-24812-U01 GOVER, L. GRIP 1 1 1 1 LRA LUGA, URA, XERA, KRA FOP-3-2 6 HZW5-24813-U01 GRIP, RENOTE CONTROL HANDLE 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 7 HZW5-24813-U21 GOVER, DUAL, GRIP 1 1 1 LRA, UGRA, URA, XERA, KRA FOP-3-2 8 HZW5-24814-U01 GAP, GRIP 2 2 FOP-3-2 8 HZW5-24814-U01 GAP, GRIP 2 2 2 FOP-3-2 8 HZW5-24814-U01 GAP, GRIP 2 1 LDA, UGRA, URA, XERA, KRA FOP-3-2 8 HZW5-24814-U01 GAP, GRIP 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 9 HZW5-24814-U01 GAP, GRIP 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 10 HZW5-24814-U01 BUTTON, TRROTTLE 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 11 HZW5-24818-U01 PLATE, CABLE CLAMP 1 1 LRA, UGRA, URA, XERA, KRA FOP-3-2 12 HZW5-24818-U01 BUTTON, TRROTTLE 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 13 HZZS-24820-R22 HOUSING COMP., RENOTE CONTROL 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 14 HZW5-24818-U01 BUTGON, CEAD 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 15 HZW5-24825-U01 PLATE, DWELL 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 16 HZW5-24831-U01 FLATE, DWELL 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 17 HZW5-24825-U01 FLOWER DWELL 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 18 HZW5-24831-U01 FLATE, DWELL 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 15 HZW5-24831-U01 FLATE, DWELL 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 16 HZW5-24831-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 17 HZW5-24831-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 18 HZW5-24831-U01 SWB HANNESS ASSY., POWER 1 1 1 LRA, UGRA, URA, XERA, KRA FOP-3-2 2 1 HZW5-32530-U10 SWB HANNESS ASSY., POWER 1 1 1 LRA, UGRA, URA, XERA, KRA FOP-3-2 2 1 HZW5-35370-U12 SWITCH ASSY., POWER 1 1 1 LRA, UGRA, URA, XERA, KRA FOP-3-2 2 1 HZW5-35370-U12 SWITCH ASSY., POWER 1 1 1 LRA, UGRA, URA, XERA, KRA FOP-3-2 2 1 HZW5-35370-U10 SCREW, PAM. SXIO 2 2 2 LRA, UGRA, URA, XERA, KRA FOP-3-2 2 1 HZW5-35370-U10 SCREW, PAM. SXIO 2 2 2 LRA, UGRA, URA, XERA, KRA FOP	F0P-3-2	1	HZZ3-06240-R61	BOX KIT, REMOTE CONTROL	1	1	1	
FOP-3-2 4 HZW5-24813-U01 MANDLE, REMOTE CONTROL. 2 2 2 LRA, UCRA, URA, XGRA, KRA FOP-3-2 5 HZW5-24813-U01 GOVER, L. GRIP 1 1 1 1 LRA, UCRA, URA, XGRA, KRA FOP-3-2 6 HZW5-24813-U01 GOVER, DUAL, GRIP 1 1 1 1 LRA, UCRA, URA, XGRA, KRA FOP-3-2 7 HZW5-24813-U01 GOVER, DUAL, GRIP 2 2 2 LRA, UCRA, URA, XGRA, KRA FOP-3-2 8 HZW5-24813-U01 GAP, GRIP 2 2 2 FOP-3-2 8 HZW5-24814-U01 GAP, GRIP 2 2 2 FOP-3-2 8 HZW5-24814-U01 GAP, GRIP 2 1 LDA, UCRA, URA, XGRA, XRA FOP-3-2 9 HZW5-24814-U01 GAP, GRIP 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 9 HZW5-24813-U01 BUTTON, THROTTLE 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 10 HZW5-24813-U01 PLATE, HANDLE 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 11 HZW5-24813-U01 PLATE, CARLE GLAMP 1 1 LRA, UCRA, URA, XGRA, XRA FOP-3-2 12 HZW5-24813-U01 BRACKET, REMOTE CONTROL 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 13 HZZS-24820-R22 HOUSTING COMP., REMOTE CONTROL 1 1 BOX GOULD, LRA, UCRA, URA, XGRA, XRA FOP-3-2 15 HZW5-24831-U01 FLATE, DWELL 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 16 HZW5-24831-U01 FLATE, DWELL 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 16 HZW5-24831-U01 SPACET, REMOTE CONTROL 1 1 1 LRA, UCRA, URA, XGRA, XRA FOP-3-2 16 HZW5-24831-U01 SPACET, DWELL 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 16 HZW5-24831-U01 SPACET, DWELL 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 17 HZW5-24831-U01 SPACET, DWELL 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 18 HZW5-24831-U01 SPACET, DWELL 1 1 1 LRA, UCRA, URA, XGRA, XRA FOP-3-2 1 1 HZW5-24831-U01 SPACET, DWELL 1 1 1 LRA, UCRA, URA, XGRA, XRA FOP-3-2 1 1 HZW5-24831-U01 SPACET, DWELL 1 1 1 LRA, UCRA, URA, XGRA, XRA FOP-3-2 2 1 HZW5-35370-U12 SWITCH ASSY., POWER 1 1 1 LRA, UCRA, URA, XGRA, XRA FOP-3-2 2 1 HZW5-35370-U12 SWITCH ASSY., POWER 1 1 1 LRA, UCRA, URA, XGRA, XRA FOP-3-2 2 1 HZW5-35370-U12 SWITCH ASSY., POWER 1 1 1 LRA, UCRA, URA, XGRA, XRA FOP-3-2 2 1 HZW5-35370-U10 SCREW, PAM, SX10 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 2 1 HZW5-35370-U10 SCREW, PAM, SX10 2 2 2 LRA, UCRA, URA, XGRA, XRA FOP-3-2 2 1 HZW5-35370-U10 SCREW, PAM, SX10 2 2 2 LRA, UCRA, URA, XGRA, XRA	F0P-3-2	2	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	1	1	
FOP-3-2 5 HZM5-24813-U01 COVER, L. GRIP 1 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 6 HZM5-24813-U01 GRIP, REMOTE CONTROL HANDLE 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 7 HZM5-24813-U21 COVER, DUAL GRIP 1 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 8 HZM5-24813-U01 CAP, GRIP 2 2 2 FOP-3-2 8 HZM5-24814-U01 CAP, GRIP 2 1 LDA, UCRA, URA, XCRA, XRA FOP-3-2 8 HZM5-24814-U01 CAP, GRIP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 9 HZM5-24814-U01 CAP, GRIP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 10 HZM5-24816-U01 BUTTON, THROTTLE 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 11 HZM5-24818-U01 PLATE, HANDLE 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 12 HZM5-24818-U01 PLATE, CABLE CLAMP 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 13 HZZ3-24820-R22 HOUSING COMP., REMOTE CONTROL 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 14 HZM5-24819-U01 BRACKET, REMOTE CONTROL 1 1 1 BOX (DUAL) FOP-3-2 15 HZM5-24820-U11 HOUSING, LEAD 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 16 HZM5-24820-U11 PLATE, DIBELL 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 17 HZM5-24832-U01 SPACER, CABLE CLAMP 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 18 HZM5-24832-U01 SPACER, CABLE CLAMP 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 HZM5-24832-U01 SPACER, CABLE CLAMP 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 HZM5-24832-U01 SPACER, CABLE CLAMP 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 HZM5-24832-U01 SPACER, CABLE CLAMP 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 HZM5-24832-U01 SPACER, CABLE CLAMP 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 HZM5-24832-U01 SPACER, CABLE CLAMP 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZM5-24834-U21 PACKING, DUAL 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZM5-24834-U21 SPACER, CABLE CLAMP 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 RZM5-2530-U10 SUB HARNESS ASSY., POWER 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZM5-269101-U10 SCREW, PAN, SX16 3 3 3 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZM5-90101-U100 SCREW, PAN, SX16 3 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZM5-90101-U100 SCREW, PAN, SX16 3 2 2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	3	HZW5-24810-U11	HOUSING ASSY., R. INNER	1	1	1	
FOP-3-2 6	F0P-3-2	4	HZW5-24811-U01	HANDLE, REMOTE CONTROL	2	2	2	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 7 HZW5-24813-U21 COVER. DUAL GRIP 1 1 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 8 HZW5-24814-U01 CAP, GRIP 2 2 2 FOP-3-2 8 HZW5-24814-U01 CAP, GRIP 2 1 LDA, UGDA, UDA, XGRA, XRA FOP-3-2 8 HZW5-24814-U01 CAP, GRIP 2 2 LRA, UGRA, URA, XGRA, XRA FOP-3-2 9 HZW5-24814-U01 BUTTON, THROTTLE 2 2 2 LRA, UGRA, URA, XGRA, XRA FOP-3-2 10 HZW5-24818-U01 PLATE, CABLE CLAMP 1 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 11 HZW5-24818-U01 PLATE, CABLE CLAMP 1 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 12 HZW5-24819-U01 BRACKET, RENOTE CONTROL 2 2 2 LRA, UGRA, URA, XGRA, XRA FOP-3-2 13 HZZ3-24820-R22 HOUSING COMP., RENOTE CONTROL 1 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 14 HZW5-24825-U01 HOUSING, LEAD 2 2 2 LRA, UGRA, URA, XGRA, XRA FOP-3-2 15 HZW5-24826-U01 PLATE, DWELL 2 2 2 LRA, UGRA, URA, XGRA, XRA FOP-3-2 16 HZW5-24831-U01 SPAGER, CABLE CLAMP 2 2 2 LRA, UGRA, URA, XGRA, XRA FOP-3-2 17 HZW5-24831-U01 SPAGER, CABLE CLAMP 2 2 2 LRA, UGRA, URA, XGRA, XRA FOP-3-2 18 HZW5-24831-U01 SPAGER, CABLE CLAMP 2 2 2 LRA, UGRA, URA, XGRA, XRA FOP-3-2 19 HZW5-24831-U01 SPAGER, CABLE CLAMP 2 2 2 LRA, UGRA, URA, XGRA, XRA FOP-3-2 19 HZW5-24834-U21 PACKING, DUAL 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 2 HZW5-24834-U21 SW BARNESS ASSY., POWER 1 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 2 HZW5-3530-U00 SUB HARNESS ASSY., POWER 1 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 2 HZW5-3530-U02 SW HARNESS ASSY., POWER TRIM-TILT 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 2 HZW5-3530-U02 SW HARNESS ASSY., POWER TRIM-TILT 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 2 HZW5-3530-U02 SW HARNESS ASSY., POWER TRIM-TILT 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 2 HZW5-3530-U02 SW HARNESS ASSY., POWER TRIM-TILT 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 2 HZW5-3530-U02 SW HARNESS ASSY., POWER TRIM-TILT 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 2 HZW5-3530-U02 SW HARNESS ASSY., POWER TRIM-TILT 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 2 HZW5-3530-U02 SGRW, PAN, SX10 2 2 2 LRA, UGRA, URA, XGRA, XRA	F0P-3-2	5	HZW5-24812-U01	COVER, L. GRIP	1	1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 8	F0P-3-2	6	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	2	2	2	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 8 H2W5-24814-U01 CAP, GRIP 1 LDA, UCDA, UDA, XCDA, XDA FOP-3-2 8 H2W5-24814-U01 CAP, GRIP 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 9 H2W5-24816-U01 BUTTON, THROTTLE 2 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 10 H2W5-24818-U01 PLATE, HANDLE 2 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 11 H2W5-24818-U01 PLATE, CABLE CLAMP 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 12 H2W5-24819-U01 BRACKET, REMOTE CONTROL 2 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 13 H2Z3-24820-R22 HOUSING COMP., REMOTE CONTROL 1 1 1 BOX (DUAL) FOP-3-2 14 H2W5-24825-U01 HOUSING, LEAD 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 15 H2W5-24826-U01 PLATE, DWELL 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 16 H2W5-24826-U01 TERMINAL, CABLE 4 4 4 LRA, UCRA, URA, XCRA, XRA FOP-3-2 17 H2W5-24831-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 18 H2W5-24831-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 H2W5-24831-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 H2W5-24831-U01 SPACER, CABLE CLAMP 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 17 H2W5-24831-U01 SPACER, CABLE CLAMP 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 H2W7-32530-U00 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILIT (B) FOP-3-2 2 1 H2W5-35370-U02 SWITCH ASSY., POWER 1 1 1 TRIM-TILIT (B) FOP-3-2 2 1 H2W5-35370-U02 SWITCH ASSY., POWER 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 4 H2W5-35370-U12 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 4 H2W5-35370-U12 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 4 H2W5-35370-U12 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 4 H2W5-35370-U12 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 4 H2W5-90101-U00 SCREW, PAM, 5X10 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 5 H2W5-90102-U00 SCREW, PAM, 5X10 2 2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	7	HZW5-24813-U21	COVER, DUAL GRIP	1	1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 8 HZW5-24814-U01 CAP, GRIP 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 9 HZW5-24816-U01 BUTTON, THROTTLE 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 10 HZW5-24817-U01 PLATE, HANDLE 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 11 HZW5-24818-U01 PLATE, CABLE CLAMP 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 12 HZW5-24819-U01 BRACKET, REMOTE CONTROL 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 13 HZZ3-24820-R22 HOUSING COMP., REMOTE CONTROL 1 1 1 BOX (DUAL) LRA, UCRA, URA, XCRA, XRA FOP-3-2 14 HZW5-24826-U01 HOUSING, LEAD 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 15 HZW5-24826-U01 PLATE, DWELL 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 16 HZW5-24831-U01 TERMINAL, CABLE 4 4 4 LRA, UCRA, URA, XCRA, XRA FOP-3-2 17 HZW5-24832-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 18 HZW5-24834-U21 PACKING, DUAL FOP-3-2 19 HZW7-32530-U00 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILIT(A) LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U02 SWITCH ASSY., POWER 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILIT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-90102-U00 SCREW, PAN, 5X16 3 3 3 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	8	HZW5-24814-U01	CAP, GRIP	2	2		
FOP-3-2 9 HZW5-24816-U01 BUTTON, THROTTLE 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 10 HZW5-24817-U01 PLATE, HANDLE 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 11 HZW5-24818-U01 PLATE, CABLE CLAMP 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 12 HZW5-24819-U01 BRACKET, REMOTE CONTROL 2 2 2 HOUSING LRA, UCRA, URA, XCRA, XRA FOP-3-2 13 HZZ3-24820-R22 HOUSING COMP., REMOTE CONTROL 1 1 1 BOX (DUAL) FOP-3-2 14 HZW5-24825-U01 HOUSING, LEAD 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 15 HZW5-24826-U01 PLATE, DWELL 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 16 HZW5-24831-U01 TERMINAL, CABLE 4 4 4 LRA, UCRA, URA, XCRA, XRA FOP-3-2 17 HZW5-24832-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 18 HZW5-24832-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 HZW7-32530-U00 SUB HARNESS ASSY., POWER 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U02 SWITCH ASSY., POWER 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2	F0P-3-2	8	HZW5-24814-U01	CAP, GRIP			1	LDA, UCDA, UDA, XCDA, XDA
FOP-3-2 10 HZW5-24817-U01 PLATE, HANDLE 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 11 HZW5-24818-U01 PLATE, CABLE CLAMP 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 12 HZW5-24819-U01 BRACKET, REMOTE CONTROL 2 2 2 EMA, UCRA, URA, XCRA, XRA FOP-3-2 13 HZZ3-24820-R22 HOUSING COMP., REMOTE CONTROL 1 1 1 1 BRACKET, REMOTE CONTROL 1 1 1 1 BRACKET, REMOTE CONTROL 1 1 1 1 BRACKET, REMOTE CONTROL 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 14 HZW5-24825-U01 HOUSING, LEAD 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 15 HZW5-24826-U01 PLATE, DWELL 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 16 HZW5-24831-U01 TERMINAL, CABLE 4 4 4 LRA, UCRA, URA, XCRA, XRA FOP-3-2 17 HZW5-24832-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 18 HZW5-24834-U21 PACKING, DUAL 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 HZW7-32530-U00 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILT (A) FOP-3-2 20 HZW7-32530-U10 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILT (B) LRA, UCRA, URA, XCRA, XRA FOP-3-2 21 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 22 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 24 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 24 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 25 HZW5-90101-U00 SCREW, PAN, 5X16 3 3 3 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 25 HZW5-90101-U00 SCREW, PAN, 5X10 2 2 2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	8	HZW5-24814-U01	CAP, GRIP			2	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 11 HZW5-24818-U01 PLATE, CABLE CLAMP 1 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 12 HZW5-24819-U01 BRACKET, REMOTE CONTROL 2 2 2 2 HOUSING FOP-3-2 13 HZZ3-24820-R22 HOUSING COMP., REMOTE CONTROL 1 1 1 1 BX (DUIAL) FOP-3-2 14 HZW5-24825-U01 HOUSING, LEAD 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 15 HZW5-24826-U01 PLATE, DWELL 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 16 HZW5-24831-U01 TERMINAL, CABLE 4 4 4 4 LRA, UCRA, URA, XCRA, XRA FOP-3-2 17 HZW5-24832-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 18 HZW5-24834-U21 PACKING, DUAL 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 HZW7-32530-U00 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILT (A) LRA, UCRA, URA, XCRA, XRA FOP-3-2 20 HZW7-32530-U10 SUB HARNESS ASSY., POWER 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 21 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 22 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 23 HZZ3-87703-RO2 MARK, REMOTE CONTROL (DUAL) 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 24 HZW5-90101-U00 SCREW, PAN, 5X10 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 25 HZW5-90102-U00 SCREW, PAN, 5X10 2 2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	9	HZW5-24816-U01	BUTTON, THROTTLE	2	2	2	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 12 HZW5-24819-U01 BRACKET, REMOTE CONTROL 2 2 2 2 2 2 2 2 1 HOUSING LEA, UCRA, URA, XCRA, XRA FOP-3-2 13 HZZ3-24820-R22 HOUSING COMP., REMOTE CONTROL 1	F0P-3-2	10	HZW5-24817-U01	PLATE, HANDLE	2	2	2	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 12 RZNS-Z4829-U1 BRACKET, REMUTE CONTROL 2 2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	11	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 14 HZW5-24825-U01 HOUSING COMP*. REMOTE CONTROL FOP-3-2 14 HZW5-24825-U01 HOUSING, LEAD 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 15 HZW5-24826-U01 PLATE, DWELL 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 16 HZW5-24831-U01 TERMINAL, CABLE FOP-3-2 17 HZW5-24832-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 18 HZW5-24834-U21 PACKING, DUAL FOP-3-2 19 HZW7-32530-U00 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILT (A) LRA, UCRA, URA, XCRA, XRA FOP-3-2 20 HZW7-32530-U10 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILT (B) LRA, UCRA, URA, XCRA, XRA FOP-3-2 21 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 22 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 23 HZZ3-87703-RO2 MARK, REMOTE CONTROL (DUAL) FOP-3-2 24 HZW5-90101-U00 SCREW, PAN, 5X10 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 25 HZW5-90102-U00 SCREW, PAN, 5X10 2 2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	12	HZW5-24819-U01	BRACKET, REMOTE CONTROL	2	2	2	
F0P-3-2 15 HZW5-24826-U01 PLATE, DWELL 2 2 2 LRA, UCRA, URA, XCRA, XRA F0P-3-2 16 HZW5-24831-U01 TERMINAL, CABLE 4 4 4 LRA, UCRA, URA, XCRA, XRA F0P-3-2 17 HZW5-24832-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA F0P-3-2 18 HZW5-24834-U21 PACKING, DUAL 1 1 1 LRA, UCRA, URA, XCRA, XRA F0P-3-2 19 HZW7-32530-U00 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILT (A) LRA, UCRA, URA, XCRA, XRA F0P-3-2 20 HZW7-32530-U10 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILT (B) LRA, UCRA, URA, XCRA, XRA F0P-3-2 21 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 1 1 1 LRA, UCRA, URA, XCRA, XRA F0P-3-2 22 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 1 1 1 LRA, UCRA, URA, XCRA, XRA F0P-3-2 23 <	F0P-3-2	13	HZZ3-24820-R22	HOUSING COMP., REMOTE CONTROL	1	1	1	
F0P-3-2 16 HZW5-24831-U01 TERMINAL, CABLE 4 4 4 4 LRA, UCRA, URA, XCRA, XRA F0P-3-2 17 HZW5-24832-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA F0P-3-2 18 HZW5-24834-U21 PACKING, DUAL 1 1 1 LRA, UCRA, URA, XCRA, XRA F0P-3-2 19 HZW7-32530-U00 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILT (B) LRA, UCRA, URA, XCRA, XRA F0P-3-2 20 HZW7-32530-U10 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILT (B) LRA, UCRA, URA, XCRA, XRA F0P-3-2 21 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 1 1 LRA, UCRA, URA, XCRA, XRA F0P-3-2 22 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 1 1 1 LRA, UCRA, URA, XCRA, XRA F0P-3-2 23 HZZ3-87703-R02 MARK, REMOTE CONTROL (DUAL) 1 1 1 1 1 1 1 1 <td>F0P-3-2</td> <td>14</td> <td>HZW5-24825-U01</td> <td>HOUSING, LEAD</td> <td>2</td> <td>2</td> <td>2</td> <td>LRA, UCRA, URA, XCRA, XRA</td>	F0P-3-2	14	HZW5-24825-U01	HOUSING, LEAD	2	2	2	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 17 HZW5-24832-U01 SPACER, CABLE CLAMP 2 2 2 LRA, UCRA, URA, XCRA, XRA FOP-3-2 18 HZW5-24834-U21 PACKING, DUAL 1 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 HZW7-32530-U00 SUB HARNESS ASSY., POWER 1 1 1 TRIM-TILT (B) LRA, UCRA, URA, XCRA, XRA FOP-3-2 20 HZW7-32530-U10 SUB HARNESS ASSY., POWER 1 1 1 1 TRIM-TILT (B) LRA, UCRA, URA, XCRA, XRA FOP-3-2 21 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 1 1 (A) LRA, UCRA, URA, XCRA, XRA FOP-3-2 22 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 1 1 1 (B) LRA, UCRA, URA, XCRA, XRA FOP-3-2 23 HZZ3-87703-R02 MARK, REMOTE CONTROL (DUAL) 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	F0P-3-2	15	HZW5-24826-U01	PLATE, DWELL	2	2	2	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 18 HZW5-24834-U21 PACKING, DUAL 1 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 19 HZW7-32530-U00 SUB HARNESS ASSY., POWER 1 1 1 1 TRIM-TILT (B) LRA, UCRA, URA, XCRA, XRA FOP-3-2 20 HZW7-32530-U10 SUB HARNESS ASSY., POWER 1 1 1 1 1 IRIM-TILT (B) LRA, UCRA, URA, XCRA, XRA FOP-3-2 21 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 1 1 (A) LRA, UCRA, URA, XCRA, XRA FOP-3-2 22 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 1 1 1 (B) LRA, UCRA, URA, XCRA, XRA FOP-3-2 23 HZZ3-87703-R02 MARK, REMOTE CONTROL (DUAL) 1 1 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 24 HZW5-90101-U00 SCREW, PAN, 5X16 3 3 3 LRA, UCRA, URA, XCRA, XRA FOP-3-2 25 HZW5-90102-U00 SCREW, PAN, 5X10 2 2 2	F0P-3-2	16	HZW5-24831-U01	TERMINAL, CABLE	4	4	4	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 19 HZW7-32530-U00 SUB HARNESS ASSY POWER 1 1 1 TRIM-TILT (A) LRA, UCRA, URA, XCRA, XRA FOP-3-2 20 HZW7-32530-U10 SUB HARNESS ASSY POWER 1 1 1 1 TRIM-TILT (A) LRA, UCRA, URA, XCRA, XRA FOP-3-2 21 HZW5-35370-U02 SWITCH ASSY POWER TRIM-TILT 1 1 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 22 HZW5-35370-U12 SWITCH ASSY POWER TRIM-TILT 1	F0P-3-2	17	HZW5-24832-U01	SPACER, CABLE CLAMP	2	2	2	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 20 HZW7-32530-U10 SUB HARNESS ASSY. POWER 1 1 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 21 HZW5-35370-U02 SWITCH ASSY. POWER TRIM-TILT 1 1 1 (A) LRA, UGRA, URA, XGRA, XRA FOP-3-2 22 HZW5-35370-U12 SWITCH ASSY. POWER TRIM-TILT 1 1 1 (B) LRA, UGRA, URA, XGRA, XRA FOP-3-2 22 HZW5-35370-U12 SWITCH ASSY. POWER TRIM-TILT 1 1 1 1 (B) LRA, UGRA, URA, XGRA, XRA FOP-3-2 23 HZZ3-87703-R02 MARK, REMOTE CONTROL (DUAL) 1 1 1 LRA, UGRA, URA, XGRA, XRA FOP-3-2 24 HZW5-90101-U00 SCREW, PAN, 5X16 3 3 3 LRA, UGRA, URA, XGRA, XRA FOP-3-2 25 HZW5-90102-U00 SCREW, PAN, 5X10 2 2 2 LRA, UGRA, URA, XGRA, XRA	F0P-3-2	18	HZW5-24834-U21	PACKING, DUAL	1	1	1	LRA, UCRA, URA, XCRA, XRA
FOP-3-2 21 HZW5-35370-U02 SWITCH ASSY., POWER TRIM-TILT 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	F0P-3-2	19	HZW7-32530-U00	SUB HARNESS ASSY., POWER	1	1	1	
FOP-3-2 22 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 22 HZW5-35370-U12 SWITCH ASSY., POWER TRIM-TILT 1 1 1 1 (B) LRA, UCRA, URA, XCRA, XRA FOP-3-2 23 HZZ3-87703-R02 MARK, REMOTE CONTROL (DUAL) 1 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 24 HZW5-90101-U00 SCREW, PAN, 5X16 3 3 3 LRA, UCRA, URA, XCRA, XRA FOP-3-2 25 HZW5-90102-U00 SCREW, PAN, 5X10 2 2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	20	HZW7-32530-U10	SUB HARNESS ASSY., POWER	1	1	1	
FOP-3-2 22 HZW5-95370-U12 SWITCH ASST. POWER IRIM-TILLI I I LRA, UCRA, URA, XCRA, XRA FOP-3-2 23 HZZ3-87703-R02 MARK, REMOTE CONTROL (DUAL) 1 1 1 1 LRA, UCRA, URA, XCRA, XRA FOP-3-2 24 HZW5-90101-U00 SCREW, PAN, 5X16 3 3 3 LRA, UCRA, URA, XCRA, XRA FOP-3-2 25 HZW5-90102-U00 SCREW, PAN, 5X10 2 2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	21	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	1	1	
F0P-3-2 24 HZW5-90101-U00 SCREW, PAN, 5X16 3 3 3 LRA, UCRA, URA, XCRA, XRA F0P-3-2 25 HZW5-90102-U00 SCREW, PAN, 5X10 2 2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	22	HZW5-35370-U12	SWITCH ASSY., POWER TRIM-TILT	1	1	1	
F0P-3-2 25 HZW5-90102-U00 SCREW, PAN, 5X10 2 2 2 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	23	HZZ3-87703-R02	MARK, REMOTE CONTROL (DUAL)	1	1	1	LRA, UCRA, URA, XCRA, XRA
	F0P-3-2	24	HZW5-90101-U00	SCREW, PAN, 5X16	3	3	3	LRA, UCRA, URA, XCRA, XRA
FOR 0 0 00 117WF 00100 1101	F0P-3-2	25	HZW5-90102-U00	SCREW, PAN, 5X10	2	2	2	LRA, UCRA, URA, XCRA, XRA
- FUF-3-2 ZO	F0P-3-2	26	HZW5-90103-U01	SCREW, PAN, 5X20	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-2 27 HZW5-90104-U00 SCREW, PAN, 5X18 4 4 4 LRA, UCRA, URA, XCRA, XRA	F0P-3-2	27	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	4	LRA, UCRA, URA, XCRA, XRA




				1	Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-2	28	HZW5-90105-U01	SCREW, PAN, 4X10	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-2	29	HZW5-90106-U00	SCREW, PAN, 6X18	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-2	30	HZW5-90107-U00	SCREW, PAN, 5X40	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-2	31	HZW5-90108-U00	SCREW, PAN, 5X55	3	3	3	LRA, UCRA, URA, XCRA, XRA
F0P-3-2	32	HZW5-90301-U00	NUT, HEX., 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-2	33	HZW5-90302-U21	NUT, HEX., 5MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-2	34	HZW5-90501-U00	WASHER, LOCK, 5MM	8	8	8	LRA, UCRA, URA, XCRA, XRA
F0P-3-2	35	HZW5-90502-U00	WASHER, LOCK, 6MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-2	36	HZW5-90503-U00	WASHER, PLAIN, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-2	37	HCO-94540-06029	E-RING, 6MM	4	4	4	LRA, UCRA, URA, XCRA, XRA




F0P-3-3 1 HZZ3- F0P-3-3 2 HZZ5-	24800-P14 24810-D01 24811-D01	Description BOX ASSY., REMOTE CONTROL	BFT200D —	BFT225D	BFT250D	Remarks
F0P-3-3 2 HZZ5-	24810-D01	BOX ASSY., REMOTE CONTROL	1			
				1	1	(NHK MEC) Lra, Ucra, Ura, XCra, Xra
F0P-3-3 3 HZZ5-	24811-D01	PLATE ASSY.	1	1	1	LRA, UCRA, URA, XCRA, XRA
		LEVER, HAND	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 4 HZZ5-	24812-D01	ARM, NEUTRAL LOCK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 5 HZZ5-	24813-D01	GRIP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 6 HZZ5-	24814-D01	COVER, LEVER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 7 HZZ5-	24815-D01	ARM ASSY., BRAKE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 8 HZZ5-	24816-D01	SPRING(2)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 9 HZZ5-	24817-D01	CLIP, DETENT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 10 HZZ5-	24818-D01	SPACER (1)	1	1	1	(LOOSE PARTS) LRA, UCRA, URA, XCRA, XRA
F0P-3-3 11 HZZ5-	24819-D01	BRACKET	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 12 HZZ5-	24821-D01	HOUSING, FR.	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 13 HZZ5-	24822-D01	HOUSING, RR.	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 14 HZZ5-	24823-D01	PANEL, BACK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 15 HZZ5-	24824-D01	BRACKET, WIRE CLAMP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 16 HZZ5-	24826-D01	CAP, RUBBER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 17 HZZ5-	24827-D01	ADJUSTER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 18 HZZ5-	24828-D01	COVER, POWER TRIM-TILT WIRE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 19 HZZ5-	24828-D01	COVER, POWER TRIM-TILT WIRE	1	1	1	(LOOSE PARTS) LRA, UCRA, URA, XCRA, XRA
F0P-3-3 20 HZZ5-	24829-D01	SEAL, RUBBER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 21 HZZ5-	24831-D01	HOLDER, NEUTRAL LOCK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 22 HZZ5-	24832-D01	GROMMET, WIRE (14)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 23 HZZ5-	24833-D01	CAP, TROLLING CONTROL SWITCH	1	1	1	BLANK LRA, UCRA, URA, XCRA, XRA
F0P-3-3 24 HZZ5-	24845-D01	GEAR ASSY., SHIFT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 25 HZZ5-	24850-D01	GEAR, DRIVE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 26 HZZ5-	24855-D01	TERMINAL, CABLE	2	2	2	(LOOSE PARTS) LRA, UCRA, URA, XCRA, XRA
F0P-3-3 27 HZZ5-	24875-D01	DRUM ASSY., FREE THROTTLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 28 HZZ5-	24876-D01	SPRING(1)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3 29 HZZ5-	24878-D01	LEVER, FREE THROTTLE	1	1	1	LRA, UCRA, URA, XCRA, XRA




	Q' ty						
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-3	30	HZZ5-24883-D01	SPRING, DETENT	5	5	5	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	31	HZZ5-32530-D01	CABLE ASSY., REMOTE CONTROL(B)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	32	HZV5-32823-003	PLUG, INNER CONNECTOR	7	7	7	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	33	HZV5-32824-003	PLUG, OUTER CONNECTOR	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	34	HZZ3-35100-R12	SWITCH ASSY., COMBINATION	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	35	HZZ5-35370-D02	SWITCH ASSY., POWER TRIM-TILT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	36	HZZ3-35645-A41	PLATE, SWITCH	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	37	HZZ5-35701-D01	BAND, WIRE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	38	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	39	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	40	HZZ5-37210-D02	LAMP ASSY., INDICATION	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	41	H341-38403-672	PLATE, WINKER BUZZER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	42	HZV5-38410-003	BUZZER COMP., WARNING	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	43	HZZ5-87701-D00	MARK, FAST IDLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	44	HZZ5-87702-A00	MARK, EMERGENCY STOP (US)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	45	HZZ5-87702-A00	MARK, EMERGENCY STOP (US)	1	1	1	(LOOSE PARTS) LRA, UCRA, URA, XCRA, XRA
F0P-3-3	46	HZZ5-87703-P01	MARK, EMBLEM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	47	HZZ5-87704-D01	LABEL, SIGP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	48	HZZ5-90101-D01	SCREW, 5X18	7	7	7	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	49	HZZ5-90102-D01	SCREW, 4X6	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	50	HZZ5-90103-D01	SCREW, 5X10	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	51	HZZ5-90104-D01	SCREW, 4X10	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	52	HZZ5-90106-D01	SCREW, 5X12	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	53	HZZ5-90107-D01	SCREW, 6X90	3	3	3	(LOOSE PARTS) LRA, UCRA, URA, XCRA, XRA
F0P-3-3	54	HZZ5-90108-D01	BOLT, 8X50	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	55	HZZ5-90109-D01	BOLT, 5X25	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	56	HZZ5-90301-D01	NUT, 6MM	3	3	3	(LOOSE PARTS) LRA, UCRA, URA, XCRA, XRA
F0P-3-3	57	H921-90302-000	NUT, HEX., 16MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	58	HZZ5-90302-D01	NUT, 5MM	1	1	1	LRA, UCRA, URA, XCRA, XRA




				T	Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-3	59	HZZ5-90501-D01	BEARING(1)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	60	HZZ5-90502-D01	WASHER (3)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	61	HZZ5-90503-D01	WASHER (4)	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	62	HZZ5-90504-D01	WASHER (5)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	63	HZZ5-90506-D01	WASHER, 8MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	64	HZZ5-90507-D01	WASHER (7)	3	3	3	(LOOSE PARTS) LRA, UCRA, URA, XCRA, XRA
F0P-3-3	65	HZZ5-90508-D01	WASHER, WAVE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	66	HZZ5-90509-D01	SPACER (2)	3	3	3	(LOOSE PARTS) LRA, UCRA, URA, XCRA, XRA
F0P-3-3	67	HZZ5-90651-D01	E-RING, 6MM	2	2	2	(LOOSE PARTS) LRA, UCRA, URA, XCRA, XRA
F0P-3-3	68	HZZ5-91151-D01	ROLLER, DRIVE GEAR CAM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	69	HZZ5-91152-D01	ROLLER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	70	HZZ5-91153-D01	BEARING (2)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	71	HZZ5-91154-D01	BEARING(3)	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	72	HZZ5-91156-D01	ROLLER, FREE THROTTLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-3	73	HZZ5-91157-D01	CLIP, ROLLER	1	1	1	LRA, UCRA, URA, XCRA, XRA




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-4	1	HZVL-06240-P02	BOX KIT, REMOTE CONTROL (FLUSH MOUNT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	2	HZVL-24800-P01	BOX ASSY., REMOTE CONTROL			1	(FLUSH MOUNT) (RH) LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	3	HZVL-24801-003	BAND, NYLON			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	4	HZVL-24802-003	BOLT, SOCKET			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	5	HZVL-24810-003	HOUSING ASSY. (FLUSH MOUNT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	6	HZVL-24811-003	COLLAR, STOPPER			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	7	HZVL-24811-701	SHOE, BRAKE			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	8	HZVL-24812-003	SCREW			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	9	HZVL-24815-701	SCREW			6	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	10	HZVL-24816-701	SCREW SET			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	11	HZVL-24817-701	SCREW SET			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	12	HZVL-24830-003	COVER ASSY. (FLUSH MOUNT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	13	HZVL-24831-003	SHEET, WATER PROOF			1	(FLUSH MOUNT) LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	14	HZVL-24840-003	NUT SET, MOUNTING			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	15	HZVL-24841-003	NUT, NYLON			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	16	HZVL-24841-701	NUT			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	17	HZVL-24842-003	WASHER			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	18	HZVL-24843-003	BOLT			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	19	HZVL-24850-003	BASE ASSY. (FLUSH MOUNT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	20	HZVL-24851-003	COLLAR, BASE			8	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	21	HZVL-24870-P01	LEVER ASSY. (FLUSH MOUNT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	22	HZVL-24872-P01	PANEL, LEVER(FLUSH MOUNT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	23	HZVL-24873-003	CAP, LEVER(FLUSH MOUNT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	24	HZVL-24874-003	PLATE, LEVER PANEL			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	25	HZVL-24875-003	SPRING, COIL			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	26	HZVL-24875-701	BOLT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	27	HZVL-24876-701	WASHER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	28	HZVL-24877-701	SCREW			5	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	29	HZVL-24878-701	WASHER			1	LDA, UCDA, UDA, XCDA, XDA




					Q'ty		_
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-4	30	HZVL-30420-000	CASE, CONTROL UNIT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	31	HZVL-32107-003	TERMINATOR ASSY.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	32	HKFG-32108-000	COVER, CONNECTOR			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	33	HZZ3-32127-000	SUSPENSION, COUPLER			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	34	HZVL-32530-010	CABLE ASSY., REMOTE CONTROL			1	(MAIN) LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	35	HK44-32606-V01	CAP, DUMMY(WPC 4P 090 M)(RED)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	36	HZVL-34330-013	CONTROL UNIT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	37	HZVL-35370-003	SWITCH ASSY., POWER TRIM-TILT			1	(FLUSH MOUNT) LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	38	HV15-38206-003	FUSE, BLADE (3A)			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	39	HZ2E-38216-003	COVER ASSY., FUSE			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	40	HZZ3-38580-003	RELAY ASSY., MAIN			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	41	HZZ5-38586-003	SUSPENSION, RELAY			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	42	HZ2E-87117-000	LABEL, FUSE (3A)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	43	HZVL-87118-000	LABEL, FUSE (5A)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	44	HZW7-87703-U00	MARK, FLUSH MOUNT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	45	HZZ5-90018-M01	BOLT, FLANGE, 6X20			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	46	HZW5-90109-000	SCREW, PAN, 5X40			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	47	HZZ5-90301-M01	NUT, FLANGE, 5MM			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	48	HZZ5-90501-M01	WASHER, PLAIN, 5MM			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	49	HZZ5-90502-M01	WASHER, SPRING, 5MM			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	50	HSTK-91535-003	CLIP, COUPLER (DARK BLUE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	51	HTA0-91535-003	CLIP, COUPLER (DARK BROWN)			6	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	52	HS0A-91541-003	CLIP, HARNESS BAND (BLACK)			5	(145MM) LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	53	HC0-98200-40500	FUSE, MINI (5A)			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	54	HZV5-32823-003	PLUG, INNER CONNECTOR			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	55	HZY6-38580-V11	RELAY ASSY., CONTROL			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-4	56	HSR3-91531-003	HOLDER, COUPLER (NATURAL) (128. 6MM)			1	LDA, UCDA, UDA, XCDA, XDA
-							
					•		



					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-5	1	HZVL-06240-P12	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE) (MAIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	2	HZVL-24800-P11	BOX ASSY., REMOTE CONTROL			1	(TOP MOUNT SINGLE) (RH) LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	3	HZVL-24801-601	GASKET (SINGLE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	4	HZVL-24802-701	COVER, CAP			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	5	HZVL-24803-601	PLATE, COVER FIX(SINGLE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	6	HZVL-24804-601	SHEET, WATER PROOF(SINGLE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	7	HZVL-24805-701	BOLT, SOCKET			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	8	HZVL-24806-701	SCREW			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	9	HZVL-24807-701	BAND, NYLON			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	10	HZVL-24810-701	HOUSING ASSY., L.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	11	HZVL-24811-701	SHOE, BRAKE			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	12	HZVL-24812-701	PLATE, HARNESS			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	13	HZVL-24813-701	BOLT, STUD			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	14	HZVL-24814-701	BOLT			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	15	HZVL-24815-701	SCREW			9	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	16	HZVL-24816-701	SCREW SET			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	17	HZVL-24817-701	SCREW SET			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	18	HZVL-24820-601	HOUSING ASSY., SINGLE			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	19	HZVL-24830-P11	COVER ASSY., SINGLE			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	20	HZVL-24831-P11	LED ASSY., COVER(S)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	21	HZVL-24832-701	BAND, NYLON			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	22	HZVL-24840-701	NUT SET, MOUNTING			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	23	HZVL-24841-701	NUT			7	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	24	HZVL-24842-701	WASHER			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	25	HZVL-24870-701	LEVER ASSY., L.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	26	HZVL-24871-701	LEVER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	27	HZVL-24872-701	PANEL, LEVER(POWER TRIM-TILT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	28	HZVL-24873-701	CAP, LEVER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	29	HZVL-24874-701	PLATE, LEVER PANEL			1	LDA, UCDA, UDA, XCDA, XDA




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-5	30	HZVL-24875-701	BOLT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	31	HZVL-24876-701	WASHER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	32	HZVL-24877-701	SCREW			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	33	HZVL-24878-701	WASHER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	34	HZVL-24879-701	SCREW			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	35	HZVL-30420-000	CASE, CONTROL UNIT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	36	HZVL-32107-003	TERMINATOR ASSY.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	37	HKFG-32108-000	COVER, CONNECTOR			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	38	HZZ3-32127-000	SUSPENSION, COUPLER			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	39	HZVL-32530-010	CABLE ASSY., REMOTE CONTROL			1	(MAIN) LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	40	HK44-32606-V01	CAP, DUMMY (WPC 4P 090 M) (RED)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	41	HZVL-34330-013	CONTROL UNIT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	42	HZVL-35330-701	SWITCH ASSY., SELECT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	43	HZVL-35370-701	SWITCH ASSY., POWER TRIM-TILT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	44	HV15-38206-003	FUSE, BLADE (3A)			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	45	HZ2E-38216-003	COVER ASSY., FUSE			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	46	HZZ3-38580-003	RELAY ASSY., MAIN			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	47	HZZ5-38586-003	SUSPENSION, RELAY			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	48	HZ2E-87117-000	LABEL, FUSE (3A)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	49	HZVL-87118-000	LABEL, FUSE (5A)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	50	HZZ5-90018-M01	BOLT, FLANGE, 6X20			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	51	HZW5-90109-000	SCREW, PAN, 5X40			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	52	HZZ5-90301-M01	NUT, FLANGE, 5MM			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	53	HZZ5-90501-M01	WASHER, PLAIN, 5MM			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	54	HZZ5-90502-M01	WASHER, SPRING, 5MM			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	55	HSTK-91535-003	CLIP, COUPLER (DARK BLUE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	56	HTA0-91535-003	CLIP, COUPLER (DARK BROWN)			6	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	57	HS0A-91541-003	CLIP, HARNESS BAND (BLACK)			5	(145MM) LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	58	HCO-93500-05065-4J	SCREW, PAN, 5X65			4	LDA, UCDA, UDA, XCDA, XDA




					Q' ty		_
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-5	59	HCO-98200-40500	FUSE, MINI (5A)			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	60	HZV5-32823-003	PLUG, INNER CONNECTOR			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	61	HZY6-38580-V11	RELAY ASSY., CONTROL			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-5	62	HSR3-91531-003	HOLDER, COUPLER(NATURAL) (128.6MM)			1	LDA, UCDA, UDA, XCDA, XDA

FOP-3-6 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (MAIN) (DBW)




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-6	1	HZVL-06240-P22	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL) (MAIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	2	HZVL-24800-P21	BOX ASSY., REMOTE CONTROL (TOP MOUNT DUAL) (RH)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	3	HZVL-24801-701	GASKET (TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	4	HZVL-24802-701	COVER, CAP			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	5	HZVL-24803-701	PLATE, COVER FIX (TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	6	HZVL-24804-701	SHEET, WATER PROOF (TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	7	HZVL-24805-701	BOLT, SOCKET			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	8	HZVL-24806-701	SCREW			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	9	HZVL-24807-701	BAND, NYLON			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	10	HZVL-24810-701	HOUSING ASSY., L.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	11	HZVL-24811-701	SHOE, BRAKE			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	12	HZVL-24812-701	PLATE, HARNESS			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	13	HZVL-24813-701	BOLT, STUD			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	14	HZVL-24814-701	BOLT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	15	HZVL-24815-701	SCREW			18	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	16	HZVL-24816-701	SCREW SET			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	17	HZVL-24817-701	SCREW SET			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	18	HZVL-24820-701	HOUSING ASSY., R.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	19	HZVL-24830-P21	COVER ASSY., TWIN			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	20	HZVL-24831-P21	LED ASSY., COVER(T)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	21	HZVL-24832-701	BAND, NYLON			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	22	HZVL-24840-701	NUT SET, MOUNTING			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	23	HZVL-24841-701	NUT			10	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	24	HZVL-24842-701	WASHER			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	25	HZVL-24870-701	LEVER ASSY., L.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	26	HZVL-24871-701	LEVER			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	27	HZVL-24872-701	PANEL, LEVER(POWER TRIM-TILT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	28	HZVL-24873-701	CAP, LEVER			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6	29	HZVL-24874-701	PLATE, LEVER PANEL			2	LDA, UCDA, UDA, XCDA, XDA

FOP-3-6 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (MAIN) (DBW)




Ref. No.	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-6 3	0 HZVL-24875-701	BOLT			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 3	1 HZVL-24876-701	WASHER			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 3	2 HZVL-24877-701	SCREW			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 3	3 HZVL-24878-701	WASHER			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 3	4 HZVL-24879-701	SCREW			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 3	5 HZVL-24880-701	LEVER ASSY., R.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 3	6 HZVL-24881-701	PANEL, LEVER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 3	7 HZVL-30420-000	CASE, CONTROL UNIT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 3	8 HZVL-32107-003	TERMINATOR ASSY.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 3	9 HKFG-32108-000	COVER, CONNECTOR			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 4	0 HZZ3-32127-000	SUSPENSION, COUPLER			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 4	1 HZVL-32530-010	CABLE ASSY., REMOTE CONTROL (MAIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 4	2 HK44-32606-V01	CAP, DUMMY(WPC 4P 090 M) (RED)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 4	3 HZVL-34330-013	CONTROL UNIT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 4	4 HZVL-35330-701	SWITCH ASSY., SELECT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 4	5 HZVL-35370-701	SWITCH ASSY., POWER TRIM-TILT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 4	6 HV15-38206-003	FUSE, BLADE (3A)			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 4	7 HZ2E-38216-003	COVER ASSY., FUSE			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 4	8 HZZ3-38580-003	RELAY ASSY., MAIN			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 4	9 HZZ5-38586-003	SUSPENSION, RELAY			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 5	0 HZ2E-87117-000	LABEL, FUSE (3A)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 5	1 HZVL-87118-000	LABEL, FUSE (5A)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 5	2 HZZ5-90018-M01	BOLT, FLANGE, 6X20			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 5	3 HZW5-90109-000	SCREW, PAN, 5X40			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 5	4 HZZ5-90301-M01	NUT, FLANGE, 5MM			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 5	5 HZZ5-90501-M01	WASHER, PLAIN, 5MM			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 5	6 HZZ5-90502-M01	WASHER, SPRING, 5MM			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 5	7 HSTK-91535-003	CLIP, COUPLER (DARK BLUE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-6 5	8 HTA0-91535-003	CLIP, COUPLER (DARK BROWN)			6	LDA, UCDA, UDA, XCDA, XDA


FOP-3-6 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (MAIN) (DBW)




Ref. No. Part No. Bescription The company of the company o						Q' ty		
FOP-3-6 60 HCO-93500-05065-4J SCREW, PAN, 5X65 4 LDA, UCDA, UDA, XCDA, XDA FOP-3-6 61 HCO-98200-40500 FUSE, MINI (5A) 2 LDA, UCDA, UDA, XCDA, XDA FOP-3-6 62 HZV5-32823-003 PLUG, INNER CONNECTOR 2 LDA, UCDA, UDA, XCDA, XDA FOP-3-6 63 HZY6-38580-V11 RELAY ASSY., CONTROL 1 LDA, UCDA, UDA, XCDA, XDA	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-6 61 HC0-98200-40500 FUSE, MINI (5A) 2 LDA, UCDA, UDA, XCDA, XDA F0P-3-6 62 HZV5-32823-003 PLUG, INNER CONNECTOR 2 LDA, UCDA, UDA, XCDA, XDA F0P-3-6 63 HZY6-38580-V11 RELAY ASSY., CONTROL 1 LDA, UCDA, UDA, XCDA, XDA	F0P-3-6	59	HS0A-91541-003	CLIP, HARNESS BAND(BLACK)			5	
F0P-3-6 62 HZV5-32823-003 PLUG, INNER CONNECTOR 2 LDA, UCDA, UDA, XCDA, XDA F0P-3-6 63 HZY6-38580-V11 RELAY ASSY., CONTROL 1 LDA, UCDA, UDA, XCDA, XDA	F0P-3-6	60	HCO-93500-05065-4J	SCREW, PAN, 5X65			4	LDA, UCDA, UDA, XCDA, XDA
FOP-3-6 63 HZY6-38580-V11 RELAY ASSY., CONTROL 1 LDA, UCDA, UDA, XCDA, XDA	F0P-3-6	61	HCO-98200-40500	FUSE, MINI (5A)			2	LDA, UCDA, UDA, XCDA, XDA
	F0P-3-6	62	HZV5-32823-003	PLUG, INNER CONNECTOR			2	LDA, UCDA, UDA, XCDA, XDA
FOP-3-6 64 HSR3-91531-003 HOLDER, COUPLER (NATURAL) (128.6MM) 1 LDA, UCDA, UDA, XCDA, XDA	F0P-3-6	63	HZY6-38580-V11	RELAY ASSY., CONTROL			1	LDA, UCDA, UDA, XCDA, XDA
	F0P-3-6	64	HSR3-91531-003	HOLDER, COUPLER(NATURAL) (128.6MM)			1	LDA, UCDA, UDA, XCDA, XDA




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-7	1	HZVL-06250-P12	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE) (2ND)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	2	HZVL-24800-P11	BOX ASSY., REMOTE CONTROL (TOP MOUNT SINGLE) (RH)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	3	HZVL-24801-601	GASKET (SINGLE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	4	HZVL-24802-701	COVER, CAP			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	5	HZVL-24803-601	PLATE, COVER FIX(SINGLE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	6	HZVL-24804-601	SHEET, WATER PROOF (SINGLE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	7	HZVL-24805-701	BOLT, SOCKET			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	8	HZVL-24806-701	SCREW			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	9	HZVL-24807-701	BAND, NYLON			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	10	HZVL-24810-701	HOUSING ASSY., L.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	11	HZVL-24811-701	SHOE, BRAKE			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	12	HZVL-24812-701	PLATE, HARNESS			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	13	HZVL-24813-701	BOLT, STUD			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	14	HZVL-24814-701	BOLT			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	15	HZVL-24815-701	SCREW			9	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	16	HZVL-24816-701	SCREW SET			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	17	HZVL-24817-701	SCREW SET			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	18	HZVL-24820-601	HOUSING ASSY., SINGLE			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	19	HZVL-24830-P11	COVER ASSY., SINGLE			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	20	HZVL-24831-P11	LED ASSY., COVER(S)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	21	HZVL-24832-701	BAND, NYLON			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	22	HZVL-24840-701	NUT SET, MOUNTING			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	23	HZVL-24841-701	NUT			7	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	24	HZVL-24842-701	WASHER			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	25	HZVL-24870-701	LEVER ASSY., L.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	26	HZVL-24871-701	LEVER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	27	HZVL-24872-701	PANEL, LEVER(POWER TRIM-TILT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	28	HZVL-24873-701	CAP, LEVER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	29	HZVL-24874-701	PLATE, LEVER PANEL			1	LDA, UCDA, UDA, XCDA, XDA




				Q'ty		
Ref. No.	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-7	30 HZVL-24875-701	BOLT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	31 HZVL-24876-701	WASHER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	32 HZVL-24877-701	SCREW			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	33 HZVL-24878-701	WASHER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	34 HZVL-24879-701	SCREW			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	35 HZVL-30420-000	CASE, CONTROL UNIT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	36 HZVL-32107-003	TERMINATOR ASSY.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	37 HKFG-32108-000	COVER, CONNECTOR			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	38 HZVL-32108-003	DUMMY, WATER PROOF CONNECTOR			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	39 HZZ3-32127-000	SUSPENSION, COUPLER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	40 HZVL-32390-P01	PANEL ASSY., EMERGENCY STOP			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	41 HZVL-32396-P01	PANEL, EMERGENCY STOP SWITCH			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	42 HZVL-32530-600	CABLE ASSY., REMOTE CONTROL (2ND)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	43 HK44-32606-V01	CAP, DUMMY(WPC 4P 090 M)(RED)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	44 HZVL-34330-013	CONTROL UNIT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	45 HZVL-35330-701	SWITCH ASSY., SELECT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	46 HZVL-35370-701	SWITCH ASSY., POWER TRIM-TILT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	47 HZVL-36180-003	SWITCH ASSY., EMERGENCY STOP			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	48 HZY6-36182-003	CORD COMP., EMERGENCY			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	49 HZY9-38400-A00	BUZZER ASSY., WARNING			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	50 HZY9-38402-A00	SUSPENSION, WARNING BUZZER			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	51 HZZ5-90018-M01	BOLT, FLANGE, 6X20			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	52 HZW5-90109-000	SCREW, PAN, 5X40			8	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	53 HZZ5-90301-M01	NUT, FLANGE, 5MM			8	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	54 HZY6-90302-003	NUT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	55 HZZ5-90501-M01	WASHER, PLAIN, 5MM			8	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	56 HZZ5-90502-M01	WASHER, SPRING, 5MM			8	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	57 HSTK-91535-003	CLIP, COUPLER (DARK BLUE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	58 HTAO-91535-003	CLIP, COUPLER (DARK BROWN)			2	LDA, UCDA, UDA, XCDA, XDA




					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-7	59	HS0A-91541-003	CLIP, HARNESS BAND(BLACK) (145MM)			5	LDA, UCDA, UDA, XCDA, XDA
F0P-3-7	60	HTTA-91549-003	CLIP, BAND HARNESS(BLACK) (152.4MM)			1	LDA, UCDA, UDA, XCDA, XDA



Ref. No.						
	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-8 1	HZVL-06250-P22	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL) (2ND)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	PZVL-24800-P21	BOX ASSY., REMOTE CONTROL (TOP MOUNT DUAL) (RH)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 3	3 HZVL-24801-701	GASKET (TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 4	HZVL-24802-701	COVER, CAP			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 5	5 HZVL-24803-701	PLATE, COVER FIX(TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 6	6 HZVL-24804-701	SHEET, WATER PROOF(TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 7	7 HZVL-24805-701	BOLT, SOCKET			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 8	3 HZVL-24806-701	SCREW			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 9	HZVL-24807-701	BAND, NYLON			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 10	0 HZVL-24810-701	HOUSING ASSY., L.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 1	1 HZVL-24811-701	SHOE, BRAKE			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 1:	2 HZVL-24812-701	PLATE, HARNESS			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 1	3 HZVL-24813-701	BOLT, STUD			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 1	4 HZVL-24814-701	BOLT			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 1	5 HZVL-24815-701	SCREW			18	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 1	6 HZVL-24816-701	SCREW SET			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 1	7 HZVL-24817-701	SCREW SET			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 1	8 HZVL-24820-701	HOUSING ASSY., R.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 1	9 HZVL-24830-P21	COVER ASSY., TWIN			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	0 HZVL-24831-P21	LED ASSY., COVER(T)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	1 HZVL-24832-701	BAND, NYLON			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	2 HZVL-24840-701	NUT SET, MOUNTING			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	3 HZVL-24841-701	NUT			10	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	4 HZVL-24842-701	WASHER			4	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	5 HZVL-24870-701	LEVER ASSY., L.			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	6 HZVL-24871-701	LEVER			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	7 HZVL-24872-701	PANEL, LEVER(POWER TRIM-TILT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	8 HZVL-24873-701	CAP, LEVER			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8 2	9 HZVL-24874-701	PLATE, LEVER PANEL			2	LDA, UCDA, UDA, XCDA, XDA




Ref. No. Part No. Description ET 2000 ET 2000 ET 2000 ET 2000 Remark FOP-3-8 30 HZVL-24875-701 BOLT 2 LDA, UCDA, UDA, XCDA, FOP-3-8 31 HZVL-24876-701 WASHER 2 LDA, UCDA, UDA, XCDA, FOP-3-8 32 HZVL-24877-701 SCREW 2 LDA, UCDA, UDA, XCDA, FOP-3-8 33 HZVL-24878-701 WASHER 2 LDA, UCDA, UDA, XCDA, FOP-3-8 34 HZVL-24879-701 SCREW 2 LDA, UCDA, UDA, XCDA, FOP-3-8 35 HZVL-24880-701 LEVER ASSY., R. 1 LDA, UCDA, UDA, XCDA, FOP-3-8 36 HZVL-24881-701 PANEL, LEVER 1 LDA, UCDA, UDA, XCDA, FOP-3-8 37 HZVL-30420-000 CASE, CONTROL UNIT 1 LDA, UCDA, UDA, XCDA,	XDA XDA XDA XDA XDA XDA
FOP-3-8 31 HZVL-24876-701 WASHER 2 LDA, UCDA, UDA, XCDA, FOP-3-8 32 HZVL-24877-701 SCREW 2 LDA, UCDA, UDA, XCDA, FOP-3-8 33 HZVL-24878-701 WASHER 2 LDA, UCDA, UDA, XCDA, FOP-3-8 34 HZVL-24879-701 SCREW 2 LDA, UCDA, UDA, XCDA, FOP-3-8 35 HZVL-24880-701 LEVER ASSY., R. 1 LDA, UCDA, UDA, XCDA, FOP-3-8 36 HZVL-24881-701 PANEL, LEVER 1 LDA, UCDA, UDA, XCDA, FOP-3-8 37 HZVL-30420-000 CASE, CONTROL UNIT 1 LDA, UCDA, UDA, XCDA,	XDA XDA XDA XDA XDA XDA
FOP-3-8 32 HZVL-24877-701 SCREW 2 LDA, UCDA, UDA, XCDA, FOP-3-8 33 HZVL-24878-701 WASHER 2 LDA, UCDA, UDA, XCDA, FOP-3-8 34 HZVL-24879-701 SCREW 2 LDA, UCDA, UDA, XCDA, FOP-3-8 35 HZVL-24880-701 LEVER ASSY., R. 1 LDA, UCDA, UDA, XCDA, FOP-3-8 36 HZVL-24881-701 PANEL, LEVER 1 LDA, UCDA, UDA, XCDA, FOP-3-8 37 HZVL-30420-000 CASE, CONTROL UNIT 1 LDA, UCDA, UDA, XCDA,	XDA XDA XDA XDA
FOP-3-8 33 HZVL-24878-701 WASHER 2 LDA, UCDA, UDA, XCDA, FOP-3-8 34 HZVL-24879-701 SCREW 2 LDA, UCDA, UDA, XCDA, FOP-3-8 35 HZVL-24880-701 LEVER ASSY., R. 1 LDA, UCDA, UDA, XCDA, FOP-3-8 36 HZVL-24881-701 PANEL, LEVER 1 LDA, UCDA, UDA, XCDA, FOP-3-8 37 HZVL-30420-000 CASE, CONTROL UNIT 1 LDA, UCDA, UDA, XCDA,	XDA XDA
FOP-3-8 34 HZVL-24879-701 SCREW 2 LDA, UCDA, UDA, XCDA, FOP-3-8 35 HZVL-24880-701 LEVER ASSY., R. 1 LDA, UCDA, UDA, XCDA, FOP-3-8 36 HZVL-24881-701 PANEL, LEVER 1 LDA, UCDA, UDA, XCDA, FOP-3-8 37 HZVL-30420-000 CASE, CONTROL UNIT 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 35 HZVL-24880-701 LEVER ASSY., R. 1 LDA, UCDA, UDA, XCDA, FOP-3-8 36 HZVL-24881-701 PANEL, LEVER 1 LDA, UCDA, UDA, XCDA, FOP-3-8 37 HZVL-30420-000 CASE, CONTROL UNIT 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 36 HZVL-24881-701 PANEL, LEVER 1 LDA, UCDA, UDA, XCDA, FOP-3-8 37 HZVL-30420-000 CASE, CONTROL UNIT 1 LDA, UCDA, UDA, XCDA,	
FOP-3-8 37 HZVL-30420-000 CASE, CONTROL UNIT 1 LDA, UCDA, UDA, XCDA,	XDA
	XDA
FOP-3-8 38 HZVL-32107-003 TERMINATOR ASSY. 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 39 HKFG-32108-000 COVER, CONNECTOR 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 40 HZVL-32108-003 DUMMY, WATER PROOF CONNECTOR 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 41 HZZ3-32127-000 SUSPENSION, COUPLER 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 42 HZVL-32390-P01 PANEL ASSY., EMERGENCY STOP 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 43 HZVL-32396-P01 PANEL, EMERGENCY STOP SWITCH 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 44 HZVL-32530-600 CABLE ASSY., REMOTE CONTROL (2ND) 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 45 HK44-32606-V01 CAP, DUMMY (WPC 4P 090 M) (RED) 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 46 HZVL-34330-013 CONTROL UNIT 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 47 HZVL-35330-701 SWITCH ASSY., SELECT 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 48 HZVL-35370-701 SWITCH ASSY., POWER TRIM-TILT 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 49 HZVL-36180-003 SWITCH ASSY., EMERGENCY STOP 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 50 HZY6-36182-003 CORD COMP., EMERGENCY 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 51 HZY9-38400-A00 BUZZER ASSY., WARNING 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 52 HZY9-38402-A00 SUSPENSION, WARNING BUZZER 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 53 HZZ5-90018-M01 BOLT, FLANGE, 6X20 2 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 54 HZW5-90109-000 SCREW, PAN, 5X40 8 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 55 HZZ5-90301-M01 NUT, FLANGE, 5MM 8 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 56 HZY6-90302-003 NUT 1 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 57 HZZ5-90501-M01 WASHER, PLAIN, 5MM 8 LDA, UCDA, UDA, XCDA,	XDA
FOP-3-8 58 HZZ5-90502-M01 WASHER, SPRING, 5MM 8 LDA, UCDA, UDA, XCDA,	XDA




				Q' ty			
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-8	59	HSTK-91535-003	CLIP, COUPLER (DARK BLUE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8	60	HTA0-91535-003	CLIP, COUPLER (DARK BROWN)			2	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8	61	HS0A-91541-003	CLIP, HARNESS BAND(BLACK) (145MM)			5	LDA, UCDA, UDA, XCDA, XDA
F0P-3-8	62	HTTA-91549-003	CLIP, BAND HARNESS(BLACK) (152.4MM)			1	LDA, UCDA, UDA, XCDA, XDA

FOP-3-9 REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (NHK MEC)




		0' ty					
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-9	1	HZY6-06240-R90	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	2	HZY6-24810-U11	HOUSING ASSY., L. INNER (TOP MOUNT)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	3	HZY6-24811-U11	HANDLE, REMOTE CONTROL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	4	HZY6-24812-U11	COVER, GRIP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	5	HZY6-24813-U11	GRIP, REMOTE CONTROL HANDLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	6	HZY6-24814-U11	COVER, LEVER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	7	HZY6-24816-U11	BUTTON, THROTTLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	8	HZW5-24817-U01	PLATE, HANDLE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	9	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	10	HZY6-24819-U11	BRACKET, REMOTE CONTROL HOUSING	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	11	HZY6-24820-U11	HOUSING, SINGLE REMOTE CONTROL BOX	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	12	HZY6-24821-U11	PLUG, SINGLE HOUSING	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	13	HZY6-24824-U11	GUIDE, SINGLE WATER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	14	HZY6-24825-U11	HOUSING, LEAD	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	15	HZW5-24826-U01	PLATE, DWELL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	16	HZY6-24826-R11	COVER, HOUSING SIDE	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	17	HZY6-24827-U11	RING, SNAP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	18	HZY6-24828-U11	GROMMET	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	19	HZW5-24831-U01	TERMINAL, CABLE (LOOSE PARTS)	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-9 2	20	HZW5-24832-U01	SPACER, CABLE CLAMP (LOOSE PARTS)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9 2	21	HZY6-24832-U91	CAP, BLANK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9 2	22	HZW5-24834-U01	PACKING, SINGLE (LOOSE PARTS)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9 2	23	HZY6-35370-U11	SWITCH ASSY., POWER TRIM-TILT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9 2	24	HZY6-87703-R11	MARK, REMOTE CONTROL (SINGLE)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9 2	25	HZW5-90101-U00	SCREW, PAN, 5X16	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	26	HZY6-90102-U11	SCREW, TRUSS, 5X10	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	27	HZY6-90103-U11	SCREW, TRUSS, 5X16 (TAPPING)	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	28	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	29	HZY6-90104-U11	SCREW, PAN, 5X14 (TAPPING)	1	1	1	LRA, UCRA, URA, XCRA, XRA

FOP-3-9 REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (NHK MEC)




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-9	30	HZW5-90106-U00	SCREW, PAN, 6X18	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	31	HZY6-90106-U11	SCREW, PAN, 5X14 (TAPPING)	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	32	HZW5-90107-U00	SCREW, PAN, 5X40 (LOOSE PARTS)	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	33	HZY6-90111-U11	BOLT, STOPPER(F)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	34	HZY6-90112-U11	BOLT, STOPPER (R)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	35	HZW5-90301-U00	NUT, HEX., 5MM (LOOSE PARTS)	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	36	HZZ5-90301-D01	NUT, 6MM	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	37	HZW5-90501-U00	WASHER, LOCK, 5MM	3	3	3	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	38	HZW5-90502-U00	WASHER, LOCK, 6MM	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	39	HZW5-90503-U00	WASHER, PLAIN, 5MM (LOOSE PARTS)	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	40	HZZ5-90651-D01	E-RING, 6MM (LOOSE PARTS)	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	41	HZZ5-90651-D01	E-RING, 6MM	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	42	HZY6-06241-U10	SPACER KIT, REMOTE CONTROL BOX (TOP MOUNT SINGLE)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	43	HZV4-90502-000	WASHER, PLAIN, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	44	HCO-93500-05065-4J	SCREW, PAN, 5X65	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-9	45	HCO-94001-05490-0S	NUT, HEX., 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA

FOP-3-10 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (NHK MEC)




				Q' ty			
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-10	1	HZY6-06240-S90	BOX KIT, REMOTE CONTROL(TOP MOUNT DUAL)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	2	HZY6-24810-U11	HOUSING ASSY., L. INNER(TOP MOUNT)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	3	HZY6-24810-V11	HOUSING ASSY., R. INNER(TOP MOUNT)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	4	HZY6-24811-U11	HANDLE, REMOTE CONTROL	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	5	HZY6-24812-U11	COVER, GRIP	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	6	HZY6-24813-U11	GRIP, REMOTE CONTROL HANDLE	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	7	HZY6-24814-U11	COVER, LEVER	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	8	HZY6-24816-U11	BUTTON, THROTTLE	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	9	HZW5-24817-U01	PLATE, HANDLE	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	10	HZW5-24818-U01	PLATE, CABLE CLAMP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	11	HZY6-24819-V11	BRACKET, REMOTE CONTROL HOUSING	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	12	HZY6-24820-V11	HOUSING, DUAL REMOTE CONTROL BOX	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	13	HZY6-24821-V11	PLUG, DUAL HOUSING	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	14	HZY6-24824-V11	GUIDE, DUAL WATER	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	15	HZY6-24825-U11	HOUSING, LEAD	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	16	HZW5-24826-U01	PLATE, DWELL	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	17	HZY6-24827-U11	RING, SNAP	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	18	HZY6-24828-U11	GROMMET	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	19	HZW5-24831-U01	TERMINAL, CABLE (LOOSE PARTS)	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	20	HZW5-24832-U01	SPACER, CABLE CLAMP (LOOSE PARTS)	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	21	HZY6-24832-U91	CAP, BLANK	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	22	HZY6-24832-V11	CAP, POWER TRIM-TILT BLANK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	23	HZY6-24834-V11	PACKING, DUAL (LOOSE PARTS)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	24	HZY6-24835-U11	BAND, TY-RAP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	25	HZY6-35370-U11	SWITCH ASSY., POWER TRIM-TILT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	26	HZY6-35370-V11	SWITCH ASSY., POWER TRIM-TILT (PORT)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	27	HZY6-35370-V21	SWITCH ASSY., POWER TRIM-TILT (STAR)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	28	HZY6-35375-V90	CABLE ASSY., POWER TRIM-TILT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10	29	H797-38206-A01	FUSE, BLADE (3A)	2	2	2	LRA, UCRA, URA, XCRA, XRA

FOP-3-10 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (NHK MEC)





Ref. No. FOP-3-10 30 FOP-3-10 31 FOP-3-10 32		Description COVER ASSY., FUSE (3A)	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-10 31		COVER ASSY FUSE (3A)		D	0D	
	HZY6-38580-V11	337217 713371. , 1 332 (377)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 32		RELAY ASSY., CONTROL	2	2	2	LRA, UCRA, URA, XCRA, XRA
	HZY6-38581-V11	HOLDER, RELAY	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 33	HZ2E-87117-000	LABEL, FUSE (3A)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 34	HZY6-87703-S11	MARK, REMOTE CONTROL (DUAL)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 35	HZW5-90101-U00	SCREW, PAN, 5X16	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 36	HZY6-90102-U11	SCREW, TRUSS, 5X10	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 37	HZY6-90103-U11	SCREW, TRUSS, 5X16 (TAPPING)	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 38	HZW5-90104-U00	SCREW, PAN, 5X18	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 39	HZY6-90104-U11	SCREW, PAN, 5X14 (TAPPING)	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 40	HZW5-90106-U00	SCREW, PAN, 6X18	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 41	HZY6-90106-U11	SCREW, PAN, 5X14(TAPPING)	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 42	HZW5-90107-U00	SCREW, PAN, 5X40 (LOOSE PARTS)	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 43	HZW5-90108-U00	SCREW, PAN, 5X55	3	3	3	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 44	HZY6-90111-U11	BOLT, STOPPER(F)	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 45	HZY6-90112-U11	BOLT, STOPPER (R)	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 46	HZW5-90301-U00	NUT, HEX., 5MM (LOOSE PARTS)	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 47	HZZ5-90301-D01	NUT, 6MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 48	HZW5-90302-U21	NUT, HEX., 5MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 49	HZW5-90501-U00	WASHER, LOCK, 5MM	6	6	6	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 50	HZW5-90502-U00	WASHER, LOCK, 6MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 51	HZW5-90503-U00	WASHER, PLAIN, 5MM (LOOSE PARTS)	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 52	HZZ5-90651-D01	E-RING, 6MM (LOOSE PARTS)	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 53	HZZ5-90651-D01	E-RING, 6MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 54	HSR3-91531-003	HOLDER, COUPLER (NATURAL) (128.6MM)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 55	HZY6-91541-V11	CLIP, HARNESS BAND	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 56	HZY6-06241-V10	SPACER KIT, REMOTE CONTROL BOX (TOP MOUNT DUAL)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 57	HZV4-90502-000	WASHER, PLAIN, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-3-10 58	HCO-93500-05065-4J	SCREW, PAN, 5X65	4	4	4	LRA, UCRA, URA, XCRA, XRA


FOP-3-10 REMOTE CONTROL (TOP MOUNT DUAL TYPE) (NHK MEC)



				Q' ty		
Ref. No.	Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-3-10 59	HCO-94001-05490-0S	NUT, HEX., 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA









					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
FOP-4	1	3PU-72571-3	TRIM METER ASSY	1	1	1	White
FOP-4	1	3PV-72571-3	TRIM METER ASSY	1	1	1	Black
F0P-4	2	3PU-72637-2	TACHOMETER HOUR METER	1	1	1	White
F0P-4	2	3PV-72637-2	TACHOMETER HOUR METER	1	1	1	Black
F0P-4	3	3PU-72537-0	METER LEAD WIRE	1	1	1	

FOP-5 SWITCH PANEL KIT (1) (MECH)




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-5	1	HZY6-06323-R01	PANEL KIT, SWITCH(SINGLE)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5	2	HZY6-32340-R01	PANEL ASSY., CONTROL (SINGLE)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5	3	HZY6-32346-R01	PANEL, CONTROL (SINGLE)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5	5	HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	1	1	1	(GREEN) LRA, UCRA, URA, XCRA, XRA
F0P-5	6	HZV5-32823-003	PLUG, INNER CONNECTOR	9	9	9	LRA, UCRA, URA, XCRA, XRA
F0P-5	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	7	7	7	LRA, UCRA, URA, XCRA, XRA
F0P-5	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5	9	HZY6-36180-003	SWITCH ASSY., EMERGENCY STOP	1	1	1	(SINGLE) Lra, Ucra, Ura, XCra, Xra
FOP-5	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	1	LRA, UCRA, URA, XCRA, XRA
FOP-5	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5	13	HZY9-38410-A01	BUZZER COMP., WARNING	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5	14	HZY6-38414-003	BRACKET	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5	16	HZZ5-90301-M01	NUT, FLANGE, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5	17	HZY6-90302-003	NUT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5	19	HZZ5-90502-M01	WASHER, SPRING, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
-							

FOP-5-1 SWITCH PANEL KIT (2) (MECH)




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-5-1	1	HZY6-06323-R11	PANEL KIT, SWITCH(TWIN)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	2	HZY6-32340-R11	PANEL ASSY., CONTROL (TWIN)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	3	HZY6-32346-R11	PANEL, CONTROL (TWIN)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	5	HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	2	2	2	(GREEN) LRA, UCRA, URA, XCRA, XRA
F0P-5-1	6	HZV5-32823-003	PLUG, INNER CONNECTOR	18	18	18	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	14	14	14	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	9	HZY6-36180-712	SWITCH ASSY., EMERGENCY STOP	1	1	1	(TWIN) Lra, Ucra, Ura, XCra, Xra
F0P-5-1	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	13	HZY9-38410-A01	BUZZER COMP., WARNING	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	14	HZY6-38414-003	BRACKET	2	2	2	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	16	HZZ5-90301-M01	NUT, FLANGE, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	17	HZY6-90302-003	NUT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5-1	19	HZZ5-90502-M01	WASHER, SPRING, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
			·				

FOP-5-2 SWITCH PANEL KIT (3) (MECH)




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-5-2	1	HZY6-06323-R21	PANEL KIT, SWITCH(TRIPLE)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	2	HZY6-32340-R21	PANEL ASSY., CONTROL (TRIPLE)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	3	HZY6-32346-R21	PANEL, CONTROL (TRIPLE)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	4	HZY6-32545-003	HARNESS ASSY., SWITCH PANEL	3	3	3	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	5	HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR	3	3	3	(GREEN) LRA, UCRA, URA, XCRA, XRA
F0P-5-2	6	HZV5-32823-003	PLUG, INNER CONNECTOR	27	27	27	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	7	HZV5-32824-003	PLUG, OUTER CONNECTOR	21	21	21	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	8	HZY6-35100-R01	SWITCH ASSY., COMBINATION	3	3	3	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	9	HZY6-36180-612	SWITCH ASSY., EMERGENCY STOP	1	1	1	(TRIPLE) LRA, UCRA, URA, XCRA, XRA
F0P-5-2	10	HZY6-36182-003	CORD COMP., EMERGENCY	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	11	HZY6-36187-003	CLIP, EMERGENCY LOCK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	12	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT	3	3	3	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	13	HZY9-38410-A01	BUZZER COMP., WARNING	3	3	3	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	14	HZY6-38414-003	BRACKET	3	3	3	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	15	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	16	HZZ5-90301-M01	NUT, FLANGE, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	17	HZY6-90302-003	NUT	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	18	HZZ5-90501-M01	WASHER, PLAIN, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5-2	19	HZZ5-90502-M01	WASHER, SPRING, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA

FOP-5-3 SWITCH PANEL KIT (4) (MECH)




					Q'ty	:y	
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-5-3	1	HZZ3-06323-R24	PANEL KIT, SWITCH(B) (4-LED)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	2	HZZ5-06352-M01	SWITCH KIT, LIGHT	1			LRA
F0P-5-3	3	HZZ3-32341-R32	PANEL ASSY., SWITCH	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	4	HZZ3-32346-R22	PANEL, CONTROL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	5	HZZ3-32347-R02	PANEL, CONTROL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	6	HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	7	HZV5-32823-003	PLUG, INNER CONNECTOR	8	8	8	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	8	HZV5-32824-003	PLUG, OUTER CONNECTOR	3	3	3	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	9	HZZ3-35100-R12	SWITCH ASSY., COMBINATION	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	10	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	11	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	12	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	13	HZZ3-37205-R03	PANEL ASSY., INDICATOR (4-LED)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	14	HZZ5-37210-763	LAMP ASSY., INDICATION (4-LED)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	15	H341-38403-672	PLATE, WINKER BUZZER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	16	HZV5-38410-003	BUZZER COMP., WARNING	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	17	HZZ5-38414-003	BRACKET, BUZZER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	18	HZW5-90109-000	SCREW, PAN, 5X40	12			LRA
F0P-5-3	18	HZW5-90109-000	SCREW, PAN, 5X40	8			XCRA, XRA
F0P-5-3	18	HZW5-90109-000	SCREW, PAN, 5X40		8	8	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	19	HZZ5-90301-M01	NUT, FLANGE, 5MM	12			LRA
F0P-5-3	19	HZZ5-90301-M01	NUT, FLANGE, 5MM	8			XCRA, XRA
F0P-5-3	19	HZZ5-90301-M01	NUT, FLANGE, 5MM		8	8	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	20	H921-90302-000	NUT, HEX., 16MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	21	HZZ5-90501-M01	WASHER, PLAIN, 5MM	12			LRA
F0P-5-3	21	HZZ5-90501-M01	WASHER, PLAIN, 5MM	8			XCRA, XRA
F0P-5-3	21	HZZ5-90501-M01	WASHER, PLAIN, 5MM		8	8	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	22	HZZ5-90502-M01	WASHER, SPRING, 5MM	12			LRA
F0P-5-3	22	HZZ5-90502-M01	WASHER, SPRING, 5MM	8			XCRA, XRA

FOP-5-3 SWITCH PANEL KIT (4) (MECH)




					Q'ty	,	
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-5-3	22	HZZ5-90502-M01	WASHER, SPRING, 5MM		8	8	LRA, UCRA, URA, XCRA, XRA
F0P-5-3	23	HSC2-90649-003	BAND, WIRE HARNESS (NATURAL)	1	1	1	(150MM) LRA, UCRA, URA, XCRA, XRA
-							
					1		




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-5-4	1	HZZ3-06323-R34	PANEL KIT, SWITCH(4-LED)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	2	HZZ3-32346-R32	PANEL, CONTROL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	3	HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	4	HZV5-32823-003	PLUG, INNER CONNECTOR	8	8	8	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	5	HZV5-32824-003	PLUG, OUTER CONNECTOR	3	3	3	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	6	HZZ3-35100-R12	SWITCH ASSY., COMBINATION	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	7	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	8	HZV4-36182-651	CORD COMP., EMERGENCY	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	9	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	10	HZZ5-37210-713	LAMP ASSY., INDICATION (4-LED)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	11	H341-38403-672	PLATE, WINKER BUZZER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	12	HZV5-38410-003	BUZZER COMP., WARNING	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	13	HZZ5-38414-003	BRACKET, BUZZER	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	14	HZW5-90109-000	SCREW, PAN, 5X40	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	15	HZZ5-90301-M01	NUT, FLANGE, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	16	H921-90302-000	NUT, HEX., 16MM	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	17	HZZ5-90501-M01	WASHER, PLAIN, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	18	HZZ5-90502-M01	WASHER, SPRING, 5MM	4	4	4	LRA, UCRA, URA, XCRA, XRA
F0P-5-4	19	HSC2-90649-003	BAND, WIRE HARNESS (NATURAL)	1	1	1	(150MM) LRA, UCRA, URA, XCRA, XRA
-							
-							
	•			•			


FOP-5-5 SWITCH PANEL KIT (6) (DBW)



					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-5-5	1	HZVL-06323-P01	PANEL KIT, KEY SWITCH(SINGLE) (START)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	1	HZVL-06323-P21	PANEL KIT, KEY SWITCH			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	2	HZVL-06323-P11	PANEL KIT, KEY SWITCH(SINGLE) (START)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	2	HZVL-06323-P31	PANEL KIT, KEY SWITCH			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	3	HZVL-32380-P01	PANEL ASSY., KEY SWITCH(START)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	3	HZVL-32380-P21	PANEL ASSY., KEY SWITCH			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	4	HZVL-32380-P11	PANEL ASSY., KEY SWITCH(START)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	4	HZVL-32380-P31	PANEL ASSY., KEY SWITCH			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	5	HZVL-32386-P01	PANEL, KEY SWITCH(START)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	5	HZVL-32386-P21	PANEL, KEY SWITCH			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	6	HZVL-32386-P11	PANEL, KEY SWITCH(START)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	6	HZVL-32386-P31	PANEL, KEY SWITCH			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	7	HZVL-35100-P01	SWITCH ASSY., COMBINATION (START)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	7	HZVL-35100-P11	SWITCH ASSY., COMBINATION			1	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	8	HZVL-36180-003	SWITCH ASSY., EMERGENCY STOP			2	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	9	HZY6-36182-003	CORD COMP., EMERGENCY			2	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	10	HZY6-36187-003	CLIP, EMERGENCY LOCK			2	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	11	HGC1-38402-000	SUSPENSION, AUDIBLE PILOT			2	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	12	HZY9-38410-A01	BUZZER COMP., WARNING			2	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	13	HZW5-90109-000	SCREW, PAN, 5X40			8	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	14	HZZ5-90301-M01	NUT, FLANGE, 5MM			8	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	15	HZY6-90302-003	NUT			2	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	16	HZZ5-90501-M01	WASHER, PLAIN, 5MM			8	LDA, UCDA, UDA, XCDA, XDA
F0P-5-5	17	HZZ5-90502-M01	WASHER, SPRING, 5MM			8	LDA, UCDA, UDA, XCDA, XDA


FOP-6 SWITCH PANEL KIT (POWER TILT)






					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
FOP-6	1	HZVL-06325-P01	PANEL KIT, POWER TRIM-TILT SWITCH (TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
FOP-6	2	HZVL-06325-P11	PANEL KIT, POWER TRIM-TILT SWITCH (TRIPLE)			1	LDA, UCDA, UDA, XCDA, XDA
FOP-6	3	HZVL-32320-P01	PANEL ASSY., POWER TRIM-TILT SWITCH (TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
FOP-6	4	HZVL-32320-P11	PANEL ASSY., POWER TRIM-TILT SWITCH (TRIPLE)			1	LDA, UCDA, UDA, XCDA, XDA
FOP-6	5	HZVL-32326-P01	PANEL, POWER TRIM-TILT SWITCH (TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
FOP-6	6	HZVL-32326-P11	PANEL, POWER TRIM-TILT SWITCH (TRIPLE)			1	LDA, UCDA, UDA, XCDA, XDA
FOP-6	7	HZVL-35640-003	SWITCH ASSY., POWER TILT			5	LDA, UCDA, UDA, XCDA, XDA
FOP-6	8	HZW5-90109-000	SCREW, PAN, 5X40			8	LDA, UCDA, UDA, XCDA, XDA
FOP-6	9	HZZ5-90301-M01	NUT, FLANGE, 5MM			8	LDA, UCDA, UDA, XCDA, XDA
FOP-6	10	HZZ5-90501-M01	WASHER, PLAIN, 5MM			8	LDA, UCDA, UDA, XCDA, XDA
FOP-6	11	HZZ5-90502-M01	WASHER, SPRING, 5MM			8	LDA, UCDA, UDA, XCDA, XDA
-							
-	1	i	1				<u> </u>

FOP-6-1 SWITCH PANEL KIT (START STOP)




				1	Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-6-1	1	HZVL-06324-P01	PANEL KIT, START STOP SWITCH (ALL)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	2	HZVL-06324-P11	PANEL KIT, START STOP SWITCH (TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	3	HZVL-06324-P21	PANEL KIT, START STOP SWITCH (TRIPLE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	4	HZVL-32340-P01	PANEL ASSY., START STOP (ALL)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	5	HZVL-32340-P11	PANEL ASSY., START STOP (TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	6	HZVL-32340-P21	PANEL ASSY., START STOP (TRIPLE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	7	HZVL-32344-P11	PANEL COMP., START STOP (TWIN)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	8	HZVL-32344-P21	PANEL COMP., START STOP (TRIPLE)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	9	HZVL-32346-P01	PANEL, START STOP (ALL)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	10	HZW5-90109-000	SCREW, PAN, 5X40			12	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	11	HZZ5-90301-M01	NUT, FLANGE, 5MM			12	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	12	HZZ5-90501-M01	WASHER, PLAIN, 5MM			12	LDA, UCDA, UDA, XCDA, XDA
F0P-6-1	13	HZZ5-90502-M01	WASHER, SPRING, 5MM			12	LDA, UCDA, UDA, XCDA, XDA

FOP-6-2 SWITCH PANEL KIT (FUNCTION)




Ref. No. Part No. Description Page 50 Page 50	
FOP-6-2 2 HZVL-32351-PO1 PANEL ASSY., FUNCTION SWITCH 1 LDA, UCDA, UDA, XCDA, XDA FOP-6-2 3 HZVL-32354-PO1 PANEL COMP., FUNCTION SWITCH 1 LDA, UCDA, UDA, XCDA, XDA FOP-6-2 4 HZVL-32357-003 SUB HARNESS ASSY., FUNCTION SWITCH 1 LDA, UCDA, UDA, XCDA, XDA FOP-6-2 5 HZW5-90109-000 SCREW, PAN, 5X40 4 LDA, UCDA, UDA, XCDA, XDA FOP-6-2 6 HZZ5-90301-M01 NUT, FLANGE, 5MM 4 LDA, UCDA, UDA, XCDA, XDA FOP-6-2 7 HZZ5-90501-M01 WASHER, PLAIN, 5MM 4 LDA, UCDA, UDA, XCDA, XDA	
F0P-6-2 3 HZVL-32354-P01 PANEL COMP., FUNCTION SWITCH 1 LDA, UCDA, UDA, XCDA, XDA F0P-6-2 4 HZVL-32357-003 SUB HARNESS ASSY., FUNCTION SWITCH 1 LDA, UCDA, UDA, XCDA, XDA F0P-6-2 5 HZW5-90109-000 SCREW, PAN, 5X40 4 LDA, UCDA, UDA, XCDA, XDA F0P-6-2 6 HZZ5-90301-M01 NUT, FLANGE, 5MM 4 LDA, UCDA, UDA, XCDA, XDA F0P-6-2 7 HZZ5-90501-M01 WASHER, PLAIN, 5MM 4 LDA, UCDA, UDA, XCDA, XDA	
FOP-6-2 4 HZVL-32357-003 SUB HARNESS ASSY., FUNCTION SWITCH 1 LDA, UCDA, UDA, XCDA, XDA FOP-6-2 5 HZW5-90109-000 SCREW, PAN, 5X40 4 LDA, UCDA, UDA, XCDA, XDA FOP-6-2 6 HZZ5-90301-M01 NUT, FLANGE, 5MM 4 LDA, UCDA, UDA, XCDA, XDA FOP-6-2 7 HZZ5-90501-M01 WASHER, PLAIN, 5MM 4 LDA, UCDA, UDA, XCDA, XDA	
F0P-6-2 5 HZW5-90109-000 SCREW, PAN, 5X40 4 LDA, UCDA, UDA, XCDA, XDA F0P-6-2 6 HZZ5-90301-M01 NUT, FLANGE, 5MM 4 LDA, UCDA, UDA, XCDA, XDA F0P-6-2 7 HZZ5-90501-M01 WASHER, PLAIN, 5MM 4 LDA, UCDA, UDA, XCDA, XDA	
FOP-6-2 6 HZZ5-90301-M01 NUT, FLANGE, 5MM 4 LDA, UCDA, UDA, XCDA, XDA FOP-6-2 7 HZZ5-90501-M01 WASHER, PLAIN, 5MM 4 LDA, UCDA, UDA, XCDA, XDA	
FOP-6-2 7 HZZ5-90501-M01 WASHER, PLAIN, 5MM 4 LDA, UCDA, UDA, XCDA, XDA	
F0P-6-2 8 HZZ5-90502-M01 WASHER, SPRING, 5MM 4 LDA, UCDA, UDA, XCDA, XDA	


FOP-7 INTERFACE CABLE KIT




					Q' ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-7	1	HZVL-06328-601	CABLE KIT, INTERFACE (10FT)	1	1	1	
F0P-7	1	HZVL-06328-701	CABLE KIT, INTERFACE (16FT)	1	1	1	
F0P-7	1	HZZ3-06328-764	KIT, CABLE (NMEA) (6FT)	1	1	1	
F0P-7	2	HZVL-32800-600	CABLE ASSY., INTERFACE(10FT)	1	1	1	
F0P-7	2	HZVL-32800-700	CABLE ASSY., INTERFACE(16FT)	1	1	1	
F0P-7	2	HZZ3-32800-000	CABLE ASSY., INTERFACE(6FT)	1	1	1	
F0P-7	3	HZZ3-32805-000	CONNECTOR (T)	1	1	1	
F0P-7	4	HZY1-90650-003	TIE, CABLE	2	2	2	
F0P-7	5	HSTK-91540-003	CLIP, HARNESS BAND(BLACK) (155.3MM)	2	2	2	(155. 3MM)
F0P-7	6	HCO-93901-446J0	SCREW, TAPPING, 4X25	2	2	2	



				Q'ty			
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-10	1	HZVL-06328-800	CONNECTOR KIT, TERMINATOR	1	1	1	
F0P-10	2	HZVL-32580-900	CABLE ASSY., PANEL INDICATOR	1	1	1	(20FT) LRA, UCRA, URA, XCRA, XRA
F0P-10	2	HZVL-32580-910	CABLE ASSY., PANEL INDICATOR	1	1	1	(25FT) LRA, UCRA, URA, XCRA, XRA
F0P-10	2	HZVL-32580-920	CABLE ASSY., PANEL INDICATOR	1	1	1	(30FT) LRA, UCRA, URA, XCRA, XRA
F0P-10	3	HZVL-32806-000	TERMINATOR (M)	1	1	1	
F0P-10	4	HZVL-32807-000	TERMINATOR (F)	1	1	1	
F0P-10	5	HZVL-32590-901	CABLE ASSY., CONVERSION (6FT)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-10	5	HZVL-32590-911	CABLE ASSY., CONVERSION (10FT)	1	1	1	LRA, UCRA, URA, XCRA, XRA
F0P-10	6	HZVL-31576-000	CORD ASSY., EXTENSION POWER	1	1	1	
F0P-10	7	HZVL-32540-600	CABLE ASSY., BRANCH			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	8	HZVL-32580-600	CABLE ASSY., TRUNK (DBW) (18FT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	8	HZVL-32580-700	CABLE ASSY., TRUNK (DBW) (24FT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	8	HZVL-32580-800	CABLE ASSY., TRUNK (DBW) (30FT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	9	HZVL-32590-810	CABLE ASSY., ENGINE DROP (SINGLE 16FT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	9	HZVL-32590-820	CABLE ASSY., ENGINE DROP (SINGLE 20FT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	9	HZVL-32590-830	CABLE ASSY., ENGINE DROP (SINGLE 25FT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	9	HZVL-32590-840	CABLE ASSY., ENGINE DROP (SINGLE 30FT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	10	HZVL-32590-600	CABLE ASSY., ENGINE DROP(6FT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	10	HZVL-32590-700	CABLE ASSY., ENGINE DROP(10FT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	10	HZVL-32590-800	CABLE ASSY., ENGINE DROP(14FT)			1	LDA, UCDA, UDA, XCDA, XDA
F0P-10	11	HZVL-32815-000	CABLE ASSY., NETWORK (6FT)			1	
F0P-10	11	HZVL-32815-600	CABLE ASSY., NETWORK (16FT)			1	
F0P-10	11	HZVL-32815-700	CABLE ASSY., NETWORK (32FT)			1	
F0P-10	11	HZVL-32815-800	CABLE ASSY., NETWORK (49FT)			1	




For No. Part No. Description						Q' ty		
FOP-15	Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
FOP-15 1 HZX2-58130-T21 PROPELLER COMP. THREE BLADES 1 1 1 LDA. LRA. UDA, URA. XDA, XRA	F0P-15	1	HZX2-58130-T01	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15 1 HZX2-58130-T31 PROPELLER COMP., THREE BLADES 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA FOP-15 1 HZX2-58130-T31 PROPELLER COMP., THREE BLADES 1 1 1 1 (14-3/4X23) FOP-15 1 HZX2-58130-T41 PROPELLER COMP., THREE BLADES 1 1 1 1 (14-1/2X25) LDA, LRA, UDA, URA, XDA, XRA FOP-15 1 HZX2-58130-T51 PROPELLER COMP., THREE BLADES 1 1 1 1 (14-1/2X25) LDA, LRA, UDA, URA, XDA, XRA FOP-15 1 HZX2-58130-T61 PROPELLER COMP., THREE BLADES 1 1 1 1 (14-1/2X27) LDA, LRA, UDA, URA, XDA, XRA FOP-15 1 HZX2-58180-T01 PROPELLER COMP., THREE BLADES 1 1 1 1 (15-3/4X15) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T11 PROPELLER COMP., THREE BLADES 1 1 1 1 (15-1/4X19) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T21 PROPELLER COMP., THREE BLADES 1 1 1 1 (15-1/4X19) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T31 PROPELLER COMP., THREE BLADES 1 1 1 1 (15-1/4X19) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T31 PROPELLER COMP., THREE BLADES 1 1 1 1 (15-1/4X19) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T31 PROPELLER COMP., THREE BLADES 1 1 1 1 (14-3/4X23) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T51 PROPELLER COMP., THREE BLADES 1 1 1 1 (14-3/4X23) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T51 PROPELLER COMP., THREE BLADES 1 1 1 1 (14-1/2X27) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T51 PROPELLER COMP., THREE BLADES 1 1 1 1 (14-1/2X27) (C/R) UCDA, UCRA, XCDA, XCRA	F0P-15	1	HZX2-58130-T11	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15	F0P-15	1	HZX2-58130-T21	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15 1 HZX2-58130-T51 PROPELLER COMP. THREE BLADES 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA FOP-15 1 HZX2-58130-T51 PROPELLER COMP. THREE BLADES 1 1 1 1 (14-1/2X25) LDA, LRA, UDA, URA, XDA, XRA FOP-15 1 HZX2-58130-T61 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-3/4X15) (G/R) FOP-15 1 HZX2-58180-T01 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/2X17) (G/R) FOP-15 1 HZX2-58180-T11 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/2X17) (G/R) FOP-15 1 HZX2-58180-T21 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/2X17) (G/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T31 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/4X19) (G/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T31 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/4X2) (G/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T41 PROPELLER COMP. THREE BLADES 1 1 1 1 (14-3/4X23) (G/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T51 PROPELLER COMP. THREE BLADES 1 1 1 1 (14-1/2X25) (G/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T51 PROPELLER COMP. THREE BLADES 1 1 1 1 (14-1/2X25) (G/R) UCDA, UCRA, XCDA, XCRA	F0P-15	1	HZX2-58130-T31	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15 1 HZX2-58180-T01 PROPELLER COMP. THREE BLADES 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA FOP-15 1 HZX2-58180-T01 PROPELLER COMP. THREE BLADES 1 1 1 1 (14-1/2X27) LDA, LRA, UDA, URA, XDA, XRA FOP-15 1 HZX2-58180-T01 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-3/4X15) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T11 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/2X17) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T21 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/4X19) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T31 PROPELLER COMP. THREE BLADES 1 1 1 1 (15X21) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T41 PROPELLER COMP. THREE BLADES 1 1 1 (14-3/4X23) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T51 PROPELLER COMP. THREE BLADES 1 1 1 (14-1/2X25) (C/R) UCDA, UCRA, XCDA, XCRA	F0P-15	1	HZX2-58130-T41	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15 1 HZX2-58180-T01 PROPELLER COMP. THREE BLADES 1 1 1 1 LDA, LRA, UDA, URA, XDA, XRA FOP-15 1 HZX2-58180-T01 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-3/4X15) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T11 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/2X17) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T21 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/4X19) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T31 PROPELLER COMP. THREE BLADES 1 1 1 1 (15X21) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T41 PROPELLER COMP. THREE BLADES 1 1 1 1 (14-3/4X23) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T51 PROPELLER COMP. THREE BLADES 1 1 1 1 (14-1/2X25) (C/R) UCDA, UCRA, XCDA, XCRA	F0P-15	1	HZX2-58130-T51	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15 1 HZX2-58180-T11 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/2X17) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T21 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/4X19) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T31 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/4X19) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T31 PROPELLER COMP. THREE BLADES 1 1 1 1 (15X21) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T41 PROPELLER COMP. THREE BLADES 1 1 1 1 (14-3/4X23) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T51 PROPELLER COMP. THREE BLADES 1 1 1 (14-1/2X25) (C/R) UCDA, UCRA, XCDA, XCRA	F0P-15	1	HZX2-58130-T61	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15 1 HZX2-58180-T21 PROPELLER COMP. THREE BLADES 1 1 1 1 UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T21 PROPELLER COMP. THREE BLADES 1 1 1 1 (15-1/4X19) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T31 PROPELLER COMP. THREE BLADES 1 1 1 1 (15X21) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T41 PROPELLER COMP. THREE BLADES 1 1 1 1 (14-3/4X23) (C/R) UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T51 PROPELLER COMP. THREE BLADES 1 1 1 1 (14-1/2X25) (C/R) UCDA, UCRA, XCDA, XCRA	F0P-15	1	HZX2-58180-T01	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15	F0P-15	1	HZX2-58180-T11	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15	F0P-15	1	HZX2-58180-T21	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15 1 HZX2-58180-141 PROPELLER COMP. THREE BLADES 1 1 UCDA, UCRA, XCDA, XCRA FOP-15 1 HZX2-58180-T51 PROPELLER COMP. THREE BLADES 1 1 (14-1/2X25) (C/R) UCDA, UCRA, XCDA, XCRA FOR-15 1 HZX2-58180-T61 PROPELLER COMP. THREE BLADES 1 1 (14-1/2X27) (C/R)	F0P-15	1	HZX2-58180-T31	PROPELLER COMP., THREE BLADES	1	1	1	
FOP-15 1 H2AZ-98180-151 PROPELLER COMP. THREE BLADES 1 UCDA, UCRA, XCDA, XCRA	F0P-15	1	HZX2-58180-T41	PROPELLER COMP., THREE BLADES	1	1	1	(14-3/4X23) (G/R) UCDA, UCRA, XCDA, XCRA
FOP-15 1 HZX2-58180-T61 PROPELLER COMP THREE BLADES 1 1 1 1 (14-1/2X27) (C/R) UCDA, UGRA, XCDA, XCRA	F0P-15	1	HZX2-58180-T51	PROPELLER COMP., THREE BLADES	1	1	1	
	F0P-15	1	HZX2-58180-T61	PROPELLER COMP., THREE BLADES	1	1	1	(14-1/2X27) (C/R) UCDA, UCRA, XCDA, XCRA




-				Q' ty			
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-17	1	HZX2-06125-C01	CASE KIT, GEAR	1	1	1	
F0P-17	2	HZW1-90758-B00	PIN, SPLIT, 4.0	1	1	1	
F0P-17	3	HZY3-91251-C01	SEAL, WATER, 26X42X7	2	2	2	
F0P-17	4	HZZ3-91252-003	SEAL, WATER, 30X45X7	2	2	2	
F0P-17	5	HZY3-91254-003	SEAL, WATER, 12X21X6	2	2	2	
F0P-17	6	HZW4-91301-003	0-RING, 6.9X1.45	2	2	2	
F0P-17	7	HMJ0-91308-003	O-RING	1	1	1	
F0P-17	8	HZX2-91351-C00	0-RING, 121X3.1	1	1	1	
		·					


FOP-18 MAINTENANCE KIT (200)



					Q'ty		
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-18	1	HZVL-06160-010	STRAINER ASSY., FUEL (HIGH)	1	1	1	
F0P-18	2	HZW1-06411-020	METAL KIT, ANODE	1	1	1	
F0P-18	3	HZVL-06510-010	MAINTENANCE KIT (200)	1	1	1	
F0P-18	4	HRTA-15400-003	CARTRIDGE, OIL FILTER (MAHLE TENNEX)	1	1	1	
F0P-18	5	HZY3-19210-003	IMPELLER, PUMP	1	1	1	
F0P-18	6	HZY3-19223-000	LINER, PUMP	1	1	1	
F0P-18	7	HZY3-19231-000	COVER, IMPELLER	1	1	1	
F0P-18	8	HZX2-19234-C00	GASKET B, IMPELLER	1	1	1	
F0P-18	9	HZY3-19253-000	RING, WATER TUBE SEAL	1	1	1	
F0P-18	10	HZX2-19300-003	THERMOSTAT ASSY.	2	2	2	
F0P-18	11	HZW1-41109-B00	METAL COMP., ANODE	2	2	2	
F0P-18	12	HZW9-90101-003	BOLT, OIL CHECK	1	1	1	
F0P-18	13	HZY3-90120-000	BOLT, DRAIN PLUG	1	1	1	
F0P-18	14	HZY1-90205-000	NUT, SELF-LOCK, 6MM	1	1	1	
F0P-18	15	HZE2-90601-000	WASHER, DRAIN PLUG, 12MM	1	1	1	
F0P-18	16	HZY3-90752-003	KEY, WOODRUFF	1	1	1	
F0P-18	17	HZVL-90756-000	DOWEL PIN, 6X10	2	2	2	
F0P-18	18	HZW1-90758-B00	PIN, SPLIT, 4.0	1	1	1	
F0P-18	19	HZW4-91301-003	0-RING, 6.9X1.45	2	2	2	
F0P-18	20	HZY3-91356-003	O-RING, WATER PUMP	1	1	1	
F0P-18	21	HCO-92101-06055-4J	BOLT, HEX., 6X55	1	1	1	



				Q'ty			
Ref. No.		Part No.	Description	BFT200D	BFT225D	BFT250D	Remarks
F0P-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)	1			~6011098 LRA, XRA
F0P-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)	1			~7011019 XCRA
F0P-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)		1		~6011067 LRA, XRA
F0P-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)		1		~7011015 XCRA
F0P-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)			1	~6011240 LDA, LRA, UDA, URA, XDA, XRA
F0P-18-1	1	HZVL-06161-000	MAINTENANCE KIT (400)			1	~7011069 UCDA, UCRA, XCDA, XCRA
F0P-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)	1			6011099~ LRA, XRA
F0P-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)	1			7011020~ XCRA
F0P-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)		1		6011068~ LRA, XRA
F0P-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)		1		7011016~ XCRA
F0P-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)			1	6011241~ LDA, LRA, UDA, URA, XDA, XRA
F0P-18-1	1	HZVL-06161-010	MAINTENANCE KIT (400)			1	7011070~ UCDA, UCRA, XCDA, XCRA
F0P-18-1	2	HZV5-12155-000	METAL, ANODE	4			~6011098 LRA, XRA
F0P-18-1	2	HZV5-12155-000	METAL, ANODE	4			~7011019 XCRA
F0P-18-1	2	HZV5-12155-000	METAL, ANODE		4		~6011067 LRA, XRA
F0P-18-1	2	HZV5-12155-000	METAL, ANODE		4		~7011015 XCRA
F0P-18-1	2	HZV5-12155-000	METAL, ANODE			4	~6011240 LDA, LRA, UDA, URA, XDA, XRA
F0P-18-1	2	HZV5-12155-000	METAL, ANODE			4	~7011069 UCDA, UCRA, XCDA, XCRA
F0P-18-1	2	HZV5-12155-010	METAL, ANODE	4			6011099~ LRA, XRA
F0P-18-1	2	HZV5-12155-010	METAL, ANODE	4			7011020~ XCRA
F0P-18-1	2	HZV5-12155-010	METAL, ANODE		4		6011068~ LRA, XRA
F0P-18-1	2	HZV5-12155-010	METAL, ANODE		4		7011016~ XCRA
F0P-18-1	2	HZV5-12155-010	METAL, ANODE			4	6011241~ LDA, LRA, UDA, URA, XDA, XRA
F0P-18-1	2	HZV5-12155-010	METAL, ANODE			4	7011070~ UCDA, UCRA, XCDA, XCRA
F0P-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM	6			∼6011098 LRA, XRA
F0P-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM	6			~7011019 XCRA
F0P-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM		6		~6011067 LRA, XRA
F0P-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM		6		~7011015 XCRA
F0P-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM			6	∼6011240 LDA, LRA, UDA, URA, XDA, XRA



Ref. No. Part No. Description Section Section Remarks Repairs Remarks Repairs Remarks Repairs Remarks Repairs Remarks Ref. R	0' ty							
FOP-18-1 3 H2Y3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11020~ FOP-18-1 3 H2Y3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11020~ FOP-18-1 3 H2Y3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11020~ XCRA FOP-18-1 3 H2Y3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11068~ LRA, XRA FOP-18-1 3 H2Y3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11068~ LRA, XRA FOP-18-1 3 H2Y3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11241~ LDA, LRA, UDA, URA, XDA, XRA FOP-18-1 3 H2Y3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11241~ LDA, LRA, UDA, URA, XDA, XRA FOP-18-1 4 H2Y3-12171-305 WASHER, SEALING, 22MM 6 GO11070~ UCDA, UCRA, XCDA, XCRA FOP-18-1 5 H2Y3-16901-003 STRAINER, FUEL 1 1 1 FOP-18-1 6 H2Y3-16918-003 O-RING 1 1 1 FOP-18-1 7 H2Y3-18115-003 GASKET, R. EX. MANIFOLD 1 1 1 1 FOP-18-1 8 H2Y3-18125-003 GASKET, L. EX. MANIFOLD 1 1 1 1	Ref. No.		Part No.	Description	BFT200D			Remarks
FOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 7011020~ XCRA FOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11068~ LRA, XRA FOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11068~ LRA, XRA FOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11068~ XCRA FOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11241~ LOA, LRA, UDA, URA, XDA, XRA FOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 GO11241~ LOA, LRA, UDA, URA, XDA, XRA FOP-18-1 4 HZY3-12171-305 WASHER, SEALING, 22MM 6 GO11070~ UCDA, UCRA, XCDA, XCRA FOP-18-1 5 HZY3-16901-003 STRAINER, FUEL 1 1 1 1 FOP-18-1 6 HZY3-16918-003 O-RING 1 1 1 1 FOP-18-1 7 HZY3-18115-003 GASKET, R. EX. MANIFOLD 1 1 1 1 FOP-18-1 8 HZY3-18125-003 GASKET, L. EX. MANIFOLD 1 1 1 1	F0P-18-1	3	HZY3-12160-000	BOLT ASSY., SEALING, 22MM			6	
FOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 6 6011068~ EVALUATION FOR THE PROPERTY OF THE PROPERTY	F0P-18-1	3	HZY3-12160-010	BOLT ASSY., SEALING, 22MM	6			
FOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 7011016~ XCRA FOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 6 6011241~ EOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 6 6011241~ EOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 6 7011070~ UCDA, UCRA, XCDA, XCRA FOP-18-1 4 HZY3-12171-305 WASHER, SEALING, 22MM 6 6 6 6 FOP-18-1 5 HZY3-16901-003 STRAINER, FUEL 1 1 1 1 FOP-18-1 6 HZY3-16918-003 O-RING 1 1 1 1 FOP-18-1 7 HZY3-18115-003 GASKET, R. EX. MANIFOLD 1 1 1 1 FOP-18-1 8 HZY3-18125-003 GASKET, L. EX. MANIFOLD 1 1 1 1	F0P-18-1	3	HZY3-12160-010	BOLT ASSY., SEALING, 22MM	6			
FOP-18-1 3 H2Y3-12160-010 BOLT ASSY., SEALING, 22MM 6 6 6011241~ EOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 6 6011241~ EOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 6 7011070~ UCDA, UCRA, XCDA, XCRA FOP-18-1 4 HZY3-12171-305 WASHER, SEALING, 22MM 6 6 6 6 FOP-18-1 5 HZY3-16901-003 STRAINER, FUEL 1 1 1 FOP-18-1 6 HZY3-16918-003 O-RING 1 1 1 FOP-18-1 7 HZY3-18115-003 GASKET, R. EX. MANIFOLD 1 1 1 FOP-18-1 8 HZY3-18125-003 GASKET, L. EX. MANIFOLD 1 1 1 1	F0P-18-1	3	HZY3-12160-010	BOLT ASSY., SEALING, 22MM		6		
FOP-18-1 3 HZY3-12160-010 BOLT ASSY., SEALING, 22MM 6 7011070~ UCDA, UCRA, XCDA, XCRA FOP-18-1 4 HZY3-12171-305 WASHER, SEALING, 22MM 6 6 6 6 FOP-18-1 5 HZY3-16901-003 STRAINER, FUEL 1 1 1 FOP-18-1 6 HZY3-16918-003 O-RING 1 1 1 1 FOP-18-1 7 HZY3-18115-003 GASKET, R. EX. MANIFOLD 1 1 1 1 FOP-18-1 8 HZY3-18125-003 GASKET, L. EX. MANIFOLD 1 1 1 1	F0P-18-1	3	HZY3-12160-010	BOLT ASSY., SEALING, 22MM		6		
FOP-18-1 3 H2T3-12100-010 BOLT ASST. SEALING, 22MM 6 0 UCDA, UCRA, XCDA, XCRA FOP-18-1 4 HZY3-12171-305 WASHER, SEALING, 22MM 6 6 6 6 FOP-18-1 5 HZY3-16901-003 STRAINER, FUEL 1 1 1 1 FOP-18-1 6 HZY3-16918-003 O-RING 1 1 1 1 FOP-18-1 7 HZY3-18115-003 GASKET, R. EX. MANIFOLD 1 1 1 1 FOP-18-1 8 HZY3-18125-003 GASKET, L. EX. MANIFOLD 1 1 1 1	F0P-18-1	3	HZY3-12160-010	BOLT ASSY., SEALING, 22MM			6	
FOP-18-1 5 HZY3-16901-003 STRAINER, FUEL 1 1 1 1 FOP-18-1 6 HZY3-16918-003 O-RING 1 1 1 1 FOP-18-1 7 HZY3-18115-003 GASKET, R. EX. MANIFOLD 1 1 1 FOP-18-1 8 HZY3-18125-003 GASKET, L. EX. MANIFOLD 1 1 1	F0P-18-1	3	HZY3-12160-010	BOLT ASSY., SEALING, 22MM			6	
FOP-18-1 6 HZY3-16918-003 O-RING 1 1 1 1 FOP-18-1 7 HZY3-18115-003 GASKET, R. EX. MANIFOLD 1 1 1 1 FOP-18-1 8 HZY3-18125-003 GASKET, L. EX. MANIFOLD 1 1 1 1	F0P-18-1	4	HZY3-12171-305	WASHER, SEALING, 22MM	6	6	6	
FOP-18-1 7 HZY3-18115-003 GASKET, R. EX. MANIFOLD 1 1 1 1 FOP-18-1 8 HZY3-18125-003 GASKET, L. EX. MANIFOLD 1 1 1 1	F0P-18-1	5	HZY3-16901-003	STRAINER, FUEL	1	1	1	
FOP-18-1 8 HZY3-18125-003 GASKET, L. EX. MANIFOLD 1 1 1 1	F0P-18-1	6	HZY3-16918-003	O-RING	1	1	1	
	F0P-18-1	7	HZY3-18115-003	GASKET, R. EX. MANIFOLD	1	1	1	
FOP-18-1 9 HZY3-91301-003 O-RING, 66.4X3.1 2 2 2	F0P-18-1	8	HZY3-18125-003	GASKET, L. EX. MANIFOLD	1	1	1	
	F0P-18-1	9	HZY3-91301-003	0-RING, 66.4X3.1	2	2	2	

INDEX

332-70201-0	* CLAMP • • • • • • • F-6-8
307-70217-0	* CLAMP····· F-6-5
307-70220-1	* JOINT ASSY (INLET) · · · · · · · · · · · · · · · · · · ·
307-70224-1	* JOINT ASSY (OUTLET) · · · · · · · · · · · · · · · · · · ·
3FF-70200-4	PRIMER BULB ASSY · · · · · · · · · · · · · · · · · ·
3GF-70211-1	* PRIMER BULB · · · · · · · · · · · · · · · · · · ·
3GF-70240-1	* LOW PERMEATION HOSE L=1600 · · · · · · · · · · · · · · · · · ·
3GF-70241-1	* LOW PERMEATION HOSE L=700 · · · · · · · · · · · · · · · · · F-6-6
3PU-72537-0	METER LEAD WIRE · · · · · · FOP-4-3
3PU-72571-3	TRIM METER ASSY · · · · · · FOP-4-1
3PU-72637-2	TACHOMETER HOUR METER · · · · · · · · · · · · · · · · · · ·
3PV-72571-3	TRIM METER ASSY · · · · · · FOP-4-1
3PV-72637-2	TACHOMETER HOUR METER · · · · · · · · · · · · · · · · · · ·
H121-51640-730	RUBBER, FR. CARRIER CUSHION · · · · · · · · · · · · · · · · F-3-20-24
H196-47117-000	RUBBER, STOPPER · · · · · · · · · · · · · · · · · · ·
H341-38403-672	PLATE, WINKER BUZZER • • • • • • • • • • • • • • • • • • •
H341-38403-672	PLATE, WINKER BUZZER • • • • • • • • • • • • • • • • • • •
H341-38403-672	PLATE, WINKER BUZZER • • • • • • • • • • • • • • • • • • •
H355-89217-000	WRENCH, BOX (10MM) • • • • • • • • • • • • • • • • • •
H371-89221-000	WRENCH, HEX., 6MM · · · · · · · · · · · · · · · · · ·
H371-90009-015	BOLT, FLANGE, 10X120 (SATO) • • • • • • • • • • • • • • • • • • E-6-10-26
H5YS-30530-J01	SENSOR, KNOCK · · · · · · · · · · · · · · · · · · ·
H723-90472-000	WASHER, PLAIN, 12MM · · · · · · · · · · · · · · · · · ·
H747-16731-003	CLIP, TUBE · · · · · · · · · · · · · · · · · · ·
H759-16911-003	STRAINER, FUEL PUMP · · · · · · · · · · · · · · · · · · ·
H763-90681-A01	CLIP, WIRE HARNESS · · · · · · · · · · · · · · · · · ·
H763-90681-A01	CLIP, WIRE HARNESS • • • • • • • • • • • • • • • • • •
H797-38206-A01	FUSE, BLADE (3A) • • • • • • • • • • • • • • • • • • •
H800-91303-000	0-RING, 16MM · · · · · · · · · · · · · · · · · ·
H881-90110-000	BOLT, HEX., 6X14 • • • • • • • • • • • • • • • • • • •
H881-90114-000	BOLT, HEX., 6X40 • • • • • • • • • • • • • • • • • • •
H921-17936-000	WASHER, PIVOT · · · · · · · · · · · · · · · · · · ·
H921-17936-000	WASHER, PIVOT · · · · · · · · · · · · · · · · · · ·
H921-90302-000	NUT, HEX., 16MM • • • • • • • • • • • • • • • • • •
H921-90302-000	NUT, HEX., 16MM · · · · · · · · · · · · · · · · · ·
H921-90302-000	NUT, HEX., 16MM • • • • • • • • • • • • • • • • • •
H921-90302-000	NUT, HEX., 16MM • • • • • • • • • • • • • • • • • •
H921-90511-000	WASHER, PLAIN, 10MM · · · · · · · · · · · · · · · · · ·
H958-90428-000	WASHER B, THRUST, 14MM · · · · · · · · · · · · · · · · · ·
H958-90428-000	WASHER B, THRUST, 14MM · · · · · · · · · · · · · · · · · ·
HCO-92101-06055-4J	BOLT, HEX., 6X55 • • • • • • • • • • • • • • • • • •
HCO-92101-06055-4J	BOLT, HEX., 6X55 • • • • • • • • • • • • • • • • • •
HCO-93500-04014-4J	SCREW, PAN, 4X14 · · · · · · · · · · · · · · · · · · ·
HCO-93500-05016-4J	SCREW, PAN, 5X16 · · · · · · · · · · · · · · · · · · ·
HCO-93500-05016-4J	SCREW, PAN, 5X16 · · · · · · · · · · · · · · · · · · ·

HCO-93500-05020-4J	SCREW, PAN, 5X20 · · · · · · · · · · · · · · · · · · ·
HCO-93500-05020-4J	SCREW, PAN, 5X20
HCO-93500-05065-4J	SCREW, PAN, 5X65 · · · · · · · · · · · · · · · · · · ·
HCO-93500-05065-4J	SCREW, PAN, 5X65 · · · · · · · · · · · · · · · · · · ·
HCO-93500-05065-4J	SCREW, PAN, 5X65 · · · · · · · · · · · · · · · · · · ·
HCO-93500-05065-4J	SCREW, PAN, 5X65 · · · · · · · · · · · · · · · · · · ·
HCO-93500-06018-4J	SCREW, PAN, 6X18 · · · · · · · · · · · · · · · · · · ·
HCO-93500-06018-4J	SCREW, PAN, 6X18 · · · · · · · · · · · · · · · · · · ·
HCO-93500-06018-4J	SCREW, PAN, 6X18 · · · · · · · · · · · · · · · · · · ·
HCO-93600-06016-0A	SCREW, FLAT, 6X16 · · · · · · · · · · · · · · · · · E-5-20
HCO-93901-446J0	SCREW, TAPPING, 4X25 · · · · · · · · · · · · · · · · · · ·
HCO-94001-05490-0S	NUT, HEX., 5MM F-10-73
HCO-94001-05490-0S	NUT, HEX., 5MM • • • • • • • • • • • • • • • • • •
HCO-94001-05490-0S	NUT, HEX., 5MM · · · · · · · · · · · · · · · · · ·
HCO-94001-06080-0S	NUT, HEX., 6MM · · · · · · · · · · · · · · · · · ·
HCO-94001-12490-0S	NUT, HEX., 12MM · · · · · · · · · · · · · · · · · ·
HCO-94002-04490-0S	NUT, HEX., 4MM · · · · · · · · · · · · · · · · · ·
HCO-94301-06100	DOWEL PIN, 6X10 • • • • • • • • • • • • • • • • • E-3-53
HCO-94301-06100	DOWEL PIN, 6X10 E-15-21
HCO-94301-06100	DOWEL PIN, 6X10 E-15-30
HCO-94301-08140	DOWEL PIN, 8X14 • • • • • • • • • • • • • • • • • E-3-10-19
HCO-94301-10120	DOWEL PIN, 10X12 • • • • • • • • • • • • • • • • • • •
HCO-94302-06100	PIN B, DOWEL, 6X10 • • • • • • • • • • • • • • • • • • •
HCO-94302-06100	DOWEL PIN, 6X10 • • • • • • • • • • • • • • • • E-13-30
HCO-94302-10160	PIN B, DOWEL, 10X16 E-5-21
HCO-94302-10160	PIN B, DOWEL, 10X16 • • • • • • • • • • • • • • • • E-6-10-51
HCO-94305-30203	PIN, SPRING, 3X20 · · · · · · · · · · · · · · · · · F-10-76
HCO-94510-15000	CIRCLIP, EXTERNAL, 15MM · · · · · · · · · · · · · · · · · F-5-31
HCO-94510-15000	CIRCLIP, EXTERNAL, 15MM · · · · · · · · · · · · · · · · · ·
HCO-94520-47000	CIRCLIP, INTERNAL, 47MM · · · · · · · · · · · · · · · · · ·
HCO-94540-04029	E-RING, 4MM····· F-2-46
HCO-94540-06029	E-RING, 6MM····· FOP-3-32
HCO-94540-06029	E-RING, 6MM · · · · · · · · · · · · · · · · · ·
HCO-94540-06029	E-RING, 6MM · · · · · · · · · · · · · · · · · ·
HCO-94540-10019	E-RING, 10MM • • • • • • • • • • • • • • • • • •
HCO-94540-12029	E-RING, 12MM • • • • • • • • • • • • • • • • • •
HCO-94540-12029	E-RING, 12MM · · · · · · · · · · · · · · · · · ·
HCO-94540-15029	E-RING, 15MM · · · · · · · · · · · · · · · · · ·
HCO-95001-35055-40	TUBE, FUEL, 3.5X55 E-18-10-30
HCO-95003-05060-31	TUBE, VINYL, 3. 5X6. 5X600 • • • • • • • • • • • • • • • • • •
HCO-95005-50045-30	TUBE, 5X45 (95005–50001–30M) • • • • • • • • • • • • • • • F-10–77
HCO-95005-50250-30	TUBE, 5X250 (95005-50001-30M) • • • • • • • • • • • • • • • • F-10-78
HCO-95005-50340-30	TUBE, 5X340 (95005–50001–30M) • • • • • • • • • • • • • • • • F-10–79
HCO-95011-63000	RUBBER C, STAND STOPPER · · · · · · · · · · · · · · · · · F-3-20-54
HCO-95701-06014-09	BOLT, FLANGE, 6X14 · · · · · · · · · · · · · · · · · E-5-22
HCO-95701-06018-09	BOLT, FLANGE, 6X18 · · · · · · · · · · · · · · · · · · ·
HCO-95701-08030-09	BOLT, FLANGE, 8X30 · · · · · · · · · · · · · · · · · · ·
HCO-95701-10070-09	BOLT, FLANGE, 10X70 · · · · · · · · · · · · · · · · · · ·
•	

1100 05701 10100 00	POLT 51 MOS 40V400
HCO-95701-12120-09	BOLT, FLANGE, 12X120 • • • • • • • • • • • • • • • • • • •
HCO-96211-07000	BALL, STEEL, #7 (7/32) F-5-32
HC0-96211-07000	BALL, STEEL, #7 (7/32) F-5-1-34
HCO-96211-12000	BALL, STEEL, #12(3/8) F-5-33
HCO-96211-12000	BALL, STEEL, #12(3/8) F-5-1-35
HCO-96220-50080	ROLLER, 5X8 E-5-25
HCO-9807B-5617C	PLUG, SPARK (IZFR6K-11E) (NGK) · · · · · · · · · · · · · · · · E-20-3
HCO-98200-40500	FUSE, MINI (5A) • • • • • • • • • • • • • • • • • • •
HCO-98200-40500	FUSE, MINI (5A) • • • • • • • • • • • • • • • • • • •
HCO-98200-40500	FUSE, MINI (5A) • • • • • • • • • • • • • • • • • • •
HCO-98200-40750	FUSE, MINI (7. 5A) • • • • • • • • • • • • • • • • • • •
HCO-98200-41000	FUSE, MINI (10A) • • • • • • • • • • • • • • • • • • •
HCO-98200-41000	FUSE, MINI (10A) • • • • • • • • • • • • • • • • • • •
HCO-98200-41000	FUSE, MINI (10A) • • • • • • • • • • • • • • • • • • •
HCO-98200-41500	FUSE, MINI (15A) • • • • • • • • • • • • • • • • • • •
HCO-98200-42000	FUSE, MINI (20A) • • • • • • • • • • • • • • • • • • •
HCO-98200-43000	FUSE, MINI (30A) • • • • • • • • • • • • • • • • • • •
HCO-98200-43000	FUSE, MINI (30A) • • • • • • • • • • • • • • • • • • •
HCO-99003-10000	DRIVER 1, PLUS SCREW(NO.2) · · · · · · · · · · · · · · · · · · F-13-4
HCO-99003-50000	GRIP, SCREW DRIVER • • • • • • • • • • • • • • • • • • •
HCO-99006-19000	WRENCH, EYE, 19MM····· F-13-6
HCO-99008-02000	BAG, TOOL, 200MM F-13-7
HGC1-38402-000	SUSPENSION, AUDIBLE PILOT · · · · · · · · · · · · · · · · · · FOP-5-12
HGC1-38402-000	SUSPENSION, AUDIBLE PILOT · · · · · · · · · · · · · · · · · · FOP-5-1-12
HGC1-38402-000	SUSPENSION, AUDIBLE PILOT · · · · · · · · · · · · · · · · · · FOP-5-2-12
HGC1-38402-000	SUSPENSION, AUDIBLE PILOT · · · · · · · · · · · · · · · · · · FOP-5-5-11
HGHB-16075-830	O-RING, 1.9X10 · · · · · · · · · · · · · · · · · · ·
HGHB-16163-610	CLIP, TUBE • • • • • • • • • • • • • • • • • • •
HGJE-38221-J01	FUSE, BLADE (MINI) (1A)
HHA0-90402-000	WASHER, THRUST, 14MM · · · · · · · · · · · · · · · · · ·
HHA0-90402-000	WASHER, THRUST, 14MM · · · · · · · · · · · · · · · · · ·
HHE0-50310-003	CLIP A. WIRE E-1-11
HHW1-90207-671	BOLT, FLANGE, 6X40 · · · · · · · · · · · · · · · · · · ·
HHW1-90214-671	BOLT, FLANGE, 6X25 (SUS-D) · · · · · · · · · · · · · · · · · · F-10-84
HHW1-90215-671	BOLT. FLANGE. 6X16 · · · · · · · · · · · · · · · · · · ·
HK44-32606-V01	CAP, DUMMY (WPC 4P 090 M) (RED) F-7-5
HK44-32606-V01	CAP, DUMMY (WPC 4P 090 M) (RED) • • • • • • • • • • • • • • • F0P-3-4-35
HK44-32606-V01	CAP, DUMMY (WPC 4P 090 M) (RED) • • • • • • • • • • • • • • • F0P-3-5-40
HK44-32606-V01	CAP, DUMMY (WPC 4P 090 M) (RED) • • • • • • • • • • • • • • • • • • •
HK44-32606-V01	CAP, DUMMY (WPC 4P 090 M) (RED) • • • • • • • • • • • • • • • F0P-3-7-43
HK44-32606-V01	CAP, DUMMY (WPC 4P 090 M) (RED) F0P-3-8-45
HKFG-32108-000	COVER, CONNECTOR · · · · · · · · · · · · · · · · · · ·
HKFG-32108-000	COVER, CONNECTOR · · · · · · · · · · · · · · · · · · ·
HKFG-32108-000	COVER, CONNECTOR · · · · · · · · · · · · · · · · · · ·
HKFG-32108-000	COVER, CONNECTOR · · · · · · · · · · · · · · · · · · ·
	COVER, CONNECTOR • • • • • • • • • • • • • • • • • • •
HKFG-32108-000	BAND, WIRE · · · · · · · · · · · · · · · · · · ·
HKM3-32161-003	BAND, WIRE
HKM3-32161-003	DANU, WIRE

HKN5-17224-670	WASHER, AIR CLEANER COVER • • • • • • • • • • • • • • • • • • •	F-2-1
HKSV-32501-J00	FUSE, BLADE (40A)	• F-7-10-28
HKSV-32501-J00	FUSE, BLADE (40A)	• F-7-10-28
HKSV-32501-J00	FUSE, BLADE (40A) · · · · · · · · · · · · · · · · · · ·	• F-7-10-28
HKSV-32501-J00	FUSE, BLADE (40A) · · · · · · · · · · · · · · · · · · ·	• F-7-10-28
HKSV-32501-J00	FUSE, BLADE (40A) · · · · · · · · · · · · · · · · · · ·	• F-7-10-28
HKSV-32501-J00	FUSE, BLADE (40A) · · · · · · · · · · · · · · · · · · ·	• F-7-10-28
HKSV-32501-J00	FUSE, BLADE(40A) · · · · · · · · · · · · · · · · · · ·	• F-7-10-28
HKV6-90651-003	BAND, WIRE, 165MM(BLACK) · · · · · · · · · · · · · · · · · · ·	• F-7-10-21
HMAL-91302-601	0-RING, 18.1X3.6 · · · · · · · · · · · · · · · · · · ·	• E-3-10-17
HMB9-83551-000	GROMMET	E-14-10-10
HMG9-35701-950	BAND (BLACK 3. 5X140) • • • • • • • • • • • • • • • • • • •	F-10-80
HMG9-35701-950	BAND (BLACK 3. 5X140) • • • • • • • • • • • • • • • • • • •	F-11-3
HMJ0-91301-003	0-RING, 7.8X1.9(ARAI)	E-14-32
HMJ0-91301-003	0-RING, 7.8X1.9(ARAI)	E-18-53
HMJ0-91301-003	0-RING, 7.8X1.9(ARAI)	E0P-1-15
HMJ0-91308-003	$0\text{-RING} \cdot \cdot$	
HMJ0-91308-003	$0\text{-RING} \cdot \cdot$	• F0P-17-7
HMR5-16966-000	JOINT, FUEL TUBE • • • • • • • • • • • • • • • • • • •	• F-13-8
HMT2-17193-000	T-JOINT · · · · · · · · · · · · · · · · · · ·	E-1-7
HP01-91212-003	01L SEAL, 31X46X7 (NOK) • • • • • • • • • • • • • • • • • • •	• E-5-18
HP08-12342-004	SEAL, SPARK PLUG TUBE(NOK) · · · · · · · · · · · · · · · · · · ·	
HP0A-91303-A02	$0\text{-RING} \cdot \cdot$	
HP0X-91321-003	0-RING, 25X2.4(NOK) • • • • • • • • • • • • • • • • • • •	
HP13-31141-003	PULLEY · · · · · · · · · · · · · · · · · · ·	
HP13-31147-003	SCREW	E-19-10
HP13-31148-003	SCREW, WAVE WASHER • • • • • • • • • • • • • • • • • • •	• E−19−12
HP5A-13115-000	CLIP, PISTON PIN·····	• E−7−4
HP5A-31201-005	ROTOR COMP.	E-21-2
HP5A-31243-005	BOLT A, THROUGH · · · · · · · · · · · · · · · · · · ·	
HP5G-16614-003	MESH, FUEL FILTER · · · · · · · · · · · · · · · · · · ·	
HP8A-11812-A00	GROMMET, TIMING BELT COVER	
HP8A-13204-A01	BOLT, CONNECTING ROD · · · · · · · · · · · · · · · · · · ·	
HP8A-14400-A01	BELT, TIMING (197YU26 B-323) · · · · · · · · · · · · · · · · · · ·	
HP8A-14551-A01	BOLT, IDLER · · · · · · · · · · · · · · · · · · ·	
HP8A-14620-A01	ARM ASSY., INTAKE ROCKER	• E-9-10-4
HP8A-14626-A00	ARM COMP. A, EX. ROCKER • • • • • • • • • • • • • • • • • • •	
HP8A-14626-A00	ARM COMP. A, EX. ROCKER • • • • • • • • • • • • • • • • • • •	
HP8A-14626-A00	ARM COMP. A, EX. ROCKER • • • • • • • • • • • • • • • • • • •	
HP8A-14627-A00	ARM COMP. B, EX. ROCKER • • • • • • • • • • • • • • • • • • •	
HP8A-14627-A00	ARM COMP. B, EX. ROCKER • • • • • • • • • • • • • • • • • • •	
HP8A-14627-A00	ARM COMP. B, EX. ROCKER • • • • • • • • • • • • • • • • • • •	E-9-10-6
HP8A-14631-A00	SHAFT COMP., INTAKE ROCKER ARM	
HP8A-14645-A01	SPRING, ROCKER ARM · · · · · · · · · · · · · · · · · · ·	
HP8A-14645-A01	SPRING, ROCKER ARM · · · · · · · · · · · · · · · · · · ·	
HP8A-14645-A01	SPRING, ROCKER ARM · · · · · · · · · · · · · · · · · · ·	
HP8A-15115-A01	PACKING, OIL HOLE · · · · · · · · · · · · · · · · · · ·	E-3-9
HP8A-15140-A00	ORIFICE ASSY., OIL CONTROL	• E−3−10

HP8A-15142-A00	O-RING, 8.8X2.4 · · · · · · · · · · · · · · · · · · ·	E-3-11
HP8A-15150-A00	JOINT ASSY., OIL PIPE	E-3-12
HP8A-90003-A00	BOLT, FLANGE, 8X30 · · · · · · · · · · · · · · · · · · ·	E-9-10-20
HP8A-90004-A00	BOLT, FLANGE, 8X40 · · · · · · · · · · · · · · · · · · ·	E-9-10-21
HP8A-90017-A01	BOLT, SPECIAL, 8X29 · · · · · · · · · · · · · · · · · · ·	E-13-10-9
HP8A-90031-A01	BOLT-WASHER, 12X35 · · · · · · · · · · · · · · · · · · ·	
HP8A-90701-A00	DOWEL PIN, 6X10 · · · · · · · · · · · · · · · · · · ·	
HP8A-91301-A00	O-RING, 48. 5X2. 4 · · · · · · · · · · · · · · · · · ·	∙ E-9-17
HP8A-91308-A01	O-RING, 18. 3X3. 5 · · · · · · · · · · · · · · · · · ·	E-3-45
HP8A-91309-A01	O-RING, 16. 3X3. 5 · · · · · · · · · · · · · · · · · ·	E−3−47
HP8E-14762-A01	SPRING, EX. VALVE (YELLOW GREEN)	
HP8E-17105-A01	GASKET, INTAKE MANIFOLD · · · · · · · · · · · · · · · · · · ·	
HP8E-17105-A01	GASKET, INTAKE MANIFOLD · · · · · · · · · · · · · · · · · · ·	E0P-1-9
HP8F-14820-A01	MOTION COMP., LOST · · · · · · · · · · · · · · · · · · ·	
HPC6-15233-000	BOLT, SEALING, 18MM · · · · · · · · · · · · · · · · · ·	
HPC6-91324-000	O-RING, 20.6X2.6 · · · · · · · · · · · · · · · · · · ·	
HPC6-91324-000	O-RING, 20.6X2.6 · · · · · · · · · · · · · · · · · · ·	
HPD1-31138-004	COVER, BEARING	
HPD1-31142-004	NUT, PULLEY LOCK · · · · · · · · · · · · · · · · · · ·	
HPD1-31145-004	BOLT, STUD, 6X68 · · · · · · · · · · · · · · · · · · ·	
HPD1-90231-014	NUT-WASHER, 5MM · · · · · · · · · · · · · · · · · ·	
HPD6-90430-003	WASHER, SEALING, 6MM · · · · · · · · · · · · · · · · · ·	
HPE0-15231-000	VALVE, RELIEF · · · · · · · · · · · · · · · · · · ·	
HPEA-13111-000	PIN, PISTON · · · · · · · · · · · · · · · · · · ·	
HPF0-91302-003	0-RING, 26. 9X2. 4 (NOK)	E0P-1-17
HPF0-91302-003	O-RING, 26.9X2.4 (NOK)	
HPF0-91302-003	O-RING, 26.9X2.4 (NOK)	
HPF4-91324-004	O-RING, 28. 3X2. 4 (NOK)	E-3-10-18
HPG4-91033-013	BEARING, NEEDLE, 50X72X4.5 · · · · · · · · · · · · · · · · · · ·	F-5-1-25
HPG6-15232-000	SPRING, RELIEF VALVE	E-5-9
HPG7-16741-005	O-RING, PRESSURE REGULATOR · · · · · · · · · · · · · · · · · · ·	
HPGK-37835-A01	0-RING	E-14-10-9
HPH1-90015-013	HOLDER, OIL FILTER	E-3-10-8
HPH7-90081-000	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·	E-5-15
HPH7-90081-000	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·	E-5-15
HPH7-90081-000	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·	E-5-15
HPH7-90715-000	DOWEL PIN, 13X37	E-3-40
HPK1-91308-003	0-RING, 26. 2X2. 4 (NOK)	E-3-46
HPLC-91301-000	O-RING, 7. 47X3. 6 · · · · · · · · · · · · · · · · · ·	E-14-33
HPM3-14744-000	SCREW, TAPPET ADJUSTING	E-9-10-13
HPM3-14775-000	SEAT, VALVE SPRING	E-9-10-18
HPM3-90206-004	NUT, TAPPET ADJUSTING	E-9-10-22
HPM3-90206-004	NUT, TAPPET ADJUSTING	E-9-10-27
HPM3-90206-004	NUT, TAPPET ADJUSTING	E-9-10-27
HPM3-90206-004	NUT, TAPPET ADJUSTING	
HPNA-91214-014	OIL SEAL, 80X98X10(ARAI) • • • • • • • • • • • • • • • • • • •	
HPNA-91302-003	O-RING, 7. 45X3. 61 (NOK)	
HPNA-91307-003	0-RING, 9.5X1.9 · · · · · · · · · · · · · · · · · · ·	

HPNA-91307-003	O-RING, 9.5X1.9 · · · · · · · · · · · · · · · · · · ·	E-4-23
HPNA-91307-003	O-RING, 9.5X1.9 · · · · · · · · · · · · · · · · · · ·	E0P-1-19
HPNA-91333-003	0-RING, 15X1.9 · · · · · · · · · · · · · · · · · · ·	∙ E-3-50
HPNB-37500-003	SENSOR ASSY., CRANK • • • • • • • • • • • • • • • • • • •	E-3-25
HPP4-90009-E01	BOLT, SEALING, 6MM · · · · · · · · · · · · · · · · · ·	E−18−45
HPR3-91319-003	O-RING, 13X1.5(ARAI)	E-3-48
HPR3-91319-003	O-RING, 13X1.5(ARAI)	E0P-1-20
HPR7-31105-A01	HOLDER ASSY., BRUSH	E-19-1
HPT0-14744-004	SCREW, TAPPET ADJUSTING	E-9-10-14
HPT0-14744-004	SCREW, TAPPET ADJUSTING	E-9-10-26
HPT0-14744-004	SCREW, TAPPET ADJUSTING	E-9-10-26
HPT0-14744-004	SCREW, TAPPET ADJUSTING	E-9-10-26
HPT0-31111-003	BEARING, RR. GENERATOR	E-19-2
HPT0-31114-013	BEARING, FR. GENERATOR	
HPT0-31118-003	BUSH, INSULATION	E-19-4
HPT0-31146-003	SCREW	
HPT0-31147-003	SCREW-WASHER · · · · · · · · · · · · · · · · · · ·	
HPT0-31148-003	SCREW, WAVE WASHER • • • • • • • • • • • • • • • • • • •	
HPT0-90005-003	BOLT-WASHER, 12X163 · · · · · · · · · · · · · · · · · · ·	
HPT0-90206-004	NUT, TAPPET ADJUSTING	
HPT0-90206-004	NUT. TAPPET ADJUSTING	
HPT0-90206-004	NUT, TAPPET ADJUSTING · · · · · · · · · · · · · · · · · · ·	
HPT0-90206-004	NUT, TAPPET ADJUSTING · · · · · · · · · · · · · · · · · · ·	
HPT0-90705-000	DOWEL PIN, 16X22 · · · · · · · · · · · · · · · · · ·	
HPT2-91005-N01	BEARING, THRUST (F)	
HPT2-91005-N01	BEARING, THRUST (F)	
HPW5-90701-000	DOWEL PIN, 14X15	
HPW5-90701-000	DOWEL PIN, 14X15 • • • • • • • • • • • • • • • • • • •	
HPY3-17249-000	SPRING, AIR FLOW TUBE · · · · · · · · · · · · · · · · · · ·	
HPY3-31215-004	GEAR ASSY., PLANETARY · · · · · · · · · · · · · · · · · · ·	
HPY3-31218-004	BALL, STEEL · · · · · · · · · · · · · · · · · ·	
HPZ1-12210-004	SEAL A, VALVE STEM(NOK) · · · · · · · · · · · · · · · · · · ·	
HPZ1-12211-004	SEAL B, VALVE STEM(NOK) · · · · · · · · · · · · · · · · · · ·	
HR70-14646-A00	WASHER, THRUST · · · · · · · · · · · · · · · · · · ·	
HR70-14646-A00	WASHER, THRUST · · · · · · · · · · · · · · · · · · ·	
HR70-14646-A00	WASHER, THRUST · · · · · · · · · · · · · · · · · · ·	
HR70-15280-A00	BODY, OIL JET · · · · · · · · · · · · · · · · · · ·	
HR70-37840-A01	SENSOR ASSY., TDC · · · · · · · · · · · · · · · · · · ·	
HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM · · · · · · · · · · · · · · · · · · ·	
HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM · · · · · · · · · · · · · · · · · · ·	
HRCA-14632-A00	SHAFT COMP., EX. ROCKER ARM · · · · · · · · · · · · · · · · · · ·	
HRCA-17055-A01	GASKET, FR. INJECTOR BASE · · · · · · · · · · · · · · · · · · ·	
HRCA-17055-A01	GASKET, FR. INJECTOR BASE · · · · · · · · · · · · · · · · · · ·	
HRCA-17065-A01	GASKET, RR. INJECTOR BASE	
HRCA-17065-A01	GASKET, RR. INJECTOR BASE · · · · · · · · · · · · · · · · · · ·	
HRCA-90014-A01	BOLT-WASHER, 11X105 · · · · · · · · · · · · · · · · · · ·	
HRCA-90704-A00	KEY, 4.5X24 · · · · · · · · · · · · · · · · · · ·	
HRDV-14610-J00	ARM ASSY., FR. INTAKE ROCKER	
טטט טוטדו זעאווו	ANIM ACCI., IN. INTAKE NOOKEN	L ∂ 10 ⁻ 3

HRDV-14631-J00	SHAFT COMP., FR. INTAKE ROCKERARM • • • • • • • • • • • • • • • • • • •	E-9-10-7
HRDV-14646-J00	WASHER, THRUST · · · · · · · · · · · · · · · · · · ·	• E−9−10−10
HRDV-14765-J00	RETAINER, VALVE SPRING	• E−9−10−17
HRGM-14781-A01	COTTER, VALVE (FUJI VALVE) • • • • • • • • • • • • • • • • • • •	E-9-10-19
HRJA-14711-000	VALVE, IN. · · · · · · · · · · · · · · · · · · ·	• E−9−10−11
HRJA-14721-E00	VALVE, EX. · · · · · · · · · · · · · · · · · · ·	• E−9−10−12
HRJA-15290-000	BOLT COMP., OIL JET	E-3-14
HRJA-90017-003	BOLT-WASHER, 16X49 · · · · · · · · · · · · · · · · · · ·	• E−13−22
HRKG-13210-000	ROD COMP., CONNECTING · · · · · · · · · · · · · · · · · · ·	E-7-6
HRKG-14761-003	SPRING, VALVE (PINK) · · · · · · · · · · · · · · · · · · ·	E-9-10-15
HRKG-91213-003	OIL SEAL, 39X53X8 (NOK) • • • • • • • • • • • • • • • • • • •	• E−9−16
HRMA-16723-E00	JOINT, FUEL FEED HOSE • • • • • • • • • • • • • • • • • • •	E-18-10-6
HRNA-37260-A01	SENSOR, OIL PRESSURE · · · · · · · · · · · · · · · · · · ·	∙ E-3-24
HRNA-37830-A01	SENSOR ASSY., MAP	E-14-10-6
HRTA-15400-003	CARTRIDGE, OIL FILTER	E-3-10-4
HRTA-15400-003	CARTRIDGE, OIL FILTER (MAHLE TENNEX)	F0P-18-4
HRYE-13211-A01	BEARING A, CONNECTING ROD (BLACK)	E-7-7
HRYE-13212-A01	BEARING B, CONNECTING ROD(BROWN)	• E-7-7
HRYE-13213-A01	BEARING C, CONNECTING ROD(GREEN)	• E-7-7
HRYE-13214-A01	BEARING D, CONNECTING ROD (YELLOW)	E-7-7
HRYE-13215-A01	BEARING E, CONNECTING ROD(PINK)	E-7-7
HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	F-2-45
HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	F-2-1-34
HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	F-7-9
HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	F-7-9
HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	F-7-10-26
HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	F0P-3-4-52
HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	F0P-3-5-57
HS0A-91541-003	CLIP, HARNESS BAND (BLACK)	F0P-3-6-59
HS0A-91541-003	CLIP, HARNESS BAND (BLACK) (145MM) · · · · · · · · · · · · · · · · · ·	• F0P-3-7-59
HS0A-91541-003	CLIP, HARNESS BAND (BLACK) (145MM) · · · · · · · · · · · · · · · · · ·	F0P-3-8-61
HS0X-17711-931	RETAINER (BLUE GREEN) (TOKAI) · · · · · · · · · · · · · · · · · · ·	E-14-22
HS0X-46392-A01	CLIP, BRAKE PIPE · · · · · · · · · · · · · · · · · · ·	• E−15−14
HSA0-90683-003	CLIP, WIRE HARNESS, 25MM · · · · · · · · · · · · · · · · · ·	• E-1-15
HSA0-90683-003	CLIP, WIRE HARNESS, 25MM·······	• E-20-10-11
HSB2-90650-003	CLIP, WIRE HARNESS, 10MM · · · · · · · · · · · · · · · · · ·	• E−14−31
HSC2-90649-003	BAND, WIRE HARNESS(NATURAL)	F0P-5-3-23
HSC2-90649-003	BAND, WIRE HARNESS(NATURAL)	F0P-5-4-19
HSD2-90705-931	PIN, SNAP, 6MM······	
HSD4-91356-952	0-RING, 31.5X2.4(ARAI)	∙ E-4-24
HSDA-39794-004	RELAY ASSY., FUEL PUMP (DENSO)	F-7-20-5
HSE0-53740-953	CLIP, SENSOR HOSE	E-18-10-24
HSF4-89216-000	WRENCH, PLUG · · · · · · · · · · · · · · · · · · ·	
HSK7-91566-003	CLIP D, WASHER TUBE	
HSR3-91531-003	HOLDER, COUPLER (NATURAL) (128.6MM) · · · · · · · · · · · · · · · · · ·	
HSR3-91531-003	HOLDER, COUPLER (NATURAL) (128.6MM) · · · · · · · · · · · · · · · · · ·	
HSR3-91531-003	HOLDER, COUPLER (NATURAL) (128.6MM) · · · · · · · · · · · · · · · · · ·	
HSR3-91531-003	HOLDER, COUPLER (NATURAL) (128.6MM) · · · · · · · · · · · · · · · · · ·	

HSR3-91531-003	HOLDER, COUPLER (NATURAL) (128.6MM) • • • • • • • • • • • • • • • • FOP-3-10-54
HSTK-91535-003	CLIP, COUPLER (DARK BLUE) • • • • • • • • • • • • • • • • • • •
HSTK-91535-003	CLIP, COUPLER (DARK BLUE) • • • • • • • • • • • • • • • • • • •
HSTK-91535-003	CLIP, COUPLER (DARK BLUE) • • • • • • • • • • • • • • • • • • •
HSTK-91535-003	CLIP, COUPLER (DARK BLUE) · · · · · · · · · · · · · · · · · · ·
HSTK-91535-003	CLIP, COUPLER (DARK BLUE)
HSTK-91540-003	CLIP, HARNESS BAND (BLACK) E-18-1-17
HSTK-91540-003	CLIP, HARNESS BAND (BLACK) (155.3MM) • • • • • • • • • • FOP-7-5
HTA0-91535-003	CLIP, COUPLER (DARK BROWN)
HTA0-91535-003	CLIP, COUPLER (DARK BROWN) FOP-3-5-56
HTA0-91535-003	CLIP, COUPLER (DARK BROWN) FOP-3-6-58
HTA0-91535-003	CLIP, COUPLER (DARK BROWN) · · · · · · · · · · · · · · · · · · FOP-3-7-58
HTA0-91535-003	CLIP, COUPLER (DARK BROWN) • • • • • • • • • • • • • • • • • • FOP-3-8-60
HTTA-91549-003	CLIP, BAND HARNESS (BLACK) (152.4MM) · · · · · · · · · · · · · FOP-3-7-60
HTTA-91549-003	CLIP, BAND HARNESS (BLACK) (152.4MM) · · · · · · · · · · · · · FOP-3-8-62
HV15-38206-003	FUSE, BLADE (3A) FOP-3-4-38
HV15-38206-003	FUSE, BLADE (3A) FOP-3-5-44
HV15-38206-003	FUSE, BLADE (3A) FOP-3-6-46
HVM0-16965-771	CLAMP, HOSE · · · · · · · · · · · · · · · · · · ·
HVM0-16965-771	CLAMP, HOSE E-18-10-16
HZ2E-38216-003	COVER ASSY., FUSE · · · · · · · · · · · · · · · · · · ·
HZ2E-38216-003	COVER ASSY., FUSE · · · · · · · · · · · · · · · · · · ·
HZ2E-38216-003	COVER ASSY., FUSE · · · · · · · · · · · · · · · · · · ·
HZ2E-38216-003	COVER ASSY., FUSE · · · · · · · · · · · · · · · · · · ·
HZ2E-87117-000	LABEL, FUSE (3A) FOP-3-4-42
HZ2E-87117-000	LABEL, FUSE (3A) FOP-3-5-48
HZ2E-87117-000	LABEL, FUSE (3A) FOP-3-6-50
HZ2E-87117-000	LABEL, FUSE (3A) FOP-3-10-33
HZB7-90691-003	CLIP, HARNESS · · · · · · · · · · · · · · · · · ·
HZCO-63515-700	CAP, L. SIDE COVER · · · · · · · · · · · · · · · · · · ·
HZE2-90601-000	WASHER, DRAIN PLUG, 12MM · · · · · · · · · · · · · · · · · ·
HZE2-90601-000	WASHER, DRAIN PLUG, 12MM · · · · · · · · · · · · · · · · · ·
HZE2-90601-000	WASHER, DRAIN PLUG, 12MM · · · · · · · · · · · · · · · · · ·
HZV0-41122-000	PIN, VERTICAL SHAFT · · · · · · · · · · · · · · · · · E-13-19
HZV0-90604-000	CLIP, TUBE(B12) E-18-1-16
HZV0-90604-000	CLIP, TUBE(B12) • • • • • • • • • • • • • • • • • • •
HZV1-24210-010	SPRING COMP., CLICK · · · · · · · · · · · · · · · · · · ·
HZV1-87538-C23	LABEL, WARNING OPERATOR • • • • • • • • • • • • • • • • • F-12-10
HZV4-12155-A00	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV4-12155-A00	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV4-12155-A00	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV4-12155-A01	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV4-12155-A01	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV4-12155-A01	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV4-17704-010	BAND, TUBE CLIP, 12.5MM··········F-13-9
HZV4-17704-010	BAND, TUBE CLIP, 12.5MM··········F-13-9
HZV4-24221-010	SPRING, CLICK ASSIST · · · · · · · · · · · · · · · · · · ·
HZV4-36182-651	CORD COMP., EMERGENCY · · · · · · · · · · · · · · · · · · ·

1171/4 00400 054	CORD COUR FUEDOENCY
HZV4-36182-651	CORD COMP., EMERGENCY · · · · · · · · · · · · · · · · · · ·
HZV4-36182-651	CORD COMP., EMERGENCY · · · · · · · · · · · · · · · · · · ·
HZV4-36187-652	CLIP, EMERGENCY LOCK FOP-5-3-12
HZV4-36187-652	CLIP, EMERGENCY LOCK · · · · · · · · · · · · · · · · · · ·
HZV4-90127-000	BOLT, HEX., 6X16 E-6-10
HZV4-90302-000	NUT, SELF-LOCK, 5MM······ F-3-20
HZV4-90502-000	WASHER, PLAIN, 5MM······FOP-3-9-43
HZV4-90502-000	WASHER, PLAIN, 5MM······FOP-3-10-57
HZV4-90506-000	WASHER, PLAIN, 6MM·····F-8-10
HZV4-90512-000	WASHER, PLAIN, 6MM·····F-2-38
HZV4-90512-000	WASHER, PLAIN, 6MM·····F-10-62
HZV4-90514-000	WASHER, 10MM • • • • • • • • • • • • • • • • • •
HZV4-90605-000	CLIP, TUBE (B12. 5) • • • • • • • • • • • • • • • • • •
HZV4-90605-000	CLIP, TUBE (B12. 5) • • • • • • • • • • • • • • • • • •
HZV4-90605-000	CLIP, TUBE (B12. 5) • • • • • • • • • • • • • • • • • •
HZV4-90605-000	CLIP, TUBE (B12. 5) • • • • • • • • • • • • • • • • • •
HZV4-90605-000	CLIP, TUBE(B12.5) • • • • • • • • • • • • • • • • • • •
HZV4-90605-000	CLIP, TUBE (B12.5) • • • • • • • • • • • • • • • • • • •
HZV4-90605-000	CLIP, TUBE (B12.5) • • • • • • • • • • • • • • • • • • •
HZV4-90605-000	CLIP, TUBE (B12.5) • • • • • • • • • • • • • • • • • • •
HZV4-90605-000	CLIP, TUBE(B12.5) • • • • • • • • • • • • • • • • • • •
HZV4-90605-000	CLIP, TUBE (B12.5) • • • • • • • • • • • • • • • • • • •
HZV5-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZV5-12214-000	WASHER, SEALING(22MM) · · · · · · · · · · · · · E-3-8
HZV5-12214-000	WASHER, SEALING (22MM) · · · · · · · · · · · · · · · · E-3-10-3
HZV5-32823-003	PLUG, INNER CONNECTOR · · · · · · · · · · · · · · · · · · ·
HZV5-32823-003	PLUG, INNER CONNECTOR · · · · · · · · · · · · · · · · · · ·
HZV5-32823-003	PLUG, INNER CONNECTOR · · · · · · · · · · · · · · · · · · ·
HZV5-32823-003	PLUG, INNER CONNECTOR · · · · · · · · · · · · · · · · · · ·
HZV5-32823-003	PLUG, INNER CONNECTOR · · · · · · · · · · · · · · · · · · ·
HZV5-32823-003	PLUG, INNER CONNECTOR · · · · · · · · · · · · · · · · · · ·

HZV5-32823-003	PLUG, INNER CONNECTOR • • • • • • • • • • • • • • • • • • •
HZV5-32823-003	PLUG, INNER CONNECTOR • • • • • • • • • • • • • • • • • • •
HZV5-32823-003	PLUG, INNER CONNECTOR · · · · · · · · · · · · · · · · · · ·
HZV5-32824-003	PLUG, OUTER CONNECTOR · · · · · · · · · · · · · · · · · · ·
HZV5-32824-003	PLUG, OUTER CONNECTOR · · · · · · · · · · · · · · · · · · ·
HZV5-32824-003	PLUG, OUTER CONNECTOR • • • • • • • • • • • • • • • • • • •
HZV5-32824-003	PLUG, OUTER CONNECTOR • • • • • • • • • • • • • • • • • • •
HZV5-32824-003	PLUG, OUTER CONNECTOR • • • • • • • • • • • • • • • • • • •
HZV5-32824-003	PLUG, OUTER CONNECTOR • • • • • • • • • • • • • • • • • • •
HZV5-36136-821	SPRING, MOTOR · · · · · · · · · · · · · · · · · · ·
HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP · · · · · · · · · · · · · · · · · · ·
HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP · · · · · · · · · · · · · · · · · · ·
HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP · · · · · · · · · · · · · · · · · · ·
HZV5-38410-003	BUZZER COMP., WARNING · · · · · · · · · · · · · · · · · · ·
HZV5-38410-003	BUZZER COMP., WARNING · · · · · · · · · · · · · · · · · · ·
HZV5-38410-003	BUZZER COMP., WARNING · · · · · · · · · · · · · · · · · · ·
HZV5-40102-000	GROMMET, UNDER CASE · · · · · · · · · · · · · · · · · · ·
HZV5-40102-000	GROMMET, UNDER CASE · · · · · · · · · · · · · · · · · · ·
HZV5-41171-000	END, NIPPLE • • • • • • • F-10-10
HZV5-41172-000	NIPPLE, SENSOR · · · · · · · · · · · · · · · · · · ·
HZV5-41172-000	NIPPLE, SENSOR · · · · · · · · · · · · · · · · · · ·
HZV5-50214-003	BUSH, SWIVEL CASE · · · · · · · · · · · · · · · · · · ·
HZV5-56117-821	RING, BACK UP • • • • • • • • • • • • • • • • • •
HZV5-56118-820	BUSH, MOTOR CODE · · · · · · · · · · · · · · · · · · ·
HZV5-56513-000	BUSH, LOWER CYLINDER • • • • • • • • • • • • • • • • • • •
HZV5-90119-000	SCREW, PAN, 6X8 F-10-47
HZV5-90119-000	SCREW, PAN, 6X8 F-11-33
HZV5-90131-000	BOLT, DRAIN PLUG · · · · · · · · · · · · · · · · · · ·
HZV5-90302-003	NUT, HEX., 20MM • • • • • • • • • • • • • • • • • •
HZV5-90302-003	NUT, HEX., 20MM F-2-1-23
HZV5-90304-013	NUT, SELF-LOCK (7/8-14UNF) • • • • • • • • • • • • • • • • F-10-51
HZV5-90306-003	NUT, SELF-LOCK, 10MM · · · · · · · · · · · · · · · · · ·
HZV5-90307-003	NUT, SELF-LOCK (3/8-24UNF) • • • • • • • • • • • • • • • • F-10-53
HZV5-90501-000	WASHER, WAVE, 40MM • • • • • • • • • • • • • • • • • •
HZV5-90502-000	WASHER, WAVE, 26MM • • • • • • • • • • • • • • • • • •
HZV5-90504-000	WASHER, THRUST, 34MM • • • • • • • • • • • • • • • • • •
HZV5-90552-000	WASHER, PLAIN, 12MM F-10-64
HZV5-90559-000	WASHER, PLAIN, 12MM E-6-10-38
HZV5-90559-000	WASHER, PLAIN, 12MM · · · · · · · · · · · · · · · · F-3-23
HZV5-90559-000	WASHER, PLAIN, 12MM · · · · · · · · · · · · · · · · · F-5-20
HZV5-90559-000	WASHER, PLAIN, 12MM • • • • • • • • • • • • • • • • • •
HZV5-90559-000	WASHER, PLAIN, 12MM • • • • • • • • • • • • • • • • • F-10-65
HZV5-90563-000	WASHER, PLAIN, 10MM E-6-10-39
HZV5-90563-000	WASHER, PLAIN, 10MM · · · · · · · · · · · · · · · · · F-3-24
HZV5-90651-000	CIRCLIP, EXTERNAL, 39MM · · · · · · · · · · · · · · · · · F-10-66
HZV5-90756-000	DOWEL PIN, 6X10 F-3-25
HZV5-90756-000	DOWEL PIN, 6X10 F-3-25
HZV5-90756-000	DOWEL PIN, 6X10 F-3-20-50

HZV5-90756-000	DOWEL PIN, 6X10 F-4-24
HZV5-90756-000	DOWEL PIN. 6X10 F-4-24
HZV5-90756-000	DOWEL PIN, 6X10 F-4-24
HZV5-91203-821	OIL SEAL
HZV5-91256-003	OIL SEAL, 39.5X52X6 (ARAI) • • • • • • • • • • • • • • • • F-10-69
HZV5-91302-821	O-RING, 1.8X69.6 · · · · · · · · · · · · · · · · · · ·
HZV5-91316-821	O-RING, 3.5X38.7 · · · · · · · · · · · · · · · · · · ·
HZV7-90508-000	WASHER • • • • • • • • • • • • • • • • • • •
HZV7-90508-000	WASHER • • • • • • • • • • • • • • • • • • •
HZV7-90951-010	NIPPLE, GREASE · · · · · · · · · · · · · · · · · · ·
HZVJ-14111-000	CAMSHAFT, R E-9-10-1
HZVJ-14211-000	CAMSHAFT, L. • • • • • • • • • • • • • • • • • •
HZVJ-32100-010	HARNESS ASSY., MAIN WIRE · · · · · · · · · · · · · · · · · · ·
HZVJ-32100-010	HARNESS ASSY., MAIN WIRE F-7-1
HZVJ-32100-030	HARNESS ASSY., MAIN WIRE F-7-1
HZVJ-32100-030	HARNESS ASSY., MAIN WIRE F-7-1
HZVJ-32100-040	HARNESS ASSY., MAIN WIRE F-7-1
HZVJ-32100-040	HARNESS ASSY., MAIN WIRE F-7-1
HZVJ-34750-901	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·
HZVJ-34750-902	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·
HZVJ-87121-P00	MARK, RR. (BFT200) • • • • • • • • • • • • • • • • • •
HZVJ-87301-P00	MARK, FR. (BFT200) • • • • • • • • • • • • • • • • • •
HZVK-16400-003	THROTTLE BODY ASSY. • • • • • • • • • • • • • E-15-3
HZVK-16400-003	THROTTLE BODY ASSY. • • • • • • • • • • • • • E-15-3
HZVK-16400-013	THROTTLE BODY ASSY. • • • • • • • • • • • • • • E-15-3
HZVK-16400-023	THROTTLE BODY ASSY. • • • • • • • • • • • • • E-15-3
HZVK-16400-023	THROTTLE BODY ASSY. • • • • • • • • • • • • • • E-15-3
HZVK-34750-901	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·
HZVK-34750-901	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·
HZVK-34750-903	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·
HZVK-34750-904	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·
HZVK-87121-P00	MARK, RR. (BFT225) • • • • • • • • • • • • • • • • • • •
HZVK-87301-P00	MARK, FR. (BFT225) • • • • • • • • • • • • • • • • • • •
HZVL-06115-010	GASKET KIT (BF175/200/225/250) • • • • • • • • • • • • • • • • • E0P-1-1
HZVL-06126-000	BOLT KIT, SEALING (22MM) • • • • • • • • • • • • • • • • • •
HZVL-06160-010	STRAINER ASSY., FUEL (HIGH) • • • • • • • • • • • • • • • • • • •
HZVL-06160-010	STRAINER ASSY., FUEL (HIGH) • • • • • • • • • • • • • • • • • • •
HZVL-06161-000	MAINTENANCE KIT (400) • • • • • • • • • • • • • • • • • •
HZVL-06161-000	MAINTENANCE KIT (400) • • • • • • • • • • • • • • • • • •
HZVL-06161-000	MAINTENANCE KIT (400) • • • • • • • • • • • • • • • • • •
H7VI -06161-000	MAINTENANCE KIT (400)

HZVL-06161-000	MAINTENANCE KIT(400) · · · · · · · · · · · · · · · · · ·	P-18-1-1
HZVL-06161-000	MAINTENANCE KIT (400) · · · · · · · · · · · · · · · · · ·	P-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400) · · · · · · · · · · · · · · · · · ·	P-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400) · · · · · · · · · · · · · · · · · ·	P-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400) · · · · · · · · · · · · · · · · · ·	P-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400) · · · · · · · · · · · · · · · · · ·	P-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400) · · · · · · · · · · · · · · · · · ·	P-18-1-1
HZVL-06161-010	MAINTENANCE KIT (400) · · · · · · · · · · · · · · · · · ·	P-18-1-1
HZVL-06240-P02	BOX KIT, REMOTE CONTROL (FLUSH MOUNT) · · · · · · · · · · · · · · · · · FOF	P-3-4-1
HZVL-06240-P12	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE) (MAIN) FOF	
HZVL-06240-P22	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL) (MAIN) · · · · · · · · · · · · · · · · · · ·	
HZVL-06250-P12	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE) (2ND) · · · · · · · · · · · · · · · · · · ·	
HZVL-06250-P22	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL) (2ND) · · · · · · · · · · · · · · · · · · ·	
HZVL-06323-P01	PANEL KIT, KEY SWITCH (SINGLE) (START) · · · · · · · · · · · · · · · · · · ·	
HZVL-06323-P11	PANEL KIT, KEY SWITCH(SINGLE) (START) · · · · · · · · · · · · · · · · · · ·	
HZVL-06323-P21	PANEL KIT, KEY SWITCH FOF	
HZVL-06323-P31	PANEL KIT, KEY SWITCH FOF	
HZVL-06324-P01	PANEL KIT, START STOP SWITCH (ALL)	
HZVL-06324-P11	PANEL KIT, START STOP SWITCH(TWIN) · · · · · · · · · · · · · · · · · · ·	
HZVL-06324-P11	PANEL KIT, START STOP SWITCH(TRIPLE)	
HZVL-06325-P01	PANEL KIT, POWER TRIM-TILT SWITCH(TWIN) FOR	
	PANEL KIT, POWER TRIM—TILT SWITCH(TRIPLE) · · · · · · · · · · · · · · · · · · ·	
HZVL-06325-P11	PANEL KIT, FUNCTION SWITCH	
HZVL-06326-P01	CABLE KIT, INTERFACE (10FT)	
HZVL-06328-601	CABLE KIT, INTERFACE (10FT)	
HZVL-06328-701		
HZVL-06328-800	CONNECTOR KIT, TERMINATOR · · · · · · · · · · · · · · · · · · ·	
HZVL-06510-010	MAINTENANCE KIT (200) · · · · · · · · · · · · · · · · · ·	
HZVL-11100-020	CRANKCASE COMP. • • • • • • • • • • • • • • • • • • •	
HZVL-11100-030	CRANKCASE COMP. • • • • • • • • • • • • • • • • • • •	
HZVL-11100-900	CRANKCASE COMP. • • • • • • • • • • • • • • • • • • •	
HZVL-11100-900	CRANKCASE COMP. • • • • • • • E-3	
HZVL-11100-900	CRANKCASE COMP. • • • • • • • E-3	
HZVL-11100-901	CRANKCASE COMP. • • • • • • • • E-3	
HZVL-11100-901	CRANKCASE COMP. • • • • • • • • E-3	3-10-1
HZVL-11100-901	CRANKCASE COMP. • • • • • • • • • • • • • • • • • • •	
HZVL-11200-000	COVER ASSY., CRANKCASE UPPER · · · · · · · · · · · · · · · · · · ·	
HZVL-11200-000	COVER ASSY., CRANKCASE UPPER · · · · · · · · · · · · · · · · · · ·	
HZVL-11200-000	COVER ASSY., CRANKCASE UPPER · · · · · · · · · · · · · · · · · · ·	
HZVL-11200-010	COVER ASSY., CRANKCASE UPPER • • • • • • • • • • • • • • • • • • •	3-1
HZVL-11200-010	COVER ASSY., CRANKCASE UPPER · · · · · · · · · · · · · · · · · · ·	
HZVL-11200-010	COVER ASSY., CRANKCASE UPPER · · · · · · · · · · · · · · · · · · ·	3–1
HZVL-11310-000ZA	PAN ASSY., OIL · · · · · · · · · · · · · · · · · · ·	6-1
HZVL-11381-003	PACKING, OIL PAN · · · · · · · · · · · · · · · · · · ·	6-2
HZVL-11381-003	PACKING, OIL PAN·····EOF	P-1-2
HZVL-11820-000	COVER ASSY., R. TIMING BELTE-1	13-10-2
HZVL-11840-000	COVER ASSY., L. TIMING BELT E-1	13-10-3
HZVL-11861-000	PLATE, L. TIMING BELT COVER • • • • • • • • • • • • E-1	13-10-4
HZVL-12000-000ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY · · · · · · · · · · · · E-3	3-3

HZVL-12000-000ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY • • • • • • • • • • • • E-3-3	
HZVL-12000-000ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY • • • • • • • • • • • • E-3-3	
HZVL-12000-010ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY • • • • • • • • • • • • • • • • E-3-3	
HZVL-12000-010ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY • • • • • • • • • • • • • • • • E-3-3	
HZVL-12000-010ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY • • • • • • • • • • • • E-3-3	
HZVL-12000-020ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY • • • • • • • • • • • • E-3-3	
HZVL-12000-020ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY • • • • • • • • • • • • E-3-3	
HZVL-12000-020ZA	BLOCK ASSY., CYLINDER *NH8* DARK GRAY • • • • • • • • • • • • E-3-3	
HZVL-12210-000ZA	HEAD COMP., CYLINDER · · · · · · · · · · · · · · · · · · E-9-5	
HZVL-12210-000ZA	HEAD COMP., CYLINDER · · · · · · · · · · · · · · · · · E-9-5	
HZVL-12210-000ZA	HEAD COMP., CYLINDER · · · · · · · · · · · · · · · · · E-9-5	
HZVL-12210-010ZA	HEAD COMP., CYLINDER · · · · · · · · · · · · · · · · · · E-9-5	
HZVL-12210-010ZA	HEAD COMP., CYLINDER · · · · · · · · · · · · · · · · · · E-9-5	
HZVL-12210-010ZA	HEAD COMP., CYLINDER · · · · · · · · · · · · · · · · · · E-9-5	
HZVL-12231-000	COVER, R. CAMSHAFT THRUST • • • • • • • • • • • • • • • • E-9-7	
HZVL-12310-405ZA	COVER COMP., CYLINDER HEAD (R.) E-1-1	
HZVL-12320-405ZA	COVER COMP., CYLINDER HEAD (L.) · · · · · · · · · · · · · · · E-1-3	
HZVL-13622-000	PLATE, CRANK PULSER · · · · · · · · · · · · · · · · E-13-2	
HZVL-14270-010	PULLEY COMP., L. TIMING BELT DRIVEN E-13-5	
HZVL-14526-415ZA	BASE COMP., TIMING BELT TENSIONER *NH8* DARK GRAY • • • • • • E-13-10	
HZVL-14553-003	BOLT, TIMING BELT IDLER • • • • • • • • • • • • • • E-13-14	
HZVL-14553-003	BOLT, TIMING BELT IDLER • • • • • • • • • • • • • • • • E-13-14	
HZVL-14553-003	BOLT, TIMING BELT IDLER • • • • • • • • • • • • • • • • E-13-14	
HZVL-14553-013	BOLT, TIMING BELT IDLER • • • • • • • • • • • • • • • • • E-13-14	
HZVL-14553-013	BOLT, TIMING BELT IDLER • • • • • • • • • • • • • • • • • E-13-14	
HZVL-14553-013	BOLT, TIMING BELT IDLER • • • • • • • • • • • • • • • • • E-13-14	
HZVL-14553-023	BOLT, TIMING BELT IDLER • • • • • • • • • • • • • • • • • E-13-14	
HZVL-14553-023	BOLT, TIMING BELT IDLER E-13-14	
HZVL-14553-023	BOLT, TIMING BELT IDLER E-13-14	
HZVL-14626-700	ARM COMP. A, EX. ROCKER • • • • • • • • • • • • • • • • • • E-9-10-5	
HZVL-14626-700	ARM COMP. A, EX. ROCKER E-9-10-5	
HZVL-14626-700	ARM COMP. A, EX. ROCKER • • • • • • • • • • • • • • • • E-9-10-5	
HZVL-14627-700	ARM COMP. B, EX. ROCKER · · · · · · · · · · · · · · · · · E-9-10-6	
HZVL-14627-700	ARM COMP. B, EX. ROCKER • • • • • • • • • • • • • • • • E-9-10-6	
HZVL-14627-700	ARM COMP. B, EX. ROCKER \cdot · · · · · · · · · · · · · · · · E-9-10-6	
HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM • • • • • • • • • • • • • • • E-9-10-8	
HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM • • • • • • • • • • • • • • • E-9-10-8	
HZVL-14632-700	SHAFT COMP., EX. ROCKER ARM • • • • • • • • • • • • • • • • E-9-10-8	
HZVL-14645-700	SPRING, ROCKER ARM · · · · · · · · · · · · · · · · · · ·	
HZVL-14645-700	SPRING, ROCKER ARM · · · · · · · · · · · · · · · · · · ·	
HZVL-14645-700	SPRING, ROCKER ARM · · · · · · · · · · · · · · · · · · ·	
HZVL-14646-700	WASHER, THRUST • • • • • • • • • • • • • • • • • • •	
HZVL-14646-700	WASHER, THRUST • • • • • • • • • • • • • • • • • • •	
HZVL-14646-700	WASHER, THRUST • • • • • • • • • • • • • • • • • • •	5
HZVL-15100-000ZA	PUMP ASSY., OIL *NH8**** E-5-1	
HZVL-15100-000ZA	PUMP ASSY., OIL *NH8*···· E-5-1	
HZVL-15100-000ZA	PUMP ASSY., OIL *NH8*···· E-5-1	
HZVL-15100-010ZA	PUMP ASSY., OIL *NH8** · · · · · · · · · · · · · · · · · ·	

HZVL-15100-010ZA	PUMP ASSY., OIL *NH8*····· E-5-1
HZVL-15100-010ZA	PUMP ASSY., OIL *NH8*····· E-5-1
HZVL-15655-000	GAUGE COMP., OIL LEVEL • • • • • • • • • • • • • • • • • • •
HZVL-15656-000	COVER, OIL LEVEL GAUGE • • • • • • • • • • • • • • • • • • •
HZVL-15810-003ZA	VALVE ASSY SPOOL · · · · · · · · · · · · · · · · · ·
HZVL-16015-000	BODY • • • • • • • • • • • • • • • • • • •
HZVL-16020-003	COVER COMP. • • • • • • • • • • • • • • • • • • •
HZVL-16030-003	PUMP UNIT SET A, FUEL · · · · · · · · · · · · · · · E-18-7
HZVL-16176-003	GASKET. THROTTLE BODY · · · · · · · · · · · · · E-15-22
HZVL-16400-003	THROTTLE BODY, ELECTRONIC · · · · · · · · · · · · E-15-23
HZVL-16404-000	SPACER, THROTTLE BODY · · · · · · · · · · · · · · · E-15-24
HZVL-16406-000	GUARD, THROTTLE BODY • • • • • • • • • • • • • • • • • • •
HZVL-16700-003	PUMP ASSY., FUEL • • • • • • • • • • • • • • • • • • •
HZVL-16710-000	RUBBER, FUEL PUMP • • • • • • • • • • • • • • • E-18-30
HZVL-16725-000	STAY COMP. A, FUEL PUMP · · · · · · · · · · · · · E-18-35
HZVL-16726-000	STAY COMP. B, FUEL PUMP • • • • • • • • • • E-18-36
HZVL-16730-023	SEPARATOR ASSY., VAPOR • • • • • • • • • • • • • • • • • • •
HZVL-16730-023	SEPARATOR ASSY., VAPOR • • • • • • • • • • • • • • • • • • •
HZVL-16730-023	SEPARATOR ASSY., VAPOR • • • • • • • • • • • • • • • • • • •
HZVL-16730-033	SEPARATOR ASSY., VAPOR · · · · · · · · · · · · · · · · · · ·
HZVL-16730-033	SEPARATOR ASSY., VAPOR · · · · · · · · · · · · · · · · · · ·
HZVL-16730-033	SEPARATOR ASSY., VAPOR · · · · · · · · · · · · · · · · · · ·
HZVL-16730-043	SEPARATOR ASSY., VAPOR · · · · · · · · · · · · · · · · · · ·
HZVL-16730-043	SEPARATOR ASSY., VAPOR · · · · · · · · · · · · · · · · · · ·
HZVL-16730-043	SEPARATOR ASSY., VAPOR · · · · · · · · · · · · · · · · · · ·
HZVL-16748-000	TUBE, PRESSURE REGULATOR • • • • • • • • • • • • • • • • • • •
HZVL-16755-003	HOSE COMP., FUEL • • • • • • • • • • • • • • • • • • •
HZVL-16760-003	VALVE COMP., RELIEF · · · · · · · · · · · · · · · · · · ·
HZVL-16765-003	HOSE COMP. B, FUEL • • • • • • • • • • • • • • • • • • •
HZVL-16770-A00	TUBE, RELIEF · · · · · · · · · · · · · · · · · · ·
HZVL-16805-003	CUP SET, WATER SEPARATER • • • • • • • • • • • • • • • • • • •
HZVL-16840-A00	TUBE COMP. A, FUEL • • • • • • • • • • • • • • • • • • •
HZVL-16841-000	STAY, FUEL TUBE · · · · · · · · · · · · · · · · · E-18-1-3
HZVL-16850-A00	TUBE COMP. B, FUEL • • • • • • • • • • • • • • • • • • •
HZVL-16860-A00	TUBE COMP. C, FUEL • • • • • • • • • • • • • • • • • • •
HZVL-16870-A00	TUBE D, FUEL • • • • • • • • • • • • • • • • • • •
HZVL-16875-000	JOINT, THREE WAY • • • • • • • • • • • • • • • • • • •
HZVL-16880-A00	TUBE E, FUEL • • • • • • • • • • • • • • • • • • •
HZVL-16890-A00	TUBE F, FUEL • • • • • • • • • • • • • • • • • • •
HZVL-16900-003	STRAINER ASSY., FUEL (LOW) • • • • • • • • • • • • • • • • • • E-18-1-6
HZVL-16910-003	STRAINER COMP., FUEL (HIGH)
HZVL-16914-000	STAY A, FUEL STRAINER · · · · · · · · · · · · · · · E-18-1-9
HZVL-16916-000	STAY B, FUEL STRAINER · · · · · · · · · · · · · · · E-1-6
HZVL-16917-000	SUSPENSION, STRAINER · · · · · · · · · · · · · · · · · · ·
HZVL-17110-003	MANIFOLD COMP., INLET · · · · · · · · · · · · · · · E-14-10-3
HZVL-17131-000ZA	COVER, INTAKE MANIFOLD UPPER • • • • • • • • • • • • • • • • • E-14-10-4
HZVL-17877-900	PLATE, REMOTE CONTROL CABLE • • • • • • • • • • • • • • • • • F-2-2
HZVL-17878-900	COVER, REMOTE CONTROL CABLE F-2-3

SHAFT, THROTTLE ARM MANIFOLD COMP., R. EX. MANIFOLD COMP., L. EX. GASKET, EX. PIPE - GASKET, EX. PIPE - HOUSING, WATER PUMP -	• E-4-2 • E-4-4 • E-6-4 • EOP-1-12 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6
MANIFOLD COMP., L. EX. GASKET, EX. PIPE ·	• E-4-4 • E-6-4 • E0P-1-12 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6
GASKET, EX. PIPE	• E-6-4 • E0P-1-12 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6
GASKET, EX. PIPE	E0P-1-12 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6
HOUSING, WATER PUMP · · · · · · · · · · · · · · · · · · ·	F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6
HOUSING, WATER PUMP · · · · · · · · · · · · · · · · · · ·	F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6
HOUSING, WATER PUMP · · · · · · · · · · · · · · · · · · ·	F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6 F-4-6
HOUSING, WATER PUMP · · · · · · · · · · · · · · · · · · ·	F-4-6 F-4-6 F-4-6 F-4-6 F-4-6
HOUSING, WATER PUMP · · · · · · · · · · · · · · · · · · ·	F-4-6 F-4-6 F-4-6 F-4-6
HOUSING, WATER PUMP · · · · · · · · · · · · · · · · · · ·	F-4-6 F-4-6 F-4-6 F-4-6
HOUSING, WATER PUMP · · · · · · · · · · · · · · · · · · ·	F-4-6 F-4-6 F-4-6
HOUSING, WATER PUMP · · · · · · · · · · · · · · · · · · ·	F-4-6 F-4-6
HOUSING, WATER PUMP · · · · · · · · · · · · · · · · · · ·	F-4-6
HOUSING, WATER PUMP	
	- 4 0
	F-4-6
TUBE, R. WATER RETURN	E-4-6
TUBE, WATER · · · · · · · · · · · · · · · · · · ·	E-6-10-7
SEAT, WATER JOINT	F-3-20-4
SPACER, THERMOSTAT COVER	• E-4-12
COVER, THERMOSTAT · · · · · · · · · · · · · · · · · ·	E-4-13
COVER, R. WATER JACKET	• E-6-10-21
PACKING, WATER JACKET COVER	E-6-10-22
COVER, L. WATER JACKET	• E-6-10-23
COVER ASSY., COOLING FAN	• E-15-10
CASE COMP., MOUNT · · · · · · · · · · · · · · · · · · ·	E-6-10-24
GASKET, MOUNT CASE	• E-6-10-25
GASKET, MOUNT CASE	• E0P-1-13
SPRING COMP., CLICK · · · · · · · · · · · · · · · · · · ·	F-2-1-2
PLATE, SHIFT PIVOT	• F-2-1-8
ROD COMP., ACTUATOR LINK	• F-2-1-9
PIVOT, SHIFT SLIDE · · · · · · · · · · · · · · · · · · ·	• F-2-1-10
PIVOT, THROTTLE · · · · · · · · · · · · · · · · · · ·	F-2-17
PLATE, LOCK · · · · · · · · · · · · · · · · · · ·	F-2-18
GUIDE, SHIFT LINK	F-2-1-12
GUIDE, SHIFT LINK (MECH)	F-2-20
BRACKET, SHIFT LINK (MECH)	F-2-21
SPRING, GEARSHIFT ARM · · · · · · · · · · · · · · · · · · ·	F-2-1-14
LINK ASSY., SHIFT	F-2-1-37
LINK ASSY., SHIFT	F-2-48
BOX ASSY., REMOTE CONTROL	F0P-3-4-2
BOX ASSY., REMOTE CONTROL	
BOX ASSY., REMOTE CONTROL (TOP MOUNT SINGLE) (RH)	
BOX ASSY., REMOTE CONTROL (TOP MOUNT DUAL) (RH)	
	TUBE, R. WATER RETURN TUBE, WATER TUBE, WATER SEAT, WATER JOINT SPACER, THERMOSTAT COVER COVER, THERMOSTAT COVER, R. WATER JACKET PACKING, WATER JACKET COVER, L. WATER JACKET COVER ASSY., COOLING FAN CASE COMP., MOUNT GASKET, MOUNT CASE GASKET, MOUNT CASE SPRING COMP., CLICK PLATE, SHIFT PIVOT ROD COMP., ACTUATOR LINK PIVOT, SHIFT SLIDE PIVOT, THROTTLE PLATE, LOCK GUIDE, SHIFT LINK (MECH) BRACKET, SHIFT LINK (MECH) SPRING, GEARSHIFT ARM LINK ASSY., SHIFT LINK ASSY., SHIFT BOX ASSY., REMOTE CONTROL BOX ASSY., REMOTE CONTROL BOX ASSY., REMOTE CONTROL BOX ASSY., REMOTE CONTROL BOX ASSY., REMOTE CONTROL

HZVL-24800-P21	BOX ASSY., REMOTE CONTROL (TOP MOUNT DUAL) (RH) • • • • • • • FOP-3-8-2
HZVL-24801-003	BAND, NYLON · · · · · · · · · · · · · · · · · · ·
HZVL-24801-601	GASKET (SINGLE) · · · · · · · · · · · · · · · · · · ·
HZVL-24801-601	GASKET (SINGLE) · · · · · · · · · · · · · · · · · · ·
HZVL-24801-701	GASKET (TWIN) · · · · · · · · · · · · · · · · · · ·
HZVL-24801-701	GASKET (TWIN) · · · · · · · · · · · · · · · · · · ·
HZVL-24802-003	BOLT, SOCKET · · · · · · · · · · · · · · · · · · ·
HZVL-24802-701	COVER, CAP · · · · · · · · · · · · · · · · · · ·
HZVL-24802-701	COVER. CAP
HZVL-24802-701	COVER, CAP
HZVL-24802-701	COVER, CAP
HZVL-24803-601	PLATE, COVER FIX (SINGLE) · · · · · · · · · · · · · · · · · · ·
HZVL-24803-601	PLATE, COVER FIX (SINGLE) · · · · · · · · · · · · · · · · · · ·
HZVL-24803-701	PLATE, COVER FIX (SINGLE) PLATE, COVER FIX (TWIN) PLATE, COVER FIX (SINGLE) PLAT
HZVL-24803-701	PLATE, COVER FIX (TWIN) · · · · · · · · · · · · · · · · · · ·
	SHEET, WATER PROOF (SINGLE) · · · · · · · · · · · · · · · · · · ·
HZVL-24804-601	SHEET, WATER PROOF (SINGLE) FOP-3-5-6 SHEET, WATER PROOF (SINGLE) FOP-3-7-6
HZVL-24804-601	SHEET, WATER PROOF (TWIN) · · · · · · · · · · · · · · · · · · ·
HZVL-24804-701	
HZVL-24804-701	SHEET, WATER PROOF (TWIN) · · · · · · · · · · · · · · · · · · ·
HZVL-24805-701	BOLT, SOCKET
HZVL-24805-701	BOLT, SOCKET
HZVL-24805-701	BOLT, SOCKET · · · · · · · · · · · · · · · · · · ·
HZVL-24805-701	BOLT, SOCKET · · · · · · · · · · · · · · · · · · ·
HZVL-24806-701	SCREW F0P-3-5-8
HZVL-24806-701	SCREW F0P-3-6-8
HZVL-24806-701	SCREW FOP-3-7-8
HZVL-24806-701	SCREW F0P-3-8-8
HZVL-24807-701	BAND, NYLON · · · · · · · FOP-3-5-9
HZVL-24807-701	BAND, NYLON · · · · · · FOP-3-6-9
HZVL-24807-701	BAND, NYLON···· FOP-3-7-9
HZVL-24807-701	BAND, NYLON···· FOP-3-8-9
HZVL-24810-003	HOUSING ASSY. (FLUSH MOUNT) • • • • • • • • • • • • • • • • • • •
HZVL-24810-701	HOUSING ASSY., L. · · · · · · · · · · · · · · · · · ·
HZVL-24810-701	HOUSING ASSY., L. · · · · · · · · · · · · · · · · · ·
HZVL-24810-701	HOUSING ASSY., L. · · · · · · · · · · · · · · · · · ·
HZVL-24810-701	HOUSING ASSY., L. · · · · · · · · · · · · · · · · · ·
HZVL-24811-003	COLLAR, STOPPER · · · · · · · · · · · · · · · · · · ·
HZVL-24811-701	SHOE, BRAKE · · · · · · · · · · · · · · · · · · ·
HZVL-24811-701	SHOE, BRAKE • • • • • • • • • • • • • • • • • • •
HZVL-24811-701	SHOE, BRAKE • • • • • • • • • • • • • • • • • • •
HZVL-24811-701	SHOE, BRAKE • • • • • • • • • • • • • • • • • • •
HZVL-24811-701	SHOE, BRAKE • • • • • • • • • • • • • • • • • • •
HZVL-24812-003	SCREW F0P-3-4-8
HZVL-24812-701	PLATE, HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-24812-701	PLATE, HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-24812-701	PLATE, HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-24812-701	PLATE, HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-24813-701	BOLT, STUD FOP-3-5-13

HZVL-24813-701	BOLT, STUD • • • • • • • • • • • • • • • • • • •
HZVL-24813-701	BOLT, STUD • • • • • • • • • • • • • • • • • • •
HZVL-24813-701	BOLT, STUD • • • • • • • • • • • • • • • • • • •
HZVL-24814-701	BOLT FOP-3-5-14
HZVL-24814-701	BOLT FOP-3-6-14
HZVL-24814-701	BOLT FOP-3-7-14
HZVL-24814-701	BOLT FOP-3-8-14
HZVL-24815-701	SCREW FOP-3-4-9
HZVL-24815-701	SCREW FOP-3-5-15
HZVL-24815-701	SCREW F0P-3-6-15
HZVL-24815-701	SCREW FOP-3-7-15
HZVL-24815-701	SCREW FOP-3-8-15
HZVL-24816-701	SCREW SET · · · · · · · FOP-3-4-10
HZVL-24816-701	SCREW SET · · · · · · · FOP-3-5-16
HZVL-24816-701	SCREW SET · · · · · · · FOP-3-6-16
HZVL-24816-701	SCREW SET · · · · · · · · FOP-3-7-16
HZVL-24816-701	SCREW SET FOP-3-8-16
HZVL-24817-701	SCREW SET FOP-3-4-11
HZVL-24817-701	SCREW SET FOP-3-5-17
HZVL-24817-701	SCREW SET FOP-3-6-17
HZVL-24817-701	SCREW SET FOP-3-7-17
HZVL-24817-701	SCREW SET FOP-3-8-17
HZVL-24820-601	HOUSING ASSY., SINGLE · · · · · · · · · · · · · · · · · · ·
HZVL-24820-601	HOUSING ASSY., SINGLE · · · · · · · · · · · · · · · · · · ·
HZVL-24820-701	HOUSING ASSY., R. · · · · · · · · · · · · · · · · · ·
HZVL-24820-701	HOUSING ASSY., R. · · · · · · · · · · · · · · · · · ·
HZVL-24830-003	COVER ASSY. (FLUSH MOUNT) • • • • • • • • • • • • • • • • • • •
HZVL-24830-P11	COVER ASSY., SINGLE FOP-3-5-19
HZVL-24830-P11	COVER ASSY., SINGLE · · · · · · · · · · · · · · · · · · ·
HZVL-24830-P21	COVER ASSY., TWIN · · · · · · · · · · · · · · · · · · ·
HZVL-24830-P21	COVER ASSY., TWIN · · · · · · · · · · · · · · · · · · ·
HZVL-24831-003	SHEET, WATER PROOF · · · · · · · · · · · · · · · · · ·
HZVL-24831-P11	LED ASSY., COVER(S) FOP-3-5-20
HZVL-24831-P11	LED ASSY., COVER(S) FOP-3-7-20
HZVL-24831-P21	LED ASSY., COVER(T) FOP-3-6-20
HZVL-24831-P21	LED ASSY., COVER(T) FOP-3-8-20
HZVL-24832-701	BAND, NYLON · · · · · · · · · · · · · · · · · · ·
HZVL-24832-701	BAND, NYLON · · · · · · · · · · · · · · · · · · ·
HZVL-24832-701	BAND, NYLON · · · · · · · · · · · · · · · · · · ·
HZVL-24832-701	BAND, NYLON · · · · · · · · · · · · · · · · · · ·
HZVL-24840-003	NUT SET, MOUNTING · · · · · · · · · · · · · · · · · · ·
HZVL-24840-701	NUT SET, MOUNTING · · · · · · · · · · · · · · · · · · ·
HZVL-24840-701	NUT SET, MOUNTING · · · · · · · · · · · · · · · · · · ·
HZVL-24840-701	NUT SET, MOUNTING · · · · · · · · · · · · · · · · · · ·
HZVL-24840-701	NUT SET, MOUNTING · · · · · · · · · · · · · · · · · · ·
HZVL-24841-003	NUT, NYLON • • • • • • • • • • • • • • • • • • •
HZVL-24841-701	NUT · · · · · · · · · · · · · · · · · · ·
HZVL-24841-701	NUT F0P-3-5-23

HZVL-24841-701	NUT FOP-3-6-23
HZVL-24841-701	NUT FOP-3-7-23
HZVL-24841-701	NUT FOP-3-8-23
HZVL-24842-003	WASHER FOP-3-4-17
HZVL-24842-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24842-701	WASHER • • • • • • • • • FOP-3-6-24
HZVL-24842-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24842-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24843-003	BOLT • • • • • • • • • • • • • • • • • • •
HZVL-24850-003	BASE ASSY. (FLUSH MOUNT) · · · · · · · · · · · · · · · · · · ·
HZVL-24851-003	COLLAR, BASE · · · · · · · · · · · · · · · · · · ·
HZVL-24870-701	LEVER ASSY., L. · · · · · · · · · · · · · · · · · ·
HZVL-24870-701	LEVER ASSY., L. · · · · · · · · · · · · · · · · · ·
HZVL-24870-701	LEVER ASSY., L. · · · · · · · · · · · · · · · · · ·
HZVL-24870-701	LEVER ASSY., L. · · · · · · · · · · · · · · · · · ·
HZVL-24870-P01	LEVER ASSY. (FLUSH MOUNT) • • • • • • • • • • • • • • • • • • •
HZVL-24871-701	LEVER FOP-3-5-26
HZVL-24871-701	LEVER FOP-3-6-26
HZVL-24871-701	LEVER FOP-3-7-26
HZVL-24871-701	LEVER FOP-3-8-26
HZVL-24872-701	PANEL, LEVER (POWER TRIM-TILT)
HZVL-24872-701	PANEL, LEVER (POWER TRIM-TILT) • • • • • • • • • • • • • • • • FOP-3-6-27
HZVL-24872-701	PANEL, LEVER (POWER TRIM-TILT)
HZVL-24872-701	PANEL, LEVER (POWER TRIM-TILT)
HZVL-24872-P01	PANEL, LEVER (FLUSH MOUNT) · · · · · · · · · · · · · · · · · · FOP-3-4-22
HZVL-24873-003	CAP, LEVER(FLUSH MOUNT) · · · · · · · · · · · · · · · · · · ·
HZVL-24873-701	CAP, LEVER • • • • • • • • • • • • • • • • • • •
HZVL-24873-701	CAP, LEVER • • • • • • • • • • • • • • • • • • •
HZVL-24873-701	CAP, LEVER • • • • • • • • • • • • • • • • • • •
HZVL-24873-701	CAP, LEVER • • • • • • • • • • • • • • • • • • •
HZVL-24874-003	PLATE, LEVER PANEL • • • • • • • • • • • • • • • • • • •
HZVL-24874-701	PLATE, LEVER PANEL • • • • • • • • • • • • • • • • • • •
HZVL-24874-701	PLATE, LEVER PANEL • • • • • • • • • • • • • • • • • • •
HZVL-24874-701	PLATE, LEVER PANEL • • • • • • • • • • • • • • • • • • •
HZVL-24874-701	PLATE, LEVER PANEL • • • • • • • • • • • • • • • • • • •
HZVL-24875-003	SPRING, COIL FOP-3-4-25
HZVL-24875-701	BOLT FOP-3-4-26
HZVL-24875-701	BOLT FOP-3-5-30
HZVL-24875-701	BOLT FOP-3-6-30
HZVL-24875-701	BOLT FOP-3-7-30
HZVL-24875-701	BOLT FOP-3-8-30
HZVL-24876-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24876-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24876-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24876-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24876-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24877-701	SCREW FOP-3-4-28
HZVL-24877-701	SCREW FOP-3-5-32
	, and a second s

HZVL-24877-701	SCREW FOP-3-6-32
HZVL-24877-701	SCREW FOP-3-7-32
HZVL-24877-701	SCREW FOP-3-8-32
HZVL-24878-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24878-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24878-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24878-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24878-701	WASHER • • • • • • • • • • • • • • • • • • •
HZVL-24879-701	SCREW F0P-3-5-34
HZVL-24879-701	SCREW F0P-3-6-34
HZVL-24879-701	SCREW F0P-3-7-34
HZVL-24879-701	SCREW F0P-3-8-34
HZVL-24880-701	LEVER ASSY., R. · · · · · · · · · · · · · · · · · ·
HZVL-24880-701	LEVER ASSY., R. · · · · · · · · · · · · · · · · · ·
HZVL-24881-701	PANEL, LEVER • • • • • • • • • • • • • • • • • • •
HZVL-24881-701	PANEL, LEVER FOP-3-8-36
HZVL-30416-000	CASE, ELECTRONIC PARTS • • • • • • • • • • • • • • • • • • •
HZVL-30416-000	CASE, ELECTRONIC PARTS • • • • • • • • • • • • • • • • • • •
HZVL-30416-000	CASE, ELECTRONIC PARTS • • • • • • • • • • • • • • • • • • •
HZVL-30416-010	CASE, ELECTRONIC PARTS • • • • • • • • • • • • • • • • • E-20-10-1
HZVL-30416-010	CASE, ELECTRONIC PARTS · · · · · · · · · · · · · · · · · · ·
HZVL-30416-010	CASE, ELECTRONIC PARTS · · · · · · · · · · · · · · · · · · ·
HZVL-30416-010	CASE, ELECTRONIC PARTS • • • • • • • • • • • • • • • • • • •
HZVL-30416-020	CASE, ELECTRONIC PARTS • • • • • • • • • • • • • • • • • • •
HZVL-30416-020	CASE, ELECTRONIC PARTS • • • • • • • • • • • • • • • • • • •
HZVL-30416-020	CASE, ELECTRONIC PARTS • • • • • • • • • • • • • • • • • • •
HZVL-30420-000	CASE, CONTROL UNIT · · · · · · · · · · · · · · · · · · ·
HZVL-30420-000	CASE, CONTROL UNIT · · · · · · · · · · · · · · · · · · ·
HZVL-30420-000	CASE, CONTROL UNIT · · · · · · · · · · · · · · · · · · ·
HZVL-30420-000	CASE, CONTROL UNIT
HZVL-30420-000	CASE, CONTROL UNIT · · · · · · · · · · · · · · · · · · ·
HZVL-30520-003	COIL ASSY., PLUG TOP · · · · · · · · · · · · · · · · · · ·
HZVL-30525-000	STAY COMP., PLUG TOP COIL · · · · · · · · · · · · · · · · · E-20-2
HZVL-30531-000	GUARD, R. PLUG TOP COIL SIDE · · · · · · · · · · · · · · · · · E-20-8
HZVL-30536-000	GUARD, L. PLUG TOP COIL SIDE · · · · · · · · · · · · · · · · · E-20-9
HZVL-31575-010	HARNESS ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZVL-31575-010	HARNESS ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZVL-31575-010	HARNESS ASSY., POWER F-7-10-27
HZVL-31576-000	CORD ASSY., EXTENSION POWER FOP-10-6
HZVL-31637-000	STAY, A. C. GENERATOR · · · · · · · · · · · · · · · · · · ·
HZVL-32101-000	BRACKET, A. C. GENERATOR FUSE · · · · · · · · · · · · · · · · E-20-10-3
HZVL-32102-000	BRACKET, COUPLER A · · · · · · · · · · · · · · · · · ·
HZVL-32103-000	BRACKET, COUPLER C · · · · · · · · · · · · · · · · · ·
HZVL-32104-000	BRACKET, FUEL PUMP COUPLER • • • • • • • • • • • • • • • • • • •
*	- · ·

HZVL-32106-000	BRACKET, JUNCTION CONNECTOR • • • • • • • • • • • • • • • • • • •	F-7-2
HZVL-32107-003	TERMINATOR ASSY.	∙ F-7-3
HZVL-32107-003	TERMINATOR ASSY	F0P-3-4-31
HZVL-32107-003	TERMINATOR ASSY	F0P-3-5-36
HZVL-32107-003	TERMINATOR ASSY	F0P-3-6-38
HZVL-32107-003	TERMINATOR ASSY	F0P-3-7-36
HZVL-32107-003	TERMINATOR ASSY	F0P-3-8-38
HZVL-32108-003	DUMMY, WATER PROOF CONNECTOR • • • • • • • • • • • • • • • • • • •	• F-7-3
HZVL-32108-003	DUMMY, WATER PROOF CONNECTOR • • • • • • • • • • • • • • • • • • •	• F0P-3-7-38
HZVL-32108-003	DUMMY, WATER PROOF CONNECTOR • • • • • • • • • • • • • • • • • • •	F0P-3-8-40
HZVL-32111-000	BRACKET, COUPLER D	• E−13−18
HZVL-32114-000	BRACKET, CLIP B	E-1-9
HZVL-32114-000	BRACKET, CLIP B · · · · · · · · · · · · · · · · · ·	E-3-21
HZVL-32193-000	CORD, SWITCH · · · · · · · · · · · · · · · · · · ·	• E−3−22
HZVL-32320-P01	PANEL ASSY., POWER TRIM-TILT SWITCH(TWIN)	F0P-6-3
HZVL-32320-P11	PANEL ASSY., POWER TRIM-TILT SWITCH(TRIPLE)	
HZVL-32326-P01	PANEL, POWER TRIM-TILT SWITCH(TWIN)	
HZVL-32326-P11	PANEL, POWER TRIM-TILT SWITCH(TRIPLE)	
HZVL-32340-P01	PANEL ASSY., START STOP(ALL) · · · · · · · · · · · · · · · · · ·	
HZVL-32340-P11	PANEL ASSY., START STOP(TWIN)	
HZVL-32340-P21	PANEL ASSY., START STOP (TRIPLE)	
HZVL-32344-P11	PANEL COMP., START STOP (TWIN)	
HZVL-32344-P21	PANEL COMP., START STOP(TRIPLE)	
HZVL-32346-P01	PANEL, START STOP(ALL) · · · · · · · · · · · · · · · · · ·	F0P-6-1-9
HZVL-32351-P01	PANEL ASSY., FUNCTION SWITCH	F0P-6-2-2
HZVL-32354-P01	PANEL COMP., FUNCTION SWITCH	
HZVL-32357-003	SUB HARNESS ASSY., FUNCTION SWITCH	
HZVL-32370-013	BOX ASSY., JUNCTION	
HZVL-32371-003	COVER COMP., FUSE · · · · · · · · · · · · · · · · · · ·	F-7-20-2
HZVL-32380-P01	PANEL ASSY., KEY SWITCH(START)	F0P-5-5-3
HZVL-32380-P11	PANEL ASSY., KEY SWITCH(START)	
HZVL-32380-P21	PANEL ASSY., KEY SWITCH	F0P-5-5-3
HZVL-32380-P31	PANEL ASSY., KEY SWITCH	F0P-5-5-4
HZVL-32386-P01	PANEL, KEY SWITCH(START) · · · · · · · · · · · · · · · · · · ·	• F0P-5-5-5
HZVL-32386-P11	PANEL, KEY SWITCH(START) · · · · · · · · · · · · · · · · · · ·	F0P-5-5-6
HZVL-32386-P21	PANEL, KEY SWITCH	F0P-5-5-5
HZVL-32386-P31	PANEL, KEY SWITCH	F0P-5-5-6
HZVL-32390-P01	PANEL ASSY., EMERGENCY STOP	F0P-3-7-40
HZVL-32390-P01	PANEL ASSY., EMERGENCY STOP	F0P-3-8-42
HZVL-32396-P01	PANEL, EMERGENCY STOP SWITCH	F0P-3-7-41
HZVL-32396-P01	PANEL, EMERGENCY STOP SWITCH	F0P-3-8-43
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-000	CABLE ASSY., STARTER	
HZVL-32410-000	CABLE ASSY., STARTER	F-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER	F-7-10-3

HZVL-32410-010	CABLE ASSY., STARTER · · · · · · · · · · · · · · · · · · ·	-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER · · · · · · · · · · · · · · · · · · ·	-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER	-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER	-7-10-3
HZVL-32410-010	CABLE ASSY., STARTER	-7-10-3
HZVL-32421-000	PLATE, STARTER CABLE	-7-10-8
HZVL-32530-010	CABLE ASSY., REMOTE CONTROL	0P-3-4-34
HZVL-32530-010	CABLE ASSY., REMOTE CONTROL	0P-3-5-39
HZVL-32530-010	CABLE ASSY., REMOTE CONTROL (MAIN)	OP-3-6-41
HZVL-32530-600	CABLE ASSY., REMOTE CONTROL (2ND) · · · · · · · · · · · · · · F	
HZVL-32530-600	CABLE ASSY., REMOTE CONTROL (2ND) · · · · · · · · · · · · · · F	
HZVL-32531-000	HARNESS ASSY., LOAD SIGNAL · · · · · · · · · · · · · · · · · · ·	
HZVL-32540-600	CABLE ASSY. BRANCH F	
HZVL-32580-600	CABLE ASSY., TRUNK (DBW) (18FT) · · · · · · · · · · · · · · · F	
HZVL-32580-700	CABLE ASSY., TRUNK (DBW) (24FT) · · · · · · · · · · · · · · · F	
HZVL-32580-800	CABLE ASSY., TRUNK (DBW) (30FT) · · · · · · · · · · · · · · · F	
HZVL-32580-900	CABLE ASSY. PANEL INDICATOR · · · · · · · · · · · · · · · · · · ·	
HZVL-32580-910	CABLE ASSY., PANEL INDICATOR · · · · · · · · · · · · · · · · · · ·	
HZVL-32580-920	CABLE ASSY., PANEL INDICATOR · · · · · · · · · · · · · · · · · · ·	
HZVL-32590-600	CABLE ASSY., ENGINE DROP (6FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32590-700	CABLE ASSY. ENGINE DROP (10FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32590-800	CABLE ASSY. ENGINE DROP (14FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32590-810	CABLE ASSY., ENGINE DROP (SINGLE 16FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32590-820	CABLE ASSY., ENGINE DROP (SINGLE 20FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32590-830	CABLE ASSY., ENGINE DROP (SINGLE 25FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32590-840	CABLE ASSY., ENGINE DROP (SINGLE 30FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32590-901	CABLE ASSY., CONVERSION (6FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32590-911	CABLE ASSY., CONVERSION (10FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32800-600	CABLE ASSY., INTERFACE(10FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32800-700	CABLE ASSY., INTERFACE (16FT)	
HZVL-32806-000	TERMINATOR (M) · · · · · · · · · · · · · · · · · · ·	
HZVL-32807-000	TERMINATOR (F)	
HZVL-32815-000	CABLE ASSY., NETWORK (6FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32815-600	CABLE ASSY., NETWORK (16FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32815-700	CABLE ASSY. NETWORK (32FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-32815-800	CABLE ASSY., NETWORK (49FT) · · · · · · · · · · · · · · · · · · ·	
HZVL-34330-013	CONTROL UNIT F	
HZVL-34330-013	CONTROL UNIT	
HZVL-34330-013	CONTROL UNIT · · · · · · · · · · · · · · · · · · ·	
HZVL-34330-013	CONTROL UNIT · · · · · · · · · · · · · · · · · · ·	
HZVL-34330-013	CONTROL UNIT · · · · · · · · · · · · · · · · · · ·	
HZVL-34750-063	CONTROL UNIT, ELECTRONIC E	
HZVL-34750-901	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·	
HZVL-34750-901	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·	
HZVL-34750-902	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·	
HZVL-34750-902	CONTROL UNIT, ELECTRONIC E	
HZVL-34750-903	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·	
HZVL-34750-903	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·	
11212 04/00-304	OUNTROL UNIT, LELUTIONIU	20 10-0

HZVL-34750-904	CONTROL UNIT, ELECTRONIC · · · · · · · · · · · · · · · · · · ·
HZVL-34754-000	CASE, ELECTRONIC CONTROL UNIT • • • • • • • • • • • • • • • E-20-10-7
HZVL-35100-P01	SWITCH ASSY., COMBINATION(START) • • • • • • • • • • • • • • • • • • •
HZVL-35100-P11	SWITCH ASSY., COMBINATION · · · · · · · · · · · · · · · · · · FOP-5-5-7
HZVL-35330-701	SWITCH ASSY., SELECT • • • • • • • • • • • • • • • • • • •
HZVL-35330-701	SWITCH ASSY., SELECT • • • • • • • • • • • • • • • • • • •
HZVL-35330-701	SWITCH ASSY., SELECT · · · · · · · · · · · · · · · · · · ·
HZVL-35330-701	SWITCH ASSY., SELECT · · · · · · · · · · · · · · · · · · ·
HZVL-35370-003	SWITCH ASSY., POWER TRIM-TILT · · · · · · · · · · · · · · · · FOP-3-4-37
HZVL-35370-701	SWITCH ASSY., POWER TRIM-TILT FOP-3-5-43
HZVL-35370-701	SWITCH ASSY., POWER TRIM-TILT • • • • • • • • • • • • • • • FOP-3-6-45
HZVL-35370-701	SWITCH ASSY., POWER TRIM-TILT FOP-3-7-46
HZVL-35370-701	SWITCH ASSY., POWER TRIM-TILT FOP-3-8-48
HZVL-35477-000	COVER, NEUTRAL SWITCH · · · · · · · · · · · · · · · · · · F-2-25
HZVL-35477-000	COVER, NEUTRAL SWITCH · · · · · · · · · · · · · · · · · · F-2-1-17
HZVL-35640-003	SWITCH ASSY., POWER TILT
HZVL-36104-000	TUBE, SPIRAL (12X14. 6) • • • • • • • • • • • • • • • • • •
HZVL-36180-003	SWITCH ASSY., EMERGENCY STOP · · · · · · · · · · · · · · · · · · ·
HZVL-36180-003	SWITCH ASSY., EMERGENCY STOP · · · · · · · · · · · · · · · · · FOP-3-8-49
HZVL-36180-003	SWITCH ASSY., EMERGENCY STOP · · · · · · · · · · · · · · · · · FOP-5-5-8
HZVL-36520-003	ACTUATOR ASSY., SHIFT
HZVL-36521-000	BRACKET, SHIFT ACTUATOR • • • • • • • • • • • • • • • • • F-18-2
HZVL-36522-000	RUBBER, CUSHION · · · · · · · · · · · · · · · · · · ·
HZVL-37831-000	STAY, MAP SENSOR · · · · · · · · · · · · · · · · · · ·
HZVL-37832-000	COLLAR, 5.5X6.8 · · · · · · · · · · · · · · · · · · ·
HZVL-37832-000	COLLAR, 5.5X6.8 · · · · · · · · · · · · · · · · · · ·
HZVL-37832-000	COLLAR, 5.5X6.8 · · · · · · E-14-10-8
HZVL-37832-010	COLLAR, 5.5X6.8 · · · · · · E-14-10-8
HZVL-37832-010	COLLAR, 5.5X6.8 · · · · · · E-14-10-8
HZVL-37832-010	COLLAR, 5.5X6.8 · · · · · · E-14-10-8
HZVL-38216-901	COVER ASSY., FUSE (3A) • • • • • • • • • • • • • • • • • • •
HZVL-38550-003	RELAY ASSY., POWER TILT F-7-10-10
HZVL-40100-000	CASE ASSY., ENGINE UNDER · · · · · · · · · · · · · · · · · · ·
HZVL-40100-000	CASE ASSY., ENGINE UNDER • • • • • • • • • • • • • • • • • • •
HZVL-40100-000	CASE ASSY., ENGINE UNDER • • • • • • • • • • • • • • • • • • •
HZVL-40100-000	CASE ASSY., ENGINE UNDER • • • • • • • • • • • • • • • • • • •
HZVL-40100-000	CASE ASSY., ENGINE UNDER · · · · · · · · · · · · · · · · · · ·
HZVL-40100-000	CASE ASSY., ENGINE UNDER · · · · · · · · · · · · · · · · · · ·
HZVL-40100-010	CASE ASSY., ENGINE UNDER • • • • • • • • • • • • • • • • • • •
HZVL-40100-010	CASE ASSY., ENGINE UNDER • • • • • • • • • • • • • • • • • • •
HZVL-40100-010	CASE ASSY., ENGINE UNDER • • • • • • • • • • • • • • • • • • •
HZVL-40100-010	CASE ASSY., ENGINE UNDER · · · · · · · · · · · · · · · · · · ·
HZVL-40100-010	CASE ASSY., ENGINE UNDER · · · · · · · · · · · · · · · · · · ·
HZVL-40100-010	CASE ASSY., ENGINE UNDER · · · · · · · · · · · · · · · · · · ·
HZVL-40102-000	SEAL A, UNDER CASE · · · · · · · · · · · · · · · · · · ·
HZVL-40103-000	SEAL B, UNDER CASE · · · · · · · · · · · · · · · · · · ·
HZVL-40105-000	GROMMET, UNDER CASE · · · · · · · · · · · · · · · · · · ·
HZVL-40105-900	GROMMET, UNDER CASE (MECH) • • • • • • • • • • • • • • • • F-3-20-12

HZVL-40110-000	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-000	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-000	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-000	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-000	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-000	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-010	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-010	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-010	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-010	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-010	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40110-010	STAY COMP., HARNESS · · · · · · · · · · · · · · · · · ·
HZVL-40116-000	PORT, IDLE EXHAUST · · · · · · · · · · · · · · · · · · ·
HZVL-40151-000	COVER, SEPARATE · · · · · · · · · · · · · · · · · · ·
HZVL-40154-000	BRACKET, UNDER CASE FR. • • • • • • • • • • • • • • • • • F-3-20-16
HZVL-40201-000	CASE, EXTENSION(XL) · · · · · · · · · · · · · · · · · · ·
HZVL-40201-900	CASE, EXTENSION(L) · · · · · · · · · · · · · · · · · · ·
HZVL-40209-000	RUBBER, DRAIN PLUG·····F-3-20-19
HZVL-41100-000ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-000ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-000ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-010ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-010ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-010ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-020ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-020ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-020ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-030ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-030ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-030ZA	CASE ASSY., GEAR(XL) *T107* BAY BLUE · · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-600ZC	CASE ASSY., GEAR(UL) *T107* BAY BLUE · · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-601ZC	CASE ASSY., GEAR(UL) *T107* BAY BLUE · · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-602ZC	CASE ASSY., GEAR(UL) *T107* BAY BLUE · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-603ZC	CASE ASSY., GEAR(UL) *T107* BAY BLUE · · · · · · · · · · · · · · · F-3-10-1
HZVL-41100-700ZA	CASE ASSY., GEAR(XL) *T107* (COUNTER ROTATION) BAY BLUE • • • • • F-3-10-1
HZVL-41100-700ZA	CASE ASSY., GEAR(XL) *T107* (COUNTER ROTATION) BAY BLUE • • • • • F-3-10-1
HZVL-41100-700ZA	CASE ASSY., GEAR(XL) *T107* (COUNTER ROTATION) BAY BLUE • • • • • F-3-10-1
HZVL-41100-701ZA	CASE ASSY., GEAR(XL) *T107* (COUNTER ROTATION) BAY BLUE • • • • • F-3-10-1
HZVL-41100-701ZA	CASE ASSY., GEAR(XL) *T107* (COUNTER ROTATION) BAY BLUE • • • • • F-3-10-1
HZVL-41100-702ZA	CASE ASSY., GEAR(XL) *T107* (COUNTER ROTATION) BAY BLUE • • • • • F-3-10-1
HZVL-41100-702ZA	CASE ASSY., GEAR(XL) *T107* (COUNTER ROTATION) BAY BLUE • • • • • F-3-10-1
HZVL-41100-702ZA	CASE ASSY., GEAR(XL) *T107* (COUNTER ROTATION) BAY BLUE • • • • • F-3-10-1
HZVL-41100-703ZA	CASE ASSY., GEAR(XL) *T107* (COUNTER ROTATION) BAY BLUE • • • • • F-3-10-1
HZVL-41100-703ZA	CASE ASSY., GEAR(XL) *T107* (COUNTER ROTATION) BAY BLUE • • • • • F-3-10-1
HZVL-41100-800ZC	CASE ASSY., GEAR(UL) *T107*(COUNTER ROTATION) BAY BLUE · · · · · · F-3-10-1
HZVL-41100-801ZC	CASE ASSY., GEAR(UL) *T107*(COUNTER ROTATION) BAY BLUE · · · · · · F-3-10-1
HZVL-41100-900ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE · · · · · · · · · · · · · F-3-10-1
HZVL-41100-900ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE · · · · · · · · · · · · · F-3-10-1

HZVL-41100-901ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE • • • • • • • • • • • • • F-3-10-1
HZVL-41100-901ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE • • • • • • • • • • • • F-3-10-1
HZVL-41100-901ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE • • • • • • • • • • • • F-3-10-1
HZVL-41100-902ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE • • • • • • • • • • • • F-3-10-1
HZVL-41100-902ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE • • • • • • • • • • • • • F-3-10-1
HZVL-41100-902ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE • • • • • • • • • • • • F-3-10-1
HZVL-41100-903ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE • • • • • • • • • • • • F-3-10-1
HZVL-41100-903ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE • • • • • • • • • • • • F-3-10-1
HZVL-41100-903ZA	CASE ASSY., GEAR(L) *T107* BAY BLUE • • • • • • • • • • • • F-3-10-1
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE • • • • • • • • • • • F-5-1-12
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE • • • • • • • • • • • F-5-1-12
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE • • • • • • • • • • • F-5-1-12
HZVL-41201-000ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE • • • • • • • • • • • F-5-1-12
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · · ·
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · F-5-11
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* · · · · · · · · · · · · · · · · · · ·
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE • • • • • • • • • • • F-5-1-12
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE • • • • • • • • • • • F-5-1-12
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE • • • • • • • • • • • F-5-1-12
HZVL-41201-010ZA	HOLDER, PROPELLER SHAFT *T107* BAY BLUE • • • • • • • • • • • F-5-1-12
HZVL-50100-000	FRAME COMP., MOUNTING(XL) · · · · · · · · · · · · · · · · · · F-10-13
HZVL-50100-000	FRAME COMP., MOUNTING(XL) · · · · · · · · · · · · · · · · · · F-10-13
HZVL-50100-000	FRAME COMP., MOUNTING(XL) • • • • • • • • • • • • • • • • • • F-10-13
HZVL-50100-000	FRAME COMP., MOUNTING(XL) • • • • • • • • • • • • • • • • • • F-10-13
HZVL-50100-000	FRAME COMP., MOUNTING(XL) • • • • • • • • • • • • • • • • • • F-10-13
HZVL-50100-000	FRAME COMP., MOUNTING(XL) · · · · · · · · · · · · · · · · · · F-10-13
HZVL-50100-010	FRAME COMP., MOUNTING(XL) • • • • • • • • • • • • • • • • • • F-10-13
HZVL-50100-010	FRAME COMP., MOUNTING(XL) • • • • • • • • • • • • • • • • • • F-10-13
HZVL-50100-010	FRAME COMP., MOUNTING(XL) • • • • • • • • • • • • • • • • • • F-10-13
HZVL-50100-010	FRAME COMP., MOUNTING(XL) • • • • • • • • • • • • • • • • • • F-10-13
HZVL-50100-010	FRAME COMP., MOUNTING(XL) • • • • • • • • • • • • • • • • • • F-10-13
HZVL-50100-900	FRAME COMP., MOUNTING(L) • • • • • • • • • • • • • • • • • • •
HZVL-50100-900	FRAME COMP., MOUNTING(L) • • • • • • • • • • • • • • • • • • •
HZVL-50100-900	FRAME COMP., MOUNTING(L) • • • • • • • • • • • • • • • • • • •
HZVL-50100-901	FRAME COMP., MOUNTING(L) • • • • • • • • • • • • • • • • • • •
HZVL-50100-901	FRAME COMP., MOUNTING(L) • • • • • • • • • • • • • • • • • • •
HZVL-50100-901	FRAME COMP., MOUNTING(L) • • • • • • • • • • • • • • • • • • •

HZVL-50109-000	HOUSING, UPPER MOUNTING · · · · · · · · · · · · · · · · · F-10-14
HZVL-50166-000	COVER, UPPER MOUNT • • • • • • • • • • • • • • • • • • •
HZVL-50166-000	COVER, UPPER MOUNT • • • • • • • • • • • • • • • • • • •
HZVL-50166-000	COVER, UPPER MOUNT • • • • • • • • • • • • • • • • • • •
HZVL-50166-000	COVER, UPPER MOUNT · · · · · · · · · · · · · · · · · · ·
HZVL-50166-000	COVER, UPPER MOUNT • • • • • • • • • • • • • • • • • • F-10-18
HZVL-50166-000	COVER, UPPER MOUNT • • • • • • • • • • • • • • • • • • F-10-18
HZVL-50166-010	COVER, UPPER MOUNT F-10-18
HZVL-50166-010	COVER, UPPER MOUNT F-10-18
HZVL-50166-010	COVER, UPPER MOUNT F-10-18
HZVL-50166-010	COVER, UPPER MOUNT F-10-18
HZVL-50166-010	COVER, UPPER MOUNT F-10-18
HZVL-50166-010	COVER, UPPER MOUNT · · · · · · · · · · · · · · · · · · ·
HZVL-50201-000ZA	CASE, SWIVEL (XL) • • • • • • • • • • • • • • • • • • •
HZVL-50201-900ZA	CASE, SWIVEL (L) • • • • • • • • • • • • • • • • • • •
HZVL-50222-000	BRACKET, TILT LIMIT SWITCH • • • • • • • • • • • • • • • • • • F-10-22
HZVL-50311-000ZA	BRACKET, L. STERN · · · · · · · · · · · · · · · · · · ·
HZVL-50381-000	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-000	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-000	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-000	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-000	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-000	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-010	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-010	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-010	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-010	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-010	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-010	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50381-010	SHAFT, TILTING · · · · · · · · · · · · · · · · · · ·
HZVL-50529-000	STOPPER, TILT F-10-30
HZVL-56539-000	SHAFT, LOWER CYLINDER • • • • • • • • • • • • • • • • • F-10-34
HZVL-63100-P01ZA	COVER ASSY. ENGINE F-8-1
HZVL-63107-000	BRACKET, HOOK FR. • • • • • • • • • • • • • • • • • F-8-2
HZVL-63108-000	GROMMET, LOCK HOOK · · · · · · · · · · · · · · · · · ·
HZVL-63109-000	ROLLER, HOOK · · · · · · · · · · · · · · · · · ·
HZVL-63112-000	BRACKET, HOOK R. · · · · · · · · · · · · · · · · · ·
HZVL-63117-000	BRACKET, HOOK L. • • • • • • • • • • • • • • • • • F-8-6
HZVL-63119-000	SPRING, LEVER RETURN · · · · · · · · · · · · · · · · · · ·
HZVL-63210-000	LEVER, COVER LOCK FR. • • • • • • • • • • • • • • • • • • F-3-20-26
HZVL-63212-000	HOOK COMP., COVER LOCK R. · · · · · · · · · · · · · · · · · F-3-20-27
HZVL-63213-000	COLLAR A, COVER LOCK · · · · · · · · · · · · · · · · · · ·
HZVL-63214-000	COLLAR B, COVER LOCK · · · · · · · · · · · · · · · · · · ·
HZVL-63220-000	LEVER, COVER LOCK R. · · · · · · · · · · · · · · · · · ·
HZVL-63222-000	HOOK COMP., COVER LOCK L. · · · · · · · · · · · · · · · · F-3-20-31
HZVL-63230-000	LEVER, COVER LOCK L. · · · · · · · · · · · · · · · · · ·
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL) · · · · · · · · · · · · · · · · · · F-3-30-3
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL) · · · · · · · · · · · · · · · · · F-3-30-3

HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL) • • • • • • • • • • • • • • • • • • F-3-30-3
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL) • • • • • • • • • • • • • • • • • • F-3-30-3
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL) • • • • • • • • • • • • • • • • • F-3-30-3
HZVL-63710-000ZA	COVER COMP., ENGINE UNDER R. (XL) • • • • • • • • • • • • • • • • • • F-3-30-3
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)
HZVL-63710-010ZA	COVER COMP., ENGINE UNDER R. (XL)
HZVL-63710-900ZA	COVER COMP., ENGINE UNDER R
HZVL-63710-900ZA	COVER COMP., ENGINE UNDER R
HZVL-63710-900ZA	COVER COMP., ENGINE UNDER R
HZVL-63710-901ZA	COVER COMP., ENGINE UNDER R
HZVL-63710-901ZA	COVER COMP., ENGINE UNDER R
HZVL-63710-901ZA	COVER COMP., ENGINE UNDER R
HZVL-63715-000ZA	COVER COMP., ENGINE UNDER L
HZVL-63715-000ZA	COVER COMP. ENGINE UNDER L
HZVL-63715-000ZA	COVER COMP. ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-000ZA	COVER COMP. ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-000ZA	COVER COMP. ENGINE UNDER L. · · · · · · · · · · · · · · · · · F-3-30-5
HZVL-63715-010ZA	COVER COMP ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-010ZA	COVER COMP., ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-010ZA	COVER COMP. ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-010ZA	COVER COMP. ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-900ZA	COVER COMP. ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-900ZA	COVER COMP., ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-900ZA	COVER COMP ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-901ZA	COVER COMP., ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-901ZA	COVER COMP., ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63715-901ZA	COVER COMP., ENGINE UNDER L. · · · · · · · · · · · · · · · · · ·
HZVL-63730-000	COVER. RR
HZVL-82873-000	GROMMET. WATER CHECK · · · · · · · · · · · · · · · · · · ·
HZVL-87116-000	LABEL, FUSE (1A)
HZVL-87117-A01	LABEL, FUSE & OIL CAUTION · · · · · · · · · · · · · · · · · F-12-1
HZVL-87117-S00	LABEL, FUSE & OIL CAUTION (E) · · · · · · · · · · · · · · · · · · ·
HZVL-87118-000	LABEL, FUSE (5A) FOP-3-4-43
HZVL-87118-000	LABEL, FUSE (5A) FOP-3-5-49
HZVL-87118-000	LABEL, FUSE (5A) FOP-3-6-51
HZVL-87121-P00	MARK, RR. (BFT250) • • • • • • • • • • • • • • • • • • •
HZVL-87132-P00	MARK, SIDE STRIPE
HZVL-87301-P00	MARK, FR. (BFT250) · · · · · · · · · · · · · · · · · · ·
HZVL-87302-P01	MARK, FR. EMBLEM
HZVL-90001-000	BOLT, FLANGE, 12X95 · · · · · · · · · · · · · E-3-26
HZVL-90001-000	BOLT, FLANGE, 12X95 E-3-26
HZVL-90001-000	BOLT, FLANGE, 12X95 E-3-26
HZVL-90001-000	BOLT, FLANGE, 12X95 E-3-26
117AF 30001-010	DOLI, I LANGE, 12/30

HZVL-90001-010	BOLT, FLANGE, 12X95 · · · · · · · · · · · · · · · E-3-26
HZVL-90001-010	BOLT, FLANGE, 12X95 · · · · · · · · · · · · · · · · E-3-26
HZVL-90002-010	BOLT, FLANGE, 10X90 • • • • • • • • • • • • • • • • E-19-21
HZVL-90002-010	BOLT, FLANGE, 10X90 • • • • • • • • • • • • • • • • E-19-21
HZVL-90002-010	BOLT, FLANGE, 10X90 • • • • • • • • • • • • • • • • E-19-21
HZVL-90003-000	BOLT, FLANGE, 10X110 • • • • • • • • • • • • • • • • • •
HZVL-90003-000	BOLT, FLANGE, 10X110 • • • • • • • • • • • • • • • • • •
HZVL-90003-000	BOLT, FLANGE, 10X110 • • • • • • • • • • • • • • • • • •
HZVL-90003-010	BOLT, FLANGE, 10X110 • • • • • • • • • • • • • • • • • •
HZVL-90003-010	BOLT, FLANGE, 10X110 • • • • • • • • • • • • • • • • • •
HZVL-90003-010	BOLT, FLANGE, 10X110 • • • • • • • • • • • • • • • • • •
HZVL-90004-000	BOLT-WASHER, 5X16 · · · · · · · · · · · · · · · · E-13-10-7
HZVL-90004-000	BOLT-WASHER, 5X16 · · · · · · · · · · · · · · · · · · ·
HZVL-90004-000	BOLT-WASHER, 5X16 · · · · · · · · · · · · · · · · · · ·
HZVL-90004-010	BOLT-WASHER, 5X16 · · · · · · · · · · · · · · · · · · ·
HZVL-90004-010	BOLT-WASHER, 5X16 · · · · · · · · · · · · · · · · · · ·
HZVL-90004-010	BOLT-WASHER, 5X16 • • • • • • • • • • • • • • • • • • •
HZVL-90005-000	BOLT, FLANGE, 10X90 • • • • • • • • • • • • • • • • • • •
HZVL-90005-000	BOLT, FLANGE, 10X90 • • • • • • • • • • • • • • • • • • •
HZVL-90005-000	BOLT, FLANGE, 10X90 • • • • • • • • • • • • • • • • • • •
HZVL-90005-010	BOLT, FLANGE, 10X90 E-21-20
HZVL-90005-010	BOLT, FLANGE, 10X90 • • • • • • • • • • • • • • • • • • •
HZVL-90005-010	BOLT, FLANGE, 10X90 E-21-20
HZVL-90006-003	BOLT-WASHER, 10X109 E-3-27
HZVL-90006-003	BOLT-WASHER, 10X109 E-3-27
HZVL-90006-003	BOLT-WASHER, 10X109 • • • • • • • • • • • • • • • • E-3-27
HZVL-90006-013	BOLT-WASHER, 10X109 E-3-27
HZVL-90006-013	BOLT-WASHER, 10X109 E-3-27
HZVL-90006-013	BOLT-WASHER, 10X109 E-3-27
HZVL-90007-010	BOLT, TIMING BELT COVER E-13-10-8
HZVL-90008-003	BOLT-WASHER, 10X60 E-3-28
HZVL-90008-003	BOLT-WASHER, 10X60 E-3-28
HZVL-90008-003	BOLT-WASHER, 10X60 E-3-28
HZVL-90008-013	BOLT-WASHER, 10X60 E-3-28
HZVL-90008-013	BOLT-WASHER, 10X60 • • • • • • • • • • • • • • • • • • •
HZVL-90008-013	BOLT-WASHER, 10X60 • • • • • • • • • • • • • • • • • • •
HZVL-90009-003	BOLT-WASHER, 10X80 E-3-29
HZVL-90009-003	BOLT-WASHER, 10X80 • • • • • • • • • • • • • • • • • • •
HZVL-90009-003	BOLT-WASHER, 10X80 E-3-29
HZVL-90009-013	BOLT-WASHER, 10X80 • • • • • • • • • • • • • • • • • • •
HZVL-90009-013	BOLT-WASHER, 10X80 • • • • • • • • • • • • • • • • • • •
HZVL-90009-013	BOLT-WASHER, 10X80 E-3-29
HZVL-90010-000	BOLT, FLANGE, 8X55 E-15-26
HZVL-90010-010	BOLT, FLANGE, 8X55 E-15-26
HZVL-90011-010	BOLT, SPECIAL ADJUSTER E-19-22
HZVL-90012-000	BOLT, SOCKET, 8X25 E-15-27
HZVL-90012-010	BOLT, SOCKET, 8X25 E-15-27
HZVL-90013-000	BOLT-WASHER, 5X12 • • • • • • • • • • • • • • • • • • E-14-10-11

HZVL-90013-000	BOLT-WASHER, 5X12 • • • • • • • • • • • • • • • • • • •
HZVL-90013-000	BOLT-WASHER, 5X12 • • • • • • • • • • • • • • • • • • •
HZVL-90013-010	BOLT-WASHER, 5X12 • • • • • • • • • • • • • • • • • • •
HZVL-90013-010	BOLT-WASHER, 5X12 • • • • • • • • • • • • • • • • • • •
HZVL-90013-010	BOLT-WASHER, 5X12 • • • • • • • • • • • • • • • • • • •
HZVL-90014-000	BOLT-WASHER, 5X28 • • • • • • • • • • • • • • • • • • •
HZVL-90014-000	BOLT-WASHER, 5X28 • • • • • • • • • • • • • • • • • • •
HZVL-90014-000	BOLT-WASHER, 5X28 • • • • • • • • • • • • • • • • • E-14-10-12
HZVL-90014-010	BOLT-WASHER, 5X28 • • • • • • • • • • • • • • • • • • •
HZVL-90014-010	BOLT-WASHER, 5X28 • • • • • • • • • • • • • • • • • • •
HZVL-90014-010	BOLT-WASHER, 5X28 • • • • • • • • • • • • • • • • • • •
HZVL-90015-010	BOLT-WASHER, 6X27 · · · · · · · · · · · · · · · · · E-20-5
HZVL-90015-010	BOLT-WASHER, 6X27 • • • • • • • • • • • • • • • • • • •
HZVL-90015-010	BOLT-WASHER, 6X27 · · · · · · · · · · · · · · · · · · ·
HZVL-90016-000	BOLT, FLANGE, 10X43 • • • • • • • • • • • • • • • • • • •
HZVL-90016-000	BOLT, FLANGE, 10X43 • • • • • • • • • • • • • • • • • • •
HZVL-90016-000	BOLT. FLANGE. 10X43 • • • • • • • • • • • • • • • • • • •
HZVL-90017-701	SCREW. TAPPET ADJUSTING • • • • • • • • • • • • • • • • • • •
HZVL-90017-701	SCREW, TAPPET ADJUSTING • • • • • • • • • • • • • • • • • • •
HZVL-90017-701	SCREW, TAPPET ADJUSTING • • • • • • • • • • • • • • • • • • •
HZVL-90020-000	BOLT, FLANGE, 8X50 · · · · · · · · · · · · · · · · · · ·
	BOLT, FLANGE, 8X50 · · · · · · · · · · · · · · · · · · ·
HZVL-90020-000	BOLT, FLANGE, 8X50 · · · · · · · · · · · · · · · · · · ·
HZVL-90020-000	BOLT, FLANGE, 8X50 · · · · · · · · · · · · · · · · · · ·
HZVL-90020-010	
HZVL-90020-010	BOLT, FLANGE, 8X50 · · · · · · · · · · · · · · · · · · ·
HZVL-90020-010	BOLT, FLANGE, 8X50 · · · · · · · · · · · · · · · · · · ·
HZVL-90020-010	BOLT, FLANGE, 8X50 · · · · · · · · · · · · · · · · · · ·
HZVL-90020-010	BOLT, FLANGE, 8X50 E-14-10-15
HZVL-90020-010	BOLT, FLANGE, 8X50 E-14-10-15
HZVL-90023-010	BOLT, FLANGE, 6X22 • • • • • • • • • • • • • • • • • •
HZVL-90028-000	BOLT, FLANGE, 6X18 • • • • • • • • • • • • • • • • • • •
HZVL-90028-000	BOLT, FLANGE, 6X18 • • • • • • • • • • • • • • • • • • •
HZVL-90028-000	BOLT, FLANGE, 6X18 · · · · · · · · · · · · · · · · · · ·
HZVL-90028-010	BOLT, FLANGE, 6X18 · · · · · · · · · · · · · · · · · · ·
HZVL-90028-010	BOLT, FLANGE, 6X18 · · · · · · · · · · · · · · · · · E-3-35
HZVL-90028-010	BOLT, FLANGE, 6X18 • • • • • • • • • • • • • • • • • • •
HZVL-90034-010	BOLT, FLANGE, 6X60 · · · · · · · · · · · · · · · · · · ·
HZVL-90034-010	BOLT, FLANGE, 6X60 • • • • • • • • • • • • • • • • • • •
HZVL-90035-010	BOLT, FLANGE, 8X28 • • • • • • • • • • • • • • • • • • •
HZVL-90037-010	BOLT, FLANGE, 8X65 • • • • • • • • • • • • • • • • • • •
HZVL-90038-000	BOLT, FLANGE, 8X75 · · · · · · · · · · · · · · · · · · ·
HZVL-90038-000	BOLT, FLANGE, 8X75 · · · · · · · · · · · · · · · · · · ·
HZVL-90038-000	BOLT, FLANGE, 8X75 · · · · · · · · · · · · · · · · · · ·
HZVL-90038-010	BOLT, FLANGE, 8X75 · · · · · · · · · · · · · · · · · · ·
HZVL-90038-010	BOLT, FLANGE, 8X75 · · · · · · · · · · · · · · · · · · ·
HZVL-90038-010	BOLT, FLANGE, 8X75 · · · · · · · · · · · · · · · · · · ·
HZVL-90039-000	BOLT, FLANGE, 10X40 · · · · · · · · · · · · · · · · · · ·
HZVL-90039-000	BOLT, FLANGE, 10X40 · · · · · · · · · · · · · · · · · · ·

HZVL-90039-000	BOLT, FLANGE, 10X40 · · · · · · · · · · · · · · · · · · ·
HZVL-90039-010	BOLT, FLANGE, 10X40 • • • • • • • • • • • • • • • • • E-13-26
HZVL-90039-010	BOLT, FLANGE, 10X40 • • • • • • • • • • • • • • • • • E-13-26
HZVL-90039-010	BOLT, FLANGE, 10X40 • • • • • • • • • • • • • • • • • • •
HZVL-90040-000	BOLT, FLANGE, 10X43 E-13-27
HZVL-90040-000	BOLT, FLANGE, 10X43 • • • • • • • • • • • • • • • E-13-27
HZVL-90040-000	BOLT, FLANGE, 10X43 · · · · · · · · · · · · · · E-13-27
HZVL-90040-010	BOLT, FLANGE, 10X43 · · · · · · · · · · · · · · E-13-27
HZVL-90040-010	BOLT, FLANGE, 10X43 · · · · · · · · · · · · · · · E-13-27
HZVL-90040-010	BOLT, FLANGE, 10X43 · · · · · · · · · · · · · · · · E-13-27
HZVL-90041-010	BOLT, FLANGE, 10X55 E-3-10-10
HZVL-90043-000	BOLT, STUD, 8X28 · · · · · · · · · · · · · · · · · · ·
HZVL-90043-000	BOLT, STUD, 8X28 · · · · · · · · · · · · · · · · · · ·
HZVL-90043-000	BOLT, STUD, 8X28 · · · · · · · · · · · · · · · · · · ·
HZVL-90043-010	BOLT, STUD, 8X28 · · · · · · · · · · · · · · · · · · ·
HZVL-90043-010	BOLT, STUD, 8X28 · · · · · · · · · · · · · · · · · · ·
HZVL-90043-010	BOLT, STUD, 8X28 · · · · · · · · · · · · · · · · · · ·
HZVL-90044-010	BOLT, STUD, 8X45 · · · · · · · · · · · · · · · · · · ·
HZVL-90044-010	BOLT, STUD, 8X45 · · · · · · · · · · · · · · · · · · ·
HZVL-90044-010	BOLT, STUD, 8X45 · · · · · · · · · · · · · · · · · · ·
HZVL-90045-000	BOLT, STUD, 10X45 E-6-10-33
HZVL-90045-000	BOLT, STUD, 10X45 E-6-10-33
HZVL-90045-000	BOLT, STUD, 10X45 E-6-10-33
HZVL-90045-010	BOLT, STUD, 10X45 · · · · · · · · · · · · · · · · · · ·
HZVL-90045-010	BOLT, STUD, 10X45 E-6-10-33
HZVL-90045-010	BOLT, STUD, 10X45 · · · · · · · · · · · · · · · · · · ·
HZVL-90046-000	BOLT, FLANGE, 8X120 · · · · · · · · · · · · · · · · E-6-10-34
HZVL-90049-000	BOLT, FLANGE, 8X30 · · · · · · · · · · · · · · · · · · ·
HZVL-90049-000	BOLT, FLANGE, 8X30 E-6-10-35
HZVL-90049-000	BOLT, FLANGE, 8X30 E-6-10-35
HZVL-90049-010	BOLT. FLANGE. 8X30
HZVL-90049-010	BOLT. FLANGE. 8X30
HZVL-90049-010	BOLT. FLANGE. 8X30
HZVL-90055-010	BOLT. TENSIONER · · · · · · · · · · · · · · · · · · ·
HZVL-90055-010	BOLT, TENSIONER · · · · · · · · · · · · · · · · · · ·
HZVL-90055-010	BOLT, TENSIONER · · · · · · · · · · · · · · · · · · ·
HZVL-90063-000	BOLT, FLANGE, 6X37 · · · · · · · · · · · · · · · · · · ·
HZVL-90063-000	BOLT, FLANGE, 6X37 · · · · · · · · · · · · · · · · · · ·
HZVL-90063-000	BOLT, FLANGE, 6X37 · · · · · · · · · · · · · · · · · · ·
HZVL-90063-010	BOLT, FLANGE, 6X37 · · · · · · · · · · · · · · · · · · ·
HZVL-90063-010	BOLT, FLANGE, 6X37 · · · · · · · · · · · · · · · · · · ·
HZVL-90063-010	BOLT, FLANGE, 6X37 · · · · · · · · · · · · · · · · · · ·
HZVL-90003-010	BOLT-WASHER, 8X35 (SUS) • • • • • • • • • • • • • • • • • • •
HZVL-90070-000	BOLT-WASHER, 8X35 (SUS) • • • • • • • • • • • • • • • • • • •
HZVL-90070-000	BOLT-WASHER, 8X35 (SUS) • • • • • • • • • • • • • • • • • • •
HZVL-90070-000	BOLT-WASHER, 8X35 (SUS) • • • • • • • • • • • • • • • • • • •
HZVL-90070-010	BOLT-WASHER, 8X35 (SUS) • • • • • • • • • • • • • • • • • • •
HZVL-90070-010	BOLT-WASHER, 8X35 (SUS) • • • • • • • • • • • • • • • • • • •
11212 30070 010	DOL: INICIEN, ONO (000)

HZVL-90071-000	BOLT-WASHER, 8X28 (SUS) • • • • • • • • • • • • • • • • • • •
HZVL-90072-010	BOLT-WASHER, 6X60 • • • • • • • • • • • • • • • • E-15-18
HZVL-90101-000	BOLT, SOCKET, 6X25 · · · · · · · · · · · · · · · · · · ·
HZVL-90102-000	BOLT-WASHER, 10X35 • • • • • • • • • • • • • • • • • • •
HZVL-90103-000	BOLT-WASHER, 12X50 • • • • • • • • • • • • • • • • • • •
HZVL-90105-000	BOLT, STUD, 10X28 • • • • • • • • • • • • • • • F-10-42
HZVL-90106-000	BOLT, SOCKET, 6X30 · · · · · · · · · · · · · · · · · · ·
HZVL-90106-000	BOLT, SOCKET, 6X30 · · · · · · · · · · · · · · · · · · ·
HZVL-90106-010	BOLT, SOCKET, 6X30 · · · · · · · · · · · · · · · · · · ·
HZVL-90106-010	BOLT, SOCKET, 6X30 · · · · · · · · · · · · · · · · · · ·
HZVL-90107-000	BOLT-WASHER, 8X35 • • • • • • • • • • • • • • • • • • •
HZVL-90107-000	BOLT-WASHER, 8X35 · · · · · · · · · · · · · · · · · · ·
HZVL-90109-000	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZVL-90109-000	BOLT, FLANGE, 6X25 · · · · · · · · · · · · · · · · · · ·
HZVL-90109-000	BOLT, FLANGE, 6X25 · · · · · · · · · · · · · · · · · · ·
HZVL-90109-000	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZVL-90109-000	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZVL-90109-000	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZVL-90109-000	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZVL-90109-000	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZVL-90109-000	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZVL-90109-000	BOLT, FLANGE, 6X25 · · · · · · · · · · · · · · · · · · ·
HZVL-90109-000	BOLT, FLANGE, 6X25 · · · · · · · · · · · · · · · · · · ·
HZVL-90109-000	BOLT, FLANGE, 6X25 · · · · · · · · · · · · · · · · · · ·
HZVL-90109-000	BOLT, FLANGE, 6X25 · · · · · · · · · · · · · · · · · · ·
HZVL-90110-000	BOLT, WASHER, 6X25 • • • • • • • • • • • • • • • • • • •
HZVL-90110-000	BOLT, WASHER, 6X25 • • • • • • • • • • • • • • • • • • •
HZVL-90110-000	BOLT, WASHER, 6X25 • • • • • • • • • • • • • • • • • • •
HZVL-90110-000	BOLT, WASHER, 6X25 F-3-30-13
HZVL-90110-000	BOLT, WASHER, 6X25 F-3-30-13
HZVL-90203-010	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·
HZVL-90203-010	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·
HZVL-90203-010	NUT. FLANGE. 8MM · · · · · · · · · · · · · · · · · ·
HZVL-90204-010	NUT, FLANGE CAP, 10MM · · · · · · · · · · · · · · · · E-3-10-16
HZVL-90512-000	WASHER, PLAIN, 6MM······F-3-30-10
HZVL-90512-000	WASHER, PLAIN, 6MM·····F-3-30-10
HZVL-90512-000	WASHER, PLAIN, 6MM · · · · · · · · · · · · · · · · · ·
HZVL-90512-000	WASHER, PLAIN, 6MM · · · · · · · · · · · · · · · · · ·
HZVL-90512-000	WASHER, PLAIN, 6MM·····F-3-30-10
HZVL-90512-000	WASHER, PLAIN, 6MM · · · · · · · · · · · · · · · · · ·
HZVL-90601-000	CLAMP, TUBE (D12. 5) • • • • • • • • • • • • • • • • • •
HZVL-90601-000	CLAMP, TUBE (D12. 5)
HZVL-90601-000	CLAMP, TUBE (D12. 5)
HZVL-90751-000	PIN, SPRING, 6X22 · · · · · · · · · · · · · · · · · ·
HZVL-90752-000	PIN, LOCK SPRING • • • • • • • • • • • • • • • • • • •
HZVL-90756-000	DOWEL PIN, 6X10 · · · · · · · · · · · · · · · · · · ·
HZVL-90756-000	DOWEL PIN, 6X10 F-4-24
HZVL-90756-000	DOWEL PIN, 6X10 F-4-24
00/00 000	5 1 4 24

HZ	ZVL-90756-000	DOWEL PIN, 6X10 F-4-24
HZ	ZVL-90756-000	DOWEL PIN, 6X10 • • • • • • • • • • • • • • • • • • •
HZ	ZVL-90756-000	DOWEL PIN, 6X10 • • • • • • • • • • • • • • • • • • •
HZ	ZVL-90756-000	DOWEL PIN, 6X10 • • • • • • • • • • • • • • • • • • •
HZ	ZVL-90756-000	DOWEL PIN, 6X10 • • • • • • • • • • • • • • • • • • •
HZ	ZVL-90756-000	DOWEL PIN, 6X10 F-4-24
HZ	ZVL-90756-000	DOWEL PIN, 6X10 · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-90756-000	DOWEL PIN, 6X10 · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91303-000	0-RING, 8.8X1.9 · · · · · · · E-3-43
HZ	ZVL-91356-003	0-RING, 31. 5X2. 4 · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-000	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-000	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-000	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-000	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-000	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-000	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-010	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-010	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-010	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-010	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-010	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91451-010	TUBE, WATER JOINT · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91508-000	COLLAR, TIMING BELT COVER · · · · · · · · · · · · · · · · · E-13-10-10
HZ	ZVL-91551-000	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91551-000	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91551-000	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91551-000	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91551-000	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91551-000	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91551-000	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91551-000	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91551-000	COLLAR, 12X6.5 • • • • • • • • • • • • • • • • • • •
	ZVL-91551-000	COLLAR, 12X6. 5 · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, 12X6. 5 · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · F-3-30-11
HZ	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · F-3-30-12
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · F-3-30-12
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZ	ZVL-91551-000	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·

HZVL-91551-010	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · E-20-7
HZVL-91551-010	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · E-20-7
HZVL-91551-010	COLLAR, C.D.I. UNIT CASE • • • • • • • • • • • • • • • • • • •
HZVL-91551-010	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · E-20-10-12
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	COLLAR, 12X6.5 · · · · · · · · · · · · · · · · · · ·
HZVL-91551-010	
HZVP-06411-000	METAL KIT, ANODE
HZVP-50116-000	
HZVP-50117-000	PLATE, ANODE METAL · · · · · · · · · · · · · · · · · · ·
HZW1-06411-020	METAL KIT, ANODE
HZW1-06411-020	METAL KIT, ANODE FOP-18-2
HZW1-19286-B00	PLATE, RUBBER SETTING · · · · · · · · · · · · · · · · · F-3-1
HZW1-24210-010	SPRING COMP., CLICK · · · · · · · · · · · · · · · · · · ·
HZW1-24327-000	RING, STOPPER · · · · · · · · · · · · · · · · · · ·
HZW1-24327-000	RING, STOPPER · · · · · · · · · · · · · · · · · · ·
HZW1-24343-B02	HOLDER, SHIFT ROD F-4-12
HZW1-24629-000	HOLDER, SEAL · · · · · · · · · · · · · · · · · · ·
HZW1-24629-000	HOLDER, SEAL · · · · · · · · · · · · · · · · · · ·
HZW1-38551-000	GROMMET, RELAY · · · · · · · · · · · · · · · · · · ·
HZW1-40107-700	GROMMET, UNDER CASE(C) · · · · · · · · · · · · · · · · · · ·
HZW1-41102-B00	GROMMET, GEAR CASE · · · · · · · · · · · · · · · · · · ·
HZW1-41109-B00	METAL COMP., ANODE · · · · · · · · · · · · · · · · · · ·
HZW1-41109-B00	METAL COMP., ANODE · · · · · · · · · · · · · · · · · · ·
HZW1-56110-701	ROD COMP., PISTON(B) • • • • • • • • • • • • • • • • • • •
HZW1-56113-701	JOINT, DRIVE · · · · · · · · · · · · · · · · · · ·
HZW1-56116-701	FILTER B

HZW1-56130-702	PISTON COMP., FREE · · · · · · · · · · · · · · · · · ·	F-11-22
HZW1-56180-701	VALVE COMP., RESERVOIR	F-11-24
HZW1-56851-703	TANK, OIL······	F-11-27
HZW1-56860-701	CAP COMP., OIL TANK	F-11-28
HZW1-90102-000	BOLT, 1/4–28UNF • • • • • • • • • • • • • • • • • • •	F-10-37
HZW1-90107-004	SCREW, PAN, 5X8 · · · · · · · · · · · · · · · · · · ·	E-21-21
HZW1-90113-702	BOLT, RECESSED	
HZW1-90114-702	BOLT, SOCKET (A) · · · · · · · · · · · · · · · · · · ·	F-11-30
HZW1-90115-702	BOLT, SOCKET (B) · · · · · · · · · · · · · · · · · · ·	F-11-31
HZW1-90116-702	BOLT, HEX.	F-11-32
HZW1-90203-000	NUT-WASHER, 8MM · · · · · · · · · · · · · · · · · ·	F-7-10-18
HZW1-90301-B00	NUT, CASTLE, 18MM · · · · · · · · · · · · · · · · · ·	F-5-14
HZW1-90301-B00	NUT, CASTLE, 18MM · · · · · · · · · · · · · · · · · ·	F-5-1-14
HZW1-90308-003	NUT, SELF-LOCK, 12MM · · · · · · · · · · · · · · · · · ·	F-3-22
HZW1-90652-702	CIRCLIP, INTERNAL	
HZW1-90758-B00	PIN, SPLIT, 4.0 · · · · · · · · · · · · · · · · · · ·	
HZW1-90758-B00	PIN, SPLIT, 4.0 · · · · · · · · · · · · · · · · · · ·	
HZW1-90758-B00	PIN, SPLIT, 4.0 · · · · · · · · · · · · · · · · · · ·	
HZW1-90758-B00	PIN, SPLIT, 4.0 · · · · · · · · · · · · · · · · · · ·	
HZW1-91207-013	0-RING, 2.0X70.5 · · · · · · · · · · · · · · · · · · ·	
HZW1-91353-703	0-RING. 1.9X11 · · · · · · · · · · · · · · · · · ·	
HZW1-91354-701	0-RING, 3.5X35.7 · · · · · · · · · · · · · · · · · · ·	
HZW1-91355-701	0-RING, 3.5X41.7 · · · · · · · · · · · · · · · · · · ·	
HZW1-91357-701	0-RING SET, 3.5X31.7 · · · · · · · · · · · · · · · · · · ·	
HZW1-91361-701	PACKING · · · · · · · · · · · · · · · · · · ·	
HZW1-91557-701	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·	
HZW1-91557-701	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·	
HZW1-91557-701	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·	
HZW1-91557-701	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·	
HZW1-91557-701	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·	
HZW1-91557-701	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·	
HZW4-90156-000	BOLT, FLANGE, 8X50 · · · · · · · · · · · · · · · · · · ·	
HZW4-90156-000	BOLT, FLANGE, 8X50 · · · · · · · · · · · · · · · · · · ·	
HZW4-90156-000	BOLT, FLANGE, 8X50 · · · · · · · · · · · · · · · · · · ·	
HZW4-90306-003	NUT, FLANGE, 10MM · · · · · · · · · · · · · · · · · ·	
HZW4-90401-000	WASHER, PLAIN, 4MM·········	
HZW4-91301-003	O-RING, 6. 9X1. 45 · · · · · · · · · · · · · · · · · ·	
HZW4-91301-003	0-RING, 6. 9X1. 45 · · · · · · · · · · · · · · · · · ·	
HZW4-91301-003	0-RING, 6.9X1.45 · · · · · · · · · · · · · · · · · · ·	
HZW5-16081-010	SCREW-WASHER · · · · · · · · · · · · · · · · · · ·	
HZW5-16086-000	COLLAR, SET · · · · · · · · · · · · · · · · · · ·	
HZW5-16087-000	WASHER, PLAIN · · · · · · · · · · · · · · · · · · ·	
HZW5-16715-023	COVER, PUMP (A) · · · · · · · · · · · · · · · · · · ·	
HZW5-16733-000	GROMMET, VAPOR SEPARATOR · · · · · · · · · · · · · · · · · · ·	
HZW5-16915-000	SUSPENSION, STRAINER · · · · · · · · · · · · · · · · · · ·	
HZW5-19291-000	VALVE, RELIEF · · · · · · · · · · · · · · · · · · ·	
HZW5-19292-000	SPRING, RELIEF VALVE · · · · · · · · · · · · · · · · · · ·	
HZW5-19297-000	PACKING, RELIEF VALVE · · · · · · · · · · · · · · · · · · ·	
	,	/

HZW5-24810-U01	HOUSING ASSY., L. INNER · · · · · · · · · · · · · · · · · · ·
HZW5-24810-U01	HOUSING ASSY., L. INNER · · · · · · · · · · · · · · · · · · ·
HZW5-24810-U11	HOUSING ASSY., R. INNER···································
HZW5-24811-U01	HANDLE, REMOTE CONTROL • • • • • • • • • • • • • • • • • • •
HZW5-24811-U01	HANDLE, REMOTE CONTROL • • • • • • • • • • • • • • • • • • •
HZW5-24812-U01	COVER, L. GRIP · · · · · · · · · · · · · · · · · · ·
HZW5-24812-U01	COVER, L. GRIP · · · · · · · · · · · · · · · · · · ·
HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE • • • • • • • • • • • • • • • • • FOP-3-5
HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE FOP-3-2-6
HZW5-24813-U21	COVER, DUAL GRIP · · · · · · · · · · · · · · · · · · ·
HZW5-24814-U01	CAP, GRIP····· FOP-3-6
HZW5-24814-U01	CAP, GRIP····· FOP-3-2-8
HZW5-24814-U01	CAP, GRIP····· FOP-3-2-8
HZW5-24814-U01	CAP, GRIP····· FOP-3-2-8
HZW5-24815-U01	CAP, SWITCH · · · · · · · · · · · · · · · · · · ·
HZW5-24816-U01	BUTTON, THROTTLE · · · · · · · · · · · · · · · · · · ·
HZW5-24816-U01	BUTTON, THROTTLE · · · · · · · · · · · · · · · · · · ·
HZW5-24816-U01	BUTTON, THROTTLE · · · · · · · · · · · · · · · · · · ·
HZW5-24817-U01	PLATE, HANDLE · · · · · · · · · · · · · · · · · · ·
HZW5-24817-U01	PLATE, HANDLE · · · · · · · · · · · · · · · · · · ·
HZW5-24817-U01	PLATE, HANDLE · · · · · · · · · · · · · · · · · · ·
HZW5-24817-U01	PLATE, HANDLE · · · · · · · · · · · · · · · · · · ·
HZW5-24818-U01	PLATE, CABLE CLAMP · · · · · · · · · · · · · · · · · · ·
HZW5-24818-U01	PLATE, CABLE CLAMP · · · · · · · · · · · · · · · · · · ·
HZW5-24818-U01	PLATE, CABLE CLAMP · · · · · · · · · · · · · · · · · · ·
HZW5-24818-U01	PLATE, CABLE CLAMP · · · · · · · · · · · · · · · · · · ·
HZW5-24819-U01	BRACKET, REMOTE CONTROL • • • • • • • • • • • • • • • • • • •
HZW5-24819-U01	BRACKET, REMOTE CONTROL • • • • • • • • • • • • • • • • • • •
HZW5-24825-U01	HOUSING, LEAD · · · · · · · · · · · · · · · · · · ·
HZW5-24825-U01	HOUSING, LEAD · · · · · · · · · · · · · · · · · · ·
HZW5-24826-U01	PLATE, DWELL • • • • • • • • • • • • • • • • • •
HZW5-24826-U01	PLATE, DWELL · · · · · · · · · · · · · · · · · ·
HZW5-24826-U01	PLATE, DWELL · · · · · · · · · · · · · · · · · ·
HZW5-24826-U01	PLATE, DWELL · · · · · · · · · · · · · · · · · ·
HZW5-24826-U01	PLATE, DWELL • • • • • • • • • • • • • • • • • •
HZW5-24831-U01	TERMINAL, CABLE FOP-3-15
HZW5-24831-U01	TERMINAL, CABLE FOP-3-1-12
HZW5-24831-U01	TERMINAL, CABLE FOP-3-2-16
HZW5-24831-U01	TERMINAL, CABLE (LOOSE PARTS) · · · · · · · · · · · · · · · · FOP-3-9-19
HZW5-24831-U01	TERMINAL, CABLE (LOOSE PARTS) · · · · · · · · · · · · · · · · FOP-3-10-19
HZW5-24832-U01	SPACER, CABLE CLAMP FOP-3-16
HZW5-24832-U01	SPACER, CABLE CLAMP · · · · · · · · · · · · · · · · · · ·
HZW5-24832-U01	SPACER, CABLE CLAMP · · · · · · · · · · · · · · · · · · ·
HZW5-24832-U01	SPACER, CABLE CLAMP (LOOSE PARTS) · · · · · · · · · · · · · · FOP-3-9-20
HZW5-24832-U01	SPACER, CABLE CLAMP (LOOSE PARTS) · · · · · · · · · · · · · · · FOP-3-10-20
HZW5-24834-U01	PACKING, SINGLE · · · · · · · · · · · · · · · · · · ·
HZW5-24834-U01	PACKING, SINGLE (LOOSE PARTS) · · · · · · · · · · · · · · · · FOP-3-9-22
HZW5-24834-U21	PACKING, DUAL · · · · · · · · · · · · · · · · · · ·

117115 00400 000	DAND 5 40 44
HZW5-32168-003	BAND · · · · · · · · · · · · · · · · · · ·
HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT · · · · · · · · · · · · · · · · · FOP-3-19
HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT · · · · · · · · · · · · · · · · · FOP-3-2-21
HZW5-35370-U12	SWITCH ASSY., POWER TRIM-TILT · · · · · · · · · · · · · · · · FOP-3-2-22
HZW5-35665-003	SENSOR ASSY., AIR TEMPERATURE • • • • • • • • • • • • • E-15-11
HZW5-90002-013	BOLT, SPECIAL, 8MM · · · · · · · · · · · · · · · · · ·
HZW5-90101-U00	SCREW, PAN, 5X16 · · · · · · · · · · · · · · · · · · ·
HZW5-90101-U00	SCREW, PAN, 5X16 FOP-3-1-20
HZW5-90101-U00	SCREW, PAN, 5X16 • • • • • • • • • • • • • • • • • • •
HZW5-90101-U00	SCREW, PAN, 5X16 • • • • • • • • • • • • • • • • • • •
HZW5-90101-U00	SCREW, PAN, 5X16 • • • • • • • • • • • • • • • • • • •
HZW5-90102-U00	SCREW, PAN, 5X10 • • • • • • • • • • • • • • • • • • •
HZW5-90102-U00	SCREW, PAN, 5X10 • • • • • • • • • • • • • • • • • • •
HZW5-90103-U01	SCREW, PAN, 5X20 · · · · · · · · · · · · · · · · · · ·
HZW5-90103-U01	SCREW, PAN, 5X20 · · · · · · · · · · · · · · · · · · ·
HZW5-90104-U00	SCREW, PAN, 5X18 · · · · · · · · · · · · · · · · · · ·
HZW5-90104-U00	SCREW, PAN, 5X18 · · · · · · · · · · · · · · · · · · ·
HZW5-90104-U00	SCREW, PAN, 5X18 · · · · · · · · · · · · · · · · · · ·
HZW5-90104-U00	SCREW, PAN, 5X18 FOP-3-10-38
HZW5-90105-U01	SCREW, PAN, 4X10 · · · · · · · · · · · · · · · · · · ·
HZW5-90105-U01	SCREW, PAN, 4X10 • • • • • • • • • • • • • • • • • • •
HZW5-90106-U00	SCREW, PAN, 6X18 · · · · · · · · · · · · · · · · · · ·
HZW5-90106-U00	SCREW, PAN, 6X18 • • • • • • • • • • • • • • • • • • •
HZW5-90106-U00	SCREW, PAN, 6X18 • • • • • • • • • • • • • • • • • • •
HZW5-90106-U00	SCREW, PAN, 6X18 · · · · · · · · · · · · · · · · · · ·
HZW5-90107-U00	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90107-U00	SCREW. PAN. 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90107-U00	SCREW, PAN, 5X40 (LOOSE PARTS) · · · · · · · · · · · · · · · · · · ·
HZW5-90107-U00	SCREW, PAN, 5X40 (LOOSE PARTS) · · · · · · · · · · · · · · · · · · ·
HZW5-90108-U00	SCREW, PAN, 5X55 · · · · · · · · · · · · · · · · ·
HZW5-90108-U00	SCREW, PAN, 5X55 · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW. PAN. 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW. PAN. 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000 HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW, PAN, 5x40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	
HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90109-000	SCREW, PAN, 5X40 · · · · · · · · · · · · · · · · · · ·
HZW5-90203-010	NUT, FLANGE, 8MM • • • • • • • • • • • • • • • • • •

=	
HZW5-90203-010	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·
HZW5-90203-010	NUT, FLANGE, 8MM·····E-19-25
HZW5-90301-U00	NUT, HEX., 5MM FOP-3-28
HZW5-90301-U00	NUT, HEX., 5MM FOP-3-2-32
HZW5-90301-U00	NUT, HEX., 5MM (LOOSE PARTS) · · · · · · · · · · · · · · · · · · ·
HZW5-90301-U00	NUT, HEX., 5MM (LOOSE PARTS) · · · · · · · · · · · · · · · · · · ·
HZW5-90302-003	NUT, FLANGE, 12MM····· F-10-50
HZW5-90302-U21	NUT, HEX., 5MM • • • • • • • • • • • • • • • • • •
HZW5-90302-U21	NUT, HEX., 5MM · · · · · · · · · · · · · · · · · ·
HZW5-90501-U00	WASHER, LOCK, 5MM····· FOP-3-29
HZW5-90501-U00	WASHER, LOCK, 5MM····· FOP-3-1-26
HZW5-90501-U00	WASHER, LOCK, 5MM····· FOP-3-2-34
HZW5-90501-U00	WASHER, LOCK, 5MM····· FOP-3-9-37
HZW5-90501-U00	WASHER, LOCK, 5MM · · · · · · · · · · · · · · · · · ·
HZW5-90502-U00	WASHER, LOCK, 6MM····· FOP-3-30
HZW5-90502-U00	WASHER, LOCK, 6MM····· FOP-3-2-35
HZW5-90502-U00	WASHER, LOCK, 6MM······ FOP-3-9-38
HZW5-90502-U00	WASHER, LOCK, 6MM····· FOP-3-10-50
HZW5-90503-U00	WASHER, PLAIN, 5MM······FOP-3-31
HZW5-90503-U00	WASHER, PLAIN, 5MM···································
HZW5-90503-U00	WASHER, PLAIN, 5MM (LOOSE PARTS) • • • • • • • • • • • • • • • FOP-3-9-39
HZW5-90503-U00	WASHER, PLAIN, 5MM (LOOSE PARTS) • • • • • • • • • • • • • • • FOP-3-10-51
HZW5-90509-711	WASHER, THRUST BEARING · · · · · · · · · · · · · · · · · · ·
HZW5-90509-711	WASHER, THRUST BEARING · · · · · · · · · · · · · · · · · · ·
HZW5-90601-030	CLAMP, TUBE (D10. 7) E-18-10-25
HZW5-90602-030	CLAMP. TUBE (D12) • • • • • • • • • • • • • • • • • • •
HZW5-90652-003	CLAMP, 6MM-12MM E-18-10-29
HZW5-91201-003	OIL SEAL, 46X60X9 · · · · · · · · · · · · · · · · E-5-17
HZW5-91202-003	SEAL, WATER, 22X35X7 • • • • • • • • • • • • • • • • • • •
HZW5-91251-003	OIL SEAL, 14X26X6 F-2-42
HZW5-91251-003	OIL SEAL, 14X26X6 · · · · · · · · · · · · · · · · · ·
HZW7-24810-U01	HOUSING ASSY., R. INNER···································
HZW7-24811-U01	HANDLE, REMOTE CONTROL · · · · · · · · · · · · · · · · · · ·
HZW7-24812-U01	COVER. GRIP · · · · · · · · · · · · · · · · · · ·
HZW7-24813-U01	ARM, NEUTRAL LOCK · · · · · · · · · · · · · · · · · · ·
HZW7-24814-U01	COVER, LOCK ARM · · · · · · · · · · · · · · · · · · ·
HZW7-24815-U01	SPRING, NEUTRAL LOCK ARM · · · · · · · · · · · · · · · · · · ·
HZW7-24817-U01	SHAFT, THROTTLE BUTTON · · · · · · · · · · · · · · · · · · ·
HZW7-24832-U01	HOLDER, NEUTRAL LOCK · · · · · · · · · · · · · · · · · · ·
HZW7-24833-U01	BASE • • • • • • • • • • • • • • • • • • •
HZW7-32530-U00	SUB HARNESS ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZW7-32530-U00	SUB HARNESS ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZW7-32530-U10	SUB HARNESS ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZW7-32530-U20	SUB HARNESS ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZW7-35370-U02	SWITCH ASSY., POWER TRIM-TILT · · · · · · · · · · · · · · · · · FOP-3-1-17
HZW7-87703-U00	MARK, FLUSH MOUNT · · · · · · · · · · · · · · · · · · ·
HZW7-87703-U00	MARK, FLUSH MOUNT · · · · · · · · · · · · · · · · · · ·
HZW7-90101-U01	SCREW, TRUSS, 4X12 · · · · · · · · · · · · · · · · · · ·
112/17 00101 001	500En, 11050, TATE

HZW7-90102-U01	SCREW, PAN, 5X30 • • • • • • • • • • • • • • • • • • •
HZW7-90103-U01	SCREW, PAN, 6X35 • • • • • • • • • • • • • • • • • • •
HZW7-90104-U01	SCREW, TAPPING, 6X30 · · · · · · · · · · · · · · · · · · ·
HZW7-90301-U01	NUT, HEX., 6MM · · · · · · · · · · · · · · · · · ·
HZW7-90502-U00	WASHER, PLAIN, 6MM······FOP-3-1-27
HZW9-19279-010	SPRING, FLUSH VALVE · · · · · · · · · · · · · · · · · · ·
HZW9-19291-000	VALVE, FLASH • • • • • • • • • • • • • • • • • • •
HZW9-19297-010	PACKING, FLASH VALVE • • • • • • • • • • • • • • • • • • •
HZW9-32117-000	BRACKET, COUPLER D
HZW9-90005-030	BOLT, FLANGE, 6X20 · · · · · · · · · · · · · · · · · · ·
HZW9-90009-000	BOLT, FLANGE, 6X23 · · · · · · · · · · · · · · · · · · ·
HZW9-90101-003	BOLT, OIL CHECK · · · · · · · · · · · · · · · · · · ·
HZW9-90101-003	BOLT, OIL CHECK · · · · · · · · · · · · · · · · · · ·
HZW9-90102-000	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZW9-90102-000	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZW9-90102-000	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZW9-90102-000	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZW9-90102-000	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZW9-90102-000	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZW9-90102-000	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZW9-90102-000	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZW9-90103-010	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZW9-90105-000	BOLT, FLANGE, 6X20 · · · · · · · · · · · · · · · · · · ·
HZX1-90101-R00	BOLT, SOCKET, 6X20 · · · · · · · · · · · · · · · · · · ·
HZX2-06125-C01	CASE KIT, GEAR · · · · · · · · · · · · · · · · · · ·
HZX2-06192-C02	PUMP KIT, IMPELLER · · · · · · · · · · · · · · · · · · ·
HZX2-06193-C02	PUMP KIT, IMPELLER · · · · · · · · · · · · · · · · · · ·
HZX2-06400-C00	GEAR KIT • • • • • • • • • • • • • • • • • • •
HZX2-06400-E01	GEAR KIT • • • • • • • • • • • • • • • • • • •
HZX2-11911-000	HANGER, ENGINE · · · · · · · · · · · · · · · · · · ·
HZX2-11911-000	HANGER, ENGINE · · · · · · · · · · · · · · · · · · ·
HZX2-11911-000	HANGER, ENGINE · · · · · · · · · · · · · · · · · · ·
HZX2-11911-010	HANGER, ENGINE · · · · · · · · · · · · · · · · · · ·
HZX2-11911-010	HANGER, ENGINE · · · · · · · · · · · · · · · · · · ·
HZX2-11911-010	HANGER, ENGINE · · · · · · · · · · · · · · · · · · ·
HZX2-13010-000	RING SET, PISTON(STD.) · · · · · · · · · · · · · · · · · · ·
HZX2-13011-000	RING SET, PISTON (0.25) • • • • • • • • • • • • • • • • • • •
HZX2-13101-000	PISTON·····E-7-2
HZX2-13102-000	PISTON (0. 25) • • • • • • • • • • • • • • • • • • •
HZX2-13310-000	CRANKSHAFT COMP. • • • • • • • • • • • • • • • • • • E-7-8
HZX2-13321-003	BEARING A, MAIN UPPER(BLACK) · · · · · · · · · · · · · · · · · E-7-9
HZX2-13322-003	BEARING B, MAIN UPPER(BROWN) · · · · · · · · · · · · · · · · · E-7-9
HZX2-13323-003	BEARING C, MAIN UPPER(GREEN) · · · · · · · · · · · · · · · · · E-7-9
HZX2-13324-003	BEARING D, MAIN UPPER (YELLOW) • • • • • • • • • • • • • • • • E-7-9
HZX2-13325-003	BEARING E, MAIN UPPER(PINK) · · · · · · · · · · · · · · · · E-7-9
HZX2-13326-003	BEARING F, MAIN UPPER(RED) • • • • • • • • • • • • • • • • • • E-7-9
HZX2-13341-003	BEARING A, MAIN LOWER (BLACK) • • • • • • • • • • • • • • • • E-7-11
HZX2-13342-003	BEARING B, MAIN LOWER (BROWN) • • • • • • • • • • • • • • • • E-7-11

HZX2-13343-003	BEARING C, MAIN LOWER (GREEN) · · · · · · · · · · · · · · · · · · ·	• E-7-11
HZX2-13344-003	BEARING D, MAIN LOWER (YELLOW)	E-7-11
HZX2-13345-003	BEARING E, MAIN LOWER (PINK)	E-7-11
HZX2-13346-003	BEARING F, MAIN LOWER (RED)	• E-7-11
HZX2-13392-000	SEAT, SPRING (250)	E-7-13
HZX2-13811-000	PULLEY, CRANKSHAFT • • • • • • • • • • • • • • • • • • •	• E-13-3
HZX2-14111-000	CAMSHAFT, R. · · · · · · · · · · · · · · · · · ·	• E-9-10-1
HZX2-14211-000	CAMSHAFT, L. · · · · · · · · · · · · · · · · · ·	• E-9-10-2
HZX2-16404-000	SPACER, THROTTLE BODY	E-15-4
HZX2-16701-003	CASE COMP., PUMP	• E−18−28
HZX2-17374-000	GROMMET, SILENCER	E-15-8
HZX2-19234-C00	GASKET B, IMPELLER • • • • • • • • • • • • • • • • • • •	• F-4-5
HZX2-19234-C00	GASKET B, IMPELLER • • • • • • • • • • • • • • • • • • •	• F0P-2-7
HZX2-19234-C00	GASKET B, IMPELLER • • • • • • • • • • • • • • • • • • •	• F0P-18-8
HZX2-19300-003	THERMOSTAT ASSY.	• E-4-10
HZX2-19300-003	THERMOSTAT ASSY.	• F0P-18-10
HZX2-19303-003	RUBBER, RING	• E-4-11
HZX2-19511-000	FAN, COOLING	• E−13−16
HZX2-24101-C00	SHIFTER, CLUTCH · · · · · · · · · · · · · · · · · · ·	F-5-1
HZX2-24101-C00	SHIFTER, CLUTCH · · · · · · · · · · · · · · · · · · ·	F-5-1-1
HZX2-30280-003	BREAKER ASSY.	F-11-1
HZX2-30280-013	BREAKER ASSY.	F-11-1
HZX2-30280-013	BREAKER ASSY.	F-11-1
HZX2-30280-013	BREAKER ASSY.	
HZX2-30280-013	BREAKER ASSY.	
HZX2-30280-013	BREAKER ASSY.	F-11-1
HZX2-30280-013	BREAKER ASSY.	F-11-1
HZX2-31106-003	BRUSH ASSY.	F-11-2
HZX2-31106-003	BRUSH ASSY.	F-11-2
HZX2-31106-003	BRUSH ASSY. • • • • • • • • • • • • • • • • • • •	
HZX2-31106-003	BRUSH ASSY. • • • • • • • • • • • • • • • • • • •	
HZX2-31106-003	BRUSH ASSY.	
HZX2-31106-003	BRUSH ASSY.	F-11-2
HZX2-31106-013	BRUSH ASSY. • • • • • • • • • • • • • • • • • • •	F-11-2
HZX2-31106-013	BRUSH ASSY. • • • • • • • • • • • • • • • • • • •	F-11-2
HZX2-31106-013	BRUSH ASSY. • • • • • • • • • • • • • • • • • • •	
HZX2-31106-013	BRUSH ASSY. • • • • • • • • • • • • • • • • • • •	
HZX2-31106-013	BRUSH ASSY.	
HZX2-31106-013	BRUSH ASSY.	
HZX2-31110-000ZA	FLYWHEEL COMP.	
HZX2-31916-003	PLUG, SPARK (ZFR6K-11E) (NGK) · · · · · · · · · · · · · · · · · · ·	
HZX2-32166-003	HARNESS COMP.	E-18-43
HZX2-32414-300	COVER B, TERMINAL (L) • • • • • • • • • • • • • • • • • • •	• F-7-10-5

HZX2-32415-000	CABLE ASSY., POWER TILT RELAY
HZX2-32435-000	CORD. A. C. GENERATOR · · · · · · · · · · · · · · · · · · ·
HZX2-35470-013	SWITCH ASSY., NEUTRAL · · · · · · · · · · · · · · · · · · F-2-23
HZX2-35470-013	SWITCH ASSY., NEUTRAL · · · · · · · · · · · · · · · · · · ·
HZX2-36120-013	MOTOR ASSY., POWER TILT • • • • • • • • • • • • • • • F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT • • • • • • • • • • • • • • • F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT
HZX2-36120-013	MOTOR ASSY., POWER TILT • • • • • • • • • • • • • • • • • F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT • • • • • • • • • • • • • • • • • F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT • • • • • • • • • • • • • • • • • F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT · · · · · · · · · · · · · · · · · F-11-5
HZX2-36120-013	MOTOR ASSY., POWER TILT · · · · · · · · · · · · · · · · · F-11-5
HZX2-36122-003	BRACKET ASSY. • • • • • • F-11-6
HZX2-36122-003	BRACKET ASSY. • • • • • • F-11-6
HZX2-36122-003	BRACKET ASSY. • • • • • • F-11-6
HZX2-36122-003	BRACKET ASSY. • • • • • • F-11-6
HZX2-36122-003	BRACKET ASSY. • • • • • • F-11-6
HZX2-36122-003	BRACKET ASSY. • • • • • • F-11-6
HZX2-36122-013	BRACKET ASSY. • • • • • • F-11-6
HZX2-36122-013	BRACKET ASSY. • • • • • • • F-11-6
HZX2-36122-013	BRACKET ASSY. • • • • • • • F-11-6
HZX2-36122-013	BRACKET ASSY. • • • • • • F-11-6
HZX2-36122-013	BRACKET ASSY. • • • • • • • F-11-6
HZX2-36122-013	BRACKET ASSY. • • • • • • • • • • • • • • F-11-6
HZX2-36122-023	BRACKET ASSY. • • • • • • • • • • • • • • • F-11-6
HZX2-36122-023	BRACKET ASSY. • • • • • • • • • • • • • • F-11-6
HZX2-36122-023	BRACKET ASSY. • • • • • • F-11-6
HZX2-36122-023	BRACKET ASSY. • • • • • • • • • • • • • • • F-11-6
HZX2-36122-023	BRACKET ASSY. • • • • • • • F-11-6
HZX2-36122-023	BRACKET ASSY. • • • • • • • • • • • • • • F-11-6
HZX2-36129-003	YOKE ASSY. • • • • • • F-11-8
HZX2-38228-003	FUSE, BLOCK (150A) • • • • • • • • • • • • • • • • • • •
HZX2-38552-000	CASE, POWER TILT RELAYF-7-10-12
HZX2-41101-C01ZC	CASE, GEAR
HZX2-41102-E00ZC	COVER, GEAR CASE · · · · · · · · · · · · · · · · · · ·
HZX2-41107-C00ZC	TAB, TRIM F-3-8
HZX2-41110-305ZB	CASE COMP., GEAR · · · · · · · · · · · · · · · · · · ·
HZX2-41112-C00	SHAFT, VERTICAL (L) · · · · · · · · · · · · · · · · · · ·
HZX2-41112-C10	SHAFT, VERTICAL (XL) · · · · · · · · · · · · · · · · · · ·
HZX2-41112-C20	SHAFT, VERTICAL (XXL) · · · · · · · · · · · · · · · · · · ·
HZX2-41150-E00	GEAR COMP., BEVEL (REVERSE) · · · · · · · · · · · · · · · · · · ·
HZX2-41151-C00	GEAR, BEVEL (REVERSE) (24T) · · · · · · · · · · · · · · · · · · F-5-9
HZX2-41161-C00	SHAFT, PROPELLER · · · · · · · · · · · · · · · · · · ·
HZX2-41161-E00	SHAFT, PROPELLER · · · · · · · · · · · · · · · · · · ·

HZX2-41200-E00	HOLDER ASSY., BEARING • • • • • • • • • • • • • • • • • • •
HZX2-41202-C00	HOLDER, BEARING · · · · · · · · · · · · · · · · · · ·
HZX2-56000-043	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-043	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-043	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-043	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-043	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-043	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-053	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-053	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-053	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-053	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-053	TRIM-TILT ASSY., POWER F-11-13
HZX2-56000-053	TRIM-TILT ASSY., POWER F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER F-11-13
HZX2-56000-063	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-063	TRIM-TILT ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZX2-56000-063	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-063	TRIM-TILT ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZX2-56000-073	TRIM-TILT ASSY., POWER • • • • • • • • • • • • • • • • • • •
HZX2-56000-073	TRIM-TILT ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZX2-56000-073	TRIM-TILT ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZX2-56000-073	TRIM-TILT ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZX2-56000-073	TRIM-TILT ASSY. POWER · · · · · · · · · · · · · · · · · · ·
HZX2-56000-073	TRIM-TILT ASSY., POWER · · · · · · · · · · · · · · · · · · ·
HZX2-56532-C00	PIN, UPPER CYLINDER · · · · · · · · · · · · · · · · · F-11-26
HZX2-58130-T01	PROPELLER COMP., THREE BLADES • • • • • • • • • • • • • • • • FOP-15-1
HZX2-58130-T11	PROPELLER COMP., THREE BLADES • • • • • • • • • • • • • • • • FOP-15-1
HZX2-58130-T21	PROPELLER COMP., THREE BLADES · · · · · · · · · · · · · · · · FOP-15-1
HZX2-58130-T31	PROPELLER COMP., THREE BLADES · · · · · · · · · · · · · · · · FOP-15-1
HZX2-58130-T41	PROPELLER COMP., THREE BLADES · · · · · · · · · · · · · · · · FOP-15-1
HZX2-58130-T51	PROPELLER COMP. THREE BLADES · · · · · · · · · · · · · · · · · FOP-15-1
HZX2-58130-T61	PROPELLER COMP. THREE BLADES FOP-15-1
HZX2-58180-T01	PROPELLER COMP., THREE BLADES · · · · · · · · · · · · · · · · FOP-15-1
HZX2-58180-T11	PROPELLER COMP., THREE BLADES · · · · · · · · · · · · · · · · FOP-15-1
HZX2-58180-T21	PROPELLER COMP., THREE BLADES FOP-15-1
HZX2-58180-T31	PROPELLER COMP., THREE BLADES · · · · · · · · · · · · · · · · FOP-15-1
HZX2-58180-T41	PROPELLER COMP., THREE BLADES · · · · · · · · · · · · · · · · FOP-15-1
HZX2-58180-T51	PROPELLER COMP., THREE BLADES · · · · · · · · · · · · · · · · FOP-15-1
HZX2-58180-T61	PROPELLER COMP., THREE BLADES FOP-15-1
HZX2-90001-000	BOLT, 12MM • • • • • • • • • • • • • • • • • •
HZX2-90001-000	BOLT, FLANGE, 10X90 · · · · · · · · · · · · · · · · · · ·
HZX2-90002-000	BOLT, FLANGE, 10X90 E-19-21
HZX2-90002-000	BOLT, FLANGE, 10X90 · · · · · · · · · · · · · · · · · · ·
HZX2-90002-000	BOLT, FLANGE, 6X18 E-4-25
HZX2-90004-000	BOLT, FLANGE, 6X18
	BOLT, FLANGE, 6X18
HZX2-90004-000	DULI, FLANGE, 0A10

HZX2-90004-000	BOLT, FLANGE, 6X18 · · · · · · · · · · · · · · · · · · ·
HZX2-90101-C00	BOLT-WASHER, 6X16 · · · · · · · · · · · · · · · · · · ·
HZX2-90105-C00	BOLT-WASHER, 8X60 · · · · · · · · · · · · · · · · · · ·
HZX2-90105-C00	BOLT-WASHER, 8X60 · · · · · · · · · · · · · · · · · · ·
HZX2-90107-C00	BOLT-WASHER, 10X47 • • • • • • • • • • • • • • • • • • •
HZX2-90129-000	BOLT, HEX., 12X130 F-10-48
HZX2-90301-C00	NUT, LOCK, 68MM F-4-19
HZX2-90303-C00	NUT, HEX., 18MM • • • • • • • • • • • • • • • • • •
HZX2-90504-C00	WASHER, UPPER MOUNTING STOPPER · · · · · · · · · · · · · · · · · · ·
HZX2-90506-C00	WASHER, PROPELLER THRUST · · · · · · · · · · · · · · · · · · ·
HZX2-90506-C00	WASHER, PROPELLER THRUST • • • • • • • • • • • • • • • • • • •
HZX2-90512-C00	WASHER, PROPELLER • • • • • • • • • • • • • • • • • • •
HZX2-90512-C00	WASHER, PROPELLER · · · · · · · · · · · · · · · · · · ·
HZX2-90518-C00	SHIM A, GEAR (0.10) · · · · · · · · · · · · · · · · · · ·
HZX2-90519-C00	SHIM B, GEAR (0.15) · · · · · · · · · · · · · · · · · · ·
HZX2-90520-C00	SHIM C, GEAR (0.30) • • • • • • • • • • • • • • • • • • •
HZX2-90521-C00	SHIM D, GEAR (0.50) · · · · · · · · · · · · · · · · · · ·
HZX2-90528-C00	SHIM A, BEVEL (0.10) • • • • • • • • • • • • • • • • • • •
HZX2-90528-C00	SHIM A, BEVEL (0.10) • • • • • • • • • • • • • • • • • • F-5-1-18
HZX2-90528-E00	SHIM A, BEVEL (0.10) • • • • • • • • • • • • • • • • • • F-5-1-19
HZX2-90529-C00	SHIM B, BEVEL (0.15) • • • • • • • • • • • • • • • • • • •
HZX2-90529-C00	SHIM B, BEVEL (0. 15) • • • • • • • • • • • • • • • • • • •
HZX2-90529-E00	SHIM B, BEVEL (0.15) • • • • • • • • • • • • • • • • • • •
HZX2-90530-C00	SHIM C, BEVEL (0.30) • • • • • • • • • • • • • • • • • • •
HZX2-90530-C00	SHIM C, BEVEL (0.30) • • • • • • • • • • • • • • • • • • F-5-1-18
HZX2-90530-E00	SHIM C, BEVEL (0.30) • • • • • • • • • • • • • • • • • • •
HZX2-90531-C00	SHIM D, BEVEL (0.50) • • • • • • • • • • • • • • • • • • •
HZX2-90531-C00	SHIM D, BEVEL (0.50) • • • • • • • • • • • • • • • • • • •
HZX2-90531-E00	SHIM D, BEVEL (0.50) • • • • • • • • • • • • • • • • • • •
HZX2-90541-E01	WASHER, THRUST, 85X110X2 • • • • • • • • • • • • • • • • • • •
HZX2-90542-E01	WASHER, THRUST, 48X74X3 • • • • • • • • • • • • • • • • • • •
HZX2-90683-003	CLIP, WIRE HARNESS · · · · · · · · · · · · · · · · · ·
HZX2-91051-C01	BEARING, TAPER ROLLER, • • • • • • • • • • • • • • • • • • •
HZX2-91053-C01	BEARING, NEEDLE, 30.5X47X37 · · · · · · · · · · · · · · · · · F-4-25
HZX2-91054-E01	BEARING, THRUST NEEDLE, • • • • • • • • • • • • • • • • • • •
HZX2-91055-C01	BEARING, RADIAL BALL, · · · · · · · · · · · · · · · · · ·
HZX2-91055-C01	BEARING, RADIAL BALL, • • • • • • • • • • • • • • • • • •
HZX2-91056-C01	BEARING, TAPER ROLLER, • • • • • • • • • • • • • • • • • • •
HZX2-91351-C00	0-RING, 121X3.1 • • • • • • • • • • • • • • • • • • •
HZX2-91351-C00	0-RING, 121X3.1 · · · · · · · · · · · · · · · · · · ·
HZX2-91351-C00	0-RING, 121X3.1 · · · · · · · · · · · · · · · · · · ·
HZX2-91352-003	0-RING, 1.68X7.25 · · · · · · · · · · · · · · · · · · ·
HZX2-91358-003	SEAL, WATER · · · · · · · · · · · · · · · · · · ·
HZX2-91358-C00	O-RING, WATER PUMP HOUSING • • • • • • • • • • • • • • • • • • F-4-31
HZX2-91358-C00	O-RING, WATER PUMP HOUSING • • • • • • • • • • • • • • • • • • •
HZX2-91359-C00	0-RING, 65. 4X2. 4 · · · · · · · · · · · · · · · · · ·
HZX2-91359-C00	O-RING, 65. 4X2. 4 · · · · · · · · · · · · · · · · · ·
HZX2-91557-003	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·

HZX2-91557-003	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·
HZX2-91557-003	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·
HZX2-91557-003	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·
HZX2-91557-003	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·
HZX2-91557-003	COLLAR, ORIFICE · · · · · · · · · · · · · · · · · · ·
HZY1-90205-000	NUT, SELF-LOCK, 6MM····· F-2-31
HZY1-90205-000	NUT, SELF-LOCK, 6MM····· F-2-1-22
HZY1-90205-000	NUT, SELF-LOCK, 6MM····· F-3-19
HZY1-90205-000	NUT, SELF-LOCK, 6MM······ F-8-9
HZY1-90205-000	NUT, SELF-LOCK, 6MM····· F-10-49
HZY1-90205-000	NUT, SELF-LOCK, 6MM······ FOP-18-14
HZY1-90650-003	TIE, CABLE · · · · · · · · · · · · · · · · · · ·
HZY2-15810-000ZA	VALVE ASSY., SPOOL · · · · · · · · · · · · · · · · · ·
HZY2-15825-000	FILTER ASSY., SPOOL VALVE · · · · · · · · · · · · · · · · E-3-19
HZY3-06532-U00	ROD KIT, STEERING · · · · · · · · · · · · · · · · · · ·
HZY3-11300-C00	CASE ASSY., OIL SEAL · · · · · · · · · · · · · · · · · · ·
HZY3-11871-000	PLATE, R. TIMING BELT COVER • • • • • • • • • • • • • • • • • E-13-10-5
HZY3-11911-010	HANGER, ENGINE · · · · · · · · · · · · · · · · · · ·
HZY3-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZY3-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZY3-12155-000	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZY3-12155-000	METAL, ANODE • • • • • • • • • • • • • • • • • • •
HZY3-12155-000	METAL, ANODE • • • • • • • • • • • • • • • • • • •
HZY3-12155-000	METAL, ANODE • • • • • • • • • • • • • • • • • • •
HZY3-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZY3-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZY3-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZY3-12155-010	METAL, ANODE • • • • • • • • • • • • • • • • • • •
HZY3-12155-010	METAL, ANODE • • • • • • • • • • • • • • • • • • •
HZY3-12155-010	METAL, ANODE · · · · · · · · · · · · · · · · · · ·
HZY3-12160-000	BOLT ASSY., SEALING, 22MM····· FOP-18-1-3
HZY3-12160-000	BOLT ASSY., SEALING, 22MM··································
HZY3-12160-000	BOLT ASSY., SEALING, 22MM····· FOP-18-1-3
HZY3-12160-000	BOLT ASSY., SEALING, 22MM····· FOP-18-1-3
HZY3-12160-000	BOLT ASSY., SEALING, 22MM····· FOP-18-1-3
HZY3-12160-000	BOLT ASSY., SEALING, 22MM····· FOP-18-1-3
HZY3-12160-000	BOLT ASSY., SEALING, 22MM····· E-3-54
HZY3-12160-000	BOLT ASSY., SEALING, 22MM····· E-3-54
HZY3-12160-000	BOLT ASSY., SEALING, 22MM····· E-3-54
HZY3-12160-010	BOLT ASSY., SEALING, 22MM····· FOP-18-1-3
HZY3-12160-010	BOLT ASSY., SEALING, 22MM····· FOP-18-1-3
HZY3-12160-010	BOLT ASSY., SEALING, 22MM····· FOP-18-1-3
HZY3-12160-010	BOLT ASSY., SEALING, 22MM··································

HZY3-12160-010	BOLT ASSY., SEALING, 22MM························ FOP-18-1	-3
HZY3-12160-010	BOLT ASSY., SEALING, 22MM··································	-3
HZY3-12160-010	BOLT ASSY., SEALING, 22MM······ E-3-54	
HZY3-12160-010	BOLT ASSY., SEALING, 22MM······ E-3-54	
HZY3-12160-010	BOLT ASSY., SEALING, 22MM······ E-3-54	
HZY3-12164-000	BOLT, SEALING, 22MM····· E-3-6	
HZY3-12171-305	WASHER, SEALING, 22MM··································	-4
HZY3-12171-305	WASHER, SEALING, 22MM······ E-3-7	
HZY3-12241-000	COVER, L. CAMSHAFT THRUST • • • • • • • • • • • • • E-9-8	
HZY3-12251-A01	GASKET COMP., CYLINDER HEAD • • • • • • • • • • • • • • • E-9-9	
HZY3-12251-A01	GASKET COMP., CYLINDER HEAD (NIPPON LEAKLESS) • • • • • • • • • EOP-1-3	
HZY3-12312-000	PACKING, HEAD COVER • • • • • • • • • • • • • • • • • • •	
HZY3-12312-000	PACKING, HEAD COVER • • • • • • • • • • • • • • • • • • •	
HZY3-13331-A06	WASHER, THRUST · · · · · · · · · · · · · · · · · · ·	
HZY3-13391-010	RETAINER, SPRING · · · · · · · · · · · · · · · · · · ·	
HZY3-13398-003	SPRING, SUPPORT · · · · · · · · · · · · · · · · · · ·	
HZY3-13621-C01	PULLEY, TIMING BELT DRIVE E-13-1	
HZY3-14261-C00	PULLEY COMP., R. TIMING BELT DRIVEN E-13-4	
HZY3-14510-013	TENSIONER COMP., TIMING BELTE-13-7	
HZY3-14515-000	CAP, TIMING BELT TENSIONER • • • • • • • • • • • • • • • • • • E-13-8	
HZY3-14520-000	SPRING COMP., TIMING BELT ADJUSTING • • • • • • • • • • • E-13-9	
HZY3-14529-000	O-RING, TIMING BELT TENSIONER BASE E-13-11	
HZY3-14529-000	O-RING, TIMING BELT TENSIONER BASE • • • • • • • • • • • • • • EOP-1-5	
HZY3-14550-003	IDLER, TIMING BELT(KOYO SEIKO) · · · · · · · · · · · · · · · · · · E-13-12	
HZY3-14555-003	IDLER B, TIMING BELT · · · · · · · · · · · · · · · · · · ·	
HZY3-15112-013	PACKING, OIL PUMP BODY · · · · · · · · · · · · · · · · · · E-5-2	
HZY3-15112-013	PACKING, OIL PUMP BODY · · · · · · · · · · · · · · · · · · ·	
HZY3-15113-000	RUBBER, OIL PUMP · · · · · · · · · · · · · · · · · · ·	
HZY3-15121-000	COVER, OIL PUMP · · · · · · · · · · · · · · · · · E-5-4	
HZY3-15131-405	ROTOR, OIL PUMP INNER · · · · · · · · · · · · · · · · · E-5-5	
HZY3-15132-405	ROTOR, OIL PUMP OUTER • • • • • • • • • • • • • • • • • • E-5-6	
HZY3-15220-020	STRAINER COMP., OIL · · · · · · · · · · · · · · · · · · E-5-7	
HZY3-15425-010	TUBE, OIL · · · · · · · · · · · · · · · · · · ·	
HZY3-15657-000	PACKING, OIL LEVEL GAUGE · · · · · · · · · · · · · · · · · · ·	
HZY3-15825-003	FILTER ASSY., SPOOL VALVE • • • • • • • • • • • • • • • • E-3-19	
HZY3-16011-A01	VALVE SET, FLOAT · · · · · · · · · · · · · · · · · · ·	
HZY3-16013-000	FLOAT SET - · · · · · · · · · · · · · · · · · ·	
HZY3-16016-003	SCREW SET E-15-1	
HZY3-16024-000	SCREW SET, DRAIN · · · · · · · · · · · · · · · · · · ·	
HZY3-16026-000	JOINT SET E-18-6	
HZY3-16031-010	STAY, PLATE · · · · · · · · · · · · · · · · · · ·	
HZY3-16031-010	STAY, PLATE · · · · · · · · · · · · · · · · · · ·	
HZY3-16031-010	STAY, PLATE · · · · · · · · · · · · · · · · · · ·	
HZY3-16031-020	STAY, PLATE · · · · · · · · · · · · · · · · · · ·	
HZY3-16031-020	STAY, PLATE · · · · · · · · · · · · · · · · · · ·	
HZY3-16031-020	STAY, PLATE · · · · · · · · · · · · · · · · · · ·	
HZY3-16036-003	PUMP UNIT SET B, FUEL • • • • • • • • • • • • • • • • • • E-18-9	
HZY3-16041-000	PLATE E-18-10	

HZY3-16042-000	HOLDER	• E−18−11
HZY3-16061-010	COVER, WATER JACKET	E-18-12
HZY3-16072-000	0-RING	• E-18-13
HZY3-16073-000	0-RING	• E-18-14
HZY3-16074-000	0-RING • • • • • • • • • • • • • • • • • • •	• E-18-15
HZY3-16075-000	0-RING	
HZY3-16076-000	0-RING • • • • • • • • • • • • • • • • • • •	• E-18-17
HZY3-16077-000	0-RING • • • • • • • • • • • • • • • • • • •	
HZY3-16078-000	0-RING • • • • • • • • • • • • • • • • • • •	
HZY3-16082-000	SCREW, PAN · · · · · · · · · · · · · · · · · · ·	
HZY3-16083-000	SCREW. WASHER • • • • • • • • • • • • • • • • • • •	
HZY3-16087-000	WASHER, PLAIN · · · · · · · · · · · · · · · · · · ·	
HZY3-16088-000	COLLAR	
HZY3-16176-000	GASKET, THROTTLE BODY · · · · · · · · · · · · · · · · · · ·	
HZY3-16193-A00	CLAMP, CHECK VALVE · · · · · · · · · · · · · · · · · · ·	
HZY3-16196-A00	TUBE, CHECK VALVE · · · · · · · · · · · · · · · · · · ·	
HZY3-16197-000	TUBE A, AIR VENT · · · · · · · · · · · · · · · · · · ·	
HZY3-16198-A00	TUBE B, AIR VENT	
HZY3-16199-A00	TUBE COMP., AIR VENT	
HZY3-16400-A01	THROTTLE BODY ASSY	
HZY3-16400-A02	THROTTLE BODY ASSY	
HZY3-16400-A03	THROTTLE BODY ASSY	
HZY3-16405-000	GASKET, EAC VALVE · · · · · · · · · · · · · · · · · · ·	
HZY3-16451-000	CLIP, INJECTOR · · · · · · · · · · · · · · · · · · ·	
HZY3-16611-A00	PIPE, R. FUEL	
HZY3-16620-A00	PIPE COMP., L. FUEL	
HZY3-16708-000	COVER, PUMP	
HZY3-16721-000	INSULATOR • • • • • • • • • • • • • • • • • • •	
HZY3-16733-000	GROMMET, VAPOR SEPARATOR · · · · · · · · · · · · · · · · · · ·	
HZY3-16734-000	STAY, PLATE	
	PUMP UNIT, FUEL	
HZY3-16735-004	REGULATOR ASSY., PRESSURE	
HZY3-16740-A01	JOINT, FUEL PIPE	
HZY3-16752-000	JOINT, FUEL PIPE	
HZY3-16752-A00	HOSE COMP., FUEL JOINT	
HZY3-16757-003	O-RING · · · · · · · · · · · · · · · · · · ·	
HZY3-16818-003		
HZY3-16901-003	STRAINER, FUEL	
HZY3-16901-003	STRAINER, FUEL	
HZY3-16904-003	SCREW, PAN, 5X12 · · · · · · · · · · · · · · · · · · ·	
HZY3-16915-010	SUSPENSION, STRAINER · · · · · · · · · · · · · · · · · · ·	
HZY3-16918-003	0-RING • • • • • • • • • • • • • • • • • • •	
HZY3-16918-003	0-RING	
HZY3-16919-003	PLATE	
HZY3-17051-A00	BASE, R. INJECTOR	
HZY3-17061-A00	BASE, L. INJECTOR · · · · · · · · · · · · · · · · · · ·	
HZY3-17105-004	GASKET, INTAKE MANIFOLD	
HZY3-17108-000	SPACER, INTAKE MANIFOLD	
H7Y3-17109-004	PACKING THROTTLE BODY	• F-14-10-2

HZY3-17138-004	PACKING, INTAKE MANIFOLD UP · · · · · · · · · · · · · · · · · ·	E-14-10-5
HZY3-17721-000	JOINT, FUEL RETURN	• E-18-10-17
HZY3-17723-A01	HOSE A, PRESSURE REGULATOR · · · · · · · · · · · · · · · · · · ·	• E-18-10-18
HZY3-17724-010	HOSE B, PRESSURE REGULATOR • • • • • • • • • • • • • • • • • • •	• E-18-10-19
HZY3-17738-000	PLUG, FUEL TUBE · · · · · · · · · · · · · · · · · · ·	E-18-1-13
HZY3-17931-000	ARM, THROTTLE • • • • • • • • • • • • • • • • • • •	F-2-4
HZY3-18115-003	GASKET, R. EX. MANIFOLD	E-4-3
HZY3-18115-003	GASKET, R. EX. MANIFOLD	E0P-1-10
HZY3-18115-003	GASKET, R. EX. MANIFOLD	F0P-18-1-7
HZY3-18125-003	GASKET, L. EX. MANIFOLD	E-4-5
HZY3-18125-003	GASKET, L. EX. MANIFOLD	E0P-1-11
HZY3-18125-003	GASKET, L. EX. MANIFOLD	F0P-18-1-8
HZY3-18141-A00ZA	GUIDE, R. EX.	E-6-10-3
HZY3-18148-003	SEAL, EXHAUST GUIDE · · · · · · · · · · · · · · · · · · ·	
HZY3-18149-A01	SEAL B, EX. GUIDE • • • • • • • • • • • • • • • • • • •	E-6-10-5
HZY3-18151-A00ZA	GUIDE, L. EX.	
HZY3-18330-020	PIPE COMP., R. EX.	• E−6−3
HZY3-18340-020	PIPE COMP., L. EX. · · · · · · · · · · · · · · · · · · ·	• E-6-5
HZY3-19210-003	IMPELLER, PUMP · · · · · · · · · · · · · · · · · · ·	• F-4-1
HZY3-19210-003	IMPELLER, PUMP · · · · · · · · · · · · · · · · · · ·	• F0P-2-3
HZY3-19210-003	IMPELLER, PUMP · · · · · · · · · · · · · · · · · · ·	• F0P-18-5
HZY3-19221-010	HOUSING, IMPELLER · · · · · · · · · · · · · · · · · · ·	F-4-2
HZY3-19221-010	HOUSING, IMPELLER · · · · · · · · · · · · · · · · · · ·	F0P-2-4
HZY3-19223-000	LINER, PUMP	F-4-3
HZY3-19223-000	LINER, PUMP	F0P-2-5
HZY3-19223-000	LINER, PUMP	F0P-18-6
HZY3-19231-000	COVER, IMPELLER · · · · · · · · · · · · · · · · · · ·	F-4-4
HZY3-19231-000	COVER, IMPELLER · · · · · · · · · · · · · · · · · · ·	F0P-2-6
HZY3-19231-000	COVER, IMPELLER · · · · · · · · · · · · · · · · · · ·	F0P-18-7
HZY3-19251-000	TUBE, WATER (L) $\cdots \cdots \cdots$	• F-4-7
HZY3-19251-611	TUBE, WATER (XL) $\cdots \cdots \cdots$	F-4-7
HZY3-19251-621	TUBE, WATER(XXL) · · · · · · · · · · · · · · · · · · ·	• F-4-7
HZY3-19252-000	GROMMET, WATER TUBE • • • • • • • • • • • • • • • • • • •	E-6-6
HZY3-19253-000	RING, WATER TUBE SEAL	F-4-8
HZY3-19253-000	RING, WATER TUBE SEAL	F0P-2-8
HZY3-19253-000	RING, WATER TUBE SEAL · · · · · · · · · · · · · · · · · · ·	F0P-18-9
HZY3-19254-000	PLATE, WATER TUBE • • • • • • • • • • • • • • • • • • •	E-6-7
HZY3-19256-010	TUBE, WATER RELIEF	• E-4-7
HZY3-19257-010	TUBE, WATER · · · · · · · · · · · · · · · · · · ·	E-4-8
HZY3-19258-010	TUBE, WATER IN.	E-18-10-20
HZY3-19259-000	TUBE, WATER OUTLET • • • • • • • • • • • • • • • • • • •	• E-18-10-21
HZY3-19261-000	TUBE, L. WATER RETURN	E-4-9
HZY3-19270-000	NUT, WATER MOUTH · · · · · · · · · · · · · · · · · · ·	
HZY3-19271-000	JOINT, WATER HOSE • • • • • • • • • • • • • • • • • • •	
HZY3-19272-000	SEAT, WATER MOUTH • • • • • • • • • • • • • • • • • • •	F-3-20-3
HZY3-19277-000ZA	COVER, FLUSH VALVE • • • • • • • • • • • • • • • • • • •	• E-6-10-8
HZY3-19278-000	CASE, FLUSH VALVE	E-6-10-9
HZY3-19289-000	CAP, WATER JOINT • • • • • • • • • • • • • • • • • • •	• F-3-20-5

HZY3-19294-000ZB	SPACER, R. RELIEF VALVE
HZY3-19295-000	COVER, R. RELIEF VALVE COVER
HZY3-19296-000	PACKING, RELIEF VALVE COVER · · · · · · · · · · · · · · · · · E-6-10-16
HZY3-19297-000	COVER, L. RELIEF VALVE
HZY3-19298-000ZB	SPACER, L. RELIEF VALVE · · · · · · · · · · · · · · · · · · ·
HZY3-23173-010	RUBBER, MOUNT CASE SEAL · · · · · · · · · · · · · · · · · · ·
HZY3-24102-000	PIN, SHIFTER, 8X50 · · · · · · · · · · · · · · · · · · ·
HZY3-24102-000	PIN, SHIFTER, 8X50 · · · · · · · · · · · · · · · · · · ·
HZY3-24103-000	RING, CROSS PIN · · · · · · · · · · · · · · · · · · ·
HZY3-24103-000	RING, CROSS PIN · · · · · · · · · · · · · · · · · · ·
HZY3-24113-A01	SLIDER COMP., SHIFT
HZY3-24113-A01	SLIDER COMP., SHIFT
HZY3-24122-A01	SLIDER, SHIFT · · · · · · · · · · · · · · · · · · ·
HZY3-24122-A01	SPRING, SHIFT · · · · · · · · · · · · · · · · · · ·
HZY3-24123-000	SPRING, SHIFT
HZY3-24123-000	PLATE, SHIFT · · · · · · · · · · · · · · · · · · ·
HZY3-24124-310	PLATE, SHIFT · · · · · · · · · · · · · · · · · · ·
HZY3-24124-310 HZY3-24221-000	SPRING, CLICK ASSIST · · · · · · · · · · · · · · · · · · ·
HZY3-24221-000	SPRING, CLICK ASSIST · · · · · · · · · · · · · · · · · · ·
	ROD COMP. SHIFT
HZY3-24310-C00	ROD COMP., SHIFT
HZY3-24310-E00 HZY3-24318-000	SPRING, SHIFT ROD · · · · · · · · · · · · · · · · · · ·
HZY3-24310-000	ROD COMP. A, SHIFT (XXL) · · · · · · · · · · · · · · · · · · ·
HZY3-24610-A00	SHAFT COMP., SHIFT (A) · · · · · · · · · · · · · · · · · · ·
	SHAFT COMP., SHIFT(A) · · · · · · · · · · · · · · · · · · ·
HZY3-24610-A00 HZY3-24617-000	COLLAR, SHIFT SLIDER · · · · · · · · · · · · · · · · · · ·
HZY3-24618-000	PIVOT, SHIFT
	PLATE, LOCK
HZY3-24619-000 HZY3-24620-000	SHAFT COMP. SHIFT(B) · · · · · · · · · · · · · · · · · · ·
HZY3-24620-000	SHAFT COMP., SHIFT(B) · · · · · · · · · · · · · · · · · · ·
HZY3-31116-000	BOSS, FLYWHEEL
HZY3-31200-003	MOTOR ASSY., STARTER · · · · · · · · · · · · · · · · · · ·
HZY3-31216-003	YOKE COMP E-21-5
HZY3-31226-003	BRUSH SET E-21-7
HZY3-31232-003	HOLDER COMP., BRUSH · · · · · · · · · · · · · · · · · · ·
HZY3-31235-003	BRACKET, FR. • • • • • • • • • • • • • • • • • • •
HZY3-31236-003	BRACKET, RR. • • • • • • • • • • • • • • • • • •
HZY3-31241-003	SWITCH ASSY., MAGNET E-21-13
HZY3-31243-003	SHAFT ASSY., CLUTCH · · · · · · · · · · · · · · · · · · ·
HZY3-31250-003	LEVER SET E-21-17
HZY3-31251-003	GEAR ASSY., INTERNAL • • • • • • • • • • • • • • • • • • •
HZY3-31630-013	GENERATOR ASSY., A. C. · · · · · · · · · · · · · · · · · E-19-14
HZY3-31631-003	ROTOR ASSY E-19-15
HZY3-31638-003	BELT, A. C. GENERATOR · · · · · · · · · · · · · · · · · · ·
HZY3-31639-003	END COVER, RR E-19-17
HZY3-31694-003	BUSH, INSULATION · · · · · · · · · · · · · · · · · · ·
HZY3-31710-003	RECTIFIER ASSY. • • • • • • • • • • • • • • • • • • •
10 01710 000	10 10 10 10 10 10 10 10 10 10 10 10 10 1

HZY3-31750-003	REGULATOR ASSY.	• • E-19-20
HZY3-32112-000	BRACKET, HARNESS CLIP A · · · · · · · · · · · · · · · · · ·	• • E-14-23
HZY3-32129-000	BRACKET C, HARNESS CLIP	• • E-1-10
HZY3-32370-H01	BOX ASSY., JUNCTION	• • F-7-20-1
HZY3-32371-H01	COVER COMP., FUSE	• • F-7-20-2
HZY3-32411-003	COVER, STARTER TERMINAL	• • F-7-10-4
HZY3-35476-010	BRACKET, NEUTRAL SWITCH	• • F-2-24
HZY3-35476-010	BRACKET, NEUTRAL SWITCH	• • F-2-1-16
HZY3-35640-013	SWITCH ASSY., POWER TILT	• • F-3-20-7
HZY3-35660-003	SENSOR ASSY., TRIM ANGLE	• • • F-10-7
HZY3-35673-003	SENSOR ASSY., WATER • • • • • • • • • • • • • • • • • • •	• • E-3-23
HZY3-35673-003	SENSOR ASSY., WATER	• • E-4-14
HZY3-36123-013	ARMATURE COMP.	• • • F-11-7
HZY3-36550-003	VALVE ASSY., EAC	• • E-15-12
HZY3-40202-621ZC	SEPARATOR, EXTENSION	• • • F-3-2
HZY3-40204-000	GROMMET, EXTENSION CASE	• • F-4-13
HZY3-40210-610	BUSH COMP., VERTICAL SHAFT	• • F-3-20-20
HZY3-40219-023	WIRE, LEAD(1.5X116MM) • • • • • • • • • • • • • • • • • •	• • F-10-9
HZY3-40219-023	WIRE, LEAD(1.5X116MM) • • • • • • • • • • • • • • • • • •	· · F-11-11
HZY3-41104-C01	SCREEN, R. WATER	• • • F-3-6
HZY3-41105-C01	SCREEN, L. WATER • • • • • • • • • • • • • • • • • • •	• • • F-3-7
HZY3-41116-000	SLINGER, OIL · · · · · · · · · · · · · · · · · · ·	• • • F-4-15
HZY3-50111-020	HOUSING, LOWER MOUNTING	• • F-3-20-21
HZY3-50151-000	MOUNT COMP., UPPER RUBBER • • • • • • • • • • • • • • • • • • •	• • F-10-15
HZY3-50153-000	RUBBER, UPPER MOUNT STOPPER • • • • • • • • • • • • • • • • • • •	• • F-10-16
HZY3-50155-000	MOUNT COMP., LOWER RUBBER • • • • • • • • • • • • • • • • • • •	• • F-3-20-22
HZY3-50157-010	STOPPER, LOWER MOUNT	• • F-3-20-23
HZY3-50161-000ZD	HOUSING, LOWER CENTER MOUNTING	• • F-10-17
HZY3-50161-610	HOUSING, LOWER CENTER MOUNTING	• • F-10-17
HZY3-50211-000	LINER, SWIVEL CASE	
HZY3-50214-000	BUSH, SWIVEL CASE	• • F-10-21
HZY3-50301-030ZC	BRACKET, R. STERN · · · · · · · · · · · · · · · · · · ·	• • F-10-25
HZY3-50522-000	BUSH, TILT ARM · · · · · · · · · · · · · · · · · · ·	• • F-10-28
HZY3-50527-000	BRACKET, TILTING · · · · · · · · · · · · · · · · · · ·	• • F-10-29
HZY3-56100-013	PUMP ASSY.	• • • F-11-14
HZY3-56100-013	PUMP ASSY.	· • • F-11-14
HZY3-56100-013	PUMP ASSY.	
HZY3-56100-023	PUMP ASSY.	· • • F-11-14
HZY3-56100-023	PUMP ASSY.	• • • F-11-14
HZY3-56100-023	PUMP ASSY.	
HZY3-56120-023	ROD COMP., PISTON • • • • • • • • • • • • • • • • • • •	
HZY3-56170-013	VALVE COMP., MANUAL	• • F-11-23

HZY3-56170-013	VALVE COMP., MANUAL	F-11-23
HZY3-56170-013	VALVE COMP., MANUAL	
HZY3-56170-013	VALVE COMP., MANUAL · · · · · · · · · · · · · · · · · · ·	
HZY3-56170-013	VALVE COMP., MANUAL · · · · · · · · · · · · · · · · · · ·	
HZY3-56170-013	VALVE COMP., MANUAL	
HZY3-56170-023	VALVE COMP., MANUAL · · · · · · · · · · · · · · · · · · ·	
HZY3-56170-023	VALVE COMP., MANUAL · · · · · · · · · · · · · · · · · · ·	
HZY3-56170-023	VALVE COMP., MANUAL · · · · · · · · · · · · · · · · · · ·	
HZY3-56170-023	VALVE COMP., MANUAL	
HZY3-56170-023	VALVE COMP., MANUAL · · · · · · · · · · · · · · · · · · ·	
HZY3-56170-023	VALVE COMP., MANUAL · · · · · · · · · · · · · · · · · · ·	
HZY3-56516-A00	RECEIVER, THRUST · · · · · · · · · · · · · · · · · · ·	
HZY3-56518-A00	BUSH A, THRUST RECEIVE	
HZY3-56519-A00	BUSH B, THRUST RECEIVE	
	BOLT, HEX., 12X120 · · · · · · · · · · · · · · · · · · ·	
HZY3-90010-000	BOLT, HEX., 12X65	
HZY3-90011-000	BOLT, HEX., 10X85	
HZY3-90013-000		
HZY3-90015-000	BOLT, HEX., 10X60	
HZY3-90026-000	BOLT, FLANGE, 8X20 · · · · · · · · · · · · · · · · · · ·	
HZY3-90026-000	BOLT, FLANGE, 8X20 · · · · · · · · · · · · · · · · · · ·	
HZY3-90031-000	BOLT, FLANGE, 6X32 · · · · · · · · · · · · · · · · · · ·	
HZY3-90031-000	BOLT, FLANGE, 6X32 · · · · · · · · · · · · · · · · · · ·	
HZY3-90031-000	BOLT, FLANGE, 6X32 · · · · · · · · · · · · · · · · · · ·	
HZY3-90044-000	BOLT, STUD, 8X45 · · · · · · · · · · · · · · · · · · ·	
HZY3-90044-000	BOLT, STUD, 8X45 · · · · · · · · · · · · · · · · · · ·	
HZY3-90044-000	BOLT, STUD, 8X45 · · · · · · · · · · · · · · · · · · ·	
HZY3-90055-000	BOLT, TENSIONER · · · · · · · · · · · · · · · · · · ·	
HZY3-90055-000	BOLT, TENSIONER · · · · · · · · · · · · · · · · · · ·	
HZY3-90055-000	BOLT, TENSIONER • • • • • • • • • • • • • • • • • • •	
HZY3-90059-000	BOLT-WASHER, 6X29 · · · · · · · · · · · · · · · · · · ·	
HZY3-90082-003	CAP, BOLT, 10MM···································	
HZY3-90104-010	BOLT, HEX., 12X200 · · · · · · · · · · · · · · · · · ·	
HZY3-90105-010	BOLT, HEX., 14X180 • • • • • • • • • • • • • • • • • • •	
HZY3-90106-A00	BOLT, FLANGE, 8X22 · · · · · · · · · · · · · · · · · ·	
HZY3-90107-000	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·	
HZY3-90111-000	BOLT, SPECIAL, 6X17 · · · · · · · · · · · · · · · · · · ·	F-3-30-9
HZY3-90111-000	BOLT, SPECIAL, 6X17 · · · · · · · · · · · · · · · · · · ·	F-3-30-9
HZY3-90111-000	BOLT, SPECIAL, 6X17 · · · · · · · · · · · · · · · · · · ·	F-3-30-9
HZY3-90111-000	BOLT, SPECIAL, 6X17 · · · · · · · · · · · · · · · · · · ·	F-3-30-9
HZY3-90117-000	BOLT, 3/8-24UNF · · · · · · · · · · · · · · · · · · ·	F-10-46
HZY3-90120-000	BOLT, DRAIN PLUG · · · · · · · · · · · · · · · · · · ·	• F-3-15
HZY3-90120-000	BOLT, DRAIN PLUG · · · · · · · · · · · · · · · · · · ·	• F0P-18-13
HZY3-90123-000	BOLT, HEX., 12X45 • • • • • • • • • • • • • • • • • • •	F-5-13
HZY3-90123-000	BOLT, HEX., 12X45 • • • • • • • • • • • • • • • • • • •	F-5-1-13
HZY3-90124-000	BOLT, STUD, 12X40 · · · · · · · · · · · · · · · · · · ·	F-3-16
HZY3-90130-620	BOLT, STUD, 12X170 • • • • • • • • • • • • • • • • • • •	• F-3-17
HZY3-90131-620	BOLT, STUD, 10X170 • • • • • • • • • • • • • • • • • • •	• F-3-18
HZY3-90136-003	SCREW, 4X16	

HZY3-90136-003	SCREW. 4X16 F-11-48
HZY3-90130-003	NUT, FLANGE, 8MM • • • • • • • • • • • • • • • • • •
HZY3-90205-000	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·
	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·
HZY3-90205-000	NUT, SELF-LOCK, 14MM · · · · · · · · · · · · · · · · · ·
HZY3-90302-000	
HZY3-90304-000	NUT-WASHER, 6MM · · · · · · · · · · · · · · · · · ·
HZY3-90405-000	WASHER, PLAIN, 8MM
HZY3-90501-A00	WASHER, WAVE, 12MM F-10-56
HZY3-90503-610	WASHER, 30MM F-3-20-44
HZY3-90509-000	WASHER, 7/8" F-10-60
HZY3-90511-000	WASHER, PLAIN, 14MM····· F-3-20-45
HZY3-90548-000	SHIM A, THRUST (2. 75) • • • • • • • • • • • • • • • • • • •
HZY3-90549-000	SHIM B, THRUST (2.80) • • • • • • • • • • • • • • • • • • •
HZY3-90550-000	SHIM C, THRUST (2.85) • • • • • • • • • • • • • • • • • • •
HZY3-90551-000	SHIM D, THRUST (2.90) • • • • • • • • • • • • • • • • • • •
HZY3-90552-000	SHIM E, THRUST (2.95) • • • • • • • • • • • • • • • • • • •
HZY3-90553-000	SHIM F, THRUST (3.00) • • • • • • • • • • • • • • • • • •
HZY3-90554-000	SHIM G, THRUST (3.05) • • • • • • • • • • • • • • • • • • •
HZY3-90555-000	SHIM H, THRUST (3.10) • • • • • • • • • • • • • • • • • • •
HZY3-90556-000	SHIM I, THRUST (2.70) • • • • • • • • • • • • • • • • • • •
HZY3-90557-000	SHIM J, THRUST (2.65) • • • • • • • • • • • • • • • • • • •
HZY3-90558-000	SHIM K, THRUST (2.60) • • • • • • • • • • • • • • • • • • •
HZY3-90559-000	SHIM L, THRUST (2.55) • • • • • • • • • • • • • • • • • •
HZY3-90560-000	SHIM M, THRUST (2.50) • • • • • • • • • • • • • • • • • • •
HZY3-90601-030	CLAMP, TUBE (D10. 5) • • • • • • • • • • • • • • • • • •
HZY3-90601-030	CLAMP, TUBE (D10. 5) • • • • • • • • • • • • • • • • • •
HZY3-90601-030	CLAMP, TUBE (D10. 5) • • • • • • • • • • • • • • • • • •
HZY3-90601-030	CLAMP, TUBE (D10. 5) • • • • • • • • • • • • • • • • • •
HZY3-90601-030	CLAMP, TUBE (D10. 5) • • • • • • • • • • • • • • • • • •
HZY3-90601-030	CLAMP, TUBE (D10. 5) E-18-10-26
HZY3-90602-020	CLAMP, TUBE (D32. 5) • • • • • • • • • • • • • • • • • •
HZY3-90603-020	CLAMP, TUBE (D29) • • • • • • • • • • • • • • • • • • •
HZY3-90604-020	CLAMP, TUBE (D21) • • • • • • • • • • • • • • • • • • •
HZY3-90652-000	CIRCLIP, INTERNAL, 43 · · · · · · · · · · · · · · · · · ·
HZY3-90653-003	CLIP, WIRE HARNESS F-7-8
HZY3-90741-000	KEY, SPECIAL · · · · · · · · · · · · · · · · · · ·
HZY3-90751-000	PIN, LINK F-2-40
HZY3-90752-003	KEY, WOODRUFF · · · · · · · · · · · · · · · · · ·
HZY3-90752-003	KEY, WOODRUFF · · · · · · · · · · · · · · · · · ·
HZY3-90752-003	KEY, WOODRUFF · · · · · · · · · · · · · · · · · ·
HZY3-91001-003	BEARING, NEEDLE, 20X28X13 · · · · · · · · · · · · · · E-6-10-43
HZY3-91056-711	BEARING, NEEDLE, 28X39X30 · · · · · · · · · · · · · · · · · F-5-1-28
HZY3-91057-003	BEARING, NEEDLE, 32X42X30 · · · · · · · · · · · · · · · · · F-5-27
HZY3-91057-003	BEARING, NEEDLE, 32X42X30 · · · · · · · · · · · · · · · · · F-5-1-29
HZY3-91151-000	ROLLER, 3X13.8 · · · · · · · · · · · · · · · · · · ·
HZY3-91151-000	ROLLER, 3X13.8 • • • • • • • • • • • • • • • • • • •
HZY3-91152-003	RING, INNER (15X20X23) • • • • • • • • • • • • • • • • • • •
HZY3-91152-003	RING, INNER(15X20X23) • • • • • • • • • • • • • • • • • • •

HZY3-91212-003	OIL SEAL, 41X66X8 · · · · · · · · · · · · · · · · · · ·	F-3-41
HZY3-91251-C01	SEAL, WATER, 26X42X7 · · · · · · · · · · · · · · · · · · ·	
HZY3-91251-C01	SEAL, WATER, 26X42X7 · · · · · · · · · · · · · · · · · · ·	
HZY3-91254-003	SEAL, WATER, 12X21X6 · · · · · · · · · · · · · · · · · · ·	
HZY3-91254-003	SEAL, WATER, 12X21X6 · · · · · · · · · · · · · · · · · · ·	
HZY3-91255-003	SEAL, WATER (14X26X8) · · · · · · · · · · · · · · · · · · ·	
HZY3-91255-003	SEAL, WATER (14X26X8) · · · · · · · · · · · · · · · · · · ·	
HZY3-91301-003	0-RING, 66. 4X3. 1 · · · · · · · · · · · · · · · · · ·	
HZY3-91301-003	0-RING, 66. 4X3. 1 · · · · · · · · · · · · · · · · · ·	
HZY3-91301-003	0-RING, 66. 4X3. 1 · · · · · · · · · · · · · · · · · ·	
HZY3-91303-000	O-RING, 59. 4X3. 1 · · · · · · · · · · · · · · · · · ·	
HZY3-91303-000	O-RING, 59. 4X3. 1 · · · · · · · · · · · · · · · · · ·	
HZY3-91304-000	O-RING. 49. 4X3. 1 · · · · · · · · · · · · · · · · · ·	
HZY3-91305-003	0-RING. 33.5X2 · · · · · · · · · · · · · · · · · · ·	
HZY3-91306-003	O-RING, 23.5X2 · · · · · · · · · · · · · · · · · · ·	
HZY3-91356-003	O-RING, WATER PUMP	
HZY3-91356-003	O-RING. WATER PUMP	
HZY3-91356-003	O-RING, WATER PUMP	
HZY3-91401-A00	TUBE COMP. A, BREATHER · · · · · · · · · · · · · · · · · · ·	
HZY3-91402-030	TUBE B, BREATHER · · · · · · · · · · · · · · · · · · ·	
HZY3-91403-000	TUBE C, BREATHER · · · · · · · · · · · · · · · · · · ·	
HZY3-91405-000	TUBE, FLUSH VALVE • • • • • • • • • • • • • • • • • • •	
HZY3-91551-000	COLLAR, DISTANCE · · · · · · · · · · · · · · · · · · ·	
HZY3-91551-000	COLLAR, DISTANCE · · · · · · · · · · · · · · · · · · ·	
HZY3-91556-000	COLLAR, DISTANCE, 6.5X9X3 · · · · · · · · · · · · · · · · · · ·	
HZY3-91560-000	COLLAR, STEERING ROD	
HZY6-06240-R90	BOX KIT, REMOTE CONTROL (TOP MOUNT SINGLE)	
HZY6-06240-S90	BOX KIT, REMOTE CONTROL (TOP MOUNT DUAL)	
HZY6-06241-U10	SPACER KIT, REMOTE CONTROL BOX(TOP MOUNT SINGLE)	
HZY6-06241-V10	SPACER KIT, REMOTE CONTROL BOX(TOP MOUNT DUAL)	
HZY6-06323-R01	PANEL KIT, SWITCH(SINGLE)	
HZY6-06323-R11	PANEL KIT, SWITCH(TWIN)	
HZY6-06323-R21	PANEL KIT, SWITCH(TRIPLE)	
HZY6-16450-003	INJECTOR ASSY., FUEL • • • • • • • • • • • • • • • • • • •	• E-14-1
HZY6-16718-013	INSULATOR COMP.	E-18-32
HZY6-16723-003	RING·····	• E−18−34
HZY6-19269-000	T-JOINT · · · · · · · · · · · · · · · · · · ·	E-18-10-22
HZY6-24320-000	ROD COMP. A, SHIFT(L) · · · · · · · · · · · · · · · · · · ·	F-4-11
HZY6-24320-610	ROD COMP. A, SHIFT(XL) · · · · · · · · · · · · · · · · · · ·	
HZY6-24810-U11	HOUSING ASSY., L. INNER (TOP MOUNT)	
HZY6-24810-U11	HOUSING ASSY., L. INNER(TOP MOUNT)	
HZY6-24810-V11	HOUSING ASSY., R. INNER(TOP MOUNT)	• F0P-3-10-3
HZY6-24811-U11	HANDLE, REMOTE CONTROL	
HZY6-24811-U11	HANDLE, REMOTE CONTROL	
HZY6-24812-U11	COVER, GRIP · · · · · · · · · · · · · · · · · · ·	
HZY6-24812-U11	COVER, GRIP · · · · · · · · · · · · · · · · · · ·	
HZY6-24813-U11	GRIP, REMOTE CONTROL HANDLE	
H7Y6-24813-II11	GRIP REMOTE CONTROL HANDLE	

HZY6-24814-U11	COVER, LEVER · · · · · · · · · · · · · · · · · · ·
HZY6-24814-U11	COVER, LEVER · · · · · · · · · · · · · · · · · · ·
HZY6-24816-U11	BUTTON, THROTTLE · · · · · · · · · · · · · · · · · · ·
HZY6-24816-U11	BUTTON, THROTTLE • • • • • • • • • • • • • • • • • • •
HZY6-24819-U11	BRACKET, REMOTE CONTROL HOUSING • • • • • • • • • • • • • • • FOP-3-9-10
HZY6-24819-V11	BRACKET, REMOTE CONTROL HOUSING • • • • • • • • • • • • • • • FOP-3-10-11
HZY6-24820-U11	HOUSING, SINGLE REMOTE CONTROL BOX • • • • • • • • • • • • • • • • • • •
HZY6-24820-V11	HOUSING, DUAL REMOTE CONTROL BOX · · · · · · · · · · · · · · · · · · ·
HZY6-24821-U11	PLUG, SINGLE HOUSING · · · · · · · · · · · · · · · · · · ·
HZY6-24821-V11	PLUG, DUAL HOUSING · · · · · · · · · · · · · · · · · · ·
HZY6-24824-U11	GUIDE, SINGLE WATER • • • • • • • • • • • • • • • • • • •
HZY6-24824-V11	GUIDE, DUAL WATER • • • • • • • • • • • • • • • • • • •
HZY6-24825-U11	HOUSING, LEAD · · · · · · · · · · · · · · · · · · ·
HZY6-24825-U11	HOUSING, LEAD · · · · · · · · · · · · · · · · · · ·
HZY6-24826-R11	COVER, HOUSING SIDE · · · · · · · · · · · · · · · · · · ·
HZY6-24827-U11	RING, SNAP FOP-3-9-17
HZY6-24827-U11	RING, SNAP FOP-3-10-17
HZY6-24828-U11	GROMMET FOP-3-9-18
HZY6-24828-U11	GROMMET FOP-3-10-18
HZY6-24832-U91	CAP, BLANK • • • • • • • • • • • • • • • • • • •
HZY6-24832-U91	CAP, BLANK • • • • • • • • • • • • • • • • • • •
HZY6-24832-V11	CAP, POWER TRIM-TILT BLANK • • • • • • • • • • • • • • • • • • •
HZY6-24834-V11	PACKING, DUAL (LOOSE PARTS) · · · · · · · · · · · · · · · · · · ·
HZY6-24835-U11	BAND, TY-RAP • • • • • • • • • • • • • • • • • • •
HZY6-32340-R01	PANEL ASSY., CONTROL (SINGLE) · · · · · · · · · · · · · · · · · · ·
HZY6-32340-R11	PANEL ASSY., CONTROL (TWIN)
HZY6-32340-R21	PANEL ASSY., CONTROL (TRIPLE)
HZY6-32346-R01	PANEL, CONTROL (SINGLE) • • • • • • • • • • • • • • • • • • •
HZY6-32346-R11	PANEL, CONTROL (TWIN) · · · · · · · · · · · · · · · · · · ·
HZY6-32346-R21	PANEL, CONTROL (TRIPLE) • • • • • • • • • • • • • • • • • • •
HZY6-32414-640	COVER B, TERMINAL · · · · · · · · · · · · · · · · · · ·
HZY6-32545-003	HARNESS ASSY., SWITCH PANEL • • • • • • • • • • • • • • • • • • •
HZY6-32545-003	HARNESS ASSY., SWITCH PANEL • • • • • • • • • • • • • • • • • FOP-5-1-4
HZY6-32545-003	HARNESS ASSY., SWITCH PANEL • • • • • • • • • • • • • • • • • • •
HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR • • • • • • • • • • • • • • • • • • •
HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR • • • • • • • • • • • • • • • • • • •
HZY6-32606-000	DUMMY, WATER PROOF CONNECTOR • • • • • • • • • • • • • • • • • • •
HZY6-35100-R01	SWITCH ASSY., COMBINATION · · · · · · · · · · · · · · · · · · FOP-5-8
HZY6-35100-R01	SWITCH ASSY., COMBINATION · · · · · · · · · · · · · · · · · · FOP-5-1-8
HZY6-35100-R01	SWITCH ASSY., COMBINATION · · · · · · · · · · · · · · · · · · ·
HZY6-35370-U11	SWITCH ASSY., POWER TRIM-TILT · · · · · · · · · · · · · · · · · FOP-3-9-23
HZY6-35370-U11	SWITCH ASSY., POWER TRIM-TILT · · · · · · · · · · · · · · · · · FOP-3-10-25
HZY6-35370-V11	SWITCH ASSY., POWER TRIM-TILT (PORT) • • • • • • • • • • • • • • • FOP-3-10-26
HZY6-35370-V21	SWITCH ASSY., POWER TRIM-TILT (STAR) • • • • • • • • • • • • • • • • FOP-3-10-27
HZY6-35375-V90	CABLE ASSY., POWER TRIM-TILT · · · · · · · · · · · · · · · · · · ·
HZY6-36135-003	VALVE, CHECK • • • • • • • • • • • • • • • • • • •
HZY6-36180-003	SWITCH ASSY., EMERGENCY STOP · · · · · · · · · · · · · · · · · · ·
HZY6-36180-612	SWITCH ASSY., EMERGENCY STOP · · · · · · · · · · · · · · · · · · ·

HZY6-36180-712	SWITCH ASSY., EMERGENCY STOP · · · · · · · · · · · · · · · · · · ·
HZY6-36182-003	CORD COMP. EMERGENCY · · · · · · · · · · · · · · · · · · ·
HZY6-36182-003	CORD COMP., EMERGENCY · · · · · · · · · · · · · · · · · · ·
HZY6-36182-003	CORD COMP., EMERGENCY · · · · · · · · · · · · · · · · · · ·
HZY6-36182-003	CORD COMP. EMERGENCY · · · · · · · · · · · · · · · · · · ·
HZY6-36182-003	CORD COMP. EMERGENCY · · · · · · · · · · · · · · · · · · ·
HZY6-36182-003	CORD COMP. EMERGENCY · · · · · · · · · · · · · · · · · · ·
HZY6-36187-003	CLIP, EMERGENCY LOCK · · · · · · · · · · · · · · · · · · ·
HZY6-36187-003	CLIP, EMERGENCY LOCK · · · · · · · · · · · · · · · · · · ·
HZY6-36187-003	CLIP, EMERGENCY LOCK · · · · · · · · · · · · · · · · · · ·
HZY6-36187-003	CLIP, EMERGENCY LOCK • • • • • • • • • • • • • • • • • • •
HZY6-38235-004	PULLER, MINI FUSE · · · · · · · · · · · · · · · · · · ·
HZY6-38414-003	BRACKET · · · · · · · · · · · · · · · · · · ·
HZY6-38414-003	BRACKET FOP-5-1-14
HZY6-38414-003	BRACKET · · · · · · · · · · · · · · · · · · ·
HZY6-38580-V11	RELAY ASSY., CONTROL · · · · · · · · · · · · · · · · · · ·
HZY6-38580-V11	RELAY ASSY., CONTROL · · · · · · · · · · · · · · · · · · ·
HZY6-38580-V11	RELAY ASSY., CONTROL · · · · · · · · · · · · · · · · · · ·
HZY6-38580-V11	RELAY ASSY., CONTROL · · · · · · · · · · · · · · · · · · ·
HZY6-38581-V11	HOLDER, RELAY • • • • • • • • • • • • • • • • • • •
HZY6-39794-003	RELAY ASSY., POWER (12V-20A) · · · · · · · · · · · · · · · · · F-7-20-6
HZY6-39794-003	RELAY ASSY., POWER (12V-20A) · · · · · · · · · · · · · · · · · F-7-20-6
HZY6-87703-R11	MARK, REMOTE CONTROL(SINGLE) · · · · · · · · · · · · · · · · · · ·
HZY6-87703-S11	MARK, REMOTE CONTROL (DUAL)
HZY6-90102-U11	SCREW, TRUSS, 5X10 • • • • • • • • • • • • • • • • • • •
HZY6-90102-U11	SCREW, TRUSS, 5X10 • • • • • • • • • • • • • • • • • • •
HZY6-90103-000	BOLT-WASHER, 10X32 · · · · · · · · · · · · · · · · · · ·
HZY6-90103-000	BOLT-WASHER, 10X32 · · · · · · · · · · · · · · · · · · ·
HZY6-90103-U11	SCREW, TRUSS, 5X16 (TAPPING) · · · · · · · · · · · · · · · · · · ·
HZY6-90103-U11	SCREW, TRUSS, 5X16(TAPPING) · · · · · · · · · · · · · · · · · · FOP-3-10-37
HZY6-90104-U11	SCREW, PAN, 5X14(TAPPING) · · · · · · · · · · · · · · · · · · FOP-3-9-29
HZY6-90104-U11	SCREW, PAN, 5X14(TAPPING) · · · · · · · · · · · · · · · · · · FOP-3-10-39
HZY6-90106-U11	SCREW, PAN, 5X14(TAPPING) · · · · · · · · · · · · · · · · · · FOP-3-9-31
HZY6-90106-U11	SCREW, PAN, 5X14(TAPPING) · · · · · · · · · · · · · · · · · · FOP-3-10-41
HZY6-90111-U11	BOLT, STOPPER(F) • • • • • • • • • • • • • • • • • • •
HZY6-90111-U11	BOLT, STOPPER(F) • • • • • • • • • • • • • • • • • • •
HZY6-90112-U11	BOLT, STOPPER(R) • • • • • • • • • • • • • • • • • • •
HZY6-90112-U11	BOLT, STOPPER(R) • • • • • • • • • • • • • • • • • • •
HZY6-90135-004	SCREW-WASHER, 5X15 • • • • • • • • • • • • • • • • • • •
HZY6-90302-003	NUT FOP-3-7-54
HZY6-90302-003	NUT FOP-3-8-56
HZY6-90302-003	NUT FOP-5-17
HZY6-90302-003	NUT • • • • • • • • • • • • • • • • • • •
HZY6-90302-003	NUT FOP-5-2-17
HZY6-90302-003	NUT FOP-5-5-15
HZY6-90651-000	CLIP B1, TUBE F-3-20-46
HZY6-90651-000	CLIP B1, TUBE F-3-20-46
HZY6-90651-000	CLIP B1, TUBE F-3-20-46

HZY6-90651-000	CLIP B1, TUBE · · · · · · · · · · · · · · · · · · ·	F-3-20-46
HZY6-90651-000	CLIP B1, TUBE · · · · · · · · · · · · · · · · · · ·	
HZY6-90651-000	CLIP B1, TUBE · · · · · · · · · · · · · · · · · · ·	
HZY6-90651-000	CLIP B1, TUBE	
	CLIP B1. TUBE	
HZY6-90651-000	CLIP B1, TUBE	
HZY6-90651-000		
HZY6-91541-V11	CLIP, HARNESS BAND	
HZY9-15600-M00	CAP ASSY., OIL FILLER.	
HZY9-15631-000	EXTENSION, OIL FILLER • • • • • • • • • • • • • • • • • • •	
HZY9-16896-003	CLAMP B, FUEL TUBE	
HZY9-17315-M01	BAND, AIR FLOW······	
HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE • • • • • • • • • • • • • • • • • • •	
HZY9-30419-003	GROMMET, ELECTRONIC PARTS CASE • • • • • • • • • • • • • • • • • • •	
HZY9-31207-H01	CLUTCH COMP., OVERRUNNING · · · · · · · · · · · · · · · · · · ·	
HZY9-31226-H01	SCREW, PAN, 6X22 · · · · · · · · · · · · · · · · · ·	• E−21−8
HZY9-31229-H01	STOPPER SET, SLEEVE · · · · · · · · · · · · · · · · · ·	E-21-9
HZY9-31246-H01	SHAFT ASSY., GEAR	E-21-16
HZY9-35645-000	STAY, POWER TILT SWITCH	F-3-20-8
HZY9-38400-A00	BUZZER ASSY., WARNING	F0P-3-7-49
HZY9-38400-A00	BUZZER ASSY., WARNING	F0P-3-8-51
HZY9-38402-A00	SUSPENSION, WARNING BUZZER • • • • • • • • • • • • • • • • • • •	• F0P-3-7-50
HZY9-38402-A00	SUSPENSION, WARNING BUZZER	
HZY9-38410-A01	BUZZER COMP., WARNING · · · · · · · · · · · · · · · · · · ·	
HZY9-38410-A01	BUZZER COMP., WARNING · · · · · · · · · · · · · · · · · · ·	
HZY9-38410-A01	BUZZER COMP., WARNING · · · · · · · · · · · · · · · · · · ·	
HZY9-38410-A01	BUZZER COMP., WARNING	
HZY9-38553-003	GROMMET, RELAY BRACKET · · · · · · · · · · · · · · · · · · ·	
HZY9-56115-023	GUIDE COMP., ROD · · · · · · · · · · · · · · · · · · ·	
HZY9-90014-M01	BOLT-WASHER, 8X35 · · · · · · · · · · · · · · · · · · ·	
HZY9-90026-M01	BOLT, FLANGE, 8X20 · · · · · · · · · · · · · · · · · · ·	
	BOLT, FLANGE, 8X20 · · · · · · · · · · · · · · · · · · ·	
HZY9-90026-M01	BOLT, FLANGE, 8X20 · · · · · · · · · · · · · · · · · · ·	
HZY9-90026-M01		
HZY9-90027-M01	BOLT, FLANGE, 8X60 · · · · · · · · · · · · · · · · · · ·	
HZY9-90042-M00	BOLT, FLANGE, 6X10 · · · · · · · · · · · · · · · · · · ·	
HZY9-90042-M00	BOLT, FLANGE, 6X10 · · · · · · · · · · · · · · · · · · ·	
HZY9-90042-M00	BOLT, FLANGE, 6X10 · · · · · · · · · · · · · · · · · · ·	
HZY9-90042-M01	BOLT, FLANGE, 6X10 · · · · · · · · · · · · · · · · · · ·	
HZY9-90042-M01	BOLT, FLANGE, 6X10 · · · · · · · · · · · · · · · · · · ·	
HZY9-90042-M01	BOLT, FLANGE, 6X10 · · · · · · · · · · · · · · · · · · ·	
HZY9-90054-M00	BOLT, FLANGE, 8X35 · · · · · · · · · · · · · · · · · · ·	
HZY9-90054-M00	BOLT, FLANGE, 8X35 · · · · · · · · · · · · · · · · · · ·	
HZY9-90054-M00	BOLT, FLANGE, 8X35 · · · · · · · · · · · · · · · · · · ·	
HZY9-90054-M01	BOLT, FLANGE, 8X35 · · · · · · · · · · · · · · · · · · ·	
HZY9-90054-M01	BOLT, FLANGE, 8X35 · · · · · · · · · · · · · · · · · · ·	• E−3−38
HZY9-90054-M01	BOLT, FLANGE, 8X35 · · · · · · · · · · · · · · · · · · ·	• E−3−38
HZY9-90205-M00	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·	• E−14−30
HZY9-90205-M00	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·	• E−14−30
HZY9-90205-M00	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·	• E-14-30

HZY9-90205-M01	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·
HZY9-90205-M01	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·
HZY9-90205-M01	NUT, FLANGE, 8MM · · · · · · · · · · · · · · · · · ·
HZY9-90205-M01	NUT, FLANGE, 8MM • • • • • • • • • • • • • • • • • •
HZY9-90205-M01	NUT, FLANGE, 8MM • • • • • • • • • • • • • • • • • •
HZY9-90205-M01	NUT, FLANGE, 8MM • • • • • • • • • • • • • • • • • •
HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91503-M00	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91503-M01	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · E-15-20
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE E-15-20
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE E-15-20
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE E-20-7
HZY9-91503-M01	COLLAR, C.D. I. UNIT CASE · · · · · · · · · · · · · · · · · E-20-7
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE E-20-7
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · E-20-10-12
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · E-20-10-12
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · E-20-10-12
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91503-M01	COLLAR, C.D.I. UNIT CASE · · · · · · · · · · · · · · · · · · ·
HZY9-91504-M00	COLLAR, 8. 5X14. 5 • • • • • • • • • • • • • • • • • •
HZY9-91504-M00	COLLAR, 8. 5X14. 5 • • • • • • • • • • • • • • • • • •
HZY9-91504-M00	COLLAR, 8. 5X14. 5 • • • • • • • • • • • • • • • • • •
HZY9-91504-M00	COLLAR, 8. 5X14. 5 · · · · · · · · · · · · · · · · · ·
HZY9-91504-M00	COLLAR, 8. 5X14. 5 · · · · · · · · · · · · · · · · · ·
HZY9-91504-M00	COLLAR, 8. 5X14. 5 · · · · · · · · · · · · · · · · · ·
HZY9-91504-M01	COLLAR, 8. 5X14. 5 • • • • • • • • • • • • • • • • • •
HZY9-91504-M01	COLLAR, 8. 5X14. 5
HZY9-91504-M01	COLLAR, 8. 5X14. 5
HZY9-91504-M01	COLLAR, 8. 5X14. 5 • • • • • • • • • • • • • • • • • •
HZY9-91504-M01	COLLAR, 8. 5X14. 5 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-000	SCREW, FLAT, 5X55 • • • • • • • • • • • • • • • • F-3-12
HZZ0-90101-M00	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M00	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M00	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M00	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M00	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M00	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M00	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M00	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M01	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M01	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·

HZZ0-90101-M01	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M01	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M01	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M01	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M01	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90101-M01	BOLT, FLANGE, 6X11 · · · · · · · · · · · · · · · · · ·
HZZ0-90102-M00	BOLT, TORX (M6X20) • • • • • • • • • • • • • • • • • • •
HZZ0-90102-M00	BOLT, TORX (M6X20) • • • • • • • • • • • • • • • • • • •
HZZ0-90102-M00	BOLT, TORX (M6X20) • • • • • • • • • • • • • • • • • • •
HZZ0-90102-M01	BOLT, TORX (M6X20) • • • • • • • • • • • • • • • • • • •
HZZ0-90102-M01	BOLT, TORX (M6X20) • • • • • • • • • • • • • • • • • • •
HZZ0-90102-M01	BOLT, TORX (M6X20) • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M00	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M00	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M00	BOLT, FLANGE, 6X10 · · · · · · · · · · · · · · · · · · ·
HZZ0-90103-M00	BOLT, FLANGE, $6X10 \cdot \cdot$
HZZ0-90103-M00	BOLT, FLANGE, 6X10 · · · · · · · · · · · · · · · · · · ·
HZZ0-90103-M00	BOLT, FLANGE, 6X10 · · · · · · · · · · · · · · · · · · ·
HZZ0-90103-M00	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M00	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M00	BOLT, FLANGE, 6X10 · · · · · · · · · · · · · · · · · · ·
HZZ0-90103-M00	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M00	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M00	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M01	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M01	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M01	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M01	BOLT, FLANGE, $6X10 \cdot \cdot$
HZZ0-90103-M01	BOLT, FLANGE, $6X10 \cdot \cdot$
HZZ0-90103-M01	BOLT, FLANGE, $6X10 \cdot \cdot$
HZZ0-90103-M01	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M01	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M01	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M01	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M01	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90103-M01	BOLT, FLANGE, 6X10 • • • • • • • • • • • • • • • • • • •
HZZ0-90151-M00	BOLT, FLANGE, 8X25 • • • • • • • • • • • • • • • • • • •
HZZ0-90151-M00	BOLT, FLANGE, 8X25 • • • • • • • • • • • • • • • • • • •
HZZ0-90151-M00	BOLT, FLANGE, 8X25 • • • • • • • • • • • • • • • • • • •
HZZ0-90151-M01	BOLT, FLANGE, 8X25 • • • • • • • • • • • • • • • • • • •
HZZ0-90151-M01	BOLT, FLANGE, 8X25 • • • • • • • • • • • • • • • • • • •
HZZ0-90151-M01	BOLT, FLANGE, 8X25 • • • • • • • • • • • • • • • • • • •
HZZ0-91601-M00	GROMMET, 1WAY • • • • • • • • • • • • • • • • • • •
HZZ3-06240-R31	BOX KIT, REMOTE CONTROL · · · · · · · · · · · · · · · · · · ·
HZZ3-06240-R41	BOX KIT, REMOTE CONTROL · · · · · · · · · · · · · · · · · · ·
HZZ3-06240-R61	BOX KIT, REMOTE CONTROL · · · · · · · · · · · · · · · · · · ·
HZZ3-06323-R24	PANEL KIT, SWITCH(B) (4-LED) · · · · · · · · · · · · · · · · · · ·
HZZ3-06323-R34	PANEL KIT, SWITCH(4-LED) · · · · · · · · · · · · · · · · · · ·

HZZ3-06328-764	KIT, CABLE(NMEA) (6FT)	F0P-7-1
HZZ3-24800-P14	BOX ASSY., REMOTE CONTROL	F0P-3-3-1
HZZ3-24820-R12	HOUSING COMP., REMOTE CONTROL	F0P-3-12
HZZ3-24820-R22	HOUSING COMP., REMOTE CONTROL	F0P-3-2-13
HZZ3-24830-R42	COVER ASSY.	F0P-3-1-11
HZZ3-32127-000	SUSPENSION, COUPLER	F-7-4
HZZ3-32127-000	SUSPENSION, COUPLER · · · · · · · · · · · · · · · · · · ·	F0P-3-4-33
HZZ3-32127-000	SUSPENSION, COUPLER	F0P-3-5-38
HZZ3-32127-000	SUSPENSION, COUPLER	F0P-3-6-40
HZZ3-32127-000	SUSPENSION, COUPLER	F0P-3-7-39
HZZ3-32127-000	SUSPENSION, COUPLER	
HZZ3-32341-R32	PANEL ASSY., SWITCH · · · · · · · · · · · · · · · · · · ·	
HZZ3-32346-R22	PANEL, CONTROL · · · · · · · · · · · · · · · · · · ·	
HZZ3-32346-R32	PANEL. CONTROL · · · · · · · · · · · · · · · · · · ·	
HZZ3-32347-R02	PANEL, CONTROL · · · · · · · · · · · · · · · · · · ·	
HZZ3-32800-000	CABLE ASSY., INTERFACE (6FT)	
HZZ3-32805-000	CONNECTOR (T)	
HZZ3-35100-R12	SWITCH ASSY., COMBINATION · · · · · · · · · · · · · · · · · · ·	
HZZ3-35100-R12	SWITCH ASSY., COMBINATION	
HZZ3-35100-R12	SWITCH ASSY., COMBINATION	
HZZ3-35645-A41	PLATE, SWITCH	
HZZ3-35745-743	SWITCH ASSY., TILT LIMIT	
	PANEL ASSY., INDICATOR (4-LED)	
HZZ3-37205-R03	COVER ASSY., FUSE (40A)	
HZZ3-38216-003	COVER ASSY. FUSE (40A)	
HZZ3-38216-003		
HZZ3-38216-003	COVER ASSY., FUSE (40A)	
HZZ3-38216-003	COVER ASSY., FUSE (40A)	
HZZ3-38216-003	COVER ASSY., FUSE (40A) · · · · · · · · · · · · · · · · · · ·	
HZZ3-38216-003	COVER ASSY., FUSE (40A) · · · · · · · · · · · · · · · · · · ·	
HZZ3-38216-003	COVER ASSY., FUSE (40A) · · · · · · · · · · · · · · · · · · ·	
HZZ3-38580-003	RELAY ASSY., MAIN	
HZZ3-38580-003	RELAY ASSY., MAIN	
HZZ3-38580-003	RELAY ASSY., MAIN	
HZZ3-50223-000	CAM A, TILT LIMIT ANGLE	F-10-23
HZZ3-50224-000	CAM B, TILT LIMIT ANGLE	
HZZ3-87701-R41	MARK, HANDLE FLUSH MOUNT	
HZZ3-87703-R02	MARK, REMOTE CONTROL (DUAL)	
HZZ3-87703-R82	MARK, REMOTE CONTROL (SINGLE) • • • • • • • • • • • • • • • • • • •	
HZZ3-91252-003	SEAL, WATER, 30X45X7 · · · · · · · · · · · · · · · · · · ·	
HZZ3-91252-003	SEAL, WATER, 30X45X7 · · · · · · · · · · · · · · · · · · ·	
HZZ3-91252-003	SEAL, WATER, 30X45X7 · · · · · · · · · · · · · · · · · · ·	
HZZ5-06352-M01	SWITCH KIT, LIGHT · · · · · · · · · · · · · · · · · · ·	
HZZ5-24810-D01	PLATE ASSY.	
HZZ5-24811-D01	LEVER, HAND · · · · · · · · · · · · · · · · · · ·	
HZZ5-24812-D01	ARM, NEUTRAL LOCK · · · · · · · · · · · · · · · · · · ·	F0P-3-3-4
HZZ5-24813-D01	GRIP	• F0P-3-3-5
HZZ5-24814-D01	COVER, LEVER · · · · · · · · · · · · · · · · · · ·	• F0P-3-3-6
HZZ5-24815-D01	ARM ASSY., BRAKE	• F0P-3-3-7

HZZ5-24816-D01	SPRING(2) · · · · · · · · · · · · · · · · · · ·	• F0P-3-3-8
HZZ5-24817-D01	CLIP, DETENT	• F0P-3-3-9
HZZ5-24818-D01	SPACER (1) • • • • • • • • • • • • • • • • • • •	• F0P-3-3-10
HZZ5-24819-D01	BRACKET	• F0P-3-3-11
HZZ5-24821-D01	HOUSING, FR.	• F0P-3-3-12
HZZ5-24822-D01	HOUSING, RR.	• F0P-3-3-13
HZZ5-24823-D01	PANEL, BACK	• F0P-3-3-14
HZZ5-24824-D01	BRACKET, WIRE CLAMP	• F0P-3-3-15
HZZ5-24826-D01	CAP, RUBBER	• F0P-3-3-16
HZZ5-24827-D01	ADJUSTER·····	• F0P-3-3-17
HZZ5-24828-D01	COVER, POWER TRIM-TILT WIRE	• F0P-3-3-18
HZZ5-24828-D01	COVER, POWER TRIM-TILT WIRE	• F0P-3-3-19
HZZ5-24829-D01	SEAL, RUBBER • • • • • • • • • • • • • • • • • • •	• F0P-3-3-20
HZZ5-24831-D01	HOLDER, NEUTRAL LOCK	• F0P-3-3-21
HZZ5-24832-D01	GROMMET, WIRE(14) · · · · · · · · · · · · · · · · · · ·	• F0P-3-3-22
HZZ5-24833-D01	CAP, TROLLING CONTROL SWITCH	• F0P-3-3-23
HZZ5-24845-D01	GEAR ASSY., SHIFT	• F0P-3-3-24
HZZ5-24850-D01	GEAR, DRIVE	• F0P-3-3-25
HZZ5-24855-D01	TERMINAL, CABLE · · · · · · · · · · · · · · · · · · ·	• F0P-3-3-26
HZZ5-24875-D01	DRUM ASSY., FREE THROTTLE	• F0P-3-3-27
HZZ5-24876-D01	SPRING(1) · · · · · · · · · · · · · · · · · · ·	• F0P-3-3-28
HZZ5-24878-D01	LEVER, FREE THROTTLE	• F0P-3-3-29
HZZ5-24883-D01	SPRING, DETENT · · · · · · · · · · · · · · · · · · ·	• F0P-3-3-30
HZZ5-32530-D01	CABLE ASSY., REMOTE CONTROL(B)	• F0P-3-3-31
HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	• F0P-5-3-6
HZZ5-32545-000	HARNESS ASSY., SWITCH PANEL	• F0P-5-4-3
HZZ5-35370-D02	SWITCH ASSY., POWER TRIM-TILT	• F0P-3-3-35
HZZ5-35701-D01	BAND, WIRE · · · · · · · · · · · · · · · · · · ·	• F0P-3-3-37
HZZ5-37210-713	LAMP ASSY., INDICATION (4-LED)	
HZZ5-37210-763	LAMP ASSY., INDICATION(4-LED)	
HZZ5-37210-D02	LAMP ASSY., INDICATION	
HZZ5-38414-003	BRACKET, BUZZER • • • • • • • • • • • • • • • • • • •	
HZZ5-38414-003	BRACKET, BUZZER • • • • • • • • • • • • • • • • • • •	• F0P-5-4-13
HZZ5-38586-003	SUSPENSION, RELAY	• F0P-3-4-41
HZZ5-38586-003	SUSPENSION, RELAY	
HZZ5-38586-003	SUSPENSION, RELAY	
HZZ5-87701-D00	MARK, FAST IDLE · · · · · · · · · · · · · · · · · · ·	
HZZ5-87702-A00	MARK, EMERGENCY STOP(US) • • • • • • • • • • • • • • • • • • •	
HZZ5-87702-A00	MARK, EMERGENCY STOP(US) • • • • • • • • • • • • • • • • • • •	
HZZ5-87703-P01	MARK, EMBLEM - · · · · · · · · · · · · · · · · · ·	
HZZ5-87704-D01	LABEL, SIGP · · · · · · · · · · · · · · · · · · ·	
HZZ5-90011-M01	BOLT, FLANGE, 6X14(CT200) · · · · · · · · · · · · · · · · · ·	
HZZ5-90011-M01	BOLT, FLANGE, 6X14(CT200) · · · · · · · · · · · · · · · · · ·	
HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTI • • • • • • • • • • • • • • • • • • •	
HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTI • • • • • • • • • • • • • • • • • • •	
HZZ5-90012-M01	BOLT, TIMING BELT ADJUSTI	
HZZ5-90012-M02	BOLT, TIMING BELT ADJUSTI	
HZZ5-90012-M02	BOLT, TIMING BELT ADJUSTI • • • • • • • • • • • • • • • • • • •	• E-13-21

U775 00040 H00	DOLT THUMB DELT ID WATE
HZZ5-90012-M02	BOLT, TIMING BELT ADJUSTI • • • • • • • • • • • • • • • E-13-21
HZZ5-90013-M00	BOLT-WASHER, 6X25 E-15-15
HZZ5-90013-M00	BOLT-WASHER, 6X25 E-15-15
HZZ5-90013-M00	BOLT-WASHER, 6X25 · · · · · · · · · · · · · · · E-15-15
HZZ5-90013-M01	BOLT-WASHER, 6X25 · · · · · · · · · · · · · · · · E-15-15
HZZ5-90013-M01	BOLT-WASHER, 6X25 · · · · · · · · · · · · · · · · E-15-15
HZZ5-90013-M01	BOLT-WASHER, 6X25 · · · · · · · · · · · · · · · · E-15-15
HZZ5-90013-M01	BOLT-WASHER, 6X25 • • • • • • • • • • • • • • • • • • •
HZZ5-90014-M00	BOLT, FLANGE, 6X25 E-18-47
HZZ5-90014-M00	BOLT, FLANGE, 6X25 E-18-47
HZZ5-90014-M00	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZZ5-90014-M01	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZZ5-90014-M01	BOLT, FLANGE, 6X25 · · · · · · · · · · · · · · · · · · ·
HZZ5-90014-M01	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZZ5-90014-M01	BOLT, FLANGE, 6X25 · · · · · · · · · · · · · · · · · · ·
HZZ5-90014-M01	BOLT, FLANGE, 6X25 • • • • • • • • • • • • • • • • • • •
HZZ5-90016-M00	BOLT, FLANGE, 6X28 • • • • • • • • • • • • • • • • • • •
HZZ5-90016-M00	BOLT, FLANGE, 6X28 • • • • • • • • • • • • • • • • • • •
HZZ5-90016-M00	BOLT, FLANGE, 6X28 E-18-48
HZZ5-90016-M01	BOLT, FLANGE, 6X28 E-18-48
HZZ5-90016-M01	BOLT, FLANGE, 6X28 • • • • • • • • • • • • • • • • • • •
HZZ5-90016-M01	BOLT, FLANGE, 6X28 • • • • • • • • • • • • • • • • • • •
HZZ5-90017-M00	BOLT, FLANGE, 6X16 • • • • • • • • • • • • • • • • • • •
HZZ5-90017-M00	BOLT, FLANGE, 6X16 • • • • • • • • • • • • • • • • • • •
HZZ5-90017-M00	BOLT, FLANGE, 6X16 • • • • • • • • • • • • • • • • • • •
HZZ5-90017-M00	BOLT, FLANGE, 6X16 · · · · · · · · · · · · · · · · · · ·
HZZ5-90017-M00	BOLT, FLANGE, 6X16 · · · · · · · · · · · · · · · · · · ·
HZZ5-90017-M00	BOLT, FLANGE, 6X16 · · · · · · · · · · · · · · · · · · ·
HZZ5-90017-M00	BOLT, FLANGE, 6X16 • • • • • • • • • • • • • • • • • • •
HZZ5-90017-M01	BOLT, FLANGE, 6X16 • • • • • • • • • • • • • • • • • • •
HZZ5-90017-M01	BOLT, FLANGE, 6X16 · · · · · · · · · · · · · · · · · · ·
HZZ5-90017-M01	BOLT, FLANGE, 6X16 · · · · · · · · · · · · · · · · · · ·
HZZ5-90017-M01	BOLT, FLANGE, 6X16 E-13-23
HZZ5-90017-M01	BOLT, FLANGE, 6X16
HZZ5-90017-M01	BOLT. FLANGE. 6X16
HZZ5-90017-M01	BOLT, FLANGE, 6X16 E-18-49
	BOLT, FLANGE, 6X16
HZZ5-90017-M01	BOLT, FLANGE, 6X16 · · · · · · · · · · · · · · · · · · ·
HZZ5-90017-M01	BOLT, FLANGE, 6X20
HZZ5-90018-M00	
HZZ5-90018-M01	BOLT, FLANGE, 6X20
HZZ5-90018-M01	BOLT, FLANGE, 6X20 · · · · · · · · · · · · · · · · · · ·
HZZ5-90018-M01	BOLT, FLANGE, 6X20 FOP-3-5-50
HZZ5-90018-M01	BOLT, FLANGE, 6X20 FOP-3-6-52
HZZ5-90018-M01	BOLT, FLANGE, 6X20 FOP-3-7-51
HZZ5-90018-M01	BOLT, FLANGE, 6X20 F0P-3-8-53
HZZ5-90019-M00	BOLT, FLANGE, 6X35 E-3-33
HZZ5-90019-M00	BOLT, FLANGE, 6X35 · · · · · · · · · · · · · · · · E-3-33
HZZ5-90019-M00	BOLT, FLANGE, 6X35 · · · · · · · · · · · · · · · · E-3-33

HZ	ZZ5-90019-M00	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-14-25
HZ	ZZ5-90019-M00	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-14-25
HZ	ZZ5-90019-M00	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-14-25
HZ	ZZ5-90019-M01	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-1-13
Н	ZZ5-90019-M01	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-3-33
HZ	ZZ5-90019-M01	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-3-33
Н	ZZ5-90019-M01	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-3-33
HZ	ZZ5-90019-M01	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-4-15
Н	ZZ5-90019-M01	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-14-25
HZ	ZZ5-90019-M01	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-14-25
HZ	ZZ5-90019-M01	BOLT,	FLANGE,	6X35 · ·	 	 	 	 	 • • E-14-25
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-3-30
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-3-30
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-3-30
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-14-26
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-14-26
Н	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E−14−26
Н	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-15-28
Н	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-18-50
Н	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-18-50
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E−18−50
Н	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-18-1-14
Н	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-18-1-14
Н	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-18-1-14
Н	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-2-27
Н	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-2-27
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-2-27
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-2-27
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-2-27
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-2-27
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-2-1-19
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-2-1-19
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-7-6
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-7-6
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-7-6
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-7-6
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-7-6
HZ	ZZ5-90021-M00	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • F-7-6
HZ	ZZ5-90021-M01	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-3-30
HZ	ZZ5-90021-M01	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-3-30
HZ	ZZ5-90021-M01	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-3-30
Н	ZZ5-90021-M01	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-14-26
HZ	ZZ5-90021-M01	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-14-26
HZ	ZZ5-90021-M01	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-14-26
HZ	ZZ5-90021-M01	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-15-28
Н	ZZ5-90021-M01	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-18-50
HZ	ZZ5-90021-M01	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E-18-50
Н	ZZ5-90021-M01	BOLT,	FLANGE,	6X14 · ·	 	 	 	 	 • • E−18−50

HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · · E-18-1-14
HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · E-18-1-14
HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · E-18-1-14
HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · · · · · · · · · · · ·
HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · F-2-27
HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · F-2-27
HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · · · · · · · · · · · ·
HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · · · · · · · · · · · ·
HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · F-2-27
HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · F-2-1-19
HZZ5-90021-M01	BOLT, FLANGE,	6X14 · · · · · · · · F-2-1-19
HZZ5-90021-M01		6X14 · · · · · · · · · · · · · · · · · · ·
HZZ5-90021-M01		6X14 · · · · · · · · · · · · · · · · · · ·
HZZ5-90021-M01		6X14 · · · · · · · · · · · · · · · · · · ·
HZZ5-90021-M01		6X14 · · · · · · · · · · · · · · · · · · ·
HZZ5-90021-M01		6X14 · · · · · · · · F-7-6
HZZ5-90021-M01		6X14 · · · · · · · · · · · · · · · · · · ·
HZZ5-90030-M00		6X22 · · · · · · · E-3-36
HZZ5-90030-M00		6X22 · · · · · · · E-3-36
HZZ5-90030-M00		6X22 · · · · · · · E-3-36
HZZ5-90030-M01		6X22 · · · · · · · E-3-36
HZZ5-90030-M01	, ,	6X22 · · · · · · · E-3-36
HZZ5-90030-M01		6X22 · · · · · · · E-3-36
HZZ5-90030-M01		6X22 · · · · · · · · E-6-10-31
HZZ5-90030-M01		6X22 · · · · · · · · E-13-24
HZZ5-90030-M01		6X22 · · · · · · · · E-15-16
HZZ5-90032-M00		6X32 · · · · · · · E-3-10-9
HZZ5-90032-M00		6X32 · · · · · · · E-3-10-9
HZZ5-90032-M00		6X32 · · · · · · E-3-10-9
HZZ5-90032-M00		6X32 · · · · · · · E-6-10-32
HZZ5-90032-M00		6X32 · · · · · · · · E-6-10-32
HZZ5-90032-M00		6X32 · · · · · · · · E-6-10-32
HZZ5-90032-M01		6X32 · · · · · · E-3-10-9
HZZ5-90032-M01		6X32 · · · · · · · E-3-10-9
HZZ5-90032-M01		6X32 · · · · · · · E-3-10-9
HZZ5-90032-M01	,,	6X32 · · · · · · · · E-6-10-32
HZZ5-90032-M01		6X32 · · · · · · · · E-6-10-32
HZZ5-90032-M01		6X32 · · · · · · · · E-6-10-32
HZZ5-90032-M01		6X32 · · · · · · · · E-14-10-14
HZZ5-90032-M01		6X32 · · · · · · · · E-14-10-14
HZZ5-90032-M01		6X32 · · · · · · · · E-14-10-14
HZZ5-90047-M00		6X55 · · · · · · · E-3-10-11
HZZ5-90047-M00		6X55 • • • • • • • • • • • • • • • • • •
HZZ5-90047-M00		6X55 · · · · · · · E-3-10-11
HZZ5-90047-M01		6X55 · · · · · · · · E-3-10-11
HZZ5-90047-M01		6X55 · · · · · · · E-3-10-11
HZZ5-90047-M01		6X55 · · · · · · · · E-3-10-11
HZZ5-90047-M01		8X18 · · · · · · · · · · · · · · · · · · ·
11220 30031-MIOU	DOLI, ILMNUE,	0/10

HZZ5-90051-M00	BOLT, FLANGE, 8X18 • • • • • • • • • • • • • • • • • • •
HZZ5-90051-M00	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·
HZZ5-90051-M00	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·
HZZ5-90051-M00	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·
HZZ5-90051-M00	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·
HZZ5-90051-M01	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·
HZZ5-90051-M01	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·
HZZ5-90051-M01	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·
HZZ5-90051-M01	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·
HZZ5-90051-M01	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·
HZZ5-90051-M01	BOLT, FLANGE, 8X18 · · · · · · · · · · · · · · · · · · ·
HZZ5-90055-M01	BOLT, FLANGE, 8X40 · · · · · · · · · · · · · · · · · · E-4-18
HZZ5-90081-M00	BOLT. SEALING. 22MM · · · · · · · · · · · · · · · · E-3-39
HZZ5-90081-M00	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · E-3-39
HZZ5-90081-M00	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · E-3-39
HZZ5-90081-M00	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M00	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · E-3-10-13
HZZ5-90081-M00	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M00	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M00	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M00	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M00	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M01	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M01	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M01	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M01	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M01	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · E-3-10-13
HZZ5-90081-M01	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · E-3-10-13
HZZ5-90081-M01	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · E-3-10-13
HZZ5-90081-M01	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · ·
HZZ5-90081-M01	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · E-5-15
HZZ5-90081-M01	BOLT, SEALING, 22MM · · · · · · · · · · · · · · · · E-5-15
HZZ5-90101-D01	SCREW. 5X18 FOP-3-3-48
HZZ5-90102-D01	SCREW. 4X6 · · · · · · · · · · · · · · · · · · ·
HZZ5-90103-D01	SCREW. 5X10 · · · · · · · · · · · · · · · · · · ·
HZZ5-90104-D01	SCREW, 4X10 · · · · · · · · · · · · · · · · · · ·
HZZ5-90105-M00	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZZ5-90105-M00	BOLT, FLANGE, 6X12 · · · · · · · · · · · · · · · · · · ·
HZZ5-90106-D01	SCREW, 5X12 · · · · · · · · · · · · · · · · · · ·
HZZ5-90107-D01	SCREW, 6X90 · · · · · · · · · · · · · · · · · · ·
HZZ5-90108-D01	BOLT, 8X50 · · · · · · · · · · · · · · · · · · ·
HZZ5-90109-D01	BOLT, 5X25 · · · · · · · · · · · · · · · · · · ·
HZZ5-90201-M00	NUT, FLANGE, 6MM · · · · · · · · · · · · · · · · · ·
HZZ5-90201-M00	NUT, FLANGE, 6MM · · · · · · · · · · · · · · · · · ·
HZZ5-90201-M00	NUT, FLANGE, 6MM · · · · · · · · · · · · · · · · · ·
HZZ5-90201-M00	NUT, FLANGE, 6MM · · · · · · · · · · · · · · · · · ·
HZZ5-90201-M00	NUT, FLANGE, 6MM · · · · · · · · · · · · · · · · · ·
HZZ5-90201-M00	NUT, FLANGE, 6MM · · · · · · · · · · · · · · · · · ·

HZZ5-90301-D01	NUT, 6MM · · · · · · · · FOP-3-3-56
HZZ5-90301-D01	NUT, 6MM · · · · · · FOP-3-9-36
HZZ5-90301-D01	NUT, 6MM · · · · · · FOP-3-10-47
HZZ5-90301-M00	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M00	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M00	NUT, FLANGE, 5MM • • • • • • • • • • • • • • • • • •
HZZ5-90301-M01	NUT, FLANGE, 5MM • • • • • • • • • • • • • • • • • •
HZZ5-90301-M01	NUT, FLANGE, 5MM • • • • • • • • • • • • • • • • • •
HZZ5-90301-M01	NUT, FLANGE, 5MM • • • • • • • • • • • • • • • • • •
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM·····FOP-5-16
HZZ5-90301-M01	NUT, FLANGE, 5MM·····FOP-5-1-16
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT. FLANGE. 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90301-M01	NUT, FLANGE, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90302-D01	NUT. 5MM FOP-3-3-58
HZZ5-90501-D01	BEARING (1) • • • • • • • • • • • • • • • • • • •
HZZ5-90501-M00	WASHER, PLAIN, 5MM • • • • • • • • • • • • • • • • • •
HZZ5-90501-M00	WASHER, PLAIN, 5MM
HZZ5-90501-M00	WASHER, PLAIN, 5MM • • • • • • • • • • • • • • • • • •
HZZ5-90501-M01	WASHER, PLAIN, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90501-M01	WASHER, PLAIN, 5MM • • • • • • • • • • • • • • • • • •
HZZ5-90501-M01	WASHER, PLAIN, 5MM • • • • • • • • • • • • • • • • • •
HZZ5-90501-M01	WASHER, PLAIN, 5MM···································
HZZ5-90501-M01	WASHER, PLAIN, 5MM···································
HZZ5-90501-M01	WASHER, PLAIN, 5MM · · · · · · · · · · · · · · · · · ·
	WASHER, PLAIN, 5MM···································
HZZ5-90501-M01	WASHER, PLAIN, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90501-M01 HZZ5-90501-M01	WASHER, PLAIN, 5MM · · · · · · · · · · · · · · · · · ·
	WASHER, PLAIN, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90501-M01	
HZZ5-90501-M01	WASHER, PLAIN, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90501-M01	WASHER, PLAIN, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90501-M01	WASHER, PLAIN, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90501-M01	WASHER, PLAIN, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90501-M01	WASHER, PLAIN, 5MM······FOP-5-4-17
HZZ5-90501-M01	WAGUED DIATM FMM
	WASHER, PLAIN, 5MM · · · · · · · · · · · · · · · · · ·
HZZ5-90501-M01 HZZ5-90501-M01	WASHER, PLAIN, 5MM

HZZ5-90501-M01	WASHER, PLAIN, 5MM···································
HZZ5-90502-D01	WASHER (3) • • • • • • • • • • • • • • • • • • •
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-3-4-49
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-3-5-54
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-3-6-56
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-3-7-56
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-3-8-58
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-5-19
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-5-1-19
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-5-2-19
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-5-3-22
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-5-3-22
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-5-3-22
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-5-4-18
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-5-5-17
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-6-11
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-6-1-13
HZZ5-90502-M01	WASHER, SPRING, 5MM····· FOP-6-2-8
HZZ5-90503-D01	WASHER (4) • • • • • • • FOP-3-3-61
HZZ5-90504-D01	WASHER (5) • • • • • • • FOP-3-3-62
HZZ5-90506-D01	WASHER, 8MM • • • • • • FOP-3-3-63
HZZ5-90507-D01	WASHER (7) • • • • • • • • • • • • • • • • • • •
HZZ5-90508-D01	WASHER, WAVE · · · · · · · · · · · · · · · · · · ·
HZZ5-90508-M01	WASHER, PLAIN, 6MM·····F-2-36
HZZ5-90508-M01	WASHER, PLAIN, 6MM·····F-2-1-27
HZZ5-90509-D01	SPACER (2) • • • • • • • FOP-3-3-66
HZZ5-90651-D01	E-RING, 6MM····· FOP-3-3-67
HZZ5-90651-D01	E-RING, 6MM (LOOSE PARTS) · · · · · · · · · · · · · · · · · · FOP-3-9-40
HZZ5-90651-D01	E-RING, 6MM····· FOP-3-9-41
HZZ5-90651-D01	E-RING, 6MM (LOOSE PARTS) · · · · · · · · · · · · · · · · · · FOP-3-10-52
HZZ5-90651-D01	E-RING, 6MM · · · · · · FOP-3-10-53
HZZ5-91151-D01	ROLLER, DRIVE GEAR CAM····································
HZZ5-91152-D01	ROLLER • • • • • • • • • • • • • • • • • • •
HZZ5-91153-D01	BEARING (2) • • • • • • • • • • • • • • • • • • •
HZZ5-91154-D01	BEARING (3) • • • • • • • • • • • • • • • • • • •
HZZ5-91156-D01	ROLLER, FREE THROTTLE • • • • • • • • • • • • • • • • • • •
HZZ5-91157-D01	CLIP, ROLLER · · · · · · · · · · · · · · · · · · ·
HZZ5-91501-010	COLLAR, MOUNTING (6MM) · · · · · · · · · · · · · · · · · ·

2025 PARTS CATALOG

BFT 200D BFT 225D BFT 250D Models US

TOHATSU CORPORATION

5-4, Azusawa 3-Chome, Itabashi-Ku Tokyo 174-0051, Japan Tel: +81-3-3966-3117 Fax: +81-3-3966-2951

www.tohatsu.com

