


2015 PARTS CATALOG

TOHATSU



BFT 115A

**OB NO.002-14ZX1-1
1411US**

Instruction for use of parts catalogue

- This parts catalogue was prepared based on the latest information available as of October 1, 2014.
- See the Service Bulletin for any revision that is made after October 1, 2014.
- **Always specify the part number when ordering a part.**
 - Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
 - Note that the illustrations (part drawings) can differ from the actual parts in shape.
Illustrations are given just to help you to refer to the parts.
- When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times.


Initial version issue date October 1, 2014

CONTENTS

E-1	CYLINDER HEAD COVER	1
E-3	CYLINDER BLOCK	3
E-4	EXHAUST PIPE.....	7
E-4-10	WATER HOSE.....	9
E-5	OIL PUMP/FLYWHEEL	11
E-6	OIL PAN	13
E-7	CRANKSHAFT/PISTON	15
E-9	CAMSHAFT/VALVE	19
E-9-10	CHAIN CASE/THARMOSTAT	23
E-9-20	CYLINDER HEAD	25
E-10	BALANCER SHAFT	29
E-13	A.C.G BELT/SILENCER DUCT	31
E-14	INTAKE MANIFOLD/INJECTOR	33
E-15	THROTTLE BODY	37
E-18	FUEL PUMP/FUEL HOSE	39
E-18-1	WATER SEPARATOR	43
E-18-10	VAPOR SEPARATOR ASSY	45
E-19	A.C.GENERATOR	49
E-20	IGNITION COIL/SPARK PLUG	53
E-20-10	ELECTRONIC CONTROL UNIT	55
E-21	STARTER MOTOR	57
F-2	SHIFT SHAFT	61
F-3	GEAR CASE	65
F-3-10	GEAR CASE ASSY	67
F-3-20	EXTENSION CASE	69
F-4	WATER PUMP/VERTICAL SHAFT	71
F-5	PROPELLER SHAFT/PROPELLER (LA/XA)	75
F-5-1	PROPELLER SHAFT/PROPELLER (XCA)	79
F-6	FUEL TUBE	83
F-7	WIRE HARNESS	85
F-7-10	STARTER CABLE	87
F-7-20	FUSE BOX/RELAY	89
F-7-30	CLAMP	91
F-8	ENGINE COVER ASSY	93
F-8-10	FR.COVER BRACKET/FR.LOCK	95
F-8-20	UNDER COVER	97
F-9	MOUNT CASE	99
F-10	STERN BRACKET/SWIVEL CASE	103
F-11	POWER TRIM-TILT	109
F-12	LABELS	113
F-13	TOOLS	115
FOP-1	RIGGING HOSE KIT	117
FOP-2	METER	119
FOP-6	CONTROL PANEL (1)	121
FOP-6-1	CONTROL PANEL (2)	123
FOP-7	TRIM ADJUST PLATE SET	125
FOP-8	REMOTE CONTROL (TOP MOUNT SINGLE TYPE) (RIGHT)	127
FOP-8-2	REMOTE CONTROL (TOP MOUNT DUAL TYPE) (RIGHT)	131
FOP-8-4	REMOTE CONTROL (FLUSH MOUNT TYPE) (RIGHT)	135
FOP-8-6	REMOTE CONTROL	139
FOP-9	BOLT KIT	145
FOP-10	WATER PUMP IMPELLER KIT (1)	147
FOP-10-1	WATER PUMP IMPELLER KIT (2)	149
FOP-11	INTERFACE CABLE KIT	151
FOP-12	TROLLING CONTROL SWITCH	153
FOP-13	SPEED SENSOR TUBE KIT	155
INDEX	157	
INDEX (Parts Number)	163	

How to refer to the part information


A. Reference with "Illustrated index"



B. Reference with "Parts number index"




INDEX (Parts Number)	
100-110544	13-13
309-00131-0	13-17
309-00972-0	13-23
309-00972-1	13-23
309-00972-2	13-37
309-00972-3	13-37
309-00972-4	13-37
309-00972-5	13-37
309-00972-6	13-37
309-00972-7	13-37
309-00972-8	13-37
309-00972-9	13-37
309-00972-10	13-37
309-00972-11	13-37
309-00972-12	13-42
323-00001-0	13-73
332-00000-0	13-13
332-00000-1	13-13
332-00000-2	13-13
332-00000-3	13-13
332-00000-4	13-13
332-00000-5	13-13
332-00000-6	13-13
332-00000-7	13-13
332-00000-8	13-13
332-00000-9	13-13
332-00000-10	13-13
332-00000-11	13-13
332-00000-12	13-13
332-00000-13	13-13
332-00000-14	13-13
332-00000-15	13-13
332-00000-16	13-13
332-00000-17	13-13
332-00000-18	13-13
332-00000-19	13-13
332-00000-20	13-13
332-00000-21	13-13
332-00000-22	13-13
332-00000-23	13-13
332-00000-24	13-13
332-00000-25	13-13
332-00000-26	13-13
332-00000-27	13-13
332-00000-28	13-13
332-00000-29	13-13
332-00000-30	13-13
332-00000-31	13-13
332-00000-32	13-13
332-00000-33	13-13
332-00000-34	13-13
332-00000-35	13-13
332-00000-36	13-13
332-00000-37	13-13
332-00000-38	13-13
332-00000-39	13-13
332-00000-40	13-13
332-00000-41	13-13
332-00000-42	13-13
332-00000-43	13-13
332-00000-44	13-13
332-00000-45	13-13
332-00000-46	13-13
332-00000-47	13-13
332-00000-48	13-13
332-00000-49	13-13
332-00000-50	13-13
332-00000-51	13-13
332-00000-52	13-13
332-00000-53	13-13
332-00000-54	13-13
332-00000-55	13-13
332-00000-56	13-13
332-00000-57	13-13
332-00000-58	13-13
332-00000-59	13-13
332-00000-60	13-13
332-00000-61	13-13
332-00000-62	13-13
332-00000-63	13-13
332-00000-64	13-13
332-00000-65	13-13
332-00000-66	13-13
332-00000-67	13-13
332-00000-68	13-13
332-00000-69	13-13
332-00000-70	13-13
332-00000-71	13-13
332-00000-72	13-13
332-00000-73	13-13
332-00000-74	13-13
332-00000-75	13-13
332-00000-76	13-13
332-00000-77	13-13
332-00000-78	13-13
332-00000-79	13-13
332-00000-80	13-13
332-00000-81	13-13
332-00000-82	13-13
332-00000-83	13-13
332-00000-84	13-13
332-00000-85	13-13
332-00000-86	13-13
332-00000-87	13-13
332-00000-88	13-13
332-00000-89	13-13
332-00000-90	13-13
332-00000-91	13-13
332-00000-92	13-13
332-00000-93	13-13
332-00000-94	13-13
332-00000-95	13-13
332-00000-96	13-13
332-00000-97	13-13
332-00000-98	13-13
332-00000-99	13-13
332-00000-100	13-13
332-00000-101	13-13
332-00000-102	13-13
332-00000-103	13-13
332-00000-104	13-13
332-00000-105	13-13
332-00000-106	13-13
332-00000-107	13-13
332-00000-108	13-13
332-00000-109	13-13
332-00000-110	13-13
332-00000-111	13-13
332-00000-112	13-13
332-00000-113	13-13
332-00000-114	13-13
332-00000-115	13-13
332-00000-116	13-13
332-00000-117	13-13
332-00000-118	13-13
332-00000-119	13-13
332-00000-120	13-13
332-00000-121	13-13
332-00000-122	13-13
332-00000-123	13-13
332-00000-124	13-13
332-00000-125	13-13
332-00000-126	13-13
332-00000-127	13-13
332-00000-128	13-13
332-00000-129	13-13
332-00000-130	13-13
332-00000-131	13-13
332-00000-132	13-13
332-00000-133	13-13
332-00000-134	13-13
332-00000-135	13-13
332-00000-136	13-13
332-00000-137	13-13
332-00000-138	13-13
332-00000-139	13-13
332-00000-140	13-13
332-00000-141	13-13
332-00000-142	13-13
332-00000-143	13-13
332-00000-144	13-13
332-00000-145	13-13
332-00000-146	13-13
332-00000-147	13-13
332-00000-148	13-13
332-00000-149	13-13
332-00000-150	13-13
332-00000-151	13-13
332-00000-152	13-13
332-00000-153	13-13
332-00000-154	13-13
332-00000-155	13-13
332-00000-156	13-13
332-00000-157	13-13
332-00000-158	13-13
332-00000-159	13-13
332-00000-160	13-13
332-00000-161	13-13
332-00000-162	13-13
332-00000-163	13-13
332-00000-164	13-13
332-00000-165	13-13
332-00000-166	13-13
332-00000-167	13-13
332-00000-168	13-13
332-00000-169	13-13
332-00000-170	13-13
332-00000-171	13-13
332-00000-172	13-13
332-00000-173	13-13
332-00000-174	13-13
332-00000-175	13-13
332-00000-176	13-13
332-00000-177	13-13
332-00000-178	13-13
332-00000-179	13-13
332-00000-180	13-13
332-00000-181	13-13
332-00000-182	13-13
332-00000-183	13-13
332-00000-184	13-13
332-00000-185	13-13
332-00000-186	13-13
332-00000-187	13-13
332-00000-188	13-13
332-00000-189	13-13
332-00000-190	13-13
332-00000-191	13-13
332-00000-192	13-13
332-00000-193	13-13
332-00000-194	13-13
332-00000-195	13-13
332-00000-196	13-13
332-00000-197	13-13
332-00000-198	13-13
332-00000-199	13-13
332-00000-200	13-13
332-00000-201	13-13
332-00000-202	13-13
332-00000-203	13-13
332-00000-204	13-13
332-00000-205	13-13
332-00000-206	13-13
332-00000-207	13-13
332-00000-208	13-13
332-00000-209	13-13
332-00000-210	13-13
332-00000-211	13-13
332-00000-212	13-13
332-00000-213	13-13
332-00000-214	13-13
332-00000-215	13-13
332-00000-216	13-13
332-00000-217	13-13
332-00000-218	13-13
332-00000-219	13-13
332-00000-220	13-13
332-00000-221	13-13
332-00000-222	13-13
332-00000-223	13-13
332-00000-224	13-13
332-00000-225	13-13
332-00000-226	13-13
332-00000-227	13-13
332-00000-228	13-13
332-00000-229	13-13
332-00000-230	13-13
332-00000-231	13-13
332-00000-232	13-13
332-00000-233	13-13
332-00000-234	13-13
332-00000-235	13-13
332-00000-236	13-13
332-00000-237	13-13
332-00000-238	13-13
332-00000-239	13-13
332-00000-240	13-13
332-00000-241	13-13
332-00000-242	13-13
332-00000-243	13-13
332-00000-244	13-13
332-00000-245	13-13
332-00000-246	13-13
332-00000-247	13-13
332-00000-248	13-13
332-00000-249	13-13
332-00000-250	13-13
332-00000-251	13-13
332-00000-252	13-13
332-00000-253	13-13
332-00000-254	13-13
332-00000-255	13-13
332-00000-256	13-13
332-00000-257	13-13
332-00000-258	13-13
332-00000-259	13-13
332-00000-260	13-13
332-00000-261	13-13
332-00000-262	13-13
332-00000-263	13-13
332-00000-264	13-13
332-00000-265	13-13
332-00000-266	13-13
332-00000-267	13-13
332-00000-268	13-13
332-00000-269	13-13
332-00000-270	13-13
332-00000-271	13-13
332-00000-272	13-13
332-00000-273	13-13
332-00000-274	13-13
332-00000-275	13-13
332-00000-276	13-13
332-00000-277	13-13
332-00000-278	13-13
332-00000-279	13-13
332-00000-280	13-13
332-00000-281	13-13
332-00000-282	13-13
332-00000-283	13-13
332-00000-284	13-13
332-00000-285	13-13
332-00000-286	13-13
332-00000-287	13-13
332-00000-288	13-13
332-00000-289	13-13
332-00000-290	13-13
332-00000-291	13-13
332-00000-292	13-13
332-00000-293	13-13
332-00000-294	13-13
332-00000-295	13-13
332-00000-296	13-13
332-00000-297	13-13
332-00000-298	13-13
332-00000-299	13-13
332-00000-300	13-13
332-00000-301	13-13
332-00000-302	13-13
332-00000-303	13-13
332-00000-304	13-13
332-00000-305	13-13
332-00000-306	13-13
332-00000-307	13-13
332-00000-308	13-13
332-00000-309	13-13
332-00000-310	13-13
332-00000-311	13-13
332-00000-312	13-13
332-00000-313	13-13
332-00000-314	13-13
332-00000-315	13-13
332-00000-316	13-13
332-00000-317	13-13
332-00000-318	13-13
332-00000-319	13-13
332-00000-320	13-13
332-00000-321	13-13
332-00000-322	13-13
332-00000-323	13-13
332-00000-324	13-13
332-00000-325	13-13
332-00000-326	13-13
332-00000-327	13-13
332-00000-328	13-13
332-00000-329	13-13
332-00000-330	13-13
332-00000-331	13-13
332-00000-332	13-13
332-00000-333	13-13
332-00000-334	13-13
332-00000-335	13-13
332-00000-336	13-13
332-00000-337	13-13
332-00000-338	13-13
332-00000-339	13-13
332-00000-340	13-13
332-00000-341	13-13
332-00000-342	13-13
332-00000-343	13-13
332-00000-	

Part catalogue structure



- ① Fig. Number
 - ② Fig. Title
 - ③ Ref. Number
 - ④ Parts Number
 - ⑤ Parts Name
 - ⑥ Q.ty
 - ⑦ Remarks
 - ⑧ Defferent specification
 - ⑨ Direction Arrow
 - ⑩ Parts enclosed within a doted line are sub assembly parts.
 - ⑪ A solid arrow indicates the block No. the part in question is connected to.

How to check the part block and serial numbers



Models, parts catalogue codes and applicable serial numbers

- Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.

Model	Type	Parts catalogue type	Engine		Applicable engine serial No.	Applicable frame serial No.
			Model	Type		
BFT 115A	LA	LA	BFT 115D	SE1	BEBHJ-1000001~	BBHJ-6000079~
	XA	XA				BBHJ-7000001~
	XCA	XCA				

Features of each type

- See the following table for the features of each type. (Items in brackets are optional)


Model		BFT 115A			
Specifications		Type	LA	XA	XCA
Transom height	508 mm		●		
	635 mm			●	●
Counter rotation					●
Propeller	14-1/2 x 15	(●)	(●)	(●)	(●)
	14-1/4 x 17	(●)	(●)	(●)	(●)
	14 x 19	(●)	(●)	(●)	(●)
	14 x 21	(●)	(●)	(●)	(●)
	14-1/2 x 23	(●)	(●)	(●)	(●)
	14 x 25	(●)	(●)	(●)	
	15-1/2 x 13	(●)	(●)	(●)	
	15-1/4 x 15	(●)	(●)	(●)	
	15 x 17	(●)	(●)	(●)	
	14-3/4 x 19	(●)	(●)	(●)	
	14-1/2 x 21	(●)	(●)	(●)	
	14-1/4 x 23	(●)	(●)	(●)	

Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets () underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name. (For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)










Bulk part number of fuel hose, general purpose hose and vinyl hose.

Example: 95001-75001-50M




CAUTION: It is DANGEROUS to confuse the fuel hose with the general purpose hose or vinyl hose.


Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.

E-1 CYLINDER HEAD COVER**E-3 CYLINDER BLOCK****E-4 EXHAUST PIPE****E-4-10 WATER HOSE****E-5 OIL PUMP/FLYWHEEL****E-6 OIL PAN****E-7 CRANKSHAFT/PISTON****E-9 CAMSHAFT/VALVE****E-9-10 CHAIN CASE/THARMOSTAT**


E-9-20 CYLINDER HEAD




E-10 BALANCER SHAFT




E-13 A.C.G BELT/SILENCER DUCT




E-14 INTAKE MANIFOLD/INJECTOR




E-15 THROTTLE BODY




E-18 FUEL PUMP/FUEL HOSE




E-18-1 WATER SEPARATOR





E-18-10 VAPOR SEPARATOR ASSY




E-19 A.C.GENERATOR




E-20 IGNITION COIL/SPARK PLUG




E-20-10 ELECTRONIC CONTROL UNIT




E-21 STARTER MOTOR




F-2 SHIFT SHAFT




F-3 GEAR CASE




F-3-10 GEAR CASE ASSY




F-3-20 EXTENSION CASE




F-4 WATER PUMP/VERTICAL SHAFT




F-5 PROPELLER SHAFT/PROPELLER (LA/XA)




F-5-1 PROPELLER SHAFT/PROPELLER (XCA)




F-6 FUEL TUBE




F-7 WIRE HARNESS




F-7-10 STARTER CABLE




F-7-20 FUSE BOX/RELAY




F-7-30 CLAMP




F-8 ENGINE COVER ASSY




F-8-10 FR.COVER BRACKET/FR.LOCK




F-8-20 UNDER COVER




F-9 MOUNT CASE




F-10 STERN BRACKET/SWIVEL CASE




F-11 POWER TRIM-TILT




F-12 LABELS




F-13 TOOLS




FOP-1 RIGGING HOSE KIT




FOP-2 METER




FOP-6 CONTROL PANEL (1)




FOP-6-1 CONTROL PANEL (2)




FOP-7 TRIM ADJUST PLATE SET




FOP-8 REMOTE CONTROL
(TOP MOUNT SINGLE TYPE) (RIGHT)




FOP-8-2 REMOTE CONTROL
(TOP MOUNT DUAL TYPE) (RIGHT)




FOP-8-4 REMOTE CONTROL
(FLUSH MOUNT TYPE) (RIGHT)




FOP-8-6 REMOTE CONTROL




FOP-9 BOLT KIT




FOP-10 WATER PUMP IMPELLER KIT (1)




FOP-10-1 WATER PUMP IMPELLER KIT (2)




FOP-11 INTERFACE CABLE KIT




FOP-12 TROLLING CONTROL SWITCH




FOP-13 SPEED SENSOR TUBE KIT





FR.↗







Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-3 1	HZY6-11100-405	CRANKCASE COMP.	1	
E-3 2	HPNA-11106-300	BOLT, SEALING, 20MM	1	
E-3 3	HPR4-11106-013	BOLT, SEALING, 28MM	1	
E-3 4	HPNA-11135-000	ORIFICE, LOWER BLOCK	1	
E-3 5	HZY6-11911-000	HANGER, ENGINE	2	
E-3 6	HZY6-12000-415ZA	BLOCK ASSY., CYLINDER	1	*NH8* DARK GRAY
E-3 7	HZV5-12214-000	WASHER, SEALING(22MM)	1	
E-3 8	HZY6-15152-000	ORIFICE, OIL JET	1	
E-3 9	HPRB-15280-A00	BODY COMP., OIL JET	2	
E-3 10	HPRA-15290-000	BOLT COMP., OIL JET	2	
E-3 11	HZY6-15299-000	BOLT-WASHER, 8X10	2	
E-3 12	H921-15611-000	CAP, OIL(YELLOW)	1	
E-3 13	HZY6-30530-003	SENSOR ASSY., KNOCK	1	
E-3 14	HZW9-32114-730	BRACKET, CLIP B	1	
E-3 15	HZY6-32114-010	BRACKET D, HARNESS CLIP	1	
E-3 16	HZY3-35673-003	SENSOR ASSY., WATER	1	TEMPERATURE
E-3 17	HRNA-37260-A01	SENSOR, OIL PRESSURE	1	
E-3 18	HZY6-38552-000	BRACKET, RELAY	1	
E-3 19	HZY6-90001-000	BOLT, FLANGE, 8X55	2	
E-3 20	HZY6-90005-000	BOLT, FLANGE, 12X83	1	
E-3 21	HPNA-90006-003	BOLT-WASHER, 11X95	10	
E-3 22	HZW9-90011-000	BOLT, FLANGE, 6X14(CT200)	7	
E-3 23	HZW9-90016-000	BOLT, FLANGE, 6X25	18	
E-3 24	HZY3-90026-000	BOLT, FLANGE, 8X20	4	
E-3 25	HZY3-90054-000	BOLT, FLANGE, 8X35	10	
E-3 26	HZV5-90081-010	BOLT, SEALING, 22MM	1	
E-3 27	HZY6-90082-003	CAP, BOLT, 8MM	1	
E-3 28	HZW4-90156-000	BOLT, FLANGE, 8X50	4	
E-3 29	HZW4-90162-000	BOLT, FLANGE, 10X70	1	












Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-5 1	HZW1-12217-010	BOLT, SEALING, 20MM	2	
E-5 2	HZY6-15100-000ZA	PUMP ASSY., OIL	1	*NH8* DARK GRAY
E-5 3	HZY6-15112-000	PACKING, OIL PUMP BODY	1	
E-5 4	HZY6-15121-000	COVER, OIL PUMP	1	
E-5 5	HPE0-15231-000	VALVE, RELIEF	1	
E-5 6	HPG6-15232-000	SPRING, RELIEF VALVE	1	
E-5 7	HPC6-15233-000	BOLT, SEALING, 18MM	1	
E-5 8	HZW5-15331-003	ROTOR, INNER OIL PUMP	1	
E-5 9	HZW5-15341-003	ROTOR, OUTER OIL PUMP	1	
E-5 10	HRTA-15400-004	CARTRIDGE, OIL FILTER	1	(TOYO ROKI)
E-5 11	HZY6-15410-010ZA	FLANGE COMP., OIL FILTER	1	*NH8* DARK GRAY
E-5 12	HZY6-31110-000ZA	FLYWHEEL COMP.	1	*TBLACK* BLACK
E-5 13	HZY3-31116-000	BOSS, FLYWHEEL	1	
E-5 14	HZW5-90002-013	BOLT, SPECIAL, 8MM	8	
E-5 15	HPH3-90011-000	BOLT, FLANGE, 12MM	8	
E-5 16	HPH1-90015-013	HOLDER, OIL FILTER	1	
E-5 17	HZW9-90016-000	BOLT, FLANGE, 6X25	4	
E-5 18	HZW5-90018-000	BOLT, FLANGE, 6X20	1	
E-5 19	HZV5-90081-010	BOLT, SEALING, 22MM	2	
E-5 20	HZW5-91201-003	OIL SEAL, 46X60X9	1	
E-5 21	HP01-91212-003	OIL SEAL, 31X46X7(NOK)	1	
E-5 22	HVD6-91360-003	O-RING, 22.5X2.4	2	
E-5 23	HCO-93600-06016-0A	SCREW, FLAT, 6X16	9	
E-5 24	HCO-94109-20000	WASHER, DRAIN PLUG, 20MM	2	
E-5 25	HCO-94301-10160	DOWEL PIN, 10X16	1	
E-5 26	HCO-94301-14200	DOWEL PIN, 14X20	1	
E-5 27	HCO-95701-08032-08	BOLT, FLANGE, 8X32	5	
E-5 28	HCO-96220-50080	ROLLER, 5X8	2	






Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-7	1	HZY6-13010-000	4	
E-7	2	HZY6-13101-000	4	
E-7		HZY6-13102-000	4	
E-7	3	HPNA-13111-010	4	
E-7	4	HP5A-13115-000	8	
E-7	5	HP8A-13204-A01	8	
E-7	6	HPPA-13210-000	4	
E-7	7	HZY6-13211-004	8	(BLUE)
E-7		HZY6-13212-004	8	(BLACK)
E-7		HZY6-13213-004	8	(BROWN)
E-7		HZY6-13214-004	8	(GREEN)
E-7		HZY6-13215-004	8	(YELLOW)
E-7		HZY6-13216-004	8	(PINK)
E-7		HZY6-13217-004	8	
E-7	8	HPPA-13310-000	1	
E-7	9	HPNA-13321-003	5	(DAIDO)
E-7		HPNA-13322-003	5	(DAIDO)
E-7		HPNA-13323-003	5	(DAIDO)
E-7		HPNA-13324-003	5	(DAIDO)
E-7		HPNA-13325-003	5	(DAIDO)
E-7		HPNA-13326-003	5	(DAIDO)
E-7				
E-7	10	HZY6-13331-013	2	
E-7	11	HPNA-13341-003	5	(DAIDO)
E-7		HPNA-13342-003	5	(DAIDO)
E-7		HPNA-13343-003	5	(DAIDO)
E-7		HPNA-13344-003	5	(DAIDO)
E-7		HPNA-13345-003	5	(DAIDO)
E-7		HPNA-13346-003	5	(DAIDO)






FR. ↗




Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-9 1	HZY5-14110-000	CAMSHAFT COMP., IN.	1	
E-9 2	HPNA-14114-003	PLATE, TDC PULSE	1	
E-9 3	HPNA-14115-000	BOLT, SEALING, 14MM	2	
E-9 4	HZY6-14120-000	CAMSHAFT COMP., EX.	1	
E-9 5	HPNA-14210-000	SPROCKET, CAM CHAIN DRIVEN	1	(46T)
E-9 6	HZY6-14311-000	SPROCKET, CAM CHAIN DRIVEN IN.	1	(46T)
E-9 7	HR40-14401-A01	CHAIN(176L)(BORG WARNER)	1	
E-9 8	HZY6-14510-003	TENSIONER ASSY., CAM CHAIN	1	
E-9 9	HPNA-14511-003	STOPPER(TOOL)	1	
E-9 10	HPPA-14520-003	ARM COMP., CAM CHAIN TENSIONER	1	
E-9 11	HPPA-14530-003	GUIDE COMP., CAM CHAIN	1	
E-9 12	HRWC-14540-A02	GUIDE COMP. B, CAM CHAIN	1	
E-9 13	HRAA-14620-A00	ARM ASSY., ROCKER	4	
E-9 14	HRAA-14624-A00	ARM ASSY., EX. ROCKER	4	
E-9 15	HPNE-14631-000	SHAFT, IN. ROCKER	1	
E-9 16	HR40-14633-A00	SHAFT, EX. ROCKER	1	
E-9 17	HRAA-14647-A00	WASHER, THRUST	8	
E-9 18	HPNA-14711-000	VALVE, IN.	8	
E-9 19	HPRB-14721-A00	VALVE, EX.	8	
E-9 20	HPNA-14744-004	SCREW, TAPPET ADJUSTING	8	
E-9 21	HPT0-14744-004	SCREW, TAPPET ADJUSTING	8	
E-9 22	HZY6-14751-003	SPRING, IN. VALVE(PINK)	8	(NIPPON HATSUJO)
E-9 23	HPNA-14762-003	SPRING, EX. VALVE(GRAY)	8	(NIPPON HATSUJO)
E-9 24	HRAA-14765-A00	RETAINER, VALVE SPRING	16	
E-9 25	HPT0-14775-000	SEAT, VALVE SPRING	16	
E-9 26	HRGM-14781-A01	COTTER, VALVE(FUJI VALVE)	32	
E-9 27	HPNA-90003-000	BOLT, TENSIONER PIVOT	1	
E-9 28	HPNA-90032-000	BOLT, FLANGE, 12X47	1	
E-9 29	HPNA-90042-003	BOLT, FLANGE, 10X32	1	

FR. ↗










Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-9-10 1	HZY6-11410-425ZA	CASE ASSY., CHAIN	1	*NH8* DARK GRAY
E-9-10 2	HZY6-11412-000	COVER, CHAIN CASE	1	
E-9-10 3	HZY3-19300-023	THERMOSTAT ASSY.	1	
E-9-10 4	HZY6-19300-003	THERMOSTAT ASSY.	1	
E-9-10 5	HZY6-19313-000ZB	SPACER, THERMOSTAT COVER	1	*TGRAY* GRAY
E-9-10 6	HZY6-19315-010	COVER, THERMOSTAT	1	
E-9-10 7	HZY6-19318-010	PACKING, THERMOSTAT COVER	1	
E-9-10 8	HZY6-19319-000	PACKING, THERMOSTAT SPACER	1	
E-9-10 9	HZY6-32112-000	BRACKET B, HARNESS CLIP	1	
E-9-10 10	HZY6-32113-000	BRACKET C, HARNESS CLIP	1	
E-9-10 11	HZW5-35673-003	SENSOR ASSY., WATER	1	TEMPERATURE
E-9-10 12	HZY3-35673-003	SENSOR ASSY., WATER	1	TEMPERATURE
E-9-10 13	HPNB-37500-003	SENSOR ASSY., CRANK	1	
E-9-10 14	HZW9-90011-000	BOLT, FLANGE, 6X14(CT200)	5	
E-9-10 15	HZY3-90016-000	BOLT, FLANGE, 6X28	13	
E-9-10 16	HZY3-90017-000	BOLT, FLANGE, 6X16	1	
E-9-10 17	HZY3-90021-000	BOLT, FLANGE, 6X14	3	
E-9-10 18	HZY6-90023-000	BOLT, SPECIAL, 6X31	2	
E-9-10 19	HZY3-90040-000	BOLT, FLANGE, 10X43	2	
E-9-10 20	HZY6-90059-000	BOLT, FLANGE, 6X38	1	
E-9-10 21	HZW4-90162-000	BOLT, FLANGE, 10X70	1	
E-9-10 22	HPNC-91212-004	OIL SEAL, 43X58X7(ARA)	1	
E-9-10 23	HPNA-91302-004	O-RING, CHAIN CASE	1	
E-9-10 24	HZY6-91304-010	PACKING, CHAIN CASE	1	
E-9-10 25	HPK2-91307-005	O-RING, 9.5X1.5(HONDA KIKAKI)	1	
E-9-10 26	HPNA-91307-003	O-RING, 9.5X1.9	1	
E-9-10 27	HPNA-91333-003	O-RING, 15X1.9	1	
E-9-10 28	HSP0-91546-A01	CLAMP, 18.5MM	1	




Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-9-20 1	HZY6-06122-010ZA	HEAD KIT, CYLINDER	1	*NH8* DARK GRAY
E-9-20 2	HPNA-12204-305	GUIDE, IN. VALVE(OS)	8	
E-9-20 3	HPNA-12205-305	GUIDE, EX. VALVE(OS)	8	
E-9-20 4	HPZ1-12210-003	SEAL A, VALVE STEM(ARAI)	8	
E-9-20	HPZ1-12210-004	SEAL A, VALVE STEM(NOK)	8	
E-9-20 5	HPZ1-12211-003	SEAL B, VALVE STEM(ARAI)	8	
E-9-20	HPZ1-12211-004	SEAL B, VALVE STEM(NOK)	8	
E-9-20 6	HZY6-12251-003	GASKET COMP., CYLINDER HEAD	1	
E-9-20 7	HRAA-15815-A02	FILTER ASSY., SPOOL VALVE	1	
E-9-20 8	HZY9-15815-000	COVER ASSY., OIL PATH	1	
E-9-20 9	HZY6-15834-000	PLUG, VTC HOLE	1	
E-9-20 10	HZY6-15840-000ZA	STRAINER ASSY., VTC	1	*NH8* DARK GRAY
E-9-20 11	HRAA-15845-A01	FILTER ASSY., VTC	1	
E-9-20 12	HZY6-32116-000	BRACKET F, CLIP	1	
E-9-20 13	HPNB-37510-003	SENSOR ASSY., TDC	1	
E-9-20 14	HZY6-37521-000	PLUG, TDC HOLE	1	
E-9-20 15	HPNA-90005-003	BOLT-WASHER, 11X155	10	
E-9-20 16	HPNA-90011-003	BOLT A, HEAD COVER	6	
E-9-20 17	HZY6-90011-000	BOLT, FLANGE, 6X52	3	
E-9-20 18	HZY3-90017-000	BOLT, FLANGE, 6X16	2	
E-9-20 19	HZW5-90018-000	BOLT, FLANGE, 6X20	4	
E-9-20 20	HZY3-90021-000	BOLT, FLANGE, 6X14	1	
E-9-20 21	HZY6-90048-010	BOLT, SEALING, 20MM	1	
E-9-20 22	HZY6-91303-003	O-RING, 15X1.9	1	
E-9-20 23	HPNA-91333-003	O-RING, 15X1.9	1	
E-9-20 24	HCO-94109-20000	WASHER, DRAIN PLUG, 20MM	1	
E-9-20 25	HCO-94301-10160	DOWEL PIN, 10X16	20	
E-9-20 26	HCO-94301-14200	DOWEL PIN, 14X20	2	
E-9-20 27	HCO-95701-06020-08	BOLT, FLANGE, 6X20	1	











FR.

Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-14	1	HZY6-16089-000	BOLT, FUEL PIPE	2
E-14	2	HZY6-16450-003	INJECTOR ASSY., FUEL	4
E-14	3	HZY6-16451-000	CLIP, INJECTOR	4
E-14	4	HZY6-16621-000	LINE, FUEL	1
E-14	5	HZY6-16740-003	REGULATOR ASSY., PRESSURE	1
E-14	6	HZY6-16744-010	CAP, REGULATOR	1
E-14	7	HZY6-16748-000	TUBE, PRESSURE REGULATOR	1
E-14	8	HZY3-16752-000	JOINT, FUEL PIPE	1
E-14	9	HZY6-16752-000	JOINT, FUEL PIPE	1
E-14	10	HZY6-17051-000ZA	BASE, INJECTOR	1
E-14	11	HPNA-17055-004	GASKET A, INJECTOR BASE	1
E-14	12	HZY6-17105-000	PACKING, INTAKE MANIFOLD	4
E-14	13	HZY6-17109-000	PACKING, THROTTLE BODY	1
E-14	14	HZX1-17110-003	MANIFOLD COMP., INLET	1
E-14	15	HZY6-32111-000	BRACKET A, HARNESS CLIP	4
E-14	16	HPS4-36454-003	FILTER COMP., ELECTRONIC AIR	1
E-14	17	HZY6-36550-003	VALVE ASSY., ELECTRONIC AIR	1
E-14	18	HZY6-36551-003	PACKING, ELECTRONIC AIR	1
E-14	19	H121-51640-730	RUBBER, FR. CARRIER CUSHION	2
E-14	20	HZW1-90014-000	BOLT-WASHER, 8X35	2
E-14	21	HZY3-90021-000	BOLT, FLANGE, 6X14	4
E-14	22	HZY3-90042-000	BOLT, FLANGE, 6X10	4
E-14	23	HZY6-90043-000	BOLT, STUD 2, 8X25	2
E-14	24	HZY6-90047-000	BOLT, STUD, 8X32	2
E-14	25	HZY3-90054-000	BOLT, FLANGE, 8X35	3
E-14	26	HZW4-90126-000	BOLT, FLANGE, 8X45	2
E-14	27	HZW4-90151-000	BOLT, FLANGE, 8X25	5
E-14	28	HZY3-90205-000	NUT, FLANGE, 8MM	4
E-14	29	HZW2-90301-F00	NUT, FLANGE, 6MM	2




FR.




FR.



Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-15	1	HZY6-16016-003	SCREW SET	1
E-15	2	HZY6-16400-013	THROTTLE BODY ASSY.	1
E-15	3	HPY3-17249-000	SPRING, AIR FLOW TUBE	1
E-15	4	HZY9-17315-000	BAND, AIR FLOW	1
E-15	5	HZY6-17371-020	CASE COMP., SILENCER	1
E-15	6	HZY6-17374-000	GROMMET, SILENCER	1
E-15	7	HZY6-17397-013	GROMMET, SILENCER DUCT	1
E-15	8	HZY6-17398-000	SPRING, SILENCER DUCT GROMMET	1
E-15	9	HZY6-32115-000	BRACKET E, HARNESS CLIP	1
E-15	10	HZY3-32128-000	BRACKET, SENSOR CORD	1
E-15	11	HRNA-37830-A01	SENSOR ASSY., MAP	1
E-15	12	HPGK-37835-A01	O-RING	1
E-15	13	HPLC-37880-004	SENSOR ASSY., AIR TEMP	1
E-15	14	HP2A-37881-000	GROMMET, TA SENSOR	1
E-15	15	HZV5-40102-000	GROMMET, UNDER CASE	3
E-15	16	HZY6-90006-000	SCREW, PAN, 5X18	1
E-15	17	HZW1-90013-000	BOLT-WASHER, 6X25	3
E-15	18	HZY9-90017-000	BOLT-WASHER, 5X30	1
E-15	19	HZY3-90056-000	BOLT, FLANGE, 6X12	1
E-15	20	HZV1-90127-010	BOLT, FLANGE, 8X60	4
E-15	21	HZV3-90601-030	CLAMP, TUBE(D17)	1
E-15	22	HZV5-91553-010	COLLAR, C.D.I. UNIT CASE	3
E-15	23	HSF1-91595-003	CLAMP, FUEL HOSE	1
E-15	24	HCO-95003-07016-31	TUBE, VINYL, 4X7X160	1
E-15	25	HCO-95005-12740-20	TUBE, 12X740	1
				(HC-95003-07001-60M)
				(HC-95005-12001-20M)




Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-18 1	HGHB-16163-610	CLIP, TUBE	1	
E-18 2	HZY6-16196-000	TUBE COMP. C, AIR VENT	1	
E-18 3	HZY6-16198-000	TUBE B, AIR VENT	1	
E-18 4	HZY6-16199-000	TUBE COMP., AIR VENT	1	
E-18 5	HZY6-16700-013	PUMP ASSY., FUEL	1	
E-18 6	HZY6-16755-003	HOSE COMP., FUEL	1	
E-18 7	HZY6-16860-A00	TUBE COMP. B, FUEL	1	
E-18 8	HZV5-16881-000	TUBE D, FUEL	1	
E-18 9	H759-16911-003	STRAINER, FUEL PUMP	1	
E-18 10	HZW5-16915-000	SUSPENSION, STRAINER	1	
E-18 11	HMZ5-16952-000	TUBE B, FUEL	1	
E-18 12	HVM0-16965-771	CLAMP, HOSE	2	
E-18 13	HKV7-17368-671	CLAMP, PIPE	1	
E-18 14	HZY6-17723-020	HOSE, PRESSURE REGULATOR	1	RETURN
E-18 15	HZY6-19269-000	T-JOINT	1	
E-18 16	HZY6-19273-000	TUBE G, WATER	1	
E-18 17	HZY6-36135-003	VALVE, CHECK	1	
E-18 18	HSE0-53740-953	CLIP, SENSOR HOSE	2	
E-18 19	HZY6-90010-000	BOLT, FLANGE, 6X27	2	
E-18 20	HZW1-90014-000	BOLT-WASHER, 8X35	2	
E-18 21	HZW9-90016-000	BOLT, FLANGE, 6X25	2	
E-18 22	HZW5-90601-030	CLAMP, TUBE(D10.7)	2	
E-18 23	HZY6-90601-000	CLIP, TUBE(B1 14.5)	1	
E-18 24	HZV0-90604-000	CLIP, TUBE(B12)	1	
E-18 25	HZY6-90605-003	CLIP, FUEL HOSE	1	
E-18 26	HPA9-91317-003	O-RING, 33.2X2.4(NOK)	1	
E-18 27	HSE0-91547-003	CLIP, HARNESS	1	
E-18 28	HZW1-91554-000	COLLAR, 8.5X14.5	2	
E-18 29	HSM4-91558-003	CLIP, TUBE(BLACK)(135MM)	1	






FR. ↗








Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-18-10 1	HZY3-16011-000	VALVE SET, FLOAT	1	
E-18-10 2	HZY3-16013-000	FLOAT SET	1	
E-18-10 3	HZY6-16014-003	STAY A, PLATE	1	
E-18-10 4	HZY6-16017-043	PUMP UNIT, FUEL	1	
E-18-10 5	HZY6-16019-003	BODY COMP., CHAMBER	1	
E-18-10 6	HZY6-16020-023	COVER COMP.	1	
E-18-10 7	HZY3-16024-000	SCREW SET, DRAIN	1	
E-18-10 8	HZY3-16026-000	JOINT SET	1	
E-18-10 9	HZY6-16036-003	PUMP UNIT, FUEL(B)	1	
E-18-10 10	HZY3-16041-000	PLATE	1	
E-18-10 11	HZY3-16042-000	HOLDER	1	
E-18-10 12	HZY3-16061-000	COVER, WATER JACKET	1	
E-18-10 13	HZY3-16072-000	O-RING	1	
E-18-10 14	HZY3-16073-000	O-RING	1	
E-18-10 15	HZY3-16074-000	O-RING	1	
E-18-10 16	HZY3-16075-000	O-RING	1	
E-18-10 17	HZY3-16076-000	O-RING	1	
E-18-10 18	HZY3-16077-000	O-RING	2	
E-18-10 19	HZY3-16078-000	O-RING	1	
E-18-10 20	HZW5-16081-010	SCREW-WASHER	21	
E-18-10 21	HZY3-16082-000	SCREW, PAN	2	
E-18-10 22	HZY3-16083-000	SCREW, WASHER	1	
E-18-10 23	HZW5-16086-000	COLLAR	8	
E-18-10 24	HZW5-16087-000	WASHER, PLAIN	8	
E-18-10 25	HZY3-16087-000	WASHER, PLAIN	1	
E-18-10 26	HZY3-16088-000	COLLAR	1	
E-18-10 27	HZY6-16701-003	CASE COMP., PUMP	1	
E-18-10 28	HZW5-16708-003	COVER, PUMP(B)	1	
E-18-10 29	HZW5-16715-023	COVER, PUMP(A)	1	







Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-19	1	HZY6-11912-000	1	
E-19	2	HPZ1-31105-003	1	
E-19	3	HPJ7-31111-013	1	
E-19	4	HPJ7-31114-013	1	
E-19	5	HPD1-31138-004	1	
E-19	6	HP64-31141-003	1	
E-19	7	HPD1-31142-004	1	
E-19	8	HPE9-31145-941	2	
E-19	9	HPJ7-31146-003	4	
E-19	10	HPT0-31147-003	6	
E-19	11	HPD1-31148-004	2	
E-19	12	HPZ1-31149-003	1	
E-19	13	HPE9-31152-942	2	
E-19	14	HPZ1-31153-003	3	
E-19	15	HZY6-31630-003	1	
E-19	16	HZW5-31631-003	1	
E-19	17	HZY6-31636-010	1	
E-19	18	HZY6-31637-000	1	
E-19	19	HZW5-31639-003	1	
E-19	20	HZW5-31644-003	1	
E-19	21	HZW5-31710-003	1	
E-19	22	HZY6-31750-003	1	
E-19	23	HZW5-90011-010	1	
E-19	24	HZY3-90017-000	1	
E-19	25	HZY3-90026-000	2	
E-19	26	HZY3-90035-000	4	
E-19	27	HZY3-90055-000	1	
E-19	28	HZW4-90163-000	1	
E-19	29	HZW5-90203-010	1	















Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
E-21	1	HZY6-31200-003	MOTOR ASSY., STARTER	1
E-21	2	HZY3-31207-003	CLUTCH COMP., OVERRUNNING	1
E-21		HZY9-31207-H01	CLUTCH COMP., OVERRUNNING	1
E-21	3	HPY3-31215-004	GEAR ASSY., PLANETARY	3
E-21	4	HZY6-31216-003	YOKES COMP.	1
E-21	5	HZW5-31217-003	ROTOR COMP.	1
E-21	6	HPY3-31218-004	BALL, STEEL	1
E-21	7	HZY6-31226-003	BRUSH SET	1
E-21		HZY6-31227-003	BRUSH SET	1
E-21	8	HZW1-31229-004	STOPPER SET, SLEEVE	1
E-21		HZY9-31229-H01	STOPPER SET, SLEEVE	1
E-21	9	HZY6-31231-003	HOLDER COMP., BRUSH	1
E-21		HZY6-31232-003	HOLDER COMP., BRUSH	1
E-21	10	HZY6-31235-003	BRACKET, FR.	1
E-21	11	HZY6-31236-003	BRACKET, RR.	1
E-21	12	HZY6-31240-003	SWITCH ASSY., MAGNET	1
E-21		HZY9-31240-003	SWITCH ASSY., MAGNET	1
E-21	13	HZY6-31242-003	SHAFT ASSY., CLUTCH	1
E-21		HZY9-31242-H01	SHAFT ASSY., CLUTCH	1
E-21	14	HZY3-31246-003	SHAFT ASSY., GEAR	1
E-21		HZY9-31246-H01	SHAFT ASSY., GEAR	1
E-21	15	HZW1-31247-004	GEAR ASSY., INTERNAL	1
E-21	16	HZW1-31249-004	PACKING	1
E-21	17	HZW1-31250-004	LEVER SET	1
E-21	18	HZW1-31261-004	BOLT A, THROUGH	2
E-21	19	HZW1-90106-004	SCREW, PAN, 6X22(SPECIAL)	2
E-21		HZY9-31226-H01	SCREW, PAN, 6X22	2
E-21	20	HZW1-90107-004	SCREW, PAN, 5X8	2
E-21	21	HZW4-90164-000	BOLT, FLANGE, 10X90	2








Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
F-2 1	HZV5-17838-000	LINKAGE, PIVOT	1	
F-2 2	HZY6-17840-000	ROD COMP., THROTTLE	1	
F-2 3	HZY6-17845-000	LINK, THROTTLE	1	
F-2 4	HZY6-17860-000	PLATE COMP., THROTTLE	1	
F-2 5	HZY6-17877-010	PLATE, REMOTE CONTROL CABLE	1	
F-2 6	HZY6-17931-000	ARM, THROTTLE	1	
F-2 7	H921-17936-000	WASHER, PIVOT	1	
F-2 8	HZY6-24166-000	ARM COMP., CLICK	1	
F-2 9	HZY6-24218-000	SPRING, CLICK	1	
F-2 10	HZY6-24320-000	ROD COMP. A, SHIFT(L)	1	LA
F-2	HZY6-24320-610	ROD COMP. A, SHIFT(XL)	1	XA,XCA
F-2 11	HZW1-24327-000	RING, STOPPER	1	
F-2 12	HZY6-24610-000	SHAFT COMP. A, SHIFT	1	
F-2 13	HZY6-24612-020	ARM, SHIFT	1	
F-2 14	HZY6-24614-000	PLATE, SHIFT PIVOT	1	
F-2 15	HZY3-24618-000	PIVOT, SHIFT	2	
F-2 16	HZY6-24618-000	PIVOT, SHIFT SLIDE	1	
F-2 17	HZY3-24619-000	PLATE, LOCK	2	
F-2 18	HZY6-24620-000	SHAFT COMP. B, SHIFT	1	
F-2 19	HZY6-24628-000	BRACKET, SHIFT LINK	1	
F-2 20	HZY6-24629-000ZA	HOLDER, SEAL	1	*NH8* DARK GRAY
F-2 21	HZY6-32418-000	BRACKET A, CABLE	1	
F-2 22	HZY3-35470-023	SWITCH ASSY., NEUTRAL	1	
F-2 23	HZY6-35475-000	BRACKET, NEUTRAL SWITCH	1	
F-2 24	HVM0-46391-003	CLIP, BRAKE PIPE(A)	1	
F-2 25	HZY3-63205-000	BUSH A, COVER LOCK	2	
F-2 26	H763-75538-C01	BUSH, BLADE BRAKE	1	
F-2 27	HZY3-90017-000	BOLT, FLANGE, 6X16	1	
F-2 28	HZY3-90021-000	BOLT, FLANGE, 6X14	2	














Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
F-4	1	H921-17936-000	WASHER, PIVOT	1
F-4	2	HZW1-19210-B04	IMPELLER, PUMP	1
F-4	3	HZY6-19221-A00	HOUSING, IMPELLER	1
F-4	4	HZW1-19223-B00	LINER, PUMP	1
F-4	5	HZY6-19231-000	COVER, IMPELLER	1
F-4	6	HZY6-19234-000	GASKET B, IMPELLER	1
F-4	7	HZY6-19251-000	TUBE, WATER(L)	1
F-4		HZY6-19251-611	TUBE, WATER(XL)	1
F-4	8	HZW1-19253-B01	RING, WATER TUBE SEAL	1
F-4	9	HZY6-24310-000	ROD COMP., SHIFT	1
F-4		HZY6-24310-710	ROD COMP., SHIFT	1
F-4	10	HZY3-24318-000	SPRING, SHIFT ROD	1
F-4	11	HZY6-24343-000	HOLDER, SHIFT ROD	1
F-4	12	HZW1-40204-000	GROMMET, EXTENSION CASE	1
F-4	13	HZY6-41112-010	SHAFT, VERTICAL(L)	1
F-4		HZY6-41112-611	SHAFT, VERTICAL(XL)	1
F-4	14	HZW1-41116-B00	SLINGER, OIL	1
F-4	15	HZZ3-41117-000	HOUSING, WATER SEAL	1
F-4	16	HZY6-41131-000	GEAR, PINION	1
F-4	17	H881-90105-000	BOLT, HEX., 6X12	1
F-4	18	HZW9-90105-000	BOLT, FLANGE, 6X20	2
F-4	19	HZY6-90116-000	BOLT-WASHER, 8X40	4
F-4	20	HZW1-90242-000	NUT, LOCK, 64MM	1
F-4	21	HZW5-90303-000	NUT, HEX., 18MM	1
F-4	22	H723-90472-000	WASHER, PLAIN, 12MM	1
F-4	23	HZW1-90518-B00	SHIM A, GEAR(0.10)	1
F-4		HZW1-90519-B00	SHIM B, GEAR(0.15)	1
F-4		HZW1-90520-B00	SHIM C, GEAR(0.30)	1
F-4		HZW1-90521-B00	SHIM D, GEAR(0.50)	1




FR.




Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
F-5 1	HZY6-24101-000	SHIFTER, CLUTCH	1	LA,XA
F-5 2	HZW1-24102-B00	PIN, SHIFTER, 8X47	1	LA,XA
F-5 3	HZW1-24103-B00	RING, CROSS PIN	1	LA,XA
F-5 4	HZY6-24122-000	SLIDER, SHIFT	1	LA,XA
F-5 5	HZY6-24123-000	SPRING, SHIFT	2	LA,XA
F-5 6	HZY6-24124-000	PLATE, SHIFT	1	LA,XA
F-5 7	HZY6-41140-000	GEAR COMP., BEVEL(FORWARD 30T)	1	LA,XA
F-5 8	HZY6-41151-000	GEAR, BEVEL(RVS. 30T)	1	LA,XA
F-5 9	HZY6-41161-000	SHAFT, PROPELLER	1	LA,XA
F-5 10	HZY6-41201-000ZC	HOLDER, PROPELLER SHAFT	1	*T107* BAY BLUE LA,XA
F-5 11	HZY3-58130-T00	PROPELLER COMP., THREE BLADES	1	(14-1/2X15)(SUS) LA,XA
F-5	HZY3-58130-T10	PROPELLER COMP., THREE BLADES	1	(14-1/4X17)(SUS) LA,XA
F-5	HZY3-58130-T20	PROPELLER COMP., THREE BLADES	1	(14X19)(SUS) LA,XA
F-5	HZY3-58130-T30	PROPELLER COMP., THREE BLADES	1	(14X21)(SUS) LA,XA
F-5	HZY3-58130-T40	PROPELLER COMP., THREE BLADES	1	(14-1/2X23)(SUS) LA,XA
F-5	HZY3-58130-T50	PROPELLER COMP., THREE BLADES	1	(14X25)(SUS) LA,XA
F-5	HZY3-58130-V01ZA	PROPELLER COMP., THREE BLADES	1	*NH283* (15-1/2X13)(AL) STIN GRAY LA,XA
F-5	HZY3-58130-V11ZA	PROPELLER COMP., THREE BLADES	1	*NH283* (15-1/4X15)(AL) STIN GRAY LA,XA
F-5	HZY3-58130-V21ZA	PROPELLER COMP., THREE BLADES	1	*NH283* (15X17)(AL) STIN GRAY LA,XA
F-5	HZY3-58130-V31ZA	PROPELLER COMP., THREE BLADES	1	*NH283* (14-3/4X19)(AL) STIN GRAY LA,XA
F-5	HZY3-58130-V41ZA	PROPELLER COMP., THREE BLADES	1	*NH283* (14-1/2X21)(AL) STIN GRAY LA,XA
F-5	HZY3-58130-V51ZA	PROPELLER COMP., THREE BLADES	1	*NH283* (14-1/4X23)(AL) STIN GRAY LA,XA
F-5 12	HZY6-90104-000	BOLT, FLANGE, 10X40	2	LA,XA
F-5 13	HZW1-90301-B00	NUT, CASTLE, 18MM	1	LA,XA
F-5 14	HZY3-90506-000	WASHER, PROPELLER THRUST	1	LA,XA
F-5 15	HZW5-90509-711	WASHER, THRUST BEARING	1	LA,XA
F-5 16	HZY3-90512-000	WASHER, PROPELLER	1	LA,XA
F-5 17	HZY3-90528-000	SHIM A, BEVEL(0.10)	1	LA,XA
F-5	HZY3-90529-000	SHIM B, BEVEL(0.15)	1	LA,XA






**PROPELLER SHAFT/PROPELLER
(XCA)**





Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
F-5-1	1	HZY6-24101-000	SHIFTER, CLUTCH	1 XCA
F-5-1	2	HZW1-24102-B00	PIN, SHIFTER, 8X47	1 XCA
F-5-1	3	HZW1-24103-B00	RING, CROSS PIN	1 XCA
F-5-1	4	HZY6-24122-000	SLIDER, SHIFT	1 XCA
F-5-1	5	HZY6-24123-000	SPRING, SHIFT	2 XCA
F-5-1	6	HZY6-24124-000	PLATE, SHIFT	1 XCA
F-5-1	7	HZY6-41141-710	GEAR, BEVEL(FORWARD 30T)	1 (COUNTER ROTATION) XCA
F-5-1	8	HZY6-41150-710	GEAR COMP., BEVEL(RVS. 30T)	1 (COUNTER ROTATION) XCA
F-5-1	9	HZY6-41161-710	SHAFT, PROPELLER	1 (COUNTER ROTATION) XCA
F-5-1	10	HZY6-41201-710ZC	HOLDER, PROPELLER SHAFT	1 *T107* BAY BLUE XCA
F-5-1	11	HZY6-41202-710	HOLDER, BEARING	1 (COUNTER ROTATION) XCA
F-5-1	12	HZY3-58180-T00	PROPELLER COMP., THREE BLADES	1 (14-1/2X15)(C/R) XCA
F-5-1		HZY3-58180-T10	PROPELLER COMP., THREE BLADES	1 (14-1/4X17)(C/R) XCA
F-5-1		HZY3-58180-T20	PROPELLER COMP., THREE BLADES	1 (14X19)(C/R) XCA
F-5-1		HZY3-58180-T30	PROPELLER COMP., THREE BLADES	1 (14X21)(C/R) XCA
F-5-1		HZY3-58180-T40	PROPELLER COMP., THREE BLADES	1 (14-1/2X23)(C/R) XCA
F-5-1	13	HZY6-90104-000	BOLT, FLANGE, 10X40	2 XCA
F-5-1	14	HZW1-90301-B00	NUT, CASTLE, 18MM	1 XCA
F-5-1	15	HZY3-90506-000	WASHER, PROPELLER THRUST	1 XCA
F-5-1	16	HZW5-90509-711	WASHER, THRUST BEARING	2 XCA
F-5-1	17	HZY3-90512-000	WASHER, PROPELLER	1 XCA
F-5-1	18	HZY3-90528-000	SHIM A, BEVEL(0.10)	1 XCA
F-5-1		HZY3-90529-000	SHIM B, BEVEL(0.15)	1 XCA
F-5-1		HZY3-90530-000	SHIM C, BEVEL(0.30)	1 XCA
F-5-1		HZY3-90531-000	SHIM D, BEVEL(0.50)	1 XCA
F-5-1	19	HZW5-90548-710	SHIM A, THRUST(0.10)	1 XCA
F-5-1		HZW5-90549-710	SHIM B, THRUST(0.15)	1 XCA
F-5-1		HZW5-90550-710	SHIM C, THRUST(0.30)	1 XCA
F-5-1		HZW5-90551-710	SHIM D, THRUST(0.50)	1 XCA


PROPELLER SHAFT/PROPELLER
(XCA)





















Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
F-8-10 1	HMG9-35701-950	BAND(BLACK 3.5X140)	1	
F-8-10 2	HZY6-40105-020	GROMMET, REMOTE CONTROL CABLE	1	
F-8-10 3	HZW1-40107-700	GROMMET, UNDER CASE(C)	1	
F-8-10 4	HZY3-40119-003	BAND, UNDER CASE GROMMET	1	
F-8-10 5	HZY6-40154-000ZC	BRACKET, FR. UNDER COVER	1	*T107* BAY BLUE
F-8-10 6	HZY6-40155-000	BRACKET, R. SIDE COVER	1	
F-8-10 7	HZY6-40157-000	BRACKET, L. SIDE COVER	1	
F-8-10 8	HZY6-60180-003	CABLE COMP. A, COVER LOCK	1	
F-8-10 9	HZY6-60185-003	CABLE COMP. B, COVER LOCK	1	
F-8-10 10	HZY3-63201-000ZC	LEVER, COVER LOCK	1	*T107* BAY BLUE
F-8-10 11	HZY3-63205-000	BUSH A, COVER LOCK	7	
F-8-10 12	HZY6-63205-000	BUSH A, COVER LOCK	1	
F-8-10 13	HZY3-63208-000	BUSH B, COVER LOCK	1	
F-8-10 14	HZY3-63212-000	SPRING, COVER LOCK HOOK	2	
F-8-10 15	HZY6-63212-000	SPRING, COVER LOCK HOOK	1	
F-8-10 16	HZY6-63223-000	SPRING, LOCK LEVER RETURN	1	
F-8-10 17	HZY3-63224-000	SHAFT, COVER OPEN	1	
F-8-10 18	HZY6-63225-000	SHAFT, FR. LOCK	1	
F-8-10 19	HZY6-63240-000	LOCK COMP., FR.	1	
F-8-10 20	HZY3-63260-000	LOCK COMP., SIDE	2	
F-8-10 21	HZC0-63515-700	CAP, L. SIDE COVER	1	
F-8-10 22	HZY6-90001-000	BOLT, FLANGE, 8X55	2	
F-8-10 23	HZY3-90030-000	BOLT, FLANGE, 6X22	2	
F-8-10 24	HZY6-90105-000	BOLT-WASHER, 8X30	2	
F-8-10 25	HMM8-90501-610	WASHER, PLAIN, 8MM	1	
F-8-10 26	HMM8-90502-610	WASHER, PLAIN, 10MM	1	
F-8-10 27	HZW9-90506-000	WASHER, WAVE, 10MM	2	
F-8-10 28	H921-90518-000	WASHER, PLAIN, 8MM	4	
F-8-10 29	HCO-94540-06029	E-RING, 6MM	5	






Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
F-9 1	HZW1-15665-020	PIPE COMP., OIL LEVEL	1	
F-9 2	HGBH-16163-610	CLIP, TUBE	1	
F-9 3	HMN5-17195-000	T-JOINT	1	
F-9 4	HZV5-17202-310	COLLAR, DISTANCE, 6.5X11X7.5	1	
F-9 5	HZY6-18130-000ZA	GUIDE COMP., EX.	1	*NH8* DARK GRAY
F-9 6	HZY6-18135-003	GASKET, EX. GUIDE	1	
F-9 7	HZY6-18211-000	PORT, IDLE EXHAUST	1	
F-9 8	HZY6-18212-000	GASKET, IDLE EX. PORT	1	
F-9 9	HZY6-19256-000	TUBE, WATER RELIEF	1	
F-9 10	HZY6-19267-010	TUBE F, WATER	1	
F-9 11	HZY3-19270-000	NUT, WATER MOUTH	1	
F-9 12	HZY3-19271-000	JOINT, WATER HOSE	1	
F-9 13	HZY3-19272-000	SEAT, WATER MOUTH	1	
F-9 14	HZZ3-19277-000	COVER, FLUSH VALVE	1	
F-9 15	HZW9-19279-000	SPRING, FLUSH VALVE	1	
F-9 16	HZY6-19290-003	VALVE ASSY., RELIEF	1	
F-9 17	HZW9-19291-000	VALVE, FLASH	1	
F-9 18	HZY6-19295-000	COVER, RELIEF VALVE	1	
F-9 19	HZW9-19297-000	PACKING, FLASH VALVE	1	
F-9 20	HZW9-19317-000	O-RING, THERMOSTAT COVER	1	
F-9 21	HZY6-23170-000ZA	CASE COMP., MOUNT	1	*NH8* DARK GRAY
F-9 22	HZY3-23173-010	RUBBER, MOUNT CASE SEAL	1	
F-9 23	HZY6-90014-000	BOLT, FLANGE, 8X30	4	
F-9 24	HZW9-90016-000	BOLT, FLANGE, 6X25	3	
F-9 25	HZY3-90017-000	BOLT, FLANGE, 6X16	1	
F-9 26	HZY3-90030-000	BOLT, FLANGE, 6X22	2	
F-9 27	HZY6-90045-000	BOLT, STUD, 10X55	2	
F-9 28	HZY3-90056-000	BOLT, FLANGE, 6X12	1	
F-9 29	HZY3-90601-030	CLAMP, TUBE(D10.5)	6	







Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
F-10 1	HZW1-06411-020	METAL KIT, ANODE	1	
F-10 2	HZV1-24210-010	SPRING COMP., CLICK	1	
F-10 3	HZV4-24221-010	SPRING, CLICK ASSIST	1	
F-10 4	HZY6-35660-013	SENSOR ASSY., TRIM ANGLE	1	
F-10 5	HZX1-50100-000	FRAME COMP., MOUNTING	1	
F-10 6	HZW5-50151-000	MOUNT COMP., UPPER RUBBER	1	
F-10 7	HZY6-50167-000	HOLDER, UPPER MOUNTING	1	
F-10 8	HZY6-50168-003	GASKET, UPPER MOUNTING HOLDER	1	
F-10 9	HZW1-50201-040ZC	CASE, SWIVEL	1	*T107* BAY BLUE
F-10 10	HZZ5-50211-000	LINER, SWIVEL CASE	2	
F-10 11	HZW1-50214-000	BUSH, SWIVEL CASE	2	
F-10 12	HZW1-50301-070ZC	BRACKET, R. STERN	1	*T107* BAY BLUE
F-10 13	HZW1-50311-070ZC	BRACKET, L. STERN	1	*T107* BAY BLUE
F-10 14	HZW5-50341-010	ROD, ADJUSTING	1	
F-10 15	HZY9-50381-000	SHAFT, TILTING	1	
F-10 16	HZV5-50522-000	BUSH, TILT ARM	2	
F-10 17	HZW1-50527-000	BRACKET, TILTING	1	
F-10 18	HZW1-50529-000	STOPPER, TILT	2	
F-10 19	HZW1-53234-010	PLATE, STEERING	1	
F-10 20	HZW5-53234-010	PLATE, STEERING	1	
F-10 21	HZW1-53238-010	ROD, STEERING	1	
F-10 22	HZW1-56516-000	RECEIVER, THRUST	2	
F-10 23	HZW1-56539-000	COLLAR, LOWER CYLINDER	1	
F-10 24	HZW9-90009-000	BOLT, FLANGE, 6X23	2	
F-10 25	HZW5-90101-000	BOLT, STUD, 12X150	2	
F-10 26	HZW1-90102-000	BOLT, 1/4-28UNF	2	
F-10 27	HZW1-90105-000	BOLT, 3/8-24UNF	1	
F-10 28	HZW9-90105-000	BOLT, FLANGE, 6X20	2	
F-10 29	HZW1-90108-000	BOLT, HEX., 10X235	1	






Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
F-10	30	H881-90110-000	BOLT, HEX., 6X14	1
F-10	31	HZZ3-90129-000	BOLT, HEX., 12X119	4
F-10				
F-10				
F-10		HZX2-90129-000	BOLT, HEX., 12X130	4
F-10				
F-10	32	HZW9-90154-000	BOLT, FLANGE, 10X25	2
F-10	33	HZW5-90302-003	NUT, FLANGE, 12MM	2
F-10	34	HZV5-90304-013	NUT, SELF-LOCK(7/8-14UNF)	1
F-10	35	HZW1-90304-013	NUT, SELF-LOCK(25X2.0)	1
F-10	36	HZW5-90304-000	NUT, ADJUSTER ROD	1
F-10	37	HZW4-90306-003	NUT, FLANGE, 10MM	3
F-10	38	HZV5-90307-003	NUT, SELF-LOCK(3/8-24UNF)	2
F-10	39	HZV5-90501-000	WASHER, WAVE, 40MM	1
F-10	40	HZV5-90502-000	WASHER, WAVE, 26MM	2
F-10	41	HZV5-90504-000	WASHER, THRUST, 34MM	1
F-10	42	HZV4-90514-000	WASHER, 10MM	3
F-10	43	H921-90511-000	WASHER, PLAIN, 10MM	1
F-10	44	HZV5-90552-000	WASHER, PLAIN, 12MM	4
F-10				
F-10	45	HZV5-90559-000	WASHER, PLAIN, 12MM	8
F-10				
F-10				











Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
F-11 1	HZY3-30280-003	BREAKER ASSY.	1	
F-11 2	HZY3-31106-003	BRUSH ASSY.	1	
F-11 3	HZV5-36104-821	TUBE, SPIRAL	1	
F-11 4	HZY6-36120-013	MOTOR ASSY., POWER TILT	1	
F-11 5	HZY3-36122-013	BRACKET ASSY.	1	
F-11 6	HZY3-36123-013	ARMATURE COMP.	1	
F-11 7	HZY6-36129-013	YOKES ASSY.	1	
F-11 8	HZV5-36136-821	SPRING, MOTOR	2	
F-11 9	HZY3-40219-013	WIRE, LEAD(1.5X116MM)	1	
F-11 10	HZV5-50214-003	BUSH, SWIVEL CASE	2	
F-11 11	HZY6-56000-043	TRIM-TILT ASSY., POWER	1	
F-11				
F-11				
F-11				
F-11 12	HZY6-56100-013	PUMP ASSY.	1	
F-11				
F-11				
F-11				
F-11 13	HZW1-56110-701	ROD COMP., PISTON(B)	2	
F-11 14	HZW1-56113-701	JOINT, DRIVE	1	
F-11 15	HZW1-56115-305	GUIDE COMP., ROD	2	
F-11 16	HZY9-56115-003	GUIDE COMP., ROD	2	
F-11 17	HZW1-56116-701	FILTER B	1	
F-11 18	HZV5-56117-821	RING, BACK UP	1	
F-11 19	HZV5-56118-820	BUSH, MOTOR CODE	1	
F-11 20	HZW1-56120-305	ROD COMP., PISTON	1	
F-11 21	HZY9-56120-003	ROD COMP., PISTON	1	
F-11 22	HZW1-56130-702	PISTON COMP., FREE	1	
F-11 23	HZY3-56170-013	VALVE COMP., MANUAL	1	






























Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
FOP-8 1	HZZ3-06240-R30	BOX KIT, REMOTE CONTROL	1	(TOP MOUNT SINGLE)(R.)
FOP-8 2	HZW5-06241-U00	SPACER KIT, REMOTE CONTROL BOX	1	(TOP MOUNT SINGLE)
FOP-8 3	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	(TOP MOUNT)
FOP-8 4	HZW5-24811-U01	HANDLE, REMOTE CONTROL	1	
FOP-8 5	HZW5-24812-U01	COVER, L. GRIP	1	
FOP-8 6	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	1	
FOP-8 7	HZW5-24814-U01	CAP, GRIP	1	
FOP-8 8	HZW5-24815-U01	CAP, SWITCH	1	
FOP-8 9	HZW5-24816-U01	BUTTON, THROTTLE	1	
FOP-8 10	HZW5-24817-U01	PLATE, HANDLE	1	
FOP-8 11	HZW5-24818-U01	PLATE, CABLE CLAMP	1	
FOP-8 12	HZW5-24819-U01	BRACKET, REMOTE CONTROL	2	HOUSING
FOP-8 13	HZW5-24820-U01	HOUSING COMP., REMOTE CONTROL	1	BOX
FOP-8	HZZ3-24820-R11	HOUSING COMP., REMOTE CONTROL	1	BOX
FOP-8 14	HZW5-24825-U01	HOUSING, LEAD	1	
FOP-8 15	HZW5-24826-U01	PLATE, DWELL	1	
FOP-8 16	HZW5-24831-U01	TERMINAL, CABLE	2	
FOP-8 17	HZW5-24832-U01	SPACER, CABLE CLAMP	1	
FOP-8 18	HZW5-24834-U01	PACKING, SINGLE	1	
FOP-8 19	HZW7-32530-U00	SUB HARNESS ASSY., POWER	1	TRIM-TILT(A)
FOP-8 20	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	(A)
FOP-8 21	HZZ3-87703-R81	MARK, REMOTE CONTROL(SINGLE)	1	
FOP-8 22	HZW5-90101-U00	SCREW, PAN, 5X16	2	
FOP-8 23	HZW5-90102-U00	SCREW, PAN, 5X10	1	
FOP-8 24	HZW5-90103-U01	SCREW, PAN, 5X20	2	
FOP-8 25	HZW5-90104-U00	SCREW, PAN, 5X18	4	
FOP-8 26	HZW5-90105-U01	SCREW, PAN, 4X10	2	
FOP-8 27	HZW5-90106-U00	SCREW, PAN, 6X18	2	
FOP-8 28	HZW5-90107-U00	SCREW, PAN, 5X40	4	







Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
FOP-8-2 1	HZZ3-06240-R60	BOX KIT, REMOTE CONTROL	1	(TOP MOUNT DUAL)(R.)
FOP-8-2 2	HZW5-06241-U10	SPACER KIT, REMOTE CONTROL BOX	1	(TOP MOUNT DUAL)
FOP-8-2 3	HZW5-24810-U01	HOUSING ASSY., L. INNER	1	(TOP MOUNT)
FOP-8-2 4	HZW5-24810-U11	HOUSING ASSY., R. INNER	1	(TOP MOUNT)
FOP-8-2 5	HZW5-24811-U01	HANDLE, REMOTE CONTROL	2	
FOP-8-2 6	HZW5-24812-U01	COVER, L. GRIP	1	
FOP-8-2 7	HZW5-24813-U01	GRIP, REMOTE CONTROL HANDLE	2	
FOP-8-2 8	HZW5-24813-U21	COVER, DUAL GRIP	1	
FOP-8-2 9	HZW5-24814-U01	CAP, GRIP	2	
FOP-8-2 10	HZW5-24816-U01	BUTTON, THROTTLE	2	
FOP-8-2 11	HZW5-24817-U01	PLATE, HANDLE	2	
FOP-8-2 12	HZW5-24818-U01	PLATE, CABLE CLAMP	1	
FOP-8-2 13	HZW5-24819-U01	BRACKET, REMOTE CONTROL	2	HOUSING
FOP-8-2 14	HZW5-24820-U21	HOUSING COMP., DUAL REMOTE	1	CONTROL BOX
FOP-8-2	HZZ3-24820-R21	HOUSING COMP., DUAL REMOTE	1	CONTROL BOX
FOP-8-2 15	HZW5-24825-U01	HOUSING, LEAD	2	
FOP-8-2 16	HZW5-24826-U01	PLATE, DWELL	2	
FOP-8-2 17	HZW5-24831-U01	TERMINAL, CABLE	4	
FOP-8-2 18	HZW5-24832-U01	SPACER, CABLE CLAMP	2	
FOP-8-2 19	HZW5-24834-U21	PACKING, DUAL	1	
FOP-8-2 20	HZW7-32530-U00	SUB HARNESS ASSY., POWER	1	TRIM-TILT(A)
FOP-8-2 21	HZW7-32530-U10	SUB HARNESS ASSY., POWER	1	TRIM-TILT(B)
FOP-8-2 22	HZW5-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	(A)
FOP-8-2 23	HZW5-35370-U12	SWITCH ASSY., POWER TRIM-TILT	1	(B)
FOP-8-2 24	HZZ3-87703-R01	MARK, REMOTE CONTROL(DUAL)	1	
FOP-8-2 25	HZW5-90101-U00	SCREW, PAN, 5X16	3	
FOP-8-2 26	HZW5-90102-U00	SCREW, PAN, 5X10	2	
FOP-8-2 27	HZW5-90103-U01	SCREW, PAN, 5X20	4	
FOP-8-2 28	HZW5-90104-U00	SCREW, PAN, 5X18	4	






Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
FOP-8-4 1	HZZ3-06240-R40	BOX KIT, REMOTE CONTROL	1	(FLUSH MOUNT)(R.)
FOP-8-4 2	HZW7-24810-U01	HOUSING ASSY., R. INNER	1	(FLUSH MOUNT)
FOP-8-4 3	HZW7-24811-U01	HANDLE, REMOTE CONTROL	1	
FOP-8-4 4	HZW7-24812-U01	COVER, GRIP	1	
FOP-8-4 5	HZW7-24813-U01	ARM, NEUTRAL LOCK	1	
FOP-8-4 6	HZW7-24814-U01	COVER, LOCK ARM	1	
FOP-8-4 7	HZW7-24815-U01	SPRING, NEUTRAL LOCK ARM	1	
FOP-8-4 8	HZW5-24816-U01	BUTTON, THROTTLE	1	
FOP-8-4 9	HZW7-24817-U01	SHAFT, THROTTLE BUTTON	1	
FOP-8-4 10	HZW5-24826-U01	PLATE, DWELL	1	
FOP-8-4 11	HZW7-24830-U01	COVER ASSY.	1	
FOP-8-4	HZZ3-24830-R41	COVER ASSY.	1	
FOP-8-4 12	HZW5-24831-U01	TERMINAL, CABLE	2	
FOP-8-4 13	HZW5-24832-U01	SPACER, CABLE CLAMP	1	
FOP-8-4 14	HZW7-24832-U01	HOLDER, NEUTRAL LOCK	1	
FOP-8-4 15	HZW7-24833-U01	BASE	1	
FOP-8-4 16	HZW7-32530-U20	SUB HARNESS ASSY., POWER	1	TRIM-TILT(C)
FOP-8-4 17	HZW7-35370-U02	SWITCH ASSY., POWER TRIM-TILT	1	(C)
FOP-8-4 18	HZW7-87701-U01	MARK, HANDLE FLUSH MOUNT	1	
FOP-8-4	HZZ3-87701-R40	MARK, HANDLE FLUSH MOUNT	1	
FOP-8-4 19	HZW7-87703-U00	MARK, FLUSH MOUNT	1	
FOP-8-4 20	HZW5-90101-U00	SCREW, PAN, 5X16	1	
FOP-8-4 21	HZW7-90101-U01	SCREW, TRUSS, 4X12	1	
FOP-8-4 22	HZW7-90102-U01	SCREW, PAN, 5X30	4	
FOP-8-4 23	HZW7-90103-U01	SCREW, PAN, 6X35	3	
FOP-8-4 24	HZW7-90104-U01	SCREW, TAPPING, 6X30	3	
FOP-8-4 25	HZW7-90301-U01	NUT, HEX., 6MM	3	
FOP-8-4 26	HZW5-90501-U00	WASHER, LOCK, 5MM	4	
FOP-8-4 27	HZW7-90502-U00	WASHER, PLAIN, 6MM	3	








Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
FOP-8-6 1	HZZ3-06240-R30	BOX ASSY., REMOTE CONTROL	1	
FOP-8-6 2	HZV5-24811-010	HANDLE, REMOTE CONTROL	1	
FOP-8-6 3	HZV5-24812-000	LEVER, HANDLE LOCK	1	
FOP-8-6 4	HZV5-24813-000	GRIP, REMOTE CONTROL HANDLE	1	
FOP-8-6 5	HZV5-24814-010	CAP, HANDLE	1	
FOP-8-6 6	HZV5-24815-010	BLOCK, NEUTRAL LOCK	1	
FOP-8-6 7	HZV5-24816-000	SPRING, REMOTE CONTROL HANDLE	1	
FOP-8-6 8	HZV5-24817-000	PLATE, LEVER SETTING	1	
FOP-8-6 9	HZV5-24818-003	CLAMP, HARNESS	1	
FOP-8-6 10	HZV5-24820-010	HOUSING COMP., REMOTE CONTROL	1	BOX(A)LA,XA
FOP-8-6 11	HZV5-24830-010	HOUSING COMP., REMOTE CONTROL	1	BOX(B)LA,XA
FOP-8-6 12	HZV5-24836-000	HOUSING, REMOTE CONTROL BOX(C)	1	
FOP-8-6 13	HZV5-24841-000	WHEEL, CONTROL	1	
FOP-8-6 14	HZV5-24845-000	ARM COMP., SHIFT LINK	1	
FOP-8-6 15	HZV5-24850-000	PLATE COMP., SLIDING	1	
FOP-8-6 16	HZV5-24854-000	COLLAR, SLIDING PLATE	1	
FOP-8-6 17	HZV5-24855-000	PIVOT, SHIFT	2	
FOP-8-6 18	HZV5-24860-000	ARM COMP., LINK JOINT	1	
FOP-8-6 19	HZV5-24865-000	BRACKET, LINK JOINT	1	
FOP-8-6 20	HZV5-24875-000	WHEEL, ACCELERATOR	1	
FOP-8-6 21	HZV5-24876-000	SPRING, ACCELERATOR WHEEL	1	
FOP-8-6 22	HZV5-24878-000	LEVER, IDLE	1	
FOP-8-6 23	HZV5-24881-000	PLATE, SPRING SETTING	2	
FOP-8-6 24	HZV5-24883-000	SPRING, SHIFT CLICK	1	
FOP-8-6 25	HZV5-24884-000	SPRING, CHOKE RETURN	1	
FOP-8-6 26	HZV5-24885-000	SPACER, REMOTE CONTROL BOX	1	
FOP-8-6 27	HZV5-24887-000	SPACER, CLICK SPRING	1	
FOP-8-6 28	HZV5-24891-000	BLOCK, THROTTLE FRICTION	1	
FOP-8-6 29	HZV5-24892-000	BOLT, FRICTION	1	




Ref.No.	Part No.	Description	Q'ty	Remarks
			BFT115A	
FOP-8-6 30	HZV5-24894-000	SPACER, NEUTRAL SWITCH	1	
FOP-8-6 31	HZV5-24895-000	CLAMP, POWER TILT CORD	1	
FOP-8-6 32	HZV5-24897-000	PIPE, HARNESS GUIDE	1	
FOP-8-6 33	HZV5-24898-000	SPACER, CABLE CLAMP	1	
FOP-8-6 34	HZZ5-32530-000	CABLE ASSY., REMOTE CONTROL(B)	1	
FOP-8-6 35	HZV5-32823-003	PLUG, INNER CONNECTOR	7	
FOP-8-6 36	HZV5-32824-003	PLUG, OUTER CONNECTOR	1	
FOP-8-6 37	H952-32901-770	TIE, CABLE(NATURAL)(2.4X92)	1	
FOP-8-6 38	HZZ3-35100-R11	SWITCH ASSY., COMBINATION	1	
FOP-8-6 39	HZV5-35370-823	SWITCH ASSY., POWER TRIM-TILT	1	
FOP-8-6 40	HMG9-35701-950	BAND(BLACK 3.5X140)	1	
FOP-8-6 41	HZV5-36180-033	SWITCH ASSY., EMERGENCY STOP	1	
FOP-8-6 42	HZV4-36182-651	CORD COMP., EMERGENCY	1	
FOP-8-6 43	HZV4-36187-652	CLIP, EMERGENCY LOCK	1	
FOP-8-6 44	HZZ5-37210-013	LAMP ASSY., INDICATION	1	
FOP-8-6 45	H341-38403-672	PLATE, WINKER BUZZER	1	
FOP-8-6 46	HZV5-38410-003	BUZZER COMP., WARNING	1	
FOP-8-6 47	HZZ3-87701-R00	PLATE, REMOTE CONTROL	1	LA,XA
FOP-8-6 48	HZW9-87702-800	MARK, FAST IDLE	1	
FOP-8-6 49	HZW9-90008-000	BOLT, FLANGE, 8X35	1	
FOP-8-6 50	HMM4-90105-000	SCREW, PAN, 6X10	1	
FOP-8-6 51	HZW4-90108-000	SCREW, FLAT, 5X12	2	
FOP-8-6 52	HZV5-90125-000	SCREW, 6X95	3	
FOP-8-6 53	H921-90302-000	NUT, HEX., 16MM	1	
FOP-8-6 54	HZV4-90304-000	NUT, HEX., 6MM	3	
FOP-8-6 55	HZW4-90401-000	WASHER, PLAIN, 4MM	2	
FOP-8-6 56	HZW4-90402-000	WASHER, PLAIN, 5MM	2	
FOP-8-6 57	HZV4-90502-000	WASHER, PLAIN, 5MM	1	
FOP-8-6 58	H921-90504-010	WASHER, PLAIN, 6MM	5	











FOP-10-1 WATER PUMP IMPELLER KIT (2)









INDEX

<A>	
ARM ASSY., EX. ROCKER.....	E-9-14
ARM ASSY., ROCKER	E-9-13
ARM COMP., CAM CHAIN TENSIONER..	E-9-10
ARM COMP., CLICK	F-2-8
ARM COMP., LINK JOINT	FOP-8-6-18
ARM COMP., SHIFT LINK	FOP-8-6-14
ARM, NEUTRAL LOCK	FOP-8-4-5
ARM, SHIFT.....	F-2-13
ARM, THROTTLE	F-2-6
ARMATURE COMP.....	F-11-6
	
BAG, TOOL, 230MM.....	F-13-12
BALL, STEEL	E-21-6
BALL, STEEL, #7(7/32).....	F-5-29
BALL, STEEL, #7(7/32)	F-5-1-31
BALL, STEEL, #9(9/32).....	F-5-30
BALL, STEEL, #9(9/32)	F-5-1-32
BAND	E-18-10-43
BAND(BLACK 3.5X140).....	F-8-10-1
BAND(BLACK 3.5X140).....	FOP-8-6-40
BAND, AIR FLOW	E-15-4
BAND, HARNESS	E-14-30
BAND, HARNESS OFFSET(10)	F-7-30-2
BAND, UNDER CASE GROMMET	F-8-10-4
BAND, WIRE	F-3-2
BAND, WIRE	FOP-13-3
BAND, WIRE HARNESS(NATURAL)	FOP-6-1-17
BASE	FOP-8-4-15
BASE, INJECTOR	E-14-10
BEARING A, CONNECTING ROD.....	E-7-7
BEARING A, MAIN LOWER(BLUE)	E-7-11
BEARING A, MAIN UPPER(BLUE)	E-7-9
BEARING B, CONNECTING ROD	E-7-
BEARING B, MAIN LOWER(BLACK)	E-7-
BEARING B, MAIN UPPER(BLACK)	E-7-
BEARING C, CONNECTING ROD.....	E-7-
BEARING C, MAIN LOWER(BROWN)	E-7-
BEARING C, MAIN UPPER(BROWN)	E-7-
BEARING D, CONNECTING ROD	E-7-
BEARING D, MAIN LOWER(GREEN)	E-7-
BEARING D, MAIN UPPER(GREEN)	E-7-
BEARING E, CONNECTING ROD	E-7-
BEARING E, MAIN LOWER(YELLOW)	E-7-
BEARING E, MAIN UPPER(YELLOW)	E-7-
BEARING F, CONNECTING ROD	E-7-
BEARING F, MAIN LOWER(PINK)	E-7-
BEARING F, MAIN UPPER(PINK)	E-7-
BEARING G, CONNECTING ROD(RED)	E-7-
BEARING, FR	E-19-4
BEARING, NEEDLE(25X32X26)	F-5-24
BEARING, NEEDLE(25X32X26)	F-5-1-26
BEARING, NEEDLE	F-4-26
BEARING, NEEDLE, 20X28X13	F-2-42
BEARING, NEEDLE, 30X37X26	F-5-20
BEARING, NEEDLE, 30X37X26	F-5-1-22
BEARING, RADIAL BALL, 50X90X20	F-5-23
BEARING, RADIAL BALL, 50X90X20	F-5-1-25
BEARING, RR	E-19-3
BEARING, TAPER ROLLER	F-4-27
BEARING, TAPER, 50X90X28	F-5-22
BEARING, TAPER, 50X90X28	F-5-1-24
BEARING, THRUST(F)	F-5-21
BEARING, THRUST(F)	F-5-1-23
BELT, A.C. GENERATOR(4PK810)	E-13-3
BLOCK ASSY., CYLINDER	E-3-6
BLOCK, NEUTRAL LOCK	FOP-8-6-6
BLOCK, THROTTLE FRICTION	FOP-8-6-28
BODY COMP., CHAMBER	E-18-10-5
BODY COMP., OIL JET	E-3-9
BODY, TROLLING CONTROL SWITCH..	FOP-12-3
BOLT	E-19-14
BOLT A, HEAD COVER	E-9-20-16
BOLT A, THROUGH.....	E-21-18
BOLT COMP., OIL JET	E-3-10
BOLT KIT, SIDE REMOTE CONTROL	FOP-9-1
BOLT, 1/4-28UNF	F-10-26
BOLT, 3/8-24UNF	F-10-27
BOLT, CHAIN GUIDE	E-10-9
BOLT, CONNECTING ROD	E-7-5
BOLT, COVER LOCK	F-8-8
BOLT, DRAIN PLUG	E-6-15
BOLT, DRAIN PLUG	F-3-14
BOLT, FLANGE, 10X105	E-10-18
BOLT, FLANGE, 10X110	E-6-23
BOLT, FLANGE, 10X25.....	F-10-32
BOLT, FLANGE, 10X32.....	E-9-29
BOLT, FLANGE, 10X40.....	E-6-9
BOLT, FLANGE, 10X40.....	F-3-20-8
BOLT, FLANGE, 10X40.....	F-5-12
BOLT, FLANGE, 10X40.....	F-5-1-13
BOLT, FLANGE, 10X43	E-9-10-19
BOLT, FLANGE, 10X45	E-4-11
BOLT, FLANGE, 10X70	E-3-29
BOLT, FLANGE, 10X70	E-9-10-21
BOLT, FLANGE, 10X75	E-4-8
BOLT, FLANGE, 10X80	E-6-10
BOLT, FLANGE, 10X80	E-19-28
BOLT, FLANGE, 10X90	E-21-21
BOLT, FLANGE, 12MM	E-5-15
BOLT, FLANGE, 12X47	E-9-28
BOLT, FLANGE, 12X83	E-3-20
BOLT, FLANGE, 6X10	E-14-22
BOLT, FLANGE, 6X12	E-6-14
BOLT, FLANGE, 6X12	E-15-19
BOLT, FLANGE, 6X12	F-2-30
BOLT, FLANGE, 6X12	F-3-20-9
BOLT, FLANGE, 6X12	F-7-3
BOLT, FLANGE, 6X12	F-7-10-10
BOLT, FLANGE, 6X12	F-7-20-7
BOLT, FLANGE, 6X12	F-9-28
BOLT, FLANGE, 6X14	E-4-9
BOLT, FLANGE, 6X14	E-9-10-17
BOLT, FLANGE, 6X14	E-9-20-20
BOLT, FLANGE, 6X14	E-10-15
BOLT, FLANGE, 6X14	E-14-21
BOLT, FLANGE, 6X14	E-18-1-19
BOLT, FLANGE, 6X14	F-2-28
BOLT, FLANGE, 6X14(CT200)	E-3-22
BOLT, FLANGE, 6X14(CT200)	E-9-10-14
BOLT, FLANGE, 6X14(CT200)	F-7-10-9
BOLT, FLANGE, 6X16	E-9-10-16
BOLT, FLANGE, 6X16	E-9-20-18
BOLT, FLANGE, 6X16	E-18-10-47
BOLT, FLANGE, 6X16	E-19-24
BOLT, FLANGE, 6X16	F-2-27
BOLT, FLANGE, 6X16	F-9-25
BOLT, FLANGE, 6X18	E-6-22
BOLT, FLANGE, 6X18	F-2-29
BOLT, FLANGE, 6X20	E-5-18
BOLT, FLANGE, 6X20	E-9-34
BOLT, FLANGE, 6X20	E-9-20-19
BOLT, FLANGE, 6X20	E-9-20-27
BOLT, FLANGE, 6X20	E-20-10-5
BOLT, FLANGE, 6X20	F-2-31
BOLT, FLANGE, 6X20	F-4-18
BOLT, FLANGE, 6X20	F-7-20-8
BOLT, FLANGE, 6X20	F-10-28
BOLT, FLANGE, 6X22	E-4-10
BOLT, FLANGE, 6X22	F-7-10-11
BOLT, FLANGE, 6X22	F-8-10-23
BOLT, FLANGE, 6X22	F-9-26
BOLT, FLANGE, 6X23	F-10-24
BOLT, FLANGE, 6X25	E-3-23
BOLT, FLANGE, 6X25	E-5-17
BOLT, FLANGE, 6X25	E-10-19
BOLT, FLANGE, 6X25	E-18-21
BOLT, FLANGE, 6X25	E-18-10-46
BOLT, FLANGE, 6X25	F-9-24
BOLT, FLANGE, 6X27	E-18-19
BOLT, FLANGE, 6X28	E-9-10-15
BOLT, FLANGE, 6X30	E-9-35
BOLT, FLANGE, 6X32	E-9-20-28
BOLT, FLANGE, 6X32	E-10-20
BOLT, FLANGE, 6X38	E-9-10-20
BOLT, FLANGE, 6X52	E-9-20-17
BOLT, FLANGE, 8X100	E-6-13
BOLT, FLANGE, 8X110	E-9-20-30
BOLT, FLANGE, 8X18	F-7-10-12
BOLT, FLANGE, 8X20	E-3-24
BOLT, FLANGE, 8X20	E-19-25
BOLT, FLANGE, 8X25	E-14-27
BOLT, FLANGE, 8X28	E-19-26
BOLT, FLANGE, 8X30	E-18-10-48
BOLT, FLANGE, 8X30	F-9-23
BOLT, FLANGE, 8X32	E-5-27
BOLT, FLANGE, 8X35	E-3-25
BOLT, FLANGE, 8X35	E-14-25
BOLT, FLANGE, 8X35	F-10-56
BOLT, FLANGE, 8X35	FOP-8-6-49
BOLT, FLANGE, 8X45	E-14-26
BOLT, FLANGE, 8X50	E-3-28
BOLT, FLANGE, 8X50	E-10-16
BOLT, FLANGE, 8X55	E-3-19
BOLT, FLANGE, 8X55	E-10-10
BOLT, FLANGE, 8X60	F-8-10-22
BOLT, FLANGE, 8X75	E-15-20
BOLT, FLANGE, 8X75	E-10-17
BOLT, FLANGE, 8X90	E-9-20-29
BOLT, FRICTION	FOP-8-6-29
BOLT, FUEL PIPE	E-14-1
BOLT, HEX	F-11-32
BOLT, HEX, 10X235	F-10-29
BOLT, HEX, 12X119	F-10-31
BOLT, HEX, 12X130	E-6-12
BOLT, HEX, 12X130	F-10-
BOLT, HEX, 12X225	F-3-20-11
BOLT, HEX, 12X70	E-6-11
BOLT, HEX, 4X20	FOP-12-7
BOLT, HEX, 5X16	FOP-8-6-68
BOLT, HEX, 6X12	F-4-17
BOLT, HEX, 6X14	F-10-30
BOLT, HEX, 6X50	F-3-20
BOLT, OIL CHECK	F-3-12
BOLT, RECESSED	F-11-29
BOLT, SEALING, 14MM	E-9-3
BOLT, SEALING, 18MM	E-5-7
BOLT, SEALING, 20MM	E-3-2
BOLT, SEALING, 20MM	E-5-1
BOLT, SEALING, 20MM	E-9-20-21
BOLT, SEALING, 22MM	E-3-26
BOLT, SEALING, 22MM	E-5-19
BOLT, SEALING, 28MM	E-3-3
BOLT, SEALING, 6MM	E-18-10-44
BOLT, SOCKET(A)	F-11-30
BOLT, SOCKET(B)	F-11-31
BOLT, SOCKET, 6X16	F-8-9
BOLT, SOCKET, 6X20	F-8-7
BOLT, SOCKET, 6X25	E-1-5
BOLT, SOCKET, 6X25	E-20-3
BOLT, SPECIAL ADJUSTER	E-19-23
BOLT, SPECIAL, 6X17	F-8-20-14
BOLT, SPECIAL, 6X220	FOP-9-2
BOLT, SPECIAL, 6X31	E-9-10-18
BOLT, SPECIAL, 8MM	E-5-14
BOLT, STUD	E-19-8
BOLT, STUD, 2, 8X25	E-14-23
BOLT, STUD, 10X55	F-9-27
BOLT, STUD, 12X150	F-10-25
BOLT, STUD, 8X32	E-14-24
BOLT, TENSIONER	E-19-27
BOLT, TENSIONER PIVOT	E-9-27
BOLT-WASHER	E-19-13
BOLT-WASHER, 10X30	E-10-11
BOLT-WASHER, 10X32	F-3-13
BOLT-WASHER, 10X40	F-3-15
BOLT-WASHER, 11X155	E-9-20-15
BOLT-WASHER, 11X95	E-3-21
BOLT-WASHER, 16X49	E-7-15
BOLT-WASHER, 5X30	E-15-18
BOLT-WASHER, 6X25	E-13-5
BOLT-WASHER, 6X25	E-15-17
BOLT-WASHER, 6X27(CT200)	E-20-10-4
BOLT-WASHER, 8X10	E-3-11
BOLT-WASHER, 8X30	F-3-20-10
BOLT-WASHER, 8X30	F-8-10-24
BOLT-WASHER, 8X35	E-14-20

BOLT-WASHER, 8X35	E-18-20	CAP, OIL(YELLOW).....	E-3-12	CLIP, WIRE HARNESS, 25MM	E-18-1-22
BOLT-WASHER, 8X35	E-18-10-45	CAP, REGULATOR.....	E-14-6	CLUTCH COMP., OVERRUNNING.....	E-21-2
BOLT-WASHER, 8X40	F-4-19	CAP, SWITCH.....	FOP-8-8	CLUTCH COMP., OVERRUNNING.....	E-21
BOLT-WASHER, 8X40	FOP-10-1-8	CAP, WATER JOINT	F-8-20-1	COIL COMP., PLUG HOLE.....	E-20-1
BOSS, FLYWHEEL	E-5-13	CARTRIDGE, OIL FILTER	E-5-10	COLLAR.....	E-18-10-23
BOX ASSY., JUNCTION	F-7-20-1	CASE ASSY., BALANCER HOLDER	E-10-1	COLLAR.....	E-18-10-26
BOX ASSY., REMOTE CONTROL	FOP-8-6-1	CASE ASSY., CHAIN	E-9-10-1	COLLAR, 8.5X14.5.....	E-14-35
BOX KIT, REMOTE CONTROL	FOP-8-1	CASE ASSY., ELECTRONIC PARTS.....	E-20-10-1	COLLAR, 8.5X14.5.....	E-18-28
BOX KIT, REMOTE CONTROL.....	FOP-8-2-1	CASE ASSY., GEAR(L).....	F-3-10-1	COLLAR, 8.5X14.5.....	E-18-10-52
BOX KIT, REMOTE CONTROL.....	FOP-8-4-1	CASE ASSY., GEAR(XL).....	F-3-10-	COLLAR, C.D.I. UNIT CASE	E-13-8
BRACKET A, CABLE.....	F-2-21	CASE ASSY., GEAR(XL).....	F-3-10-	COLLAR, C.D.I. UNIT CASE	E-15-22
BRACKET A, COUPLER.....	F-7-10-1	CASE COMP., MOUNT	F-9-21	COLLAR, C.D.I. UNIT CASE	E-20-10-6
BRACKET A, HARNESS CLIP	E-14-15	CASE COMP., PUMP	E-18-10-27	COLLAR, C.D.I. UNIT CASE	F-7-10-17
BRACKET ASSY.....	F-11-5	CASE COMP., SILENCER	E-15-5	COLLAR, CAMSHAFT	E-9-33
BRACKET B, CABLE.....	F-7-10-6	CASE, EXTENSION	F-3-20-	COLLAR, DISTANCE	F-4-34
BRACKET B, HARNESS CLIP	E-9-10-9	CASE, EXTENSION(L)	F-3-20-1	COLLAR, DISTANCE	FOP-10-1-11
BRACKET C, HARNESS CLIP	E-9-10-10	CASE, GEAR	F-3-3	COLLAR, DISTANCE(A)	FOP-9-3
BRACKET COMP., A.C. GENERATOR	E-19-17	CASE, OIL.....	E-6-1	COLLAR, DISTANCE(B)	FOP-9-4
BRACKET D, HARNESS CLIP	E-3-15	CASE, SWIVEL	F-10-9	COLLAR, DISTANCE, 6.5X11X7.5.....	F-9-4
BRACKET E, HARNESS CLIP	E-15-9	CHAIN(176L)(BORG WARNER)	E-9-7	COLLAR, DISTANCE, 6.5X9X3.....	F-8-12
BRACKET F, CLIP	E-9-20-12	CHAIN(62L).....	E-10-5	COLLAR, DISTANCE, 6.5X9X5.....	F-8-20-21
BRACKET, BUZZER	FOP-6-1-14	CIRCLIP, EXTERNAL, 14MM	F-5-28	COLLAR, DISTANCE, 6X10X43.5	FOP-8-6-67
BRACKET, CLIP B	E-3-14	CIRCLIP, EXTERNAL, 14MM	F-5-1-30	COLLAR, LINK JOINT	FOP-8-6-66
BRACKET, FR.	E-21-10	CIRCLIP, EXTERNAL, 39MM	F-10-48	COLLAR, LOWER CYLINDER	F-10-23
BRACKET, FR. UNDER COVER	F-8-10-5	CIRCLIP, INTERNAL	F-11-34	COLLAR, LOWER MOUNTING	F-3-20-6
BRACKET, HOOK	F-8-3	CIRCLIP, INTERNAL, 40	F-3-20-16	COLLAR, ORIFICE	F-11-46
BRACKET, L. SIDE COVER	F-8-10-7	CLAMP	F-6-5	COLLAR, SLIDING PLATE	FOP-8-6-16
BRACKET, L. STERN	F-10-13	CLAMP	F-6-8	COLLAR, STEERING ROD	F-10-53
BRACKET, LINK JOINT	FOP-8-6-19	CLAMP	FOP-1-2	CONTROL UNIT, ELECTRONIC	E-20-10-3
BRACKET, NEUTRAL SWITCH	F-2-23	CLAMP B, WATER TUBE	E-4-12	CORD ASSY., INDICATOR(20FT).....	FOP-6-4
BRACKET, R. SIDE COVER	F-8-10-6	CLAMP, 18.5MM	E-9-10-28	CORD ASSY., INDICATOR(25FT).....	FOP-6-
BRACKET, R. STERN	F-10-12	CLAMP, 18.5MM	E-13-7	CORD ASSY., INDICATOR(30FT).....	FOP-6-
BRACKET, RELAY	E-3-18	CLAMP, ENGINE SUB CORD	F-7-30-3	CORD COMP., EMERGENCY.....	FOP-6-1-9
BRACKET, REMOTE CONTROL	FOP-8-12	CLAMP, FUEL HOSE	E-15-23	CORD COMP., EMERGENCY.....	FOP-8-6-42
BRACKET, REMOTE CONTROL	FOP-8-2-13	CLAMP, HARNESS.....	FOP-8-6-9	COTTER, VALVE(FUJI VALVE)	E-9-26
BRACKET, RR.	E-21-11	CLAMP, HOSE	E-18-12	COVER ASSY.....	FOP-8-4-11
BRACKET, SENSOR CORD	E-15-10	CLAMP, HOSE	F-7-30-1	COVER ASSY.....	FOP-8-4
BRACKET, SHIFT LINK	F-2-19	CLAMP, PIPE.....	E-18-13	COVER ASSY., ENGINE	F-8-1
BRACKET, TILTING	F-10-17	CLAMP, POWER TILT CORD	FOP-8-6-31	COVER ASSY., OIL PATH	E-9-20-8
BRACKET, TROLLING CONTROL	FOP-12-4	CLAMP, PURGE HOSE	E-18-30	COVER B, TERMINAL	F-7-10-5
BRACKET, WATER TUBE CLAMP.....	E-4-5	CLAMP, TUBE(8.0)	E-18-10-50	COVER B, TERMINAL(L)	F-7-2
BREAKER ASSY.....	F-11-1	CLAMP, TUBE(D10.5)	E-4-10-8	COVER B, TERMINAL(L)	F-7-10-4
BRUSH ASSY.....	F-11-2	CLAMP, TUBE(D10.5)	F-9-29	COVER COMP	E-18-10-6
BRUSH SET	E-21-7	CLAMP, TUBE(D10.5)	F-9-31	COVER COMP., CYLINDER HEAD	E-1-1
BRUSH SET	E-21	CLAMP, TUBE(D10.7)	E-18-22	COVER COMP., FUSE	F-7-20-2
BUFFER, PLATE	E-18-1-4	CLAMP, TUBE(D17)	E-15-21	COVER COMP., PLUG HOLE COIL	E-1-4
BUSH A, COVER LOCK	F-2-25	CLAMP, TUBE(D25.0)	E-4-10-10	COVER, BEARING	E-19-5
BUSH A, COVER LOCK	F-8-10-11	CLAMP, TUBE(D32.5)	E-4-10-9	COVER, CHAIN CASE	E-9-10-2
BUSH A, COVER LOCK	F-8-10-12	CLAMP, WATER TUBE	E-4-10-11	COVER, DRAIN PLUG	F-8-20-8
BUSH B, COVER LOCK	F-8-10-13	CLIP B1, TUBE	F-9-32	COVER, DUAL GRIP	FOP-8-2-8
BUSH COMP., VERTICAL SHAFT	F-3-20-2	CLIP(10.7MM)	F-8-20-18	COVER, EX. MANIFOLD	E-4-3
BUSH, BLADE BRAKE	F-2-26	CLIP(14MM)	FOP-13-12	COVER, FLUSH VALVE	F-9-14
BUSH, INSULATION	E-19-20	CLIP, BRAKE PIPE(A)	F-2-24	COVER, FR. SEPARATE	F-8-20-6
BUSH, LOWER CYLINDER	F-11-25	CLIP, EMERGENCY LOCK	FOP-6-1-10	COVER, GEAR CASE	F-3-5
BUSH, MOTOR CODE	F-11-19	CLIP, EMERGENCY LOCK	FOP-8-6-43	COVER, GRIP	FOP-8-4-4
BUSH, MOTOR CODE	FOP-13-8	CLIP, FUEL HOSE	E-18-25	COVER, IMPELLER	F-4-5
BUSH, SWIVEL CASE	F-10-11	CLIP, FUEL TUBE, 14	E-14-31	COVER, IMPELLER	FOP-10-1-5
BUSH, SWIVEL CASE	F-11-10	CLIP, FUEL TUBE, 14	F-7-10-15	COVER, L. ENGINE UNDER	F-8-20-10
BUSH, TILT ARM	F-10-16	CLIP, HARNESS	E-18-27	COVER, L. GRIP	FOP-8-5
BUTTON, THROTTLE	FOP-8-9	CLIP, HARNESS BAND(BLACK)	E-3-40	COVER, LOCK ARM	FOP-8-4-6
BUTTON, THROTTLE	FOP-8-2-10	CLIP, HARNESS BAND(BLACK)	F-7-6	COVER, OIL PUMP	E-5-4
BUTTON, THROTTLE	FOP-8-4-8	CLIP, HARNESS BAND(BLACK)	F-7-10-16	COVER, PUMP(A)	E-18-10-29
BUZZER COMP., WARNING	FOP-6-1-13	CLIP, HARNESS BAND(NATURAL)	E-4-17	COVER, PUMP(B)	E-18-10-28
BUZZER COMP., WARNING	FOP-8-6-46	CLIP, INJECTOR	E-14-3	COVER, R. ENGINE UNDER	F-8-20-9
<C>		CLIP, MUDGUARD	F-8-20-19	COVER, RELIEF VALVE	F-9-18
CABLE ASSY., REMOTE CONTROL(B)	FOP-8-6-34	CLIP, PISTON PIN	E-7-4	COVER, STARTER TERMINAL	F-7-10-3
CABLE ASSY., STARTER	F-7-10-2	CLIP, SENSOR HOSE	E-18-18	COVER, THERMOSTAT	E-9-10-6
CABLE ASSY., SWITCH PANEL	FOP-6-9	CLIP, TUBE	E-18-1	COVER, WATER JACKET	E-18-10-12
CABLE ASSY., SWITCH PANEL	FOP-6-	CLIP, TUBE	E-18-1-1	CRANKCASE COMP	E-3-1
CABLE COMP. A, COVER LOCK	F-8-10-8	CLIP, TUBE	F-9-2	CRANKSHAFT COMP	E-7-8
CABLE COMP. B, COVER LOCK	F-8-10-9	CLIP, TUBE(B14.5)	E-18-23	CUP SET, WATER SEPARATOR	E-18-1-3
CABLE SET, PANEL INDICATOR	FOP-6-2	CLIP, TUBE(B14.5)	E-18-1-20	CUP, FUEL STRAINER	E-18-1-13
CABLE SET, PANEL INDICATOR	FOP-6-	CLIP, TUBE(B12)	E-18-24	<D>	
CABLE SET, PANEL INDICATOR	FOP-6-	CLIP, TUBE(B12)	E-18-1-21	DAMPER, HOOK	F-8-4
CAMSHAFT COMP., EX	E-9-4	CLIP, TUBE(B12)	F-9-30	DOWEL PIN, 10X12	E-7-17
CAMSHAFT COMP., IN	E-9-1	CLIP, TUBE(B8)	FOP-13-11	DOWEL PIN, 10X16	E-5-25
CAP COMP., OIL TANK	F-11-28	CLIP, TUBE(BLACK)(135MM)	E-18-29	DOWEL PIN, 10X16	E-6-20
CAP, BOLT, 8MM	E-3-27	CLIP, TUBE, 3.5	E-13-6	DOWEL PIN, 10X16	E-9-20-25
CAP, GRIP	FOP-8-7	CLIP, WIRE HARNESS	F-7-5	DOWEL PIN, 13X14	E-3-34
CAP, GRIP	FOP-8-2-9	CLIP, WIRE HARNESS	F-8-20-20	DOWEL PIN, 13X20	E-3-33
CAP, HANDLE	FOP-8-6-5	CLIP, WIRE HARNESS	F-10-49	DOWEL PIN, 14X20	E-5-26
CAP, L. SIDE COVER	F-8-10-21	CLIP, WIRE HARNESS(6.3MM)	FOP-8-6-65	DOWEL PIN, 14X20	E-6-21

DOWEL PIN, 14X20	E-9-20-26	GUIDE COMP, B, CAM CHAIN	E-9-12
DOWEL PIN, 18X13	E-10-12	GUIDE COMP., BALANCER SHAFT	E-10-7
DOWEL PIN, 18X22	E-3-32	GUIDE COMP., CAM CHAIN	E-9-11
DOWEL PIN, 4.2X10.3	E-9-32	GUIDE COMP., EX	F-9-5
DOWEL PIN, 6X10.....	E-6-19	GUIDE COMP., ROD	F-11-15
DOWEL PIN, 6X10.....	F-3-18	GUIDE COMP., ROD	F-11-16
DOWEL PIN, 6X10.....	F-3-20-17	GUIDE, ENGINE COVER AIR	F-8-6
DOWEL PIN, 6X10.....	F-4-25	GUIDE, EX. VALVE(OS)	E-9-20-3
DOWEL PIN, 8X10.....	E-10-13	GUIDE, IN. VALVE(OS)	E-9-20-2
DRIVER, SCREW(NO.2 + -)	F-13-1	<H>	
DUCT A, SILENCER	E-13-1	HANDLE, REMOTE CONTROL	FOP-8-4
DUCT B, SILENCER	E-13-2	HANDLE, REMOTE CONTROL	FOP-8-2-5
<E>		HANDLE, REMOTE CONTROL	FOP-8-4-3
END COVER, RR.....	E-19-19	HANDLE, REMOTE CONTROL	FOP-8-6-2
END, NIPPLE.....	F-3-10	HANGER B, ENGINE	E-19-1
END, NIPPLE.....	FOP-13-5	HANGER, ENGINE	E-3-5
E-RING, 10MM.....	F-4-35	HARNESS ASSY., MAIN WIRE	F-7-1
E-RING, 12MM.....	F-2-51	HARNESS ASSY., REMOTE CONTROL	FOP-11-2
E-RING, 15MM.....	F-11-47	HARNESS ASSY., SWITCH PANEL	FOP-6-1-4
E-RING, 3MM.....	FOP-8-6-77	HARNESS COMP.	E-18-10-42
E-RING, 4MM.....	F-2-49	HARNESS, TROLLING CONTROL	FOP-12-5
E-RING, 4MM.....	FOP-8-6-78	HEAD KIT, CYLINDER.....	E-9-20-1
E-RING, 6MM.....	F-2-50	HOLDER.....	E-18-10-11
E-RING, 6MM.....	F-8-10-29	HOLDER ASSY, BRUSH	E-19-2
E-RING, 6MM.....	FOP-8-36	HOLDER COMP., BRUSH.....	E-21-9
E-RING, 6MM.....	FOP-8-2-41	HOLDER COMP., BRUSH.....	E-21
E-RING, 6MM.....	FOP-8-4-28	HOLDER, BEARING.....	F-5-1-11
E-RING, 7MM.....	FOP-8-6-79	HOLDER, DRAIN TUBE.....	F-2-47
<F>		HOLDER, NEUTRAL LOCK	FOP-8-4-14
FILTER ASSY., SPOOL VALVE.....	E-9-20-7	HOLDER, OIL FILTER	E-5-16
FILTER ASSY., VTC.....	E-9-20-11	HOLDER, PROPELLER SHAFT	F-5-10
FILTER B.....	F-11-17	HOLDER, PROPELLER SHAFT	F-5-1-10
FILTER COMP., ELECTRONIC AIR	E-14-16	HOLDER, SEAL	F-2-20
FLANGE COMP., OIL FILTER.....	E-5-11	HOLDER, SHIFT ROD	F-4-11
FLOAT SET	E-18-10-2	HOLDER, UPPER MOUNTING	F-10-7
FLYWHEEL COMP.....	E-5-12	HOSE COMP., FUEL	E-18-6
FRAME COMP., MOUNTING	F-10-5	HOSE KIT, RIGGING	FOP-1-1
FUSE, BLOCK 100A(L TYPE).....	F-7-20-3	HOSE, PRESSURE REGULATOR.....	E-18-14
FUSE, MINI(10A).....	F-7-20-10	HOUSING ASSY, L. INNER	FOP-8-3
FUSE, MINI(15A).....	F-7-20-11	HOUSING ASSY, L. INNER	FOP-8-2-3
FUSE, MINI(30A).....	F-7-20-12	HOUSING ASSY, R. INNER	FOP-8-2-4
<G>		HOUSING COMP., DUAL REMOTE	FOP-8-2-14
GASKET A, INJECTOR BASE	E-14-11	HOUSING COMP., DUAL REMOTE	FOP-8-2
GASKET B, IMPELLER	F-4-6	HOUSING COMP., REMOTE CONTROL	FOP-8-13
GASKET B, IMPELLER	FOP-10-3	HOUSING COMP., REMOTE CONTROL	FOP-8
GASKET B, IMPELLER	FOP-10-1-6	HOUSING COMP., REMOTE CONTROL	FOP-8-6-10
GASKET COMP., CYLINDER HEAD	E-9-20-6	HOUSING COMP., REMOTE CONTROL	FOP-8-6-11
GASKET COMP., EX. MANIFOLD	E-4-4	HOUSING, IMPELLER	F-4-3
GASKET, EX. GUIDE	F-9-6	HOUSING, IMPELLER	FOP-10-1-3
GASKET, IDLE EX. PORT	F-9-8	HOUSING, LEAD	FOP-8-14
GASKET, MOUNT CASE	E-6-8	HOUSING, LEAD	FOP-8-2-15
GASKET, UPPER MOUNTING HOLDER ..	F-10-8	HOUSING, LOWER CENTER MOUNTING ..	F-3-20-7
GAUGE COMP., OIL LEVEL	E-6-5	HOUSING, LOWER MOUNTING	F-3-20-4
GEAR ASSY., PLANETARY	E-21-3	HOUSING, REMOTE CONTROL BOX(C) ..	FOP-8-6-12
GEAR ASSY., INTERNAL	E-21-15	HOUSING, WATER SEAL	F-4-15
GEAR ASSY., INTERNAL	E-21-23	<I>	
GEAR COMP., BEVEL(FORWARD 30T) ..	F-5-7	IMPELLER, PUMP	F-4-2
GEAR COMP., BEVEL(RVS. 30T) ..	F-5-1-8	IMPELLER, PUMP	FOP-10-2
GEAR, BEVEL(FORWARD 30T)	F-5-1-7	IMPELLER, PUMP	FOP-10-1-2
GEAR, BEVEL(RVS. 30T)	F-5-8	INJECTOR ASSY., FUEL	E-14-2
GEAR, PINION	F-4-16	INSULATOR	E-18-10-31
GENERATOR ASSY, A.C.....	E-19-15	INSULATOR COMP.	E-18-10-30
GRIP	F-13-2	<J>	
GRIP, REMOTE CONTROL HANDLE	FOP-8-6	JOINT A, BREather	FOP-13-2
GRIP, REMOTE CONTROL HANDLE	FOP-8-2-7	JOINT ASSY (INLET)	F-6-2
GRIP, REMOTE CONTROL HANDLE	FOP-8-6-4	JOINT ASSY (OUTLET)	F-6-3
GROMMET, ELECTRONIC PARTS CASE ..	E-20-10-2	JOINT SET	E-18-10-8
GROMMET, EXTENSION CASE	F-4-12	JOINT, DRIVE	F-11-14
GROMMET, GEAR CASE	F-3-4	JOINT, FOUR-WAY	E-4-10-6
GROMMET, POWER TILT SWITCH	F-8-20-4	JOINT, FUEL PIPE	E-14-8
GROMMET, RELAY	F-7-10-8	JOINT, FUEL PIPE	E-14-9
GROMMET, REMOTE CONTROL CABLE ..	F-8-10-2	JOINT, FUEL PIPE	E-18-10-38
GROMMET, SILENCER	E-15-6	JOINT, FUEL TUBE	E-4-10-2
GROMMET, SILENCER DUCT	E-15-7	JOINT, FUEL TUBE	E-18-1-18
GROMMET, TA SENSOR	E-15-14	JOINT, WATER HOSE	F-9-12
GROMMET, UNDER CASE	E-13-4	<K>	
GROMMET, UNDER CASE	E-15-15	KEY, 4.5X21.....	E-7-16
GROMMET, UNDER CASE(C)	F-8-10-3	KEY, WOODRUFF	F-4-24
GROMMET, UNDER COVER	F-8-20-5	KEY, WOODRUFF	FOP-10-4
GROMMET, VAPOR SEPARATOR	E-18-10-34	KEY, WOODRUFF	FOP-10-1-9
GROMMET, VAPOR SEPARATOR	E-18-10-35	KIT, CABLE(NMEA)(6FT)	FOP-11-1
GROMMET, WATER CHECK	F-8-20-13		
GROMMET, WATER TUBE	E-6-6		
		<L>	
		LABEL, FUSE	F-12-1
		LABEL, OIL CAUTION(E)	F-12-7
		LABEL, OIL CAUTION(EF)	F-12-
		LABEL, WARNING OPERATOR	F-12-8
		LABEL, WARNING OPERATOR(EC)	F-12-
		LAMP ASSY., INDICATION	FOP-8-6-44
		LAMP ASSY., INDICATION(4-LED)	FOP-6-1-11
		LEVER SET	E-21-17
		LEVER, COVER LOCK	F-8-10-10
		LEVER, HANDLE LOCK	FOP-8-6-3
		LEVER, IDLE	FOP-8-6-22
		LINE, FUEL	E-14-4
		LINER, PUMP	F-4-4
		LINER, PUMP	FOP-10-1-4
		LINER, SWIVEL CASE	F-10-10
		LINK, THROTTLE	F-2-3
		LINKAGE, PIVOT	F-2-1
		LOCK COMP., FR.	F-8-10-19
		LOCK COMP., SIDE	F-8-10-20
		LOW PERMEATION HOSE L=1600	F-6-7
		LOW PERMEATION HOSE L=700	F-6-6
		<M>	
		MANIFOLD COMP, EX	E-4-2
		MANIFOLD COMP., INLET	E-14-14
		MARK, FAST IDLE	FOP-8-6-48
		MARK, FLUSH MOUNT	FOP-8-4-19
		MARK, FR. EMBLEM(115)	F-12-4
		MARK, HANDLE FLUSH MOUNT	FOP-8-4-18
		MARK, HANDLE FLUSH MOUNT	FOP-8-4
		MARK, REMOTE CONTROL(DUAL)	FOP-8-2-24
		MARK, REMOTE CONTROL(SINGLE)	FOP-8-21
		MARK, RR.(115)	F-12-2
		MARK, SIDE STRIPE	F-12-3
		MARK, SIDE STRIPE	F-12-10
		METAL COMP., ANODE	F-3-9
		METAL KIT, ANODE	F-10-1
		METAL, ANODE	E-4-1
		METAL, BALANCER SHAFT(DAIDO)	E-10-8
		METER LEAD WIRE	FOP-2-6
		MOTOR ASSY., POWER TILT	F-11-4
		MOTOR ASSY., STARTER	E-21-1
		MOUNT COMP., UPPER RUBBER	F-10-6
		<N>	
		NIPPLE, GREASE	F-10-50
		NIPPLE, SENSOR	F-3-11
		NUT, ADJUSTER ROD	F-10-36
		NUT, CASTLE, 18MM	F-5-13
		NUT, CASTLE, 18MM	F-5-1-14
		NUT, CLIP	F-8-20-16
		NUT, FLANGE CAP, 10MM	E-3-30
		NUT, FLANGE CAP, 6MM	E-1-6
		NUT, FLANGE, 10MM	F-10-37
		NUT, FLANGE, 12MM	F-3-20-13
		NUT, FLANGE, 12MM	F-10-33
		NUT, FLANGE, 5MM	FOP-6-1-2
		NUT, FLANGE, 6MM	E-14-29
		NUT, FLANGE, 8MM	E-14-28
		NUT, FLANGE, 8MM	E-19-29
		NUT, HEX, 12MM	F-10-54
		NUT, HEX, 16MM	F-8-20-17
		NUT, HEX, 16MM	FOP-6-1-16
		NUT, HEX, 16MM	FOP-8-6-53
		NUT, HEX, 18MM	F-4-21
		NUT, HEX, 20MM	F-2-32
		NUT, HEX, 4MM	FOP-12-8
		NUT, HEX, 5MM	F-2-48
		NUT, HEX, 5MM	FOP-8-29
		NUT, HEX, 5MM	FOP-8-35
		NUT, HEX, 5MM	FOP-8-2-33
		NUT, HEX, 5MM	FOP-8-2-34
		NUT, HEX, 5MM	FOP-8-2-40
		NUT, HEX, 5MM	FOP-8-6-76
		NUT, HEX, 6MM	E-19-31
		NUT, HEX, 6MM	F-8-14
		NUT, HEX, 6MM	FOP-8-4-25
		NUT, HEX, 6MM	FOP-8-6-54
		NUT, HEX, 6MM	FOP-8-6-75
		NUT, HEX, 6MM	FOP-9-5
		NUT, HEX, 64MM	F-4-20
		NUT, PULLEY LOCK	E-19-7
		NUT, SELF-LOCK(25X2.0)	F-10-35
		NUT, SELF-LOCK(3/8-24UNF)	F-10-38

NUT, SELF-LOCK(7/8-14UNF).....	F-10-34	PACKING, SINGLE.....	FOP-8-18
NUT, SELF-LOCK, 5MM.....	F-3-17	PACKING, THERMOSTAT COVER.....	E-9-10-7
NUT, SELF-LOCK, 6MM.....	F-3-16	PACKING, THERMOSTAT SPACER.....	E-9-10-8
NUT, TAPPET ADJUSTING	E-9-30	PACKING, THROTTLE BODY	E-14-13
NUT, TAPPET ADJUSTING	E-9-31	PANEL ASSY., TROLLING CONTROL	FOP-12-6
NUT, WATER MOUTH	F-9-11	PANEL KIT, SWITCH(4-LED)	FOP-6-1-1
NUT-WASHER, 5MM	E-19-30	PANEL KIT, SWITCH(4-LED) (EU)	FOP-6-1-
NUT-WASHER, 6MM	F-7-4	PANEL, CONTROL	FOP-6-1-3
NUT-WASHER, 8MM	F-7-10-13	PANEL, CONTROL	FOP-6-1-
<O>		PIN A, DOWEL, 12X16.....	E-10-14
OIL SEAL	F-11-35	PIN, 6X6.....	FOP-8-6-63
OIL SEAL, 14X26X6	F-2-44	PIN, LINK	F-2-38
OIL SEAL, 31X46X7(NOK).....	E-5-21	PIN, LINK	F-2-40
OIL SEAL, 39.5X52X6(ARAI).....	F-10-51	PIN, LOCK, 6MM	FOP-8-6-62
OIL SEAL, 43X58X7(ARAI).....	E-9-10-22	PIN, PISTON	E-7-3
OIL SEAL, 46X60X9	E-5-20	PIN, SHIFT LINK	F-2-39
OIL SEAL, 80X98X10(ARAI).....	E-3-35	PIN, SHIFTER, 8X47.....	F-5-2
ORIFICE, LOWER BLOCK.....	E-3-4	PIN, SHIFTER, 8X47.....	F-5-1-2
ORIFICE, OIL JET	E-3-8	PIN, SNAP, 12MM.....	F-2-41
O-RING.....	E-15-12	PIN, SPLIT, 4.0	F-5-19
O-RING.....	E-18-1-5	PIN, SPRING, 2.5X20.....	F-10-55
O-RING.....	E-18-1-16	PIN, UPPER CYLINDER.....	F-11-26
O-RING.....	E-18-10-13	PIPE COMP., OIL LEVEL	F-9-1
O-RING.....	E-18-10-14	PIPE, HARNESS GUIDE.....	FOP-8-6-32
O-RING.....	E-18-10-15	PISTON A.....	E-7-2
O-RING.....	E-18-10-16	PISTON B.....	E-7-
O-RING.....	E-18-10-17	PISTON COMP., FREE.....	F-11-22
O-RING.....	E-18-10-18	PIVOT, SHIFT	F-2-15
O-RING.....	E-18-10-19	PIVOT, SHIFT	FOP-8-6-17
O-RING SET, 3.5X31.7	F-11-43	PIVOT, SHIFT SLIDE	F-2-16
O-RING, 1.8X69.6	F-11-37	PLATE.....	E-18-1-17
O-RING, 1.8X7.7	F-11-39	PLATE.....	E-18-10-10
O-RING, 1.9X11.....	F-11-40	PLATE COMP., SLIDING	FOP-8-6-15
O-RING, 105X3.1.....	F-5-27	PLATE COMP., THROTTLE	F-2-4
O-RING, 105X3.1.....	F-5-1-29	PLATE SET, TRANSMOS(5.5MM FLAT)	FOP-7-2
O-RING, 11.5X3.5	F-9-35	PLATE SET, TRIM ADJUST	FOP-7-1
O-RING, 13X1.5(ARAI).....	E-3-39	PLATE, CABLE CLAMP	FOP-8-11
O-RING, 15.54X2.26.....	F-10-52	PLATE, CABLE CLAMP	FOP-8-2-12
O-RING, 15X1.9.....	E-9-10-27	PLATE, CRANK PULSER	E-7-13
O-RING, 15X1.9.....	E-9-20-22	PLATE, DWELL	FOP-8-15
O-RING, 15X1.9.....	E-9-20-23	PLATE, DWELL	FOP-8-2-16
O-RING, 16MM	F-9-34	PLATE, HANDLE	FOP-8-4-10
O-RING, 2.0X70.5	F-11-36	PLATE, HANDLE	FOP-8-10
O-RING, 20.6X2.6	E-6-18	PLATE, LEVER SETTING	FOP-8-2-11
O-RING, 22.5X2.4	E-5-22	PLATE, LOCK	F-5-6
O-RING, 25X2.4(NOK)	F-2-46	PLATE, SHIFT	F-5-1-6
O-RING, 26X2.7	E-3-36	PLATE, SHIFT	F-2-14
O-RING, 3.5X35.7	F-11-41	PLATE, SPEED SENSOR TUBE	FOP-13-7
O-RING, 3.5X38.7	F-11-38	PLATE, SPRING SETTING	FOP-8-6-23
O-RING, 3.5X41.7	F-11-42	PLATE, STEERING	F-10-19
O-RING, 33.2X2.4(NOK)	E-18-26	PLATE, STEERING	F-10-20
O-RING, 37X2.4	E-4-15	PLATE, TDC PULSE	E-9-2
O-RING, 55.6X3.5	F-4-31	PLATE, WATER TUBE	E-6-7
O-RING, 58.5X3.5	F-4-33	PLATE, WINKER BUZZER	FOP-6-1-12
O-RING, 59.4X3.1	E-21-22	PLATE, WINKER BUZZER	FOP-8-6-45
O-RING, 6.5X1.5	E-3-37	PLUG, INNER CONNECTOR	FOP-6-1-5
O-RING, 6.9X1.45	F-3-19	PLUG, INNER CONNECTOR	FOP-8-6-35
O-RING, 7.45X3.61(NOK)	E-14-34	PLUG, INNER CONNECTOR	FOP-11-3
O-RING, 7.47X3.6	E-14-33	PLUG, OUTER CONNECTOR	FOP-6-1-6
O-RING, 7.8X1.9(ARAI).....	E-14-32	PLUG, OUTER CONNECTOR	FOP-8-6-36
O-RING, 7.8X1.9(ARAI)	E-18-10-51	PLUG, TDC HOLE	FOP-11-4
O-RING, 76.4X3.1	E-4-13	PLUG, VTC HOLE	E-9-20-9
O-RING, 79.8X3.1	E-4-14	PORT, IDLE EXHAUST	F-9-7
O-RING, 9.5X1.5(HONDA KIKAKI)	E-9-10-25	PRIMER BULB	F-6-4
O-RING, 9.5X1.9	E-3-38	PRIMER BULB ASSY	F-6-1
O-RING, 9.5X1.9	E-4-16	PROPELLER COMP., THREE BLADES	F-5-11
O-RING, 9.5X1.9	E-9-10-26	PROPELLER COMP., THREE BLADES	F-5-
O-RING, CHAIN CASE	E-9-10-23	PROPELLER COMP., THREE BLADES	F-5-
O-RING, THERMOSTAT COVER.....	F-9-20	PROPELLER COMP., THREE BLADES	F-5-
O-RING, WATER PUMP	F-4-32	PROPELLER COMP., THREE BLADES	F-5-
O-RING, WATER PUMP	FOP-10-5	PROPELLER COMP., THREE BLADES	F-5-
O-RING, WATER PUMP	FOP-10-1-10	PROPELLER COMP., THREE BLADES	F-5-
<P>		PROPELLER COMP., THREE BLADES	F-5-
PACKING	E-21-16	PROPELLER COMP., THREE BLADES	F-5-
PACKING	F-11-45	PROPELLER COMP., THREE BLADES	F-5-
PACKING, CHAIN CASE	E-9-10-24	PROPELLER COMP., THREE BLADES	F-5-
PACKING, CYLINDER HEAD COVER	E-1-2	PROPELLER COMP., THREE BLADES	F-5-
PACKING, DUAL	FOP-8-2-19	PROPELLER COMP., THREE BLADES	F-5-
PACKING, ELECTRONIC AIR	E-14-18	PROPELLER COMP., THREE BLADES	F-5-
PACKING, FLASH VALVE	F-9-19	PROPELLER COMP., THREE BLADES	F-5-
PACKING, INTAKE MANIFOLD	E-14-12	PROPELLER COMP., THREE BLADES	F-5-
PACKING, OIL PAN	E-6-2	PROPELLER COMP., THREE BLADES	F-5-
PACKING, OIL PUMP BODY	E-5-3	PROPELLER COMP., THREE BLADES	F-5-
		PROPELLER COMP., THREE BLADES	F-5-
		PROPELLER COMP., THREE BLADES	F-5-
		PROPELLER COMP., THREE BLADES	F-5-
		PROPELLER COMP., THREE BLADES	F-5-
		PROPELLER COMP., THREE BLADES	F-5-
		PROPELLER COMP., THREE BLADES	F-5-1-12
		PROPELLER COMP., THREE BLADES	F-5-1-
		PROPELLER COMP., THREE BLADES	F-5-1
		PROPELLER COMP., THREE BLADES	F-5-1-1
		PULLER, MINI FUSE	F-7-20-4
		PULLEY	E-19-6
		PULLEY, CRANKSHAFT	E-7-14
		PUMP ASSY	F-11-12
		PUMP ASSY., FUEL	E-18-5
		PUMP ASSY., OIL	E-5-2
		PUMP KIT, IMPELLER	FOP-10-1
		PUMP KIT, IMPELLER	FOP-10-1-1
		PUMP UNIT, FUEL	E-18-10-4
		PUMP UNIT, FUEL(B)	E-18-10-9
		<R>	
		RECEIVER, THRUST	F-10-22
		RECTIFIER ASSY	E-19-21
		REGULATOR ASSY	E-19-22
		REGULATOR ASSY., PRESSURE	E-14-5
		RELAY ASSY., FUEL PUMP(DENSO)	F-7-20-5
		RELAY ASSY., POWER TILT	F-7-10-7
		RELAY ASSY., POWER(12V-20A)	F-7-20-6
		RETAINER, VALVE SPRING	E-9-24
		RING	E-18-10-32
		RING SET, PISTON(STD)	E-7-1
		RING, BACK UP	F-11-18
		RING, CROSS PIN	F-5-3
		RING, CROSS PIN	F-5-1-3
		RING, INNER(15X20X23)	F-2-43
		RING, STOPPER	F-2-11
		RING, WATER TUBE SEAL	F-4-8
		RING, WATER TUBE SEAL	FOP-10-1-7
		ROD COMP. A, SHIFT(L)	F-2-10
		ROD COMP. A, SHIFT(XL)	F-2-
		ROD COMP., CONNECTING	E-7-6
		ROD COMP., PISTON	F-11-20
		ROD COMP., PISTON	F-11-21
		ROD COMP., PISTON(B)	F-11-13
		ROD COMP., SHIFT	F-4-9
		ROD COMP., SHIFT	F-4-
		ROD COMP., THROTTLE	F-2-2
		ROD, ADJUSTING	F-10-14
		ROD, STEERING	F-10-21
		ROLLER, 3X12.8	F-5-25
		ROLLER, 3X12.8	F-5-1-27
		ROLLER, 5X8	E-5-28
		ROLLER, CLICK	FOP-8-6-64
		ROTOR ASSY	E-19-16
		ROTOR COMP	E-21-5
		ROTOR, INNER OIL PUMP	E-5-8
		ROTOR, OUTER OIL PUMP	E-5-9
		RUBBER B, STAND STOPPER	F-8-20-23
		RUBBER COMP., LOWER MOUNT	F-3-20-5
		RUBBER, FR. CARRIER CUSHION	E-14-19
		RUBBER, MOUNT CASE SEAL	F-9-22
		RUBBER, OIL PUMP	E-6-3
		RUBBER, TROLLING CONTROL	FOP-12-2
		<S>	
		SCREEN COMP., FUEL STRAINER	E-18-10-40
		SCREEN, L. WATER	F-3-7
		SCREEN, R. WATER	F-3-6
		SCREW	E-19-9
		SCREW	E-19-12
		SCREW SET	E-15-1
		SCREW SET, DRAIN	E-18-10-7
		SCREW, 6X95	FOP-8-6-52
		SCREW, FLAT, 5X12	FOP-8-6-51
		SCREW, FLAT, 6X16	E-5-23
		SCREW, OVAL, 5X50	F-3-21
		SCREW, PAN	E-18-10-21
		SCREW, PAN, 4X10	FOP-8-26
		SCREW, PAN, 4X10	FOP-8-2-29
		SCREW, PAN, 5X10	FOP-8-23
		SCREW, PAN, 5X10	FOP-8-2-26
		SCREW, PAN, 5X10	FOP-8-6-69
		SCREW, PAN, 5X12	E-18-1-12
		SCREW, PAN, 5X16	FOP-8-22

SCREW, PAN, 5X16.....	FOP-8-2-25	SHAFT COMP. A, SHIFT.....	F-2-12	STRAINER COMP., FUEL	E-18-1-10
SCREW, PAN, 5X16.....	FOP-8-4-20	SHAFT COMP. B, SHIFT.....	F-2-18	STRAINER COMP., OIL.....	E-6-4
SCREW, PAN, 5X18.....	E-15-16	SHAFT COMP., FR. BALANCER	E-10-2	STRAINER, FUEL	E-18-1-11
SCREW, PAN, 5X18.....	FOP-8-25	SHAFT COMP., RR. BALANCER	E-10-3	STRAINER, FUEL PUMP.....	E-18-9
SCREW, PAN, 5X18.....	FOP-8-2-28	SHAFT, COVER OPEN.....	F-8-10-17	SUB HARNESS ASSY., POWER.....	FOP-8-19
SCREW, PAN, 5X20.....	FOP-8-24	SHAFT, EX. ROCKER.....	E-9-16	SUB HARNESS ASSY., POWER.....	FOP-8-2-20
SCREW, PAN, 5X20.....	FOP-8-2-27	SHAFT, FR. LOCK.....	F-8-10-18	SUB HARNESS ASSY., POWER.....	FOP-8-2-21
SCREW, PAN, 5X30.....	FOP-8-4-22	SHAFT, IN. ROCKER	E-9-15	SUB HARNESS ASSY., POWER.....	FOP-8-4-16
SCREW, PAN, 5X40.....	FOP-6-1-15	SHAFT, PROPELLER	F-5-9	SUSPENSION, STRAINER.....	E-18-10
SCREW, PAN, 5X40.....	FOP-8-28	SHAFT, PROPELLER	F-5-1-9	SUSPENSION, STRAINER.....	E-18-1-15
SCREW, PAN, 5X40.....	FOP-8-2-31	SHAFT, THROTTLE BUTTON	FOP-8-4-9	SWITCH ASSY., COMBINATION	FOP-6-1-7
SCREW, PAN, 5X55.....	FOP-8-2-32	SHAFT, TILTING	F-10-15	SWITCH ASSY., COMBINATION	FOP-8-6-38
SCREW, PAN, 5X65.....	FOP-8-34	SHAFT, VERTICAL(L).....	F-4-13	SWITCH ASSY., EMERGENCY STOP	FOP-6-1-8
SCREW, PAN, 5X65.....	FOP-8-2-39	SHAFT, VERTICAL(XL)	F-4-	SWITCH ASSY., EMERGENCY STOP	FOP-8-6-41
SCREW, PAN, 5X8.....	E-21-20	SHIFTER, CLUTCH.....	F-5-1	SWITCH ASSY., MAGNET	E-21-12
SCREW, PAN, 6X10.....	FOP-8-6-50	SHIFTER, CLUTCH.....	F-5-1-1	SWITCH ASSY., MAGNET	E-21
SCREW, PAN, 6X18.....	E-4-18	SHIM A, BEVEL(0.10)	F-5-17	SWITCH ASSY., NEUTRAL.....	F-2-22
SCREW, PAN, 6X18.....	FOP-8-27	SHIM A, BEVEL(0.10)	F-5-1-18	SWITCH ASSY., POWER TILT	F-8-20-2
SCREW, PAN, 6X18.....	FOP-8-2-30	SHIM A, GEAR(0.10)	F-4-23	SWITCH ASSY., POWER TRIM-TILT	FOP-8-20
SCREW, PAN, 6X22.....	E-21	SHIM A, THRUST(0.10)	F-5-1-19	SWITCH ASSY., POWER TRIM-TILT	FOP-8-22
SCREW, PAN, 6X22(SPECIAL)	E-21-19	SHIM B, BEVEL(0.15)	F-5-	SWITCH ASSY., POWER TRIM-TILT	FOP-8-2-23
SCREW, PAN, 6X25.....	F-8-20-22	SHIM B, BEVEL(0.15)	F-5-1-	SWITCH ASSY., POWER TRIM-TILT	FOP-8-4-17
SCREW, PAN, 6X35.....	FOP-8-4-23	SHIM B, GEAR(0.15)	F-4-	SWITCH ASSY., POWER TRIM-TILT	FOP-8-6-39
SCREW, PAN, 6X8.....	F-3-20-12	SHIM B, THRUST(0.15)	F-5-1-	SWITCH ASSY., TROLLING CONTROL	FOP-12-1
SCREW, PAN, 6X8.....	F-11-33	SHIM C, BEVEL(0.30)	F-5-	<T>	
SCREW, PAN, 6X8.....	FOP-13-9	SHIM C, BEVEL(0.30)	F-5-1-	TAB, TRIM	F-3-8
SCREW, RIVET, 5X10	F-8-20-15	SHIM C, GEAR(0.30)	F-4-	TACHOMETER HOUR METER (BLACK)	FOP-2-4
SCREW, RIVET, 5X10	FOP-13-10	SHIM C, THRUST(0.30)	F-5-1-	TANK, OIL	F-11-27
SCREW, TAPPET ADJUSTING.....	E-9-20	SHIM D, BEVEL(0.50)	F-5-	TENSIONER ASSY., CAM CHAIN	E-9-8
SCREW, TAPPET ADJUSTING.....	E-9-21	SHIM D, BEVEL(0.50)	F-5-1-	TENSIONER COMP., BALANCER.....	E-10-6
SCREW, TAPPING	FOP-1-3	SHIM D, GEAR(0.50)	F-4-	TERMINAL, CABLE	FOP-8-16
SCREW, TAPPING, 4X12	F-8-13	SHIM D, THRUST(0.50)	F-5-1-	TERMINAL, CABLE	FOP-8-2-17
SCREW, TAPPING, 5X10	FOP-8-6-71	SLIDER, SHIFT	F-5-4	TERMINAL, CABLE	FOP-8-4-12
SCREW, TAPPING, 5X12	FOP-8-6-72	SLIDER, SHIFT	F-5-1-4	THERMOSTAT ASSY.....	E-9-10-3
SCREW, TAPPING, 5X20	E-13-9	SLINGER, OIL	F-4-14	THERMOSTAT ASSY	E-9-10-4
SCREW, TAPPING, 5X25	FOP-8-6-74	SPACER KIT, REMOTE CONTROL BOX	FOP-8-2	THROTTLE BODY ASSY	E-15-2
SCREW, TAPPING, 5X8	FOP-8-6-70	SPACER KIT, REMOTE CONTROL BOX	FOP-8-2-2	TIE, CABLE	FOP-11-5
SCREW, TAPPING, 6X16	FOP-8-6-73	SPACER, CABLE CLAMP	FOP-8-17	TIE, CABLE(NATURAL)(2.4X92)	FOP-6-12
SCREW, TAPPING, 6X30	FOP-8-4-24	SPACER, CABLE CLAMP	FOP-8-2-18	TIE, CABLE(NATURAL)(2.4X92)	FOP-8-6-37
SCREW, TRUSS, 4X12.....	FOP-8-4-21	SPACER, CABLE CLAMP	FOP-8-4-13	T-JOINT	E-18-15
SCREW, WASHER	E-18-10-22	SPACER, CABLE CLAMP	FOP-8-6-33	T-JOINT	F-9-3
SCREW-WASHER	E-18-10-20	SPACER, CLICK SPRING	FOP-8-6-27	TRIM METER ASSY (BLACK)	FOP-2-1
SCREW-WASHER	E-19-10	SPACER, NEUTRAL SWITCH	FOP-8-6-30	TRIM-TILT ASSY., POWER	F-11-11
SCREW-WASHER, 4X25.....	E-19-11	SPACER, REMOTE CONTROL BOX	FOP-8-6-26	TUBE A, WATER RELIEF	E-4-10-4
SCREW-WASHER, SX15.....	F-7-20-9	SPACER, THERMOSTAT COVER	E-9-10-5	TUBE B, AIR VENT	E-18-3
SEAL A, COVER UNDER	F-8-20-11	SPRING COMP., CLICK	F-10-2	TUBE B, FUEL	E-18-11
SEAL A, VALVE STEM(ARA)	E-9-20-4	SPRING, ACCELERATOR WHEEL	FOP-8-6-21	TUBE B, WATER RELIEF	E-4-10-5
SEAL A, VALVE STEM(NOK)	E-9-20	SPRING, AIR FLOW TUBE	E-15-3	TUBE COMP. A, FUEL(FKM)	E-18-1-6
SEAL B, COVER UNDER	F-8-20-12	SPRING, CHOKE RETURN	FOP-8-6-25	TUBE COMP. B, FUEL	E-18-7
SEAL B, VALVE STEM(ARA)	E-9-20-5	SPRING, CLICK	F-2-9	TUBE COMP. C, AIR VENT	E-18-2
SEAL B, VALVE STEM(NOK)	E-9-20-	SPRING, CLICK ASSIST	F-10-3	TUBE COMP. C, FUEL	E-18-1-7
SEAL, ENGINE COVER	F-8-2	SPRING, COVER LOCK HOOK	F-8-10-14	TUBE COMP. E, FUEL	E-18-1-9
SEAL, FR. SEPARATE COVER	F-8-20-7	SPRING, COVER LOCK HOOK	F-8-10-15	TUBE COMP. E, WATER	E-4-10-7
SEAL, PLUG HOLE	E-20-2	SPRING, EX. VALVE(GRAY)	E-9-23	TUBE COMP., AIR VENT	E-18-4
SEAL, SPARK PLUG TUBE(NOK)	E-1-3	SPRING, FLUSH VALVE	F-9-15	TUBE COMP., WATER RELIEF	E-4-10-3
SEAL, WATER	F-11-44	SPRING, IN. VALVE(PINK)	E-9-22	TUBE D, FUEL	E-18-8
SEAL, WATER(14X26X8)	F-2-45	SPRING, LOCK ADJUSTER	F-8-5	TUBE D, FUEL	E-18-1-8
SEAL, WATER, 12X21X6	F-4-30	SPRING, LOCK LEVER RETURN	F-8-10-16	TUBE F, FUEL	E-18-10-39
SEAL, WATER, 22X35X7	F-9-33	SPRING, MOTOR	F-11-8	TUBE F, WATER	F-9-10
SEAL, WATER, 23X36X6	F-4-29	SPRING, NEUTRAL LOCK ARM	FOP-8-4-7	TUBE G, WATER	E-18-16
SEAL, WATER, 23X36X8	F-4-28	SPRING, RELIEF VALVE	E-5-6	TUBE KIT, SPEED SENSOR	FOP-13-1
SEAL, WATER, 30X45X7	F-5-26	SPRING, REMOTE CONTROL HANDLE	FOP-8-6-7	TUBE, 12X740	E-15-25
SEAL, WATER, 30X45X7	F-5-1-28	SPRING, SET	E-18-10-41	TUBE, 5X140	F-3-22
SEAT, VALVE SPRING	E-9-25	SPRING, SHIFT	F-5-5	TUBE, 5X270	F-3-
SEAT, WATER MOUTH	F-9-13	SPRING, SHIFT	F-5-1-5	TUBE, 5X950	FOP-13-13
SENSOR ASSY., AIR TEMP	E-15-13	SPRING, SHIFT CLICK	FOP-8-6-24	TUBE, 7X120	E-4-10-14
SENSOR ASSY., CRANK	E-9-10-13	SPRING, SHIFT ROD	F-4-10	TUBE, 7X160	F-9-38
SENSOR ASSY., KNOCK	E-3-13	SPRING, SILENCER DUCT GROMMET	E-15-8	TUBE, 7X200	F-9-39
SENSOR ASSY., MAP	E-15-11	SPROCKET COMP., CHAIN DRIVE	E-7-12	TUBE, 7X40	F-9-37
SENSOR ASSY., TDC	E-9-20-13	SPROCKET, CAM CHAIN DRIVEN	E-9-5	TUBE, 7X75	E-4-10-12
SENSOR ASSY., TRIM ANGLE	F-10-4	SPROCKET, CAM CHAIN DRIVEN IN	E-9-6	TUBE, 7X90	E-4-10-13
SENSOR ASSY., WATER	E-3-16	SPROCKET, DRIVEN(17T)	E-10-4	TUBE, FUEL, 3.5X430	E-18-31
SENSOR ASSY., WATER	E-4-7	STAY A, PLATE	E-18-10-3	TUBE, FUEL, 8X300	F-9-36
SENSOR ASSY., WATER	E-9-10-11	STAY A, C. GENERATOR	E-19-18	TUBE, OIL	E-4-10-1
SENSOR ASSY., WATER	E-9-10-12	STAY, FUEL STRAINER	E-18-1-14	TUBE, PRESSURE REGULATOR	E-14-7
SENSOR, LAF	E-4-6	STAY, PLATE	E-18-10-36	TUBE, SPEED SENSOR	FOP-13-6
SENSOR, OIL PRESSURE	E-3-17	STAY, POWER TILT SWITCH	F-8-20-3	TUBE, SPIRAL	F-11-3
SEPARATOR ASSY., VAPOR	E-18-10-33	STAY, VAPOR SEPARATOR	E-18-10-37	TUBE, SPIRAL	FOP-13-4
SEPARATOR ASSY., WATER	E-18-1-2	STOPPER SET, SLEEVE	E-21-8	TUBE, VINYL, 4X7X160	E-15-24
SHAFT ASSY., CLUTCH	E-21-13	STOPPER SET, SLEEVE	E-21	TUBE, WATER RELIEF	F-9-9
SHAFT ASSY., CLUTCH	E-21	STOPPER(TOOL)	E-9-9	TUBE, WATER(L)	F-4-7
SHAFT ASSY., GEAR	E-21-14	STOPPER, TILT	E-10-18	TUBE, WATER(XL)	F-4-
SHAFT ASSY., GEAR	E-21	STRAINER ASSY., VTC	E-9-20-10		

<V>	
VALVE ASSY, ELECTRONIC AIR	E-14-17
VALVE ASSY, RELIEF	F-9-16
VALVE COMP., MANUAL	F-11-23
VALVE COMP., RESERVOIR.....	F-11-24
VALVE SET, FLOAT	E-18-10-1
VALVE, CHECK.....	E-18-17
VALVE, EX.....	E-9-19
VALVE, FLASH	F-9-17
VALVE, IN.....	E-9-18
VALVE, RELIEF	E-5-5
<W>	
WASHER	F-2-35
WASHER, 10MM	F-10-42
WASHER, 26MM	F-3-20-14
WASHER, 28MM.....	FOP-8-6-61
WASHER, 6MM	FOP-8-6-59
WASHER, DRAIN PLUG, 12MM.....	E-6-17
WASHER, DRAIN PLUG, 20MM.....	E-5-24
WASHER, DRAIN PLUG, 20MM.....	E-9-20-24
WASHER, HEAD COVER	E-1-7
WASHER, LOCK, 5MM.....	FOP-8-30
WASHER, LOCK, 5MM	FOP-8-2-35
WASHER, LOCK, 5MM	FOP-8-4-26
WASHER, LOCK, 6MM	FOP-8-32
WASHER, LOCK, 6MM.....	FOP-8-2-37
WASHER, PIVOT	F-2-7
WASHER, PIVOT	F-4-1
WASHER, PLAIN	E-18-10-24
WASHER, PLAIN	E-18-10-25
WASHER, PLAIN, 10MM	F-5-18
WASHER, PLAIN, 10MM	F-5-1-20
WASHER, PLAIN, 10MM	F-8-10-26
WASHER, PLAIN, 10MM	F-10-43
WASHER, PLAIN, 10MM	F-10-47
WASHER, PLAIN, 12MM	E-6-16
WASHER, PLAIN, 12MM	F-2-34
WASHER, PLAIN, 12MM	F-3-20-15
WASHER, PLAIN, 12MM	F-4-22
WASHER, PLAIN, 12MM	F-8-11
WASHER, PLAIN, 12MM	F-10-44
WASHER, PLAIN, 12MM	F-10-45
WASHER, PLAIN, 12MM	F-10-46
WASHER, PLAIN, 4MM	FOP-8-6-55
WASHER, PLAIN, 5MM	FOP-6-1-18
WASHER, PLAIN, 5MM	FOP-8-31
WASHER, PLAIN, 5MM	FOP-8-33
WASHER, PLAIN, 5MM	FOP-8-2-36
WASHER, PLAIN, 5MM	FOP-8-2-38
WASHER, PLAIN, 5MM	FOP-8-6-56
WASHER, PLAIN, 5MM	FOP-8-6-57
WASHER, PLAIN, 6MM	F-2-36
WASHER, PLAIN, 6MM	F-8-10
WASHER, PLAIN, 6MM	FOP-8-4-27
WASHER, PLAIN, 6MM	FOP-8-6-58
WASHER, PLAIN, 8MM	F-2-37
WASHER, PLAIN, 8MM	F-7-10-14
WASHER, PLAIN, 8MM	F-8-10-25
WASHER, PLAIN, 8MM	F-8-10-28
WASHER, PLAIN, 8MM	FOP-8-6-60
WASHER, PROPELLER.....	F-5-16
WASHER, PROPELLER	F-5-1-17
WASHER, PROPELLER THRUST.....	F-5-14
WASHER, PROPELLER THRUST.....	F-5-1-15
WASHER, SEALING(22MM)	E-3-7
WASHER, SEALING, 28MM	E-3-31
WASHER, SEALING, 6MM.....	E-18-10-49
WASHER, SHIFT SHAFT.....	F-2-33
WASHER, SPRING, 4MM.....	FOP-12-9
WASHER, SPRING, 5MM	FOP-6-1-19
WASHER, THRUST	E-7-10
WASHER, THRUST	E-9-17
WASHER, THRUST BEARING	F-5-15
WASHER, THRUST BEARING	F-5-1-16
WASHER, THRUST, 34MM	F-10-41
WASHER, WAVE, 10MM	F-8-10-27
WASHER, WAVE, 26MM	F-10-40
WASHER, WAVE, 40MM	F-10-39
WHEEL, ACCELERATOR.....	FOP-8-6-20
WHEEL, CONTROL	FOP-8-6-13
WIRE, LEAD(1.5X116MM)	F-11-9
WIRE, LEAD(1.5X137MM)	F-3-20-3
WRENCH, EYE, 19MM	F-13-11
WRENCH, HEX, 6MM	F-13-6
WRENCH, PLUG.....	F-13-5
<Y>	
YOKE ASSY.....	F-11-7
YOKE COMP.	E-21-4

INDEX (Parts Number)

332-70201-0	F-6-8	HCO-94301-10160	E-9-20-25	HMM4-90105-000	FOP-8-6-50	HPNA-90006-003	E-3-21
3C7-70217-0	F-6-5	HCO-94301-12160	E-10-14	HMM8-90501-610	F-8-10-25	HPNA-90011-003	E-9-20-16
3C7-70220-1	F-6-2	HCO-94301-14200	E-5-26	HMM8-90502-610	F-8-10-26	HPNA-90031-004	E-10-11
3C7-70224-1	F-6-3	HCO-94301-14200	E-6-21	HMN5-17195-000	F-9-3	HPNA-90032-000	E-9-28
3FF-70200-4	F-6-1	HCO-94301-14200	E-9-20-26	HMR5-16966-000	E-18-1-18	HPNA-90042-003	E-9-29
3GF-70211-1	F-6-4	HCO-94305-25203	F-10-55	HMT8-18334-770	FOP-6-1-2	HPNA-90703-300	E-9-32
3GF-70240-1	F-6-7	HCO-94510-14000	F-5-28	HYM1-16959-000	E-4-10-2	HPNA-90704-000	E-7-16
3GF-70241-1	F-6-6	HCO-94510-14000	F-5-1-30	HYM5-91005-601	F-5-20	HPNA-90715-000	E-3-34
3PU-72537-0	FOP-2-6	HCO-94540-03029	FOP-8-6-77	HYM5-91005-601	F-5-1-22	HPNA-91214-014	E-3-35
3PV-72571-0	FOP-2-1	HCO-94540-04029	F-2-49	HMZ5-16952-000	E-18-11	HPNA-91302-003	E-14-34
3PV-72637-0	FOP-2-4	HCO-94540-04029	FOP-8-6-78	HP01-91212-003	E-5-21	HPNA-91302-004	E-9-10-23
H121-51640-730	E-14-19	HCO-94540-06029	F-2-50	HP0X-91321-003	F-2-46	HPNA-91307-003	E-3-38
H341-38403-672	FOP-6-1-12	HCO-94540-06029	F-8-10-29	HP2A-37881-000	E-15-14	HPNA-91307-003	E-4-16
H341-38403-672	FOP-8-6-45	HCO-94540-06029	FOP-8-36	HP5A-13115-000	E-7-4	HPNA-91307-003	E-9-10-26
H460-89221-840	F-13-6	HCO-94540-06029	FOP-8-2-41	HP64-31141-003	E-19-6	HPNA-91333-003	E-9-10-27
H538-89102-000	F-13-1	HCO-94540-06029	FOP-8-4-28	HP8A-13204-A01	E-7-5	HPNA-91333-003	E-9-20-23
H538-89103-000	F-13-2	HCO-94540-07029	FOP-8-6-79	HPA9-91317-003	E-18-26	HPNB-37500-003	E-9-10-13
H723-90472-000	F-4-22	HCO-94540-10019	F-4-35	HPC6-15233-000	E-5-7	HPNB-37510-003	E-9-20-13
H750-90628-000	FOP-13-12	HCO-94540-12029	F-2-51	HPC6-90715-000	E-3-33	HPNC-91212-004	E-9-10-22
H759-16911-003	E-18-9	HCO-94540-15029	F-11-47	HPC6-91324-000	E-6-18	HPNE-14631-000	E-9-15
H763-75538-C01	F-2-26	HCO-95001-35430-40	E-18-31	HPCX-12342-004	E-1-3	HPP4-90009-E01	E-18-10-44
H763-90681-A01	F-10-49	HCO-95001-80300-40	F-9-36	HPCX-90017-013	E-7-15	HPPA-13210-000	E-7-6
H800-91303-000	F-9-34	HCO-95003-07016-31	E-15-24	HPD1-31138-004	E-19-5	HPPA-13310-000	E-7-8
H805-91301-000	E-3-36	HCO-95005-12740-20	E-15-25	HPD1-31142-004	E-19-7	HPPA-14520-003	E-9-10
H881-90105-000	F-4-17	HCO-95005-50140-30	F-3-22	HPD1-31148-004	E-19-11	HPPA-14530-003	E-9-11
H881-90110-000	F-10-30	HCO-95005-50270-30	F-3-	HPD1-90231-014	E-19-30	HPR3-91319-003	E-3-39
H921-15611-000	E-3-12	HCO-95005-50950-30	FOP-13-13	HPD6-90430-003	E-18-10-49	HPR4-11106-013	E-3-3
H921-17936-000	F-2-7	HCO-95005-70040-30	F-9-37	HPE0-15231-000	E-5-5	HPR4-90401-000	E-3-31
H921-17936-000	F-4-1	HCO-95005-70075-30	E-4-10-12	HPE0-90703-000	E-3-32	HPR4-15290-000	E-3-10
H921-90302-000	F-8-20-17	HCO-95005-70090-30	E-4-10-13	HPE9-31145-941	E-19-8	HPRB-14721-A00	E-9-19
H921-90302-000	FOP-6-1-16	HCO-95005-70120-30	E-4-10-14	HPE9-31152-942	E-19-13	HPRB-15280-A00	E-3-9
H921-90302-000	FOP-8-6-53	HCO-95005-70160-30	F-9-38	HPFB-30522-007	E-20-2	HPS4-36454-003	E-14-16
H921-90504-010	F-8-10	HCO-95005-70200-30	F-9-39	HPG6-15232-000	E-5-6	HPT0-14744-004	E-9-21
H921-90504-010	FOP-8-6-58	HCO-95011-62000	F-8-20-23	HPGK-37835-A01	E-15-12	HPT0-14775-000	E-9-25
H921-90511-000	F-10-43	HCO-95701-06014-08	E-9-20-30	HPH1-90015-013	E-5-16	HPT0-31147-003	E-19-10
H921-90512-010	FOP-8-6-59	HCO-95701-06014-08	E-10-15	HPH3-90011-000	E-5-15	HPT0-90206-004	E-9-31
H921-90518-000	F-2-37	HCO-95701-06018-09	E-6-22	HPJ7-31111-013	E-19-3	HPT2-91005-N01	F-5-21
H921-90518-000	F-8-10-28	HCO-95701-06020-08	F-9-34	HPJ7-31114-013	E-19-4	HPT2-91005-N01	F-5-1-23
H921-90518-000	FOP-8-6-60	HCO-95701-06020-08	E-9-20-27	HPJ7-31146-003	E-19-9	HPY3-17249-000	E-15-3
H921-90602-000	FOP-13-11	HCO-95701-06030-08	E-9-35	HPJ7-91309-010	F-9-35	HPY3-31215-004	E-21-3
H952-32901-770	FOP-6-12	HCO-95701-06032-08	E-9-20-28	HPK1-32742-003	F-7-30-3	HPY3-31218-004	E-21-6
H952-32901-770	FOP-8-6-37	HCO-95701-08032-08	F-5-27	HPK2-91307-005	E-9-10-25	HPZ1-12210-003	E-9-20-4
HCO-92101-04020-4J	FOP-12-7	HCO-95701-08050-08	E-10-16	HPLC-37880-004	E-15-13	HPZ1-12210-004	E-9-20
HCO-92101-05016-4J	FOP-8-6-68	HCO-95701-08075-08	E-10-17	HPLC-91301-000	E-14-33	HPZ1-12211-003	E-9-20-5
HCO-92101-06050-4J	F-3-20	HCO-95701-08090-08	E-9-20-29	HPM3-90206-004	E-9-30	HPZ1-12211-004	E-9-20
HCO-93500-05010-4J	FOP-8-6-69	HCO-95701-10105-08	E-10-18	HPNA-11106-300	E-3-2	HPZ1-31105-003	E-19-2
HCO-93500-05065-4J	FOP-8-34	HCO-95701-10110-09	E-6-23	HPNA-11135-000	E-3-4	HPZ1-31149-003	E-19-12
HCO-93500-05065-4J	FOP-8-2-39	HCO-95801-08035-09	F-10-56	HPNA-12204-305	E-9-20-2	HPZ1-31153-003	E-19-14
HCO-93500-06018-4J	E-4-18	HCO-96211-07000	F-5-29	HPNA-12205-305	E-9-20-3	HR40-14401-A01	E-9-7
HCO-93500-06025-4J	F-8-20-22	HCO-96211-07000	F-5-1-31	HPNA-12341-000	E-1-2	HR40-14633-A00	E-9-16
HCO-93600-06016-0A	E-5-23	HCO-96211-09000	F-5-30	HPNA-13111-010	E-7-3	HR40-15115-A01	E-10-8
HCO-93700-05050-4J	F-3-21	HCO-96211-09000	F-5-1-32	HPNA-13321-003	E-7-9	HRAA-13620-A02	E-7-12
HCO-93901-250J0	FOP-8-6-70	HCO-96220-50080	E-5-28	HPNA-13322-003	E-7-	HRAA-14620-A00	E-9-13
HCO-93901-251J0	FOP-8-6-71	HCO-96300-06025-00	E-10-19	HPNA-13323-003	E-7-	HRAA-14624-A00	E-9-14
HCO-93901-252J0	FOP-8-6-72	HCO-96300-06032-00	E-10-20	HPNA-13324-003	E-7-	HRAA-14647-A00	E-9-17
HCO-93903-254G0	E-13-9	HCO-9807B-5615P	E-20-4	HPNA-13325-003	E-7-	HRAA-14765-A00	E-9-24
HCO-93903-262J0	FOP-8-6-73	HCO-9807B-5615W	E-20-	HPNA-13326-003	E-7-	HRAA-15815-A02	E-9-20-7
HCO-93905-255J0	FOP-8-6-74	HCO-9807B-5617P	E-20-	HPNA-13341-003	E-7-11	HRAA-15845-A01	E-9-20-11
HCO-93913-142J0	F-8-13	HCO-9807B-5617W	E-20-	HPNA-13342-003	E-7-	HRAD-13410-010	E-10-2
HCO-94001-04490-05	FOP-12-8	HCO-98200-41000	F-7-20-10	HPNA-13343-003	E-7-	HRAD-13420-010	E-10-3
HCO-94001-05490-05	F-2-48	HCO-98200-41500	F-7-20-11	HPNA-13344-003	E-7-	HRGM-14781-A01	E-9-26
HCO-94001-05490-05	FOP-8-35	HCO-98200-43000	F-7-20-12	HPNA-13345-003	E-7-	HRNA-37260-A01	E-3-17
HCO-94001-05490-05	FOP-8-2-40	HCO-99006-19000	F-13-11	HPNA-13346-003	E-7-	HRNA-37830-A01	E-15-11
HCO-94001-06080-05	E-19-31	HCO-99008-02300	F-13-12	HPNA-13432-000	E-10-4	HRRA-30520-007	E-20-1
HCO-94001-06490-05	FOP-8-6-75	HGE1-17357-670	FOP-13-2	HPNA-13441-004	E-10-5	HRTA-15400-004	E-5-10
HCO-94001-06490-05	FOP-9-5	HGEV-90650-003	E-14-30	HPNA-13450-004	E-10-6	HRWC-14540-A02	E-9-12
HCO-94001-12490-05	F-10-54	HGH8-16163-610	E-18-1	HPNA-13460-004	E-10-7	HS0A-91541-003	E-3-40
HCO-94002-05490-05	FOP-8-6-76	HGH8-16163-610	F-9-2	HPNA-13622-003	E-7-13	HS0A-91541-003	F-7-6
HCO-94002-06490-05	F-8-14	HHC4-90653-900	F-8-20-19	HPNA-14114-003	E-9-2	HS0A-91541-003	F-7-10-16
HCO-94103-05400	FOP-6-1-18	HHN0-91305-A00	E-4-15	HPNA-14115-000	E-9-3	HS0A-90683-003	E-18-1-22
HCO-94109-20000	E-5-24	HKJ2-90683-003	F-8-20-20	HPNA-14210-000	E-9-5	HSB2-90687-003	E-14-31
HCO-94109-20000	E-9-20-24	HKM3-32161-003	F-3-2	HPNA-14511-003	E-9-9	HSB2-90687-003	F-7-10-15
HCO-94111-04500	FOP-12-9	HKM3-32161-003	FOP-13-3	HPNA-14711-000	E-9-18	HSB6-91475-000	FOP-8-6-65
HCO-94111-05400	FOP-6-1-19	HKV7-17368-671	E-18-13	HPNA-14744-004	E-9-20	HSC2-90649-003	FOP-6-1-17
HCO-94301-06100	E-6-19	HM0-91359-000	F-4-33	HPNA-14762-003	E-9-23	HSDA-39794-004	F-7-20-5
HCO-94301-08100	E-10-13	HMG9-35701-950	F-8-10-1	HPNA-17055-004	E-14-11	HSE0-53740-953	E-18-18
HCO-94301-10120	E-7-17	HMG9-35701-950	FOP-8-6-40	HPNA-90003-000	E-9-27	HSE1-91547-003	E-18-27
HCO-94301-10160	E-5-25	HMU0-91301-003	E-14-32	HPNA-90004-000	E-10-9	HSF1-91595-003	E-15-23
HCO-94301-10160	E-6-20	HMU0-91301-003	E-18-10-51	HPNA-90005-003	E-9-20-15	HSH3-91599-A32	E-18-30

HSM4-32134-003F-7-30-2	HZV5-38410-003FOP-6-1-13	HZW1-41109-800F-3-9	HZW4-90162-000E-9-10-21
HSM4-91558-003E-18-29	HZV5-38410-003FOP-8-6-46	HZW1-41116-800F-4-14	HZW4-90163-000E-19-28
HSP0-91546-A01E-9-10-28	HZV5-40102-000E-13-4	HZW1-50111-010ZCF-3-20-4	HZW4-90164-000E-21-21
HSP0-91546-A01E-13-7	HZV5-40102-000E-15-15	HZW1-50156-010F-3-20-6	HZW4-90170-000E-4-11
HSTK-91540-003FOP-11-6	HZV5-41171-000F-3-10	HZW1-50161-020ZCF-3-20-7	HZW4-90306-003F-10-37
HSV1-91549-L01F-2-47	HZV5-41171-000FOP-13-5	HZW1-50201-040ZCF-10-9	HZW4-90401-000FOP-8-5-55
HSV4-91540-003E-4-17	HZV5-41172-000F-3-11	HZW1-50214-000F-10-11	HZW4-90402-000FOP-8-6-56
HZS5-91531-003E-13-6	HZV5-50214-003F-11-10	HZW1-50301-070ZCF-10-12	HZW4-91301-003F-3-19
HVD6-91360-003E-5-22	HZV5-50522-000F-10-16	HZW1-50311-070ZCF-10-13	HZW5-06241-U00FOP-8-2
HVM0-16965-771E-18-12	HZV5-56117-821F-11-18	HZW1-50527-000F-10-17	HZW5-06241-U10FOP-8-2-2
HVM0-16965-771F-7-30-1	HZV5-56118-820F-11-19	HZW1-50529-000F-10-18	HZW5-06900-U00FOP-9-1
HVM0-46391-003F-2-24	HZV5-56513-000F-11-25	HZW1-53234-010F-10-19	HZW5-15113-000E-6-3
HZB5-90626-730F-8-20-18	HZV5-90081-010E-3-26	HZW1-53238-010F-10-21	HZW5-15331-003E-5-8
HZC0-63515-700F-8-10-21	HZV5-90081-010E-5-19	HZW1-56110-701F-11-13	HZW5-15341-003E-5-9
HZE2-16731-003E-18-1-1	HZV5-90119-000F-3-20-12	HZW1-56113-701F-11-14	HZW5-16081-010E-18-10-20
HZE2-90601-000E-6-17	HZV5-90119-000F-11-33	HZW1-56115-305F-11-15	HZW5-16086-000E-18-10-23
HZV0-90604-000E-18-24	HZV5-90119-000FOP-13-9	HZW1-56116-701F-11-17	HZW5-16087-000E-18-10-24
HZV0-90604-000E-18-1-21	HZV5-90125-000FOP-8-6-52	HZW1-56120-305F-11-20	HZW5-16708-003E-18-10-28
HZV0-90604-000F-9-30	HZV5-90127-003F-8-20-15	HZW1-56130-702F-11-22	HZW5-16715-023E-18-10-29
HZV1-24210-010F-10-2	HZV5-90127-003FOP-13-10	HZW1-56180-701F-11-24	HZW5-16733-000E-18-10-34
HZV1-87538-C23F-12-8	HZV5-90131-000E-6-15	HZW1-56516-000F-10-22	HZW5-16915-000E-18-10
HZV1-90127-010E-15-20	HZV5-90302-003F-2-32	HZW1-56532-000F-11-26	HZW5-24810-U01FOP-8-3
HZV3-90601-030E-15-21	HZV5-90304-013F-10-34	HZW1-56539-000F-10-23	HZW5-24810-U01FOP-8-2-3
HZV4-24221-010F-10-3	HZV5-90307-003F-10-38	HZW1-56851-703F-11-27	HZW5-24810-U11FOP-8-2-4
HZV4-36182-651FOP-6-1-9	HZV5-90501-000F-10-39	HZW1-56860-701F-11-28	HZW5-24811-U01FOP-8-4
HZV4-36182-651FOP-8-6-42	HZV5-90502-000F-10-40	HZW1-87538-721F-12-	HZW5-24811-U01FOP-8-2-5
HZV4-36187-652FOP-6-1-10	HZV5-90504-000F-10-41	HZW1-90013-000E-13-5	HZW5-24812-U01FOP-8-5
HZV4-36187-652FOP-8-6-43	HZV5-90552-000F-10-44	HZW1-90013-000E-15-17	HZW5-24812-U01FOP-8-2-6
HZV4-90302-000F-3-17	HZV5-90557-000FOP-8-6-61	HZW1-90014-000E-14-20	HZW5-24813-U01FOP-8-6
HZV4-90304-000FOP-8-6-54	HZV5-90559-000E-6-16	HZW1-90014-000E-18-20	HZW5-24813-U01FOP-8-2-7
HZV4-90502-000FOP-8-31	HZV5-90559-000F-10-45	HZW1-90014-000E-18-10-45	HZW5-24813-U21FOP-8-2-8
HZV4-90502-000FOP-8-2-36	HZV5-90559-000F-10-46	HZW1-90102-000F-10-26	HZW5-24814-U01FOP-8-7
HZV4-90502-000FOP-8-6-57	HZV5-90563-000F-5-18	HZW1-90105-000F-10-27	HZW5-24814-U01FOP-8-2-9
HZV4-90512-000F-2-36	HZV5-90563-000F-5-1-20	HZW1-90106-004E-21-19	HZW5-24815-U01FOP-8-8
HZV4-90514-000F-10-42	HZV5-90563-000F-10-47	HZW1-90107-004E-21-20	HZW5-24816-U01FOP-8-9
HZV5-12155-000E-4-1	HZV5-90651-000F-10-48	HZW1-90108-000F-10-29	HZW5-24816-U01FOP-8-2-10
HZV5-12214-000E-3-7	HZV5-90751-000FOP-8-6-62	HZW1-90113-702F-11-29	HZW5-24816-U01FOP-8-4-8
HZV5-16881-000E-18-8	HZV5-90756-000F-3-18	HZW1-90114-702F-11-30	HZW5-24817-U01FOP-8-10
HZV5-17202-310F-9-4	HZV5-90756-000F-3-20-17	HZW1-90115-702F-11-31	HZW5-24817-U01FOP-8-2-11
HZV5-17838-000F-2-1	HZV5-90756-000F-4-25	HZW1-90116-702F-11-32	HZW5-24818-U01FOP-8-11
HZV5-24811-010FOP-8-6-2	HZV5-90772-000FOP-8-6-63	HZW1-90203-000F-7-10-13	HZW5-24818-U01FOP-8-2-12
HZV5-24812-000FOP-8-6-3	HZV5-91151-000FOP-8-6-64	HZW1-90242-000F-4-20	HZW5-24819-U01FOP-8-12
HZV5-24813-000FOP-8-6-4	HZV5-91203-821F-11-35	HZW1-90301-800F-5-13	HZW5-24819-U01FOP-8-2-13
HZV5-24814-010FOP-8-6-5	HZV5-91256-003F-10-51	HZW1-90301-800F-5-1-14	HZW5-24820-U01FOP-8-13
HZV5-24815-010FOP-8-6-6	HZV5-91302-821F-11-37	HZW1-90304-013F-10-35	HZW5-24820-U21FOP-8-2-14
HZV5-24816-000FOP-8-6-7	HZV5-91316-821F-11-38	HZW1-90501-710F-3-20-14	HZW5-24825-U01FOP-8-14
HZV5-24817-000FOP-8-6-8	HZV5-91352-000F-10-52	HZW1-90518-800F-4-23	HZW5-24825-U01FOP-8-2-15
HZV5-24818-003FOP-8-6-9	HZV5-91553-010E-13-8	HZW1-90519-800F-4-	HZW5-24826-U01FOP-8-15
HZV5-24820-010FOP-8-6-10	HZV5-91553-010E-15-22	HZW1-90520-800F-4-	HZW5-24826-U01FOP-8-2-16
HZV5-24830-010FOP-8-6-11	HZV5-91553-010E-20-10-6	HZW1-90521-800F-4-	HZW5-24826-U01FOP-8-4-10
HZV5-24836-000FOP-8-6-12	HZV5-91553-010F-7-10-17	HZW1-90559-000F-3-20-15	HZW5-24831-U01FOP-8-16
HZV5-24841-000FOP-8-6-13	HZV5-91560-000F-10-53	HZW1-90651-710F-3-20-16	HZW5-24831-U01FOP-8-2-17
HZV5-24845-000FOP-8-6-14	HZV5-91567-000FOP-8-6-66	HZW1-90652-702F-11-34	HZW5-24831-U01FOP-8-4-12
HZV5-24850-000FOP-8-6-15	HZV5-91570-000FOP-8-6-67	HZW1-90752-802F-4-24	HZW5-24832-U01FOP-8-17
HZV5-24854-000FOP-8-6-16	HZV7-90508-000F-2-35	HZW1-90752-802FOP-10-4	HZW5-24832-U01FOP-8-2-18
HZV5-24855-000FOP-8-6-17	HZV7-90951-010F-10-50	HZW1-90752-802FOP-10-1-9	HZW5-24832-U01FOP-8-4-13
HZV5-24860-000FOP-8-6-18	HZW1-06411-020F-10-1	HZW1-90758-800F-5-19	HZW5-24834-U01FOP-8-18
HZV5-24865-000FOP-8-6-19	HZW1-12217-010E-5-1	HZW1-90758-800F-5-1-21	HZW5-24834-U21FOP-8-2-19
HZV5-24875-000FOP-8-6-20	HZW1-15665-020F-9-1	HZW1-91054-831F-4-27	HZW5-31217-003E-21-5
HZV5-24876-000FOP-8-6-21	HZW1-19210-B04F-4-2	HZW1-91101-003F-5-25	HZW5-31631-003E-19-16
HZV5-24878-000FOP-8-6-22	HZW1-19210-B04FOP-10-2	HZW1-91101-003F-5-1-27	HZW5-31639-003E-19-19
HZV5-24881-000FOP-8-6-23	HZW1-19210-B04FOP-10-1-2	HZW1-91207-013F-11-36	HZW5-31644-003E-19-20
HZV5-24883-000FOP-8-6-24	HZW1-19223-B00F-4-4	HZW1-91352-702F-11-39	HZW5-31710-003E-19-21
HZV5-24884-000FOP-8-6-25	HZW1-19223-B00FOP-10-1-4	HZW1-91353-703F-11-40	HZW5-32168-003E-18-10-43
HZV5-24885-000FOP-8-6-26	HZW1-19252-000E-6-6	HZW1-91354-701F-11-41	HZW5-35370-U02FOP-8-20
HZV5-24887-000FOP-8-6-27	HZW1-19253-801F-4-8	HZW1-91355-701F-11-42	HZW5-35370-U02FOP-8-2-22
HZV5-24891-000FOP-8-6-28	HZW1-19253-801FOP-10-1-7	HZW1-91356-800F-4-32	HZW5-35370-U12FOP-8-2-23
HZV5-24892-000FOP-8-6-29	HZW1-19286-B00F-3-1	HZW1-91356-800FOP-10-5	HZW5-35673-003E-9-10-11
HZV5-24894-000FOP-8-6-30	HZW1-24102-B00F-5-2	HZW1-91356-800FOP-10-1-10	HZW5-50151-000F-10-6
HZV5-24895-000FOP-8-6-31	HZW1-24102-B00F-5-1-2	HZW1-91357-701F-11-43	HZW5-50155-000F-3-20-5
HZV5-24897-000FOP-8-6-32	HZW1-24103-B00F-5-3	HZW1-91358-701F-11-44	HZW5-50341-010F-10-14
HZV5-24898-000FOP-8-6-33	HZW1-24103-B00F-5-1-3	HZW1-91361-701F-11-45	HZW5-53234-010F-10-20
HZV5-32823-003FOP-6-1-5	HZW1-24327-000F-2-11	HZW1-91554-000E-14-35	HZW5-90002-013E-5-14
HZV5-32823-003FOP-8-6-35	HZW1-31229-004E-21-8	HZW1-91554-000E-18-28	HZW5-90011-010E-19-23
HZV5-32823-003FOP-11-3	HZW1-31247-004E-21-15	HZW1-91554-000E-18-10-52	HZW5-90018-000E-5-18
HZV5-32824-003FOP-6-1-6	HZW1-31249-004E-21-16	HZW1-91557-701F-11-46	HZW5-90018-000E-9-20-19
HZV5-32824-003FOP-8-6-36	HZW1-31250-004E-21-17	HZW2-90003-000E-20-10-4	HZW5-90018-000E-20-10-5
HZV5-32824-003FOP-11-4	HZW1-31261-004E-21-18	HZW2-90301-F00E-14-29	HZW5-90018-000F-7-20-8
HZV5-35370-823FOP-8-6-39	HZW1-38551-000F-7-10-8	HZW4-90108-000FOP-8-6-51	HZW5-90021-U00FOP-9-2
HZV5-36104-821F-11-3	HZW1-40107-700F-8-10-3	HZW4-90126-000E-14-26	HZW5-90101-000F-10-25
HZV5-36136-821F-11-8	HZW1-40204-000F-4-12	HZW4-90151-000E-14-27	HZW5-90101-U00FOP-8-22
HZV5-36180-033FOP-6-1-8	HZW1-40210-710F-3-20-2	HZW4-90156-000E-3-28	HZW5-90101-U00FOP-8-2-25
HZV5-36180-033FOP-8-6-41	HZW1-41102-B00F-3-4	HZW4-90162-000E-3-29	HZW5-90101-U00FOP-8-4-20

HZW5-90102-U00	FOP-8-23	HZW9-90016-000	E-18-21	HYZ3-36123-013	F-11-6	HZY3-90529-000	F-5-1-
HZW5-90102-U00	FOP-8-2-26	HZW9-90016-000	E-18-10-46	HYZ3-40119-003	F-8-10-4	HZY3-90530-000	F-5-
HZW5-90103-U01	FOP-8-24	HZW9-90016-000	F-9-24	HYZ3-40219-013	F-11-9	HZY3-90530-000	F-5-1-
HZW5-90103-U01	FOP-8-2-27	HZW9-90101-003	F-3-12	HYZ3-50388-U00	FOP-7-1	HZY3-90531-000	F-5-
HZW5-90104-U00	FOP-8-25	HZW9-90102-000	E-6-14	HYZ3-50388-U10	FOP-7-2	HZY3-90531-000	F-5-1-
HZW5-90104-U00	FOP-8-2-28	HZW9-90102-000	F-2-30	HYZ3-56170-013	F-11-23	HZY3-90601-030	E-4-10-8
HZW5-90105-U01	FOP-8-26	HZW9-90103-010	F-3-20-9	HYZ3-58130-T00	F-5-11	HZY3-90601-030	F-9-29
HZW5-90105-U01	FOP-8-2-29	HZW9-90105-000	F-2-31	HYZ3-58130-T10	F-5-	HZY3-90602-020	E-4-10-9
HZW5-90106-U00	FOP-8-27	HZW9-90105-000	F-4-18	HYZ3-58130-T20	F-5-	HZY3-90653-003	F-7-5
HZW5-90106-U00	FOP-8-2-30	HZW9-90105-000	F-10-28	HYZ3-58130-T30	F-5-	HZY3-90751-000	F-2-38
HZW5-90107-U00	FOP-8-28	HZW9-90154-000	F-10-32	HYZ3-58130-T40	F-5-	HZY3-91001-003	F-2-42
HZW5-90107-U00	FOP-8-2-31	HZW9-90506-000	F-8-10-27	HYZ3-58130-T50	F-5-	HZY3-91152-003	F-2-43
HZW5-90108-U00	FOP-8-2-32	HZX1-17110-003	E-14-14	HYZ3-58130-V01ZA	F-5-	HZY3-91254-003	F-4-30
HZW5-90109-000	FOP-6-1-15	HZX1-32100-000	F-7-1	HYZ3-58130-V11ZA	F-5-	HZY3-91255-003	F-2-45
HZW5-90203-010	E-19-29	HZX1-34750-023	E-20-10-3	HYZ3-58130-V21ZA	F-5-	HZY3-91303-000	E-21-22
HZW5-90301-U00	FOP-8-29	HZX1-50100-000	F-10-5	HYZ3-58130-V31ZA	F-5-	HZY3-91351-003	F-5-27
HZW5-90301-U00	FOP-8-2-33	HZX1-63100-R00ZA	F-8-1	HYZ3-58130-V41ZA	F-5-	HZY3-91351-003	F-5-1-29
HZW5-90302-003	F-3-20-13	HZX1-87121-R00	F-12-2	HYZ3-58130-V51ZA	F-5-	HZY3-91556-000	F-8-12
HZW5-90302-003	F-10-33	HZX1-87132-R00	F-12-3	HYZ3-58180-T00	F-5-1-12	HZY5-14110-000	E-9-1
HZW5-90302-U21	FOP-8-2-34	HZX1-87133-R00	F-12-10	HYZ3-58180-T10	F-5-1-	HZY6-06122-010ZA	E-9-20-1
HZW5-90303-000	F-4-21	HZX1-90101-R00	F-8-7	HYZ3-58180-T20	F-5-1-	HZY6-06192-000	FOP-10-1
HZW5-90304-000	F-10-36	HZX2-41102-E00ZC	F-3-5	HYZ3-58180-T30	F-5-1-	HZY6-06193-A01	FOP-10-1-1
HZW5-90501-000	F-2-33	HZX2-41107-C00ZC	F-3-8	HYZ3-58180-T40	F-5-1-	HZY6-06411-000	FOP-13-1
HZW5-90501-U00	FOP-8-30	HZX2-90129-000	F-10-	HYZ3-63107-000	F-8-3	HZY6-11100-405	E-3-1
HZW5-90501-U00	FOP-8-2-35	HYZ1-90205-000	F-3-16	HYZ3-63108-000	F-8-4	HZY6-11321-010ZB	E-6-1
HZW5-90501-U00	FOP-8-4-26	HYZ1-90650-003	FOP-11-5	HYZ3-63119-000	F-8-5	HZY6-11381-010	E-6-2
HZW5-90502-U00	FOP-8-32	HYZ3-06177-U02	FOP-1-1	HYZ3-63201-000ZC	F-8-10-10	HZY6-11410-425ZA	E-9-10-1
HZW5-90502-U00	FOP-8-2-37	HYZ3-16011-000	E-18-10-1	HYZ3-63205-000	F-2-25	HZY6-11412-000	E-9-10-2
HZW5-90503-U00	FOP-8-33	HYZ3-16013-000	E-18-10-2	HYZ3-63205-000	F-8-10-11	HZY6-11911-000	E-3-5
HZW5-90503-U00	FOP-8-2-38	HYZ3-16024-000	E-18-10-7	HYZ3-63208-000	F-8-10-13	HZY6-11912-000	E-19-1
HZW5-90509-711	F-5-15	HYZ3-16026-000	E-18-10-8	HYZ3-63212-000	F-8-10-14	HZY6-12000-415ZA	E-3-6
HZW5-90509-711	F-5-1-16	HYZ3-16041-000	E-18-10-10	HYZ3-63224-000	F-8-10-17	HZY6-12251-003	E-9-20-6
HZW5-90511-U00	FOP-9-3	HYZ3-16042-000	E-18-10-11	HYZ3-63260-000	F-8-10-20	HZY6-12310-010ZA	E-1-1
HZW5-90512-U00	FOP-9-4	HYZ3-16061-000	E-18-10-12	HYZ3-90016-000	E-9-10-15	HZY6-12500-000	E-1-4
HZW5-90548-710	F-5-1-19	HYZ3-16072-000	E-18-10-13	HYZ3-90017-000	E-9-10-16	HZY6-13010-000	E-7-1
HZW5-90549-710	F-5-1-	HYZ3-16073-000	E-18-10-14	HYZ3-90017-000	E-9-10-18	HZY6-13101-000	E-7-2
HZW5-90550-710	F-5-1-	HYZ3-16074-000	E-18-10-15	HYZ3-90017-000	E-18-10-47	HZY6-13102-000	E-7-
HZW5-90551-710	F-5-1-	HYZ3-16075-000	E-18-10-16	HYZ3-90017-000	E-19-24	HZY6-13211-004	E-7-7
HZW5-90601-030	E-18-22	HYZ3-16076-000	E-18-10-17	HYZ3-90017-000	F-2-27	HZY6-13212-004	E-7-
HZW5-91056-003	F-5-24	HYZ3-16077-000	E-18-10-18	HYZ3-90017-000	F-9-25	HZY6-13213-004	E-7-
HZW5-91056-003	F-5-1-26	HYZ3-16078-000	E-18-10-19	HYZ3-90021-000	E-4-9	HZY6-13214-004	E-7-
HZW5-91201-003	E-5-20	HYZ3-16082-000	E-18-10-21	HYZ3-90021-000	E-9-10-17	HZY6-13215-004	E-7-
HZW5-91202-003	F-9-33	HYZ3-16083-000	E-18-10-22	HYZ3-90021-000	E-9-20-20	HZY6-13216-004	E-7-
HZW5-91251-003	F-2-44	HYZ3-16087-000	E-18-10-25	HYZ3-90021-000	E-14-21	HZY6-13217-004	E-7-
HZW7-24810-U01	FOP-8-4-2	HYZ3-16088-000	E-18-10-26	HYZ3-90021-000	E-18-1-19	HZY6-13331-013	E-7-10
HZW7-24811-U01	FOP-8-4-3	HYZ3-16721-000	E-18-10-31	HYZ3-90021-000	F-2-28	HZY6-13400-000	E-10-1
HZW7-24812-U01	FOP-8-4-4	HYZ3-16733-000	E-18-10-35	HYZ3-90026-000	E-3-24	HZY6-13811-000	E-7-14
HZW7-24813-U01	FOP-8-4-5	HYZ3-16752-000	E-14-8	HYZ3-90026-000	E-19-25	HZY6-14120-000	E-9-4
HZW7-24814-U01	FOP-8-4-6	HYZ3-16752-000	E-18-10-38	HYZ3-90028-000	F-2-29	HZY6-14311-000	E-9-6
HZW7-24815-U01	FOP-8-4-7	HYZ3-16807-003	E-18-1-4	HYZ3-90030-000	E-4-10	HZY6-14510-003	E-9-8
HZW7-24817-U01	FOP-8-4-9	HYZ3-16818-003	E-18-1-5	HYZ3-90030-000	F-7-10-11	HZY6-14751-003	E-9-22
HZW7-24830-U01	FOP-8-4-11	HYZ3-16900-003	E-18-1-10	HYZ3-90030-000	F-8-10-23	HZY6-15100-000ZA	E-5-2
HZW7-24832-U01	FOP-8-4-14	HYZ3-16901-003	E-18-1-11	HYZ3-90030-000	F-9-26	HZY6-15112-000	E-5-3
HZW7-24833-U01	FOP-8-4-15	HYZ3-16904-003	E-18-1-12	HYZ3-90035-000	E-19-26	HZY6-15121-000	E-5-4
HZW7-32530-U00	FOP-8-19	HYZ3-16911-010	E-18-10-40	HYZ3-90040-000	E-9-10-19	HZY6-15152-000	E-3-8
HZW7-32530-U00	FOP-8-2-20	HYZ3-16912-003	E-18-1-13	HYZ3-90042-000	E-14-22	HZY6-15220-010	E-6-4
HZW7-32530-U10	FOP-8-2-21	HYZ3-16913-000	E-18-10-41	HYZ3-90046-000	E-6-13	HZY6-15299-000	E-3-11
HZW7-32530-U20	FOP-8-4-16	HYZ3-16915-010	E-18-1-15	HYZ3-90049-000	E-18-10-48	HZY6-15410-010ZA	E-5-11
HZW7-33570-U02	FOP-8-4-17	HYZ3-16918-003	E-18-1-16	HYZ3-90054-000	E-3-25	HZY6-15425-010	E-4-10-1
HZW7-87701-U01	FOP-8-4-18	HYZ3-16919-003	E-18-1-17	HYZ3-90054-000	E-14-25	HZY6-15655-000	E-6-5
HZW7-87703-U00	FOP-8-4-19	HYZ3-17748-U01	FOP-1-2	HYZ3-90055-000	E-19-27	HZY6-15834-000	E-9-20-9
HZW7-90101-U01	FOP-8-4-21	HYZ3-17749-U01	FOP-1-3	HYZ3-90056-000	E-15-19	HZY6-15840-000ZA	E-9-20-10
HZW7-90102-U01	FOP-8-4-22	HYZ3-19270-000	F-9-11	HYZ3-90056-000	F-9-28	HZY6-16014-003	E-18-10-3
HZW7-90103-U01	FOP-8-4-23	HYZ3-19271-000	F-9-12	HYZ3-90084-000	E-1-5	HZY6-16016-003	E-15-1
HZW7-90104-U01	FOP-8-4-24	HYZ3-19272-000	F-9-13	HYZ3-90084-000	E-20-3	HZY6-16017-043	E-18-10-4
HZW7-90301-U01	FOP-8-4-25	HYZ3-19300-023	E-9-10-3	HYZ3-90107-000	F-7-10-12	HZY6-16019-003	E-18-10-5
HZW7-90502-U00	FOP-8-4-27	HYZ3-23173-010	F-9-22	HYZ3-90109-010	F-8-8	HZY6-16020-023	E-18-10-6
HZW9-19279-000	F-9-15	HYZ3-24318-000	F-4-10	HYZ3-90111-000	F-8-20-14	HZY6-16036-003	E-18-10-9
HZW9-19291-000	F-9-17	HYZ3-24618-000	F-2-15	HYZ3-90120-000	F-3-14	HZY6-16089-000	E-14-1
HZW9-19297-000	F-9-19	HYZ3-24619-000	F-2-17	HYZ3-90133-000	F-8-9	HZY6-16196-000	E-18-2
HZW9-19317-000	F-9-20	HYZ3-30280-003	F-11-1	HYZ3-90204-000	E-3-30	HZY6-16198-000	E-18-3
HZW9-32114-730	F-3-14	HYZ3-31106-003	F-11-2	HYZ3-90205-000	E-14-28	HZY6-16199-000	E-18-4
HZW9-87702-800	FOP-8-6-48	HYZ3-31116-000	E-5-13	HYZ3-90304-000	F-7-4	HZY6-16400-013	E-15-2
HZW9-90008-000	FOP-8-6-49	HYZ3-31207-003	E-21-2	HYZ3-90405-000	F-7-10-14	HZY6-16450-003	E-14-2
HZW9-90009-000	F-10-24	HYZ3-31246-003	E-21-14	HYZ3-90506-000	F-5-14	HZY6-16451-000	E-14-3
HZW9-90011-000	E-3-22	HYZ3-32128-000	E-15-10	HYZ3-90506-000	F-5-1-15	HZY6-16621-000	E-14-4
HZW9-90011-000	E-9-10-14	HYZ3-32411-003	F-7-10-3	HYZ3-90507-000	F-2-34	HZY6-16700-013	E-18-5
HZW9-90011-000	F-7-10-9	HYZ3-35470-023	F-2-22	HYZ3-90507-000	F-8-11	HZY6-16701-003	E-18-10-27
HZW9-90013-000	F-7-3	HYZ3-35645-000	F-8-20-3	HYZ3-90512-000	F-5-16	HZY6-16718-013	E-18-10-30
HZW9-90013-000	F-7-10-10	HYZ3-35673-003	E-3-16	HYZ3-90512-000	F-5-1-17	HZY6-16723-003	E-18-10-32
HZW9-90013-000	F-7-20-7	HYZ3-35673-003	E-4-7	HYZ3-90528-000	F-5-17	HZY6-16730-063	E-18-10-33
HZW9-90016-000	E-3-23	HYZ3-35673-003	E-9-10-12	HYZ3-90528-000	F-5-1-18	HZY6-16734-003	E-18-10-36
HZW9-90016-000	E-5-17	HYZ3-36122-013	F-11-5	HYZ3-90529-000	F-5-	HZY6-16736-003	E-18-10-37

HY6-16740-003.	E-14-5	HY6-24614-000.	F-2-14	HY6-41201-000ZC.	F-5-10	HY6-91304-010.	E-9-10-24
HY6-16744-010.	E-14-6	HY6-24618-000.	F-2-16	HY6-41201-710ZC.	F-5-1-10	HY6-91305-003.	E-3-37
HY6-16748-000.	E-14-7	HY6-24620-000.	F-2-18	HY6-41202-710.	F-5-1-11	HY6-91351-003.	F-4-31
HY6-16752-000.	E-14-9	HY6-24628-000.	F-2-19	HY6-50167-000.	F-10-7	HY6-91502-003.	E-9-33
HY6-16755-003.	E-18-6	HY6-24629-000ZA.	F-2-20	HY6-50168-003.	F-10-8	HY6-91552-000.	F-4-34
HY6-16800-003.	E-18-1-2	HY6-30410-000.	E-20-10-1	HY6-50209-000.	FOP-13-7	HY6-91552-000.	FOP-10-1-11
HY6-16805-003.	E-18-1-3	HY6-30503-000.	E-3-13	HY6-56000-043.	F-11-11	HY6-91553-000.	F-8-20-21
HY6-16840-A00.	E-18-10-39	HY6-31110-000ZA.	E-5-12	HY6-56100-013.	F-11-12	HY9-15815-000.	E-9-20-8
HY6-16850-A01.	E-18-1-6	HY6-31200-003.	E-21-1	HY6-56118-000.	FOP-13-8	HY9-17315-000.	E-15-4
HY6-16860-A00.	E-18-7	HY6-31216-003.	E-21-4	HY6-60180-003.	F-8-10-8	HY9-30419-003.	E-20-10-2
HY6-16871-A00.	E-18-1-7	HY6-31226-003.	E-21-7	HY6-60185-003.	F-8-10-9	HY9-31207-H01.	E-21
HY6-16881-A00.	E-18-1-8	HY6-31227-003.	E-21	HY6-63102-010.	F-8-2	HY9-31226-H01.	E-21
HY6-16890-A00.	E-18-1-9	HY6-31231-003.	E-21-9	HY6-63144-000.	F-8-6	HY9-31229-H01.	E-21
HY6-16914-010.	E-18-1-14	HY6-31232-003.	E-21	HY6-63205-000.	F-8-10-12	HY9-31240-003.	E-21
HY6-17051-000ZA.	E-14-10	HY6-31235-003.	E-21-10	HY6-63212-000.	F-8-10-15	HY9-31242-H01.	E-21
HY6-17105-000.	E-14-12	HY6-31236-003.	E-21-11	HY6-63223-000.	F-8-10-16	HY9-31246-H01.	E-21
HY6-17109-000.	E-14-13	HY6-31240-003.	E-21-12	HY6-63225-000.	F-8-10-18	HY9-31251-H01.	E-21-23
HY6-17371-020.	E-15-5	HY6-31242-003.	E-21-13	HY6-63240-000.	F-8-10-19	HY9-50381-000.	F-10-15
HY6-17374-000.	E-15-6	HY6-31630-003.	E-19-15	HY6-63711-010ZC.	F-8-20-9	HY9-56115-003.	F-11-16
HY6-17397-013.	E-15-7	HY6-31636-010.	E-19-17	HY6-63716-010ZC.	F-8-20-10	HY9-56120-003.	F-11-21
HY6-17398-000.	E-15-8	HY6-31637-000.	E-19-18	HY6-63718-000.	F-8-20-11	HY9-90017-000.	E-15-18
HY6-17431-000.	E-13-1	HY6-31638-003.	E-13-3	HY6-63719-000.	F-8-20-12	HZZ-06240-R30.	FOP-8-1
HY6-17432-000.	E-13-2	HY6-31750-003.	E-19-22	HY6-82873-000.	F-8-20-13	HZZ-06240-R30.	FOP-8-6-1
HY6-17723-020.	E-18-14	HY6-32101-000.	F-7-10-1	HY6-87117-640.	F-12-1	HZZ-06240-R40.	FOP-8-4-1
HY6-17840-000.	F-2-2	HY6-32111-000.	E-14-15	HY6-87531-000.	F-12-7	HZZ-06240-R60.	FOP-8-2-1
HY6-17845-000.	F-2-3	HY6-32112-000.	E-9-10-9	HY6-87531-620.	F-12-	HZZ-06323-R10.	FOP-6-1-
HY6-17860-000.	F-2-4	HY6-32113-000.	E-9-10-10	HY6-89216-000.	F-13-5	HZZ-06323-R30.	FOP-6-1-1
HY6-17877-010.	F-2-5	HY6-32114-010.	E-3-15	HY6-90001-000.	E-3-19	HZZ-06328-762.	FOP-11-1
HY6-17931-000.	F-2-6	HY6-32115-000.	E-15-9	HY6-90001-000.	F-8-10-22	HZZ-19277-000.	F-9-14
HY6-18110-415ZA.	E-4-2	HY6-32116-000.	E-9-20-12	HY6-90002-000.	E-6-9	HZZ-24820-R11.	FOP-8
HY6-18112-030ZA.	E-4-3	HY6-32166-003.	E-18-10-42	HY6-90002-000.	F-3-20-8	HZZ-24820-R21.	FOP-8-2
HY6-18115-003.	E-4-4	HY6-32370-004.	F-7-20-1	HY6-90005-000.	E-3-20	HZZ-24830-R41.	FOP-8-4
HY6-18130-000ZA.	F-9-5	HY6-32371-004.	F-7-20-2	HY6-90006-000.	E-15-16	HZZ-32186-000.	FOP-11-2
HY6-18135-003.	F-9-6	HY6-32410-020.	F-7-10-2	HY6-90010-000.	E-18-19	HZZ-32346-R11.	FOP-6-1-
HY6-18211-000.	F-9-7	HY6-32414-300.	F-7-2	HY6-90011-000.	E-9-20-17	HZZ-32346-R31.	FOP-6-1-3
HY6-18212-000.	F-9-8	HY6-32414-300.	F-7-10-4	HY6-90013-000.	E-4-8	HZZ-35100-R11.	FOP-6-1-7
HY6-19221-A00.	F-4-3	HY6-32414-640.	F-7-10-5	HY6-90014-000.	F-9-23	HZZ-35100-R11.	FOP-8-6-38
HY6-19221-A00.	FOP-10-1-3	HY6-32418-000.	F-2-21	HY6-90017-000.	E-6-10	HZZ-35340-741.	FOP-12-1
HY6-19231-000.	F-4-5	HY6-32419-000.	F-7-10-6	HY6-90018-000.	E-6-11	HZZ-35341-740.	FOP-12-2
HY6-19231-000.	FOP-10-1-5	HY6-35475-000.	F-2-23	HY6-90019-000.	E-6-12	HZZ-35342-740.	FOP-12-3
HY6-19234-000.	F-4-6	HY6-35640-003.	F-8-20-2	HY6-90020-000.	E-10-10	HZZ-35343-740.	FOP-12-4
HY6-19234-000.	FOP-10-1-3	HY6-35660-013.	F-10-4	HY6-90023-000.	E-9-10-18	HZZ-35344-740.	FOP-12-5
HY6-19234-000.	FOP-10-1-6	HY6-35668-003.	E-4-6	HY6-90043-000.	E-14-23	HZZ-35345-741.	FOP-12-6
HY6-19251-000.	F-4-7	HY6-36104-003.	FOP-13-4	HY6-90045-000.	F-9-27	HZZ-41117-000.	F-4-15
HY6-19251-611.	F-4-	HY6-36120-013.	F-11-4	HY6-90047-000.	E-14-24	HZZ-87301-R00.	F-12-4
HY6-19254-000.	E-6-7	HY6-36129-013.	F-11-7	HY6-90048-010.	E-9-20-21	HZZ-87701-R00.	FOP-8-6-47
HY6-19256-000.	F-9-9	HY6-36135-003.	E-18-17	HY6-90059-000.	E-9-10-20	HZZ-87701-R40.	FOP-8-4
HY6-19260-020.	E-4-10-3	HY6-36355-003.	E-14-17	HY6-90082-003.	E-3-27	HZZ-87703-R01.	FOP-8-2-24
HY6-19261-010.	E-4-10-4	HY6-36551-003.	E-14-18	HY6-90103-000.	F-3-13	HZZ-87703-R81.	FOP-8-21
HY6-19262-010.	E-4-10-5	HY6-37521-000.	E-9-20-14	HY6-90104-000.	F-5-12	HZZ-90129-000.	F-10-31
HY6-19263-000.	E-4-10-6	HY6-38228-003.	F-7-20-3	HY6-90104-000.	F-5-1-13	HZZ-91252-003.	F-5-26
HY6-19266-000.	E-4-10-7	HY6-38235-004.	F-7-20-4	HY6-90105-000.	F-3-20-10	HZZ-91252-003.	F-5-1-28
HY6-19267-010.	F-9-10	HY6-38550-003.	F-7-10-7	HY6-90105-000.	F-8-10-24	HZZ-91253-003.	F-4-29
HY6-19268-000.	E-4-5	HY6-38552-000.	E-3-18	HY6-90116-000.	F-4-19	HZZ-06325-600.	FOP-6-2
HY6-19269-000.	E-18-15	HY6-39794-003.	F-7-20-6	HY6-90116-000.	FOP-10-1-8	HZZ-06325-700.	FOP-6-
HY6-19273-000.	E-18-16	HY6-40105-020.	F-8-10-2	HY6-90118-000.	F-3-20-11	HZZ-06325-800.	FOP-6-
HY6-19289-000.	F-8-20-1	HY6-40114-010.	F-8-20-4	HY6-90123-000.	F-3-15	HZZ-32185-600.	FOP-6-4
HY6-19290-003.	F-9-16	HY6-40116-000.	F-8-20-5	HY6-90135-004.	F-7-20-9	HZZ-32185-700.	FOP-6-
HY6-19295-000.	F-9-18	HY6-40151-010ZD.	F-8-20-6	HY6-90201-000.	E-1-6	HZZ-32185-800.	FOP-6-34
HY6-19300-003.	E-9-10-4	HY6-40152-300.	F-8-20-7	HY6-90301-000.	F-8-20-16	HZZ-32530-000.	FOP-8-6-34
HY6-19313-000ZB.	E-9-10-5	HY6-40154-000ZC.	F-8-10-5	HY6-90401-000.	E-1-7	HZZ-32545-000.	FOP-6-1-4
HY6-19315-010.	E-9-10-6	HY6-40155-000.	F-8-10-6	HY6-90601-000.	E-18-23	HZZ-32580-600.	FOP-6-9
HY6-19318-010.	E-9-10-7	HY6-40157-000.	F-8-10-7	HY6-90601-000.	E-18-1-20	HZZ-32580-700.	FOP-6-
HY6-19319-000.	E-9-10-8	HY6-40201-000ZC.	F-3-20-1	HY6-90602-020.	E-4-10-10	HZZ-32580-800.	FOP-6-
HY6-23170-000ZA.	F-9-21	HY6-40201-611ZC.	F-3-20-	HY6-90603-003.	E-4-10-11	HZZ-37210-013.	FOP-8-6-44
HY6-23172-000.	E-6-8	HY6-40212-020ZC.	F-8-20-8	HY6-90604-003.	E-4-12	HZZ-37210-712.	FOP-6-1-11
HY6-24101-000.	F-5-1	HY6-40219-023.	F-3-20-3	HY6-90605-003.	E-18-25	HZZ-38414-003.	FOP-6-1-14
HY6-24101-000.	F-5-1-1	HY6-41100-040ZC.	F-3-10-1	HY6-90606-003.	F-9-31	HZZ-50211-000.	F-10-10
HY6-24122-000.	F-5-4	HY6-41100-614ZC.	F-3-10-	HY6-90607-000.	E-18-10-50	HZZ-50211-000.	F-10-10
HY6-24122-000.	F-5-1-4	HY6-41100-714ZC.	F-3-10-	HY6-90651-000.	F-9-32	HZZ-52540-000.	FOP-6-1-4
HY6-24123-000.	F-5-5	HY6-41101-020ZC.	F-3-3	HY6-90701-000.	E-10-12	HZZ-52545-000.	FOP-6-1-4
HY6-24123-000.	F-5-1-5	HY6-41104-010.	F-3-6	HY6-90752-000.	F-2-39	HZZ-52580-600.	FOP-6-9
HY6-24124-000.	F-5-6	HY6-41105-010.	F-3-7	HY6-90753-000.	F-2-40	HZZ-52580-700.	FOP-6-
HY6-24124-000.	F-5-1-6	HY6-41112-010.	F-4-13	HY6-90755-003.	F-2-41	HZZ-52580-800.	FOP-6-
HY6-24166-000.	F-2-8	HY6-41112-611.	F-4-	HY6-91051-003.	F-5-22	HZZ-53210-013.	FOP-8-6-44
HY6-24218-000.	F-2-9	HY6-41131-000.	F-4-16	HY6-91051-003.	F-5-1-24	HZZ-537210-712.	FOP-6-1-11
HY6-24310-000.	F-4-9	HY6-41140-000.	F-5-7	HY6-91052-003.	F-4-26	HZZ-538414-003.	FOP-6-1-14
HY6-24310-710.	F-4-	HY6-41141-110.	F-5-1-7	HY6-91055-004.	F-5-23	HZZ-550211-000.	F-10-10
HY6-24320-000.	F-2-10	HY6-41150-710.	F-5-1-8	HY6-91055-004.	F-5-1-25	HZZ-550211-000.	F-10-10
HY6-24320-610.	F-2-	HY6-41151-000.	F-5-8	HY6-91251-003.	F-4-28	HZZ-550211-000.	F-10-10
HY6-24343-000.	F-4-11	HY6-41161-000.	F-5-9	HY6-91301-003.	E-4-13	HZZ-550211-000.	F-10-10
HY6-24610-000.	F-2-12	HY6-41161-710.	F-5-1-9	HY6-91302-003.	E-4-14	HZZ-550211-000.	F-10-10
HY6-24612-020.	F-2-13	HY6-41173-000.	FOP-13-6	HY6-91303-003.	E-9-20-22	HZZ-550211-000.	F-10-10

Note

Copyright © 2015 Tohatsu Corporation. All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means without the express written permission of Tohatsu Corporation.



TOHATSU CORPORATION

**Address : 5-4,3-chome,Azusawa,Itabashi-ku,
TOKYO,174-0051 JAPAN**
Phone : TOKYO (03)3966-3117
FAX : TOKYO (03)3966-0090
Website : www.tohatsu.co.jp

**2015
PARTS CATALOG
BFT 115A**